



MINI







# MINI

Saloon, Countryman and Traveller

Clubman, Estate and 1275 GT

Van, Pick-up and Moke

Cooper and Cooper 'S'

## Workshop Manual

---

Publication No. AKD 4935 (9th Edition)



**Leyland Cars—Service**  
Cowley, Oxford OX4 2PG, England



# INTRODUCTION

## DESCRIPTION

This Manual is intended to assist the skilled mechanic in carrying out repairs and replacements in a minimum time.

References to left- or right-hand side in this Manual are made when viewing the car from the rear.

## MANUAL ARRANGEMENT

The first part of the Manual includes the General Data, Engine Tuning Data, and Maintenance which incorporates the Recommended Lubricants Chart.

A Service Tools section is featured at the end of the Manual.

The remainder of the Manual is divided into sections, and each section carries a reference letter that identifies the section with an assembly or a major component. Each section is prefixed with a contents page and is sub-divided numerically. The pages and illustrations are numbered consecutively within each section and the section title and letter are shown at the top of each page.

Sections having the suffix 'a' contain supplementary information dealing with the Mini fitted with Automatic transmission.

Sections having the suffix 'b' contain supplementary information applicable to the Mini range, i.e. 850, 1000, Clubman, 1275 GT, and the Cooper 'S' Mk. III. These vehicles have **NEGATIVE** earth electrical systems.

To reduce repetition, operations covered in this manual do not include reference to testing the vehicle after repair. It is essential that work is inspected and tested after completion and if necessary a road test of the vehicle is carried out particularly where safety related items are concerned.

## REPAIRS AND REPLACEMENTS

When replacement parts are required it is essential that only genuine British Leyland parts and Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories:

Safety features embodied in the car may be impaired if other than genuine parts are fitted.

In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.

Torque wrench setting figures given in the Manual must be strictly adhered to.

Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be renewed.

Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the car conform to mandatory requirements existing in their country of origin.

The terms of the Owners Service Statement may be invalidated by the fitting of other than genuine British Leyland parts and Uniparts.

All British Leyland parts and Unipart replacements have the full backing of the Owners Service Statement.

British Leyland Distributors and Dealers are obliged to supply only genuine service parts.



4NA137B

© British Leyland UK Limited 1976

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form electronic, mechanical, photocopying, recording or other means without prior written permission of British Leyland Cars, Service and Parts, Cowley, Oxford.



## INTRODUCTION

### SPECIFICATION

British Leyland UK Limited is constantly seeking ways to improve the specification of its vehicles and alterations take place continually. While every effort is made to produce up-to-date literature this Manual should not be regarded as an infallible guide to current specifications. Further the specification details set out in this Manual apply to a range of vehicles and not to any particular one.

Distributors and Dealers are not agents of British Leyland UK Limited and have absolutely no authority to bind British Leyland UK Limited by any express or implied undertaking or representation.

During the period of running-in from new, certain adjustments may vary from the specification figures given in this Manual. These adjustments will be reset by the Distributor or Dealer at the After Sales Service, and thereafter should be maintained at the figures specified in the Manual.

#### Self-locking nuts

Deformed thread stiffnuts must not be re-used where the lacquer coating (SMT65) is affected in any way, and they must not be degreased in any circumstances. New nuts must always be used if their clamping torque has been lowered.

**IMPORTANT.** Insert-type stiffnuts must be used on the front suspension tie rods and front end to frame fixings. Deformed thread stiffnuts must not be used in these positions even if originally fitted. New stiffnuts must always be used on drive shafts.

#### Cars produced by AUTHI, Pamplona, Spain

The vehicle specification differs in some respects from those models produced in the U.K. The basic information contained in this Manual applies to cars from both sources of production.

### EMISSION CONTROL SYSTEMS

Servicing and adjusting engine emission control equipment must be carried out in accordance with the instructions given in Section T.



The service operations and adjustments showing this symbol must be followed by an exhaust emission check.







# CONTENTS

	PAGES
Introduction .. .. .	2
Data Contents .. .. .	6
General Data .. .. .	General Data 1–38
Tuning Data .. .. .	Tuning Data 1–18
<b>Maintenance</b>	
Recommended Lubricants .. .. .	Maintenance 6
Recommended Fluids, Anti-freeze, Capacities .. .. .	Maintenance 7
Routine Maintenance Operations .. .. .	Maintenance 8
<b>SECTIONS</b>	
Engine .. .. .	A, Aa
Ignition .. .. .	B, Ba
Cooling System .. .. .	C
Fuel System .. .. .	D, Da, Db
Clutch .. .. .	E
Transmission .. .. .	F, Fa
Drive Shafts .. .. .	G
Rear Suspension .. .. .	H
Steering .. .. .	J
Front Suspension .. .. .	K
Hydraulic Dampers .. .. .	L
Braking System .. .. .	M, Mb
Electrical .. .. .	N, Nb
Body .. .. .	R, Rb
Service Tools .. .. .	S
Emission Control (also includes Engine Tuning Data, Wiring Diagram) .. .. .	T

## DATA CONTENTS

### General Data

Mini Mk. I and II (848 c.c.) and Mk. II (998 c.c.) .. .. .	General Data 1–9
Mini-Cooper (997 c.c. and 998 c.c.) .. .. .	General Data 10–13
Mini-Cooper 'S' Mk. I (970 c.c., 1071 c.c., and 1275 c.c.) and Mk. II and III (1275 c.c.).. .. .	General Data 14–18
Mini Automatic (848 c.c. and 998 c.c.) .. .. .	General Data 19–20
Mini 850/1000 Saloon, Van and Pick-up .. .. .	General Data 21–23
Mini Clubman and Estate (998 c.c.).. .. .	General Data 24–26
Mini 1275 GT (1275 c.c.) .. .. .	General Data 27–34
Mini Clubman and Estate (1098 c.c.) .. .. .	General Data 35–38

### Tuning Data

Mini Mk. I, II and 850 (848 c.c.) .. .. .	Tuning Data 1
Mini Mk. II and 1000 (998 c.c.) .. .. .	Tuning Data 2
Mini Mk. I and II Automatic (848 c.c.) .. .. .	Tuning Data 3
Mini Mk. II, 1000 and Clubman Automatic (998 c.c.) .. .. .	Tuning Data 4
Mini-Cooper (997 c.c.) .. .. .	Tuning Data 5
Mini-Cooper (998 c.c.) .. .. .	Tuning Data 6
Mini-Cooper 'S' (970 c.c. and 1071 c.c.) .. .. .	Tuning Data 7
Mini-Cooper 'S' Mk. I, II and III (1275 c.c.) .. .. .	Tuning Data 8
Mini Clubman (998 c.c.)–1969/72 .. .. .	Tuning Data 9
Mini 1275 GT–1969/72 .. .. .	Tuning Data 10
Mini 1000–CANADA (998 c.c.) – 1970/74 .. .. .	Tuning Data 11
Mini Clubman – SWEDEN (998 c.c.) .. .. .	Tuning Data 12
Mini 850 (848 c.c.)–1972/74.. .. .	Tuning Data 13
Mini 1000 and Clubman (998 c.c.)–1972/74 .. .. .	Tuning Data 14
*Mini 1275 GT–1972/74 and 1974 on .. .. .	Tuning Data 15
*Mini 850 (848 c.c.)–1974 on .. .. .	Tuning Data 16
*Mini 1000 and Clubman–Manual and Automatic (998 c.c.)–1974 on .. .. .	Tuning Data 17
*Mini Clubman (1098 c.c.)–1974 on .. .. .	Tuning Data 18

\* To European emission control requirements (ECE 15).

# GENERAL DATA

## MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)

	(848 c.c.)	(998 c.c.)
<b>ENGINE</b>		
Type .. .. .	8MB.	99H.
Number of cylinders .. .. .	4.	4.
Bore .. .. .	2.478 in. (62.94 mm.).	2.543 in. (64.588 mm.).
Stroke .. .. .	2.687 in. (68.26 mm.).	3.00 in. (76.2 mm.).
Capacity .. .. .	51.7 cu. in. (848 c.c.)	60.96 cu. in. (998 c.c.).
Firing order .. .. .	1, 3, 4, 2.	1, 3, 4, 2.
Valve operation .. .. .	Overhead by push-rod.	Overhead by push-rod.
B.M.E.P. .. .. .	128 lb./sq. in. (9 kg./cm. <sup>2</sup> ) at 2,900 r.p.m.	130 lb./sq. in. (9.14 kg./cm. <sup>2</sup> ) at 2,700 r.p.m.
Torque .. .. .	44 lb. ft. (6.08 kg. m.) at 2,900 r.p.m.	52 lb. ft. (7.28 kg. m.) at 2,700 r.p.m.
Oversize bores: 1st .. .. .	+ .010 in. (.254 mm.).	+ .010 in. (.254 mm.).
2nd .. .. .	+ .020 in. (.508 mm.).	+ .020 in. (.508 mm.).
<b>CRANKSHAFT</b>		
Main journal diameter .. .. .	1.7505 to 1.751 in. (44.46 to 44.47 mm.).	
Minimum regrind diameter .. .. .	1.7105 in. (43.45 mm.).	
Crankpin journal diameter .. .. .	1.6254 to 1.6259 in. (41.28 to 41.29 mm.).	
Crankpin minimum regrind diameter .. .. .	1.5854 in. (40.27 mm.).	
<b>Main bearings</b>		
Number and type .. .. .	3 shell type.	
Material .. .. .	Steel-backed white metal.	Steel-backed copper-lead; thin wall.
Running clearance .. .. .	.0005 to .002 in. (.013 to .051 mm.).	.001 to .0027 in. (.025 to .069 mm.).
Length .. .. .	1.187 in. (30.16 mm.).	
End-clearance .. .. .	.002 to .003 in. (.051 to .076 mm.).	
End-thrust .. .. .	Taken on centre main bearing.	
<b>CONNECTING RODS</b>		
Length between centres .. .. .	5.75 in. (14.605 cm.).	
<b>Big-end bearings</b>		
Bearing side-clearance .. .. .	.008 to .012 in. (.203 to .305 mm.).	
Bearing diametrical clearance .. .. .	.001 to .0025 in. (0.25 to .063 mm.).	
Bearing length .. .. .	.875 in. (22.22 mm.).	
<b>PISTONS</b>		
Type .. .. .	Split skirt.	Solid skirt.
Clearances: Bottom of skirt .. .. .	.0006 to .0012 in. (.015 to .030 mm.).	.0005 to .0011 in. (.013 to .028 mm.).
Top of skirt .. .. .	.0026 to .0032 in. (.066 to .081 mm.).	
Oversizes .. .. .	+ .010 in., + .020 in., + .030 in., + .040 in. (.254 mm., .508 mm., .762 mm., 1.016 mm.).	+ .010 in., + .020 in. (.254 mm., .508 mm.).
<b>PISTON RINGS</b>		
Compression: Plain .. .. .	Top ring.	Top ring, chrome-faced.
Tapered .. .. .	Second and third rings.	Second and third rings.
Width .. .. .	.069 to .070 in. (1.75 to 1.78 mm.).	.0620 to .0625 in. (1.574 to 1.588 mm.).
Thickness .. .. .	.095 to .101 in. (2.41 to 2.56 mm.).	.106 to .112 in. (2.692 to 2.835 mm.).
Fitted gap .. .. .	.007 to .012 in. (.178 to .305 mm.).	
Clearance in groove .. .. .	.0015 to .0035 in. (.038 to .089 mm.).	



## GENERAL DATA

### MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

	(848 c.c.)	(998 c.c.)
Oil control type .. .. .		Slotted scraper.
Width .. .. .		.124 to .125 in. (3.15 to 3.175 mm.).
Thickness .. .. .		.095 to .101 in. (2.41 to 2.56 mm.).
Fitted gap .. .. .		.007 to .012 in. (.178 to .305 mm.).
Clearance in groove .. .. .		.0015 to .0035 in. (.038 to .089 mm.).
<b>GUDGEON PIN</b>		
Type .. .. .	Clamped in little-end.	Fully floating, with circlip location.
Fit in piston .. .. .	Hand push-fit.	Hand push-fit.
Diameter (outer) .. .. .		.624 in. (15.86 mm.).
<b>VALVES AND VALVE GEAR</b>		
<b>Valves</b>		
Seat angle: Inlet .. .. .		45°.
Exhaust .. .. .		45°.
Head diameter: Inlet .. .. .		1.093 to 1.098 in. (27.76 to 27.89 mm.).
Exhaust .. .. .		1.000 to 1.005 in. (25.40 to 25.53 mm.).
Stem diameter: Inlet .. .. .		.2793 to .2798 in. (7.096 to 7.109 mm.).
Exhaust .. .. .		.2788 to .2793 in. (7.081 to 7.096 mm.).
Valve lift .. .. .	285 in. (7.24 mm.).	.28 in. (7.14 mm.).
Valve stem to guide clearance: Inlet .. .. .		.0015 to .0025 in. (.038 to .064 mm.).
Exhaust .. .. .		.002 to .003 in. (.051 to .076 mm.).
Valve rocker clearance; Running .. .. .		.012 in. (.305 mm.) (cold).
Timing .. .. .		.019 in. (.48 mm.).
Timing markings .. .. .		Dimples on timing wheels, marks on flywheel.
Chain pitch and number of pitches .. .. .		$\frac{3}{8}$ in. (9.525 mm.). 52.
Inlet valve: Opens .. .. .		5° B.T.D.C.
Closes .. .. .		45° A.B.D.C.
Exhaust valve: Opens .. .. .		40° B.B.D.C.
Closes .. .. .		10° A.T.D.C.
Valve rocker bush bore (reamed) .. .. .		.5630 to .5635 in. (14.30 to 14.312 mm.).
<b>VALVE GUIDES</b>		
Length: Inlet and exhaust .. .. .		1.687 in. (42.86 mm.).
Diameter: Outside: Inlet and exhaust .. .. .		.469 in. (11.91 mm.).
Inside: Inlet and exhaust .. .. .		.2813 to .2818 in. (7.145 to 7.257 mm.).
<b>VALVE SPRINGS</b>		
Free length: Inlet and exhaust .. .. .		1.625 in. (41.27 mm.).
Number of working coils .. .. .		4½.
Pressure: Inlet and exhaust: Valve open .. .. .		70 lb. (31.8 kg.).
Valve closed .. .. .		37.5 lb. (17.027 kg.).
<b>TAPPETS</b>		
Diameter .. .. .		.812 in. (20.64 mm.).
Length .. .. .		1.5 in. (38.10 mm.).

## GENERAL DATA

MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

	(848 c.c.)	(998 c.c.)
<b>CAMSHAFT</b>		
Journal diameters: Front .. .. .		1.6655 to 1.666 in. (42.304 to 42.316 mm.).
Centre .. .. .		1.62275 to 1.62325 in. (41.218 to 41.231 mm.).
Rear .. .. .		1.3725 to 1.3735 in. (34.862 to 34.887 mm.).
End-float .. .. .		.003 to .007 in. (.076 to .178 mm.).
Bearings: Type: Front .. .. .		White-metal-lined, steel-backed.
Centre and rear .. .. .		Plain (running in block).
Inside diameter (reamed in position) .. .. .		1.667 to 1.6675 in. (42.342 to 42.355 mm.).
Clearance: Front .. .. .		.001 to .002 in. (.025 to .051 mm.).
Centre and rear .. .. .		.00125 to .00275 in. (.0317 to .0698 mm.).
Bearings: number and type .. .. .		3. Steel-backed white metal.
Inside diameter (reamed in position): Front .. .. .		1.667 to 1.6675 in. (42.342 to 42.355 mm.).
Centre .. .. .		1.6245 to 1.6255 in. (41.261 to 41.287 mm.).
Rear .. .. .		1.3748 to 1.3755 in. (34.914 to 34.937 mm.).
Running clearance .. .. .		.001 to .002 in. (.025 to .051 mm.).

### ENGINE LUBRICATION SYSTEM

#### Oil pump

Type .. .. .	Concentric or Hobourn-Eaton.
Relief pressure valve opens .. .. .	60 lb./sq. in. (4.2 kg./cm. <sup>2</sup> ).
Relief valve spring: Free length .. .. .	2 $\frac{5}{16}$ in. (72.63 mm.).
Fitted length .. .. .	2 $\frac{5}{32}$ in. (54.77 mm.).

#### Oil filter

Type .. .. .	Full-flow.
Capacity .. .. .	1 pint (1.2 U.S. pints, .57 litre).

#### Oil pressure

Normal running .. .. .	60 lb./sq. in. (4.22 kg./cm. <sup>2</sup> ).
Idling (minimum) .. .. .	15 lb./sq. in. (1.05 kg./cm. <sup>2</sup> ).

### COOLING SYSTEM

Type .. .. .	Pressurized radiator, thermo-siphon, pump- and fan-assisted.
Pressure cap .. .. .	13 lb./sq. in. (.91 kg./cm. <sup>2</sup> ).
Thermostat setting .. .. .	82°C. (180°F.).
Cold climates .. .. .	88°C. (188°F.).
Hot climates .. .. .	74°C. (165°F.).

### FUEL SYSTEM

Carburettor refer to 'TUNING DATA'.

#### Fuel pump

Make and type: Early saloons	S.U. electric. PD.	
Later vehicles	S.U. electric. SP.	S.U. electric. SP and AUF 201 type.

## GENERAL DATA

### MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

	(848 c.c.)	(998 c.c.)
Delivery rate: PD type .. .. .		45 pints/hr. (25.5 litres/hr.).
SP and AUF 201 type .. .. .		56 pints/hr. (32 litres/hr.).
Delivery pressure; PD type .. .. .		2 to 3 lb./sq. in. (.14 to .21 kg./cm. <sup>2</sup> ).
SP and AUF 201 type .. .. .		2½ to 3 lb./sq. in. (.17 to .21 kg./cm. <sup>2</sup> ).

#### CLUTCH

<b>BMC single dry plate</b>		
Diameter .. .. .		7½ in. (180.9 mm.).
Facing material .. .. .		Wound yarn.
Pressure springs .. .. .		6.
Colour .. .. .		Red spot.
<b>Diaphragm-spring clutch</b>		
Make .. .. .		Borg and Beck.
Diameter .. .. .		7½ in. (180.9 mm.).
Facing material .. .. .		Wound yarn.
Diaphragm-spring colour code	Brown	Light green.

#### TRANSMISSION

##### Gearbox

Number of forward speeds .. .. .		4.
Synchromesh .. .. .		Second, third, and fourth gears.
Ratios: Top .. .. .		1.0 : 1.
Third .. .. .		1.412 : 1.
Second .. .. .		2.172 : 1.
First .. .. .		3.627 : 1.
Reverse .. .. .		3.627 : 1.
Overall ratios: Top .. .. .		3.765 : 1.
Third .. .. .		5.317 : 1.
Second .. .. .		8.176 : 1.
First .. .. .		13.657 : 1.
Reverse .. .. .		13.657 : 1.

##### Final drive

Type .. .. .		Helical gears and differential.
Ratio: Saloon .. .. .	3.765 : 1 (17/64).	3.44 : 1 (18/62).
Van and Pick-up .. .. .		3.76 : 1 (17/64).

##### Gearbox

	(From Engine No. 8AM-WE-H101)	(From Engine Nos. 99H-159-H101 and 99H-251-H101)
Number of forward speed .. .. .	4.	4.
Synchromesh .. .. .	All forward gears.	All forward gears.
Ratios: Top .. .. .	1.00 : 1.	1.00 : 1.
Third .. .. .	1.43 : 1.	1.43 : 1.
Second .. .. .	2.21 : 1.	2.21 : 1.
First .. .. .	3.52 : 1.	3.52 : 1.
Reverse .. .. .	3.54 : 1.	3.54 : 1.
Overall ratios: Top .. .. .	3.76 : 1.	3.44 : 1.
Third .. .. .	5.40 : 1.	4.93 : 1.
Second .. .. .	8.32 : 1.	7.63 : 1.
First .. .. .	13.25 : 1.	12.13 : 1.
Reverse .. .. .	13.30 : 1.	12.19 : 1.
Road speed at 1,000 r.p.m. in top gear .. .. .	15.2 m.p.h. (24.3 km.p.h.).	16.2 m.p.h. (25.75 km.p.h.).



## GENERAL DATA

### MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

#### DRIVE SHAFTS

Type .. .. .	Solid shaft, reverse spline.
Make and type of joint .. .. .	Hardy Spicer, hemispherical joint.

#### STEERING

Type .. .. .	Rack and pinion.	
Steering-wheel turns—lock to lock .. .. .	2½	
Steering-wheel diameter .. .. .	15¾ in. (40 cm.).	
Camber angle .. .. .	1° positive to 3° positive.	} with vehicle in an unladen condition.
Castor angle .. .. .	3°	
King pin (swivel hub) inclination .. .. .	9° 30'	
Toe-out .. .. .	⅞ in. (1.6 mm.)	
Lock angle: outer wheel at 20°, inner wheel .. .. .	23°	

#### FRONT SUSPENSION

Early models, 1959-1964 .. .. .	Rubber cone spring.
Later models .. .. .	Hydroelastic displacers.
Fluid capacity .. .. .	4 pints (5 U.S. pints, 2.27 litres).
Fluid pressure: Early models (unladen) .. .. .	263 lb./sq. in. (18.49 kg./cm. <sup>2</sup> ).
Later models (unladen) .. .. .	282 lb./sq. in. (19.74 kg./cm. <sup>2</sup> ).

(Car Nos. given in Section H.10)

#### REAR SUSPENSION

Type .. .. .	Rubber cone spring.
Toe-in .. .. .	⅜ in. (3.18 mm.).
Camber .. .. .	1° positive.
Radius arm bushes (reamed bore) .. .. .	.8125 to .8130 in. (20.63 to 20.65 mm.).

#### HYDRAULIC DAMPERS (Rubber suspension only)

Type: Front and rear .. .. .	Tubular telescopic.
------------------------------	---------------------

#### BRAKES (Up to Chassis Nos. 296256 and 638878)

Lockheed hydraulic .. .. .	Single-leading shoe.
Drum size .. .. .	7 in. (17.8 cm.) diameter.
Lining dimensions: Front or rear .. .. .	6.75 in. x 1.25 in. (17.14 cm. x 3.17 cm.).
Lining area: Front or rear .. .. .	33.75 sq. in. (217.7 cm. <sup>2</sup> ).
Lining material .. .. .	Don 202.
Master cylinder bore diameter .. .. .	¾ in. (19.05 mm.).

#### Wheel cylinders

Cylinder bore diameter: Front .. .. .	⅞ in. (20.64 mm.).
Rear .. .. .	⅝ in. (15.87 mm.).

## GENERAL DATA

MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

### BRAKES (From Chassis Nos. 296257 and 638879)

Lockheed hydraulic .. .. .	Two-leading shoe.
Lining dimensions .. .. .	6.75 x 1.5 in. (17.4 x 3.18 cm.).
Lining area per wheel: Front .. .. .	20.5 sq. in. (132.3 cm. <sup>2</sup> ).
Rear .. .. .	17.1 sq. in. (110.3 cm. <sup>2</sup> ).
Swept area per wheel: Front .. .. .	33 sq. in. (213 cm. <sup>2</sup> ).
Rear .. .. .	27.5 sq. in. (177.4 cm. <sup>2</sup> ).
Master cylinder bore diameter .. .. .	0.7 in. (17.78 mm.).
Lining material .. .. .	Don 202.
<b>Wheel cylinders</b>	
Cylinder bore diameter: Front .. .. .	$\frac{15}{16}$ in. (23.81 mm.).
Rear .. .. .	$\frac{3}{4}$ in. (19.05 mm.).

### WHEELS

Type: ventilated disc .. .. .	3.50B x 10.
-------------------------------	-------------

### TYRES

Size:	
Standard .. .. .	5.20—10 tubeless.
Radial ply .. .. .	145—10 tubeless.
Pressures:	
Standard—normal conditions .. .. .	Front 24 lb./sq. in. (1.7 kg./cm. <sup>2</sup> ).
fully loaded .. .. .	Rear 22 lb./sq. in. (1.55 kg./cm. <sup>2</sup> ).
Radial ply, all conditions .. .. .	Front and rear 24 lb./sq. in. (1.7 kg./cm. <sup>2</sup> ).
fully loaded .. .. .	Front 28 lb./sq. in. (1.97 kg./cm. <sup>2</sup> ).
fully loaded .. .. .	Rear 26 lb./sq. in. (1.83 kg./cm. <sup>2</sup> ).

### ELECTRICAL EQUIPMENT

System .. .. .	12-volt, positive earth.
Charging system .. .. .	Compensated voltage control.
Battery .. .. .	Lucas BLT7A, BLTZ7A, BT7A, BTZ7A.
Capacity: BLT7A, BLTZ7A .. .. .	34 amp.-hr. at 20-hr. rate.
BT7A, BTZ7A .. .. .	43 amp.-hr. at 20-hr. rate.
Starter motor .. .. .	Lucas M35G.
Dynamo .. .. .	Lucas C40.
Maximum output .. .. .	22 amps. at 2,250 r.p.m.
Cut-in speed .. .. .	1,450 r.p.m. at 13.5 volts.
Control box .. .. .	Lucas RB106/2.
Cut-out: Cut-in voltage .. .. .	12.7 to 13.3.
Drop-off voltage .. .. .	8.5 to 11.0.
Reverse current .. .. .	5.0 amps. (max.).
Regulator (at 3,000 r.p.m. dynamo speed):	
Open-circuit setting at 20°C. (68°F.) .. .. .	16.0 to 16.6 volts.
For ambient temperatures other than 20°C. (68°F.) the following allowances should be made to the above setting:	
For every 10°C. (18°F.) above 20°C. (68°F.) subtract .1 volt.	
For every 10°C. (18°F.) below 20°C. (68°F.) add .1 volt.	
Alternator .. .. .	Lucas 11AC (12 volts).
Maximum output .. .. .	43 amperes.
Rotor windings: Resistance .. .. .	3.8 ± .2 ohms at 20°C. (68°F.).
Current .. .. .	3.2 amps. at 12 volts.

## GENERAL DATA

### MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

Minimum brush length .. .. .	$\frac{5}{32}$ in. (3.97 mm.).	
Brush spring pressure:		
$\frac{3}{8}$ in. (19.84 mm.) compressed length .. .. .	4 to 5 oz. (113 to 142 gm.).	
$\frac{13}{32}$ in. (10.32 mm.) compressed length .. .. .	7½ to 8½ oz. (212 to 241 gm.).	
<b>Control unit</b>		
Type .. .. .	Lucas 4TR.	
Voltage setting at 3,000 alternator r.p.m. .. .. .	13.9 to 14.3 volts.	
Circuit resistance (max.) .. .. .	.1 ohm.	
<b>Field isolating relay .. .. .</b>	Lucas 6RA.	
<b>Warning light control .. .. .</b>	Lucas 3AW.	
<b>GENERAL DIMENSIONS</b>		
Wheelbase: Saloon .. .. .	6 ft. 8 $\frac{5}{8}$ in. (2.036 m.).	
Van, Pick-up, Traveller, and Countryman .. .. .	7 ft. 0 $\frac{5}{8}$ in. (2.138 m.).	
Moke .. .. .	6 ft. 8 $\frac{5}{8}$ in. (2.036 m.).	
Overall length: Saloon .. .. .	10 ft. 0 $\frac{1}{4}$ in. (3.05 m.).	
Van, Traveller, and Countryman .. .. .	10 ft. 9 $\frac{7}{8}$ in. (3.259 m.).	
Pick-up .. .. .	10 ft. 10 $\frac{1}{2}$ in. (3.315 m.).	
Moke .. .. .	10 ft. 0 in. (3.04 m.).	
Overall width .. .. .	4 ft. 7 $\frac{1}{2}$ in. (1.41 m.).	
Moke .. .. .	4 ft 3 $\frac{1}{2}$ in. (1.36 m.).	
Overall height: Saloon .. .. .	4 ft. 5 in. (1.35 m.).	
Van .. .. .	4 ft. 6 $\frac{1}{2}$ in. (1.38 m.).	
Traveller, Countryman, and Pick-up .. .. .	4 ft. 5 $\frac{1}{2}$ in. (1.36 m.).	
Moke .. .. .	4 ft. 8 in. (1.42 m.).	
Ground clearance .. .. .	6 $\frac{5}{8}$ in. (15.63 cm.).	
Moke .. .. .	6 $\frac{1}{2}$ in. (16.2 cm.).	
Track: Front .. .. .	47 $\frac{7}{16}$ in. (1.205 m.).	
Rear .. .. .	45 $\frac{7}{8}$ in. (1.164 m.).	
Turning circle: Saloon .. .. .	31 ft. 7 in. (9.63 m.)	} Mk. I models.
Van, Pick-up, Traveller, and Countryman .. .. .	32 ft. 9 in. (9.893 m.)	
Moke .. .. .	31 ft. (9.4 m.)	
Turning circle: Saloon .. .. .	28 ft 6 in. (8.55 m.)	} Mk. II models
Van, Pick-up, Traveller, and Countryman .. .. .	29 ft. (8.84 m.)	
Kerbside weight: Saloon (Rubber suspension models) .. .. .	1,294 lb. (587 kg.).	
Saloon (Hydrolastic suspension models) .. .. .	1,398 lb. (634.5 kg.).	
Van .. .. .	1,334 lb. (605 kg.) approx.	
Traveller and Countryman .. .. .	1,456 lb. (660 kg.) approx.	
Pick-up .. .. .	1,328 lb. (604 kg.) approx.	
Moke .. .. .	1,240 lb. (562 kg.).	
Maximum permissible towing weight (suitable for 1 in 8 gradient in bottom gear):		
Saloon and Moke .. .. .	8 cwt. (406.4 kg.).	
Van, Pick-up, Traveller, and Countryman .. .. .	6 cwt. (304.7 kg.).	
<b>WEIGHT OF COMPONENTS</b>		
Engine and transmission assembly .. .. .	333 lb. (151 kg.).	



## GENERAL DATA

MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

### CAPACITIES

Transmission casing (including filter) .. .. .	8½ pints (10.2 U.S. pints, 4.83 litres).
Cooling system .. .. .	5¼ pints (6.3 U.S. pints, 3 litres).
With heater .. .. .	6¼ pints (7.5 U.S. pints, 3.55 litres).
Fuel tank: Saloon .. .. .	5½ gallons (6.6 U.S. gallons, 25 litres).
Van and Pick-up .. .. .	6 gallons (7.2 U.S. gallons, 27.3 litres).
Traveller and Countryman: Early models .. .. .	6½ gallons (7.8 U.S. gallons, 29.6 litres).
Later models with underfloor tank .. .. .	6 gallons (7.2 U.S. gallons, 27.3 litres).

### TORQUE WRENCH SETTINGS

Engine	lb. ft.	kg. m.
Camshaft nut .. .. .	60 to 70	8.3 to 9.7
Connecting rod big-end bolts .. .. .	35 to 38	4.8 to 5.3
Crankshaft pulley nut .. .. .	70 to 80	9.7 to 11.1
Cylinder head stud nuts .. .. .	40	5.5
Cylinder side cover .. .. .	3 to 4	0.42 to 0.55
Clutch spring housing to pressure plate set screws .. .. .	16	2.2
Driving strap to flywheel set screw .. .. .	16	2.2
Flywheel centre bolt .. .. .	110 to 115	15.2 to 15.9
Flywheel housing bolts and stud nuts .. .. .	18	2.5
Gudgeon pin clamp screws .. .. .	22 to 25	3.0 to 3.5
Heater control to cylinder head .. .. .	6 to 8	0.83 to 1.11
Main bearing set screws .. .. .	60 to 65	8.3 to 9.0
Manifold to cylinder head .. .. .	12 to 16	1.7 to 2.2
Oil filter bowl centre bolt .. .. .	12 to 16	1.7 to 2.2
Oil pump .. .. .	6 to 9	0.83 to 1.25
Oil pipe banjo .. .. .	35 to 40	4.8 to 5.5
Oil pressure release valve—dome nut .. .. .	40 to 45	5.5 to 6.2
Rocker cover .. .. .	3 to 4	0.41 to 0.55
Rocker shaft bracket nuts .. .. .	22 to 25	3.0 to 3.5
Spark plugs (cast iron cylinder head) .. .. .	18	2.5
Timing cover and front plate:		
¼ in. dia. UNF bolts .. .. .	4 to 6	0.55 to 0.83
⅝ in. dia. UNF bolts .. .. .	10 to 14	1.4 to 1.9
Water pump .. .. .	14 to 18	1.9 to 2.5
Water outlet elbow .. .. .	6 to 9	0.83 to 1.25
Thermal transmitter .. .. .	16	2.2
<b>Gearbox and transmission</b>		
Third motion shaft bearing retainer screws .. .. .	13	1.8
First motion shaft nut .. .. .	150	20.7
Third motion shaft nut .. .. .	150	20.7
Transmission case to crankcase .. .. .	6	.8
Transmission drain plug .. .. .	25	3.5
Transmission case studs—⅜ in. dia. UNC. .. .. .	8	1.1
Transmission case studs—⅝ in. dia. UNC. .. .. .	6	.8
Transmission case stud nuts—⅜ in. UNF. .. .. .	25	3.4
Transmission case stud nuts—⅝ in. UNF. .. .. .	18	2.5
Bottom cover set screws—¼ in. dia. UNC. (change-speed tower) .. .. .	6	.8
<b>Final drive</b>		
Driven gear to differential cage .. .. .	60	8.3
Driving flange to differential nut .. .. .	70	9.6 (and align to next split pin hole)
End cover bolts (differential housing) .. .. .	18	2.5

## GENERAL DATA

MINI MK. I & II (848 c.c.) & MK. II (998 c.c.)—continued

### TORQUE WRENCH SETTINGS

<b>Suspension and steering</b>	<b>lb. ft.</b>	<b>kg. m.</b>
Drive shaft coupling 'U' bolt nuts .. .. .	8 to 12	1.11 to 1.66
Drive shaft nut (front hub) .. .. .	60	8.3 (align to next slot)
Front suspension tie-rod to front sub-frame .. .. .	20 to 24	2.8 to 3.3
Front suspension tie-rod to lower wishbone .. .. .	17 to 20	2.4 to 2.8
Front suspension—upper support arm pivot shaft nut .. .. .	45 to 60	6.2 to 8.3
Front suspension lower wishbone pivot shaft nut .. .. .	30 to 35	4.1 to 4.8
Road wheel nuts .. .. .	40 to 45	5.5 to 6.2
Steering-column/rack pinion clamp bolt .. .. .	8 to 10	1.11 to 1.38
Steering lever to swivel hub .. .. .	30 to 35	4.1 to 4.8
Steering tie-rod ball joint to steering arm .. .. .	20 to 24	2.8 to 3.3
Steering-wheel nut .. .. .	32 to 37	4.5 to 5.1
Swivel hub ball pin retainer .. .. .	70 to 80	9.6 to 11.1
Swivel hub ball pins to wishbone arms .. .. .	35 to 40	4.8 to 5.5
Steering tie-rod ball joint to rack locknut .. .. .	35 to 40	4.8 to 5.5
Steering rack assembly 'U' bolts to floor .. .. .	10 to 12	1.4 to 1.7
Steering-column clip bracket to column clip and parcel shelf .. .. .	13 to 18	1.8 to 2.5
Rear suspension rear hub nut .. .. .	60	8.3 (align to next slot)
Rear radius arm pivot shaft nut .. .. .	45 to 60	6.2 to 8.3
Backplate to rear radius arm bolts .. .. .	18 to 22	2.5 to 3.0
 <b>Alternator (11AC)</b>	 <b>lb. in.</b>	 <b>kg. m.</b>
Brush box fixing screws .. .. .	10	.115
Diode heat sink fixings .. .. .	25	.288
Through-bolts .. .. .	45 to 50	.518 to .576
 <b>Distributor</b>		
Distributor clamp bolt: Fixed nut type .. .. .	50	.576
Fixed bolt type .. .. .	30	.345

# GENERAL DATA

## MINI COOPER 997 c.c. & 998 c.c.

The following information is applicable to the Mini-Cooper and should be used in conjunction with the preceding specification for the Mini Mk. I and II (848 c.c.) and Mk. II (998 c.c.).

	(997 c.c.)	(998 c.c.)
<b>ENGINE</b>		
Type .. .. .	9F.	9FA.
Number of cylinders .. .. .	4.	4.
Bore .. .. .	2.458 in. (62.43 mm.).	2.543 in. (64.588 mm.).
Stroke .. .. .	3.20 in. (81.28 mm.).	3.00 in. (76.2 mm.).
Capacity .. .. .	60.87 cu. in. (997 c.c.).	60.96 cu. in. (998 c.c.).
B.M.E.P.: High compression .. .. .	134 lb./sq. in. (9.42 kg./cm. <sup>2</sup> ) at 3,500 r.p.m.	142 lb. sq. in. (10 kg./cm. <sup>2</sup> ) at 3,000 r.p.m.
Low compression .. .. .	129 lb./sq. in. (9.07 kg./cm. <sup>2</sup> ) at 3,500 r.p.m.	135 lb./sq. in. (9.5 kg./cm. <sup>2</sup> ) at 3,000 r.p.m.
Torque: High compression .. .. .	54 lb. ft. (7.46 kg. m.) at 3,600 r.p.m.	57 lb. ft. (7.881 kg. m.) at 3,000 r.p.m.
Low compression .. .. .	53 lb. ft. (7.32 kg. m.) at 3,500 r.p.m.	56 lb. ft. (7.74 kg. m.) at 2,900 r.p.m.
<b>CRANKSHAFT</b>		
Main bearings		
Material .. .. .	.. .. .	Steel-backed copper-lead or aluminium-tin; thin wall.
Running clearance .. .. .	.. .. .	.001 to .0027 in. (.025 to .069 mm.).
Length .. .. .	.. .. .	1.0625 in. (26.99 mm.).
<b>CONNECTING RODS</b>		
Big-end bearings		
Material .. .. .	.. .. .	Steel-backed copper-lead or aluminium-tin; thin wall.
Bearing length .. .. .	.. .. .	.875 in. (22.22 mm.).
<b>PISTONS</b>		
Type .. .. .	Solid skirt.	Solid skirt.
Clearance:		
Bottom of skirt (pressure face)	.0016 to .0022 in. (.041 to .056 mm.).	.0005 to .0011 in. (.013 to .028 mm.).
Oversizes: 1st .. .. .	.. .. .	+.010 in. (.254 mm.).
2nd .. .. .	.. .. .	+.020 in. (.508 mm.).
<b>PISTON RINGS</b>		
Compression: Top .. .. .	.. .. .	Plain, chrome-faced.
Second and third .. .. .	.. .. .	Tapered.
Width .. .. .	.. .. .	.0620 to .0625 in. (1.574 to 1.588 mm.).
Thickness (all rings) .. .. .	.. .. .	.106 to .112 in. (2.692 to 2.835 mm.).
<b>GUDGEON PIN</b>		
Type .. .. .	.. .. .	Fully floating, with circlip location.
Fit in piston .. .. .	.. .. .	.0001 in. (.0025 mm.) tight to .00035 in. (.0089 mm.) slack.
Fit in small end .. .. .	.. .. .	.0002 in. (.005 mm.) slack, to size.
Diameter .. .. .	.. .. .	.6244 in. (15.86 mm.) to .6247 in. (15.867 mm.).



# GENERAL DATA

## MINI-COOPER (997 c.c. & 998 c.c.)—continued

	(997 c.c.)	(998 c.c.)
<b>VALVES AND VALVE GEAR</b>		
<b>Valves</b>		
Throat diameter: Inlet .. ..	.098 in. (23.06 mm.).	1.172 in. (29.77 mm.).
Exhaust .. ..	.312 in. (7.92 mm.).	.908 in. (23.06 mm.).
Head diameter: Inlet .. ..	1.156 in. (29.4 mm.).	1.219 in. (30.86 mm.).
Exhaust .. ..	1.00 in. (25.40 mm.).	1.00 in. (25.4 mm.).
Valve lift .. ..	.312 in. (7.92 mm.).	.312 in. (7.92 mm.).
Inlet valve: Opens .. ..	16° B.T.D.C. }	5° B.T.D.C. }
Closes .. ..	56° A.B.D.C. * }	45° A.B.D.C. }
Exhaust valve: Opens .. ..	51° B.B.D.C. }	51° B.B.D.C. }
Closes .. ..	21° A.T.D.C. }	21° A.T.D.C. }

\* With .019 in. (.48 mm.) valve rocker clearance (for checking purposes only).

### VALVE SPRINGS

Free length: Inner .. ..	1.672 in. (42.47 mm.).
Outer .. ..	1.75 in. (44.45 mm.).
Pressure: Inner: Valve closed .. ..	18 lb. (8.17 kg.).
Valve open .. ..	30 lb. (13.6 kg.).
Outer: Valve closed .. ..	55 lb. (24.9 kg.).
Valve open .. ..	90 lb. (40.8 kg.).

### CAMSHAFT

Journal diameters: Front .. ..	1.6655 to 1.6666 in. (42.304 to 42.316 mm.).
Centre .. ..	1.62275 to 1.62325 in. (41.218 to 41.231 mm.).
Rear .. ..	1.3725 to 1.3735 in. (34.862 to 34.887 mm.).
End-float .. ..	.003 to .007 in. (.076 to .178 mm.).
Bearings: Number and type .. ..	3. Steel-backed white metal.
Inside diameter (reamed in position): Front .. ..	1.667 to 1.6675 in. (42.342 to 42.355 mm.).
Centre .. ..	1.6245 to 1.6255 in. (41.261 to 41.287 mm.).
Rear .. ..	1.3748 to 1.3755 in. (34.914 to 34.937 mm.).

### ENGINE LUBRICATION SYSTEM

#### Oil pump

Type .. ..	Concentric or Hobourn-Eaton.
Relief pressure valve operates .. ..	70 lb./sq. in. (4.92 kg./cm. <sup>2</sup> ).
Relief valve spring: Free length .. ..	2 <sup>39</sup> / <sub>64</sub> in. (66.28 mm.).
Fitted length .. ..	2 <sup>5</sup> / <sub>32</sub> in. (54.77 mm.).

#### Oil pressure

Normal running .. ..	70 lb./sq. in. (4.92 kg./cm. <sup>2</sup> ).
Idling (minimum) .. ..	15 lb./sq. in. (1.05 kg./cm. <sup>2</sup> ).

### FUEL SYSTEM

Carburettor refer to 'TUNING DATA'.

#### Fuel pump

Make and type .. ..	S.U. electric. Type SP.
Delivery rate .. ..	56 pts./hr. (67.2 U.S. pts./hr., 32 litres/hr.).
Delivery pressure .. ..	2½ to 3 lb./sq. in. (.18 to .21 kg./cm. <sup>2</sup> ).

## GENERAL DATA

### MINI-COOPER (997 c.c. & 998 c.c.)—continued

#### AIR CLEANERS

Type .. .. .	Oil-wetted gauze.
Later models .. .. .	Paper elements

#### IGNITION SYSTEM

Coil	} Refer to 'TUNING DATA'.
Distributor	
Sparking plugs	

#### CLUTCH

Pressure springs—colour .. .. .	Black enamel with white spot.
Diaphragm spring colour code .. .. .	Light green.

#### GEARBOX

Ratios: Top .. .. .	1.0 : 1.	
Third .. .. .	1.357 : 1.	
Second .. .. .	1.916 : 1.	
First .. .. .	3.2 : 1.	
Reverse .. .. .	3.2 : 1.	
	<b>STANDARD</b>	<b>AVAILABLE ALTERNATIVE</b>
Overall ratios: Top .. .. .	3.765 : 1.	3.444 : 1.
Third .. .. .	5.11 : 1.	4.674 : 1.
Second .. .. .	7.213 : 1.	6.598 : 1.
First .. .. .	12.05 : 1.	11.03 : 1.
Reverse .. .. .	12.05 : 1.	11.03 : 1.

#### DIFFERENTIAL

Ratio .. .. .	3.765 : 1 standard. 3.444 : 1 optional (available as a Service item only).
---------------	--

#### BRAKES

Brake fluid .. .. .	Lockheed (Series 329).
---------------------	------------------------

##### Front

Type .. .. .	Disc.
Disc diameter .. .. .	7 in. (177.8 mm.).
Pad area (total) .. .. .	13.8 sq. in. (89 cm. <sup>2</sup> ).
Swept area (total) .. .. .	101 sq. in. (651.5 cm. <sup>2</sup> ).
Pad material .. .. .	M78 (Red/green/red/green/red).
Minimum pad thickness.. .. .	$\frac{1}{16}$ in. (1.6 mm.).

##### Rear

Drum size .. .. .	7 in. (17.8 cm.) diameter.
Lining dimensions .. .. .	6.75 x 1.5 in. (17.4 x 3.18 cm.).
Lining area total .. .. .	40.5 sq. in. (261.29 cm. <sup>2</sup> ).
Lining material .. .. .	Don 202.

## GENERAL DATA

### MINI-COOPER (997 c.c. & 998 c.c.)—continued

#### GENERAL DIMENSIONS

Kerbside weight: Rubber suspension models .. .. .	1,400 lb. (635 kg.).
Hydrostatic suspension models .. .. .	1,433 lb. (650 kg.).
Maximum permissible towing weight (suitable for 1 in 8 gradient in bottom gear): .. .. .	8 cwt. (406.4 kg.).

#### TORQUE WRENCH SETTINGS

	lb. ft.	kg. m.
Calliper retaining bolts .. .. .	35 to 40	4.8 to 5.5
Steering lever ball joint .. .. .	25 to 30	3.4 to 4.1.

# GENERAL DATA

MINI-COOPER 'S' MK. I (970 c.c., 1071 c.c. & 1275 c.c.)  
and COOPER 'S' MK. II & III (1275 c.c.)

The following information is applicable to the Mini-Cooper 'S' and should be used in conjunction with the preceding specifications. See Workshop Manual Supplement AKD 4957 for engine tuning data on cars fitted with exhaust emission control equipment (Exhaust Port Air Injection).

## ENGINE

Number of cylinders	.. .. .	4.
Bore (all models)	.. .. .	2.780 in. (70.6 mm.).
Stroke: 970 c.c.	.. .. .	2.4375 in. (61.91 mm.).
1071 c.c.	.. .. .	2.687 in. (68.26 mm.).
1275 c.c.	.. .. .	3.2 in. (81.33 mm.).
Cubic capacity: 970 c.c.	.. .. .	59.1 cu. in. (970 c.c.).
1071 c.c.	.. .. .	63.35 cu. in. (1071 c.c.).
1275 c.c.	.. .. .	77.9 cu. in. (1275 c.c.).
Capacity of combustion chamber (valves and sparking plug fitted)		1.306 cu. in. (21.4 c.c.).
B.M.F.P.: 970 c.c.	.. .. .	142 lb./sq. in. (9.98 kg./cm. <sup>2</sup> ) at 4,500 r.p.m.
1071 c.c.	.. .. .	143 lb./sq. in. (10.05 kg./cm. <sup>2</sup> ) at 4,500 r.p.m.
1275 c.c.	.. .. .	153 lb./sq. in. (10.76 kg./cm. <sup>2</sup> ) at 3,000 r.p.m.
Torque: 970 c.c.	.. .. .	57 lb. ft. (7.88 kg. m.) at 5,000 r.p.m.
1071 c.c.	.. .. .	62 lb. ft. (8.58 kg. m.) at 4,500 r.p.m.
1275 c.c.	.. .. .	79 lb. ft. (10.92 kg. m.) at 3,000 r.p.m.

## CRANKSHAFT

Main journal diameter	.. .. .	2.0005 to 2.0010 in. (50.81 to 50.82 mm.).
Minimum regrind diameter	.. .. .	1.9805 to 1.9810 in. (50.30 to 50.31 mm.).
<b>Main bearings</b>		
Material	.. .. .	Steel-backed copper-lead; thin wall.
Length	.. .. .	1.000 in. (25.4 mm.).
Running clearance	.. .. .	.001 to .0027 in. (.025 to .068 mm.).

## CONNECTING RODS

Little-end bore diameter	.. .. .	.8110 to .8115 in. (20.60 to 20.61 mm.).
--------------------------	---------	--

## PISTONS

Type	.. .. .	Solid skirt.
Clearance: Bottom of skirt (pressure face)	.. .. .	.0019 to .0025 in. (.048 to .063 mm.).
Top of skirt	.. .. .	.0025 to .00283 in. (.063 to .072 mm.).

## PISTON RINGS

Compression: Plain	.. .. .	Top ring.
Tapered	.. .. .	Second and third ring.
Width	.. .. .	.0459 to .0469 in. (1.16 to 1.19 mm.).
Thickness	.. .. .	.116 to .122 in. (2.94 to 3.09 mm.).
Fitting gap	.. .. .	.008 to .013 in. (.20 to .33 mm.).
Clearance in groove	.. .. .	.0015 to .0035 in. (.04 to .09 mm.).
<b>Oil control type</b>		
Width	.. .. .	.1553 to .1563 in. (3.94 to 3.96 mm.).
Thickness	.. .. .	.116 to .122 in. (2.94 to 3.09 mm.).
Fitted gap	.. .. .	.008 to .013 in. (.20 to .33 mm.).
Clearance in groove	.. .. .	.0015 to .0035 in. (.04 to .09 mm.).

## GENERAL DATA

### MINI-COOPER 'S' MK. I (970 c.c., 1071 c.c., & 1275 c.c.) & COOPER 'S' MK. II & III (1275 c.c.)—continued

#### GUDGEON PIN

Type	..	..	..	..	..	..	..	..	..	Pressed in connecting rod.
Fit in piston	..	..	..	..	..	..	..	..	..	Hand push-fit.
Diameter (outer)	..	..	..	..	..	..	..	..	..	.8123 to .8125 in. (20.63 to 20.64 mm.).
Fit in connecting rod	..	..	..	..	..	..	..	..	..	.0008 to .0015 in. (.020 to .038 mm.) interference.

#### VALVES AND VALVE GEAR

##### Valves

Head diameter:	Inlet	..	..	..	..	..	..	..	..	1.401 to 1.406 in. (35.58 to 35.71 mm.).
	Exhaust	..	..	..	..	..	..	..	..	1.214 to 1.219 in. (30.83 to 30.96 mm.).
Valve lift	..	..	..	..	..	..	..	..	..	.318 in. (8.08 mm.), nominal.
Stem diameter:	Exhaust	..	..	..	..	..	..	..	..	.2788 to .2793 in. (7.08 to 7.09 mm.).
	Inlet	..	..	..	..	..	..	..	..	.2793 to .2798 in. (7.09 to 7.11 mm.).
Valve rocker clearance:	Standard	..	..	..	..	..	..	..	..	.012 in. (.30 mm.) cold.
	Competition	..	..	..	..	..	..	..	..	.015 in. (.38 mm.) cold.
	Timing	..	..	..	..	..	..	..	..	.021 in. (.53 mm.).
Inlet valve: Opens	..	..	..	..	..	..	..	..	..	5° B.T.D.C.
	Closes	..	..	..	..	..	..	..	..	45° A.B.D.C.
Exhaust valve: Opens	..	..	..	..	..	..	..	..	..	51° B.B.D.C.
	Closes	..	..	..	..	..	..	..	..	21° A.T.D.C.

} with .021 in. (.53 mm.) valve  
} rocker clearance (for checking  
} purposes only).

#### VALVE SPRINGS

Free length:	Inner	..	..	..	..	..	..	..	..	1.705 in. (43.31 mm.).
	Outer	..	..	..	..	..	..	..	..	1.740 in. (44.19 mm.).
Number of working coils:	Inner	..	..	..	..	..	..	..	..	6¼.
	Outer	..	..	..	..	..	..	..	..	4½.
Pressure:	Inner:	Valve closed	..	..	..	..	..	..	..	26.6 lb. (12.065 kg.).
		Valve open	..	..	..	..	..	..	..	46 lb. (20.865 kg.).
	Outer:	Valve closed	..	..	..	..	..	..	..	49.6 lb. (22.498 kg.).
		Valve open	..	..	..	..	..	..	..	94 lb. (42.638 kg.).

#### CAMSHAFT

Journal diameter:	Rear	..	..	..	..	..	..	..	..	1.37275 to 1.3735 in. (34.87 to 34.88 mm.).
Inside diameter (reamed in position):	Rear	..	..	..	..	..	..	..	..	1.3745 to 1.3750 in. (34.91 to 34.92 mm.).
Running clearance:	Rear	..	..	..	..	..	..	..	..	.001 to .00225 in. (.025 to .057 mm.).
Bearing length:	Rear	..	..	..	..	..	..	..	..	1 1/8 ± .010 in. (19.45 ± .25 mm.).

#### ENGINE LUBRICATION SYSTEM

Oil pressure (normal running)	..	..	..	..	..	..	..	..	..	60 lb./sq. in. (4.22 kg./cm. <sup>2</sup> ) at 70°C. (158°F.) oil temperature.
-------------------------------	----	----	----	----	----	----	----	----	----	--

#### COOLING SYSTEM

Thermostat setting	..	..	..	..	..	..	..	..	..	82°C. (180°F.).
Cold climates	..	..	..	..	..	..	..	..	..	88°C. (188°F.).
Hot climates	..	..	..	..	..	..	..	..	..	74°C. (165°F.).

#### FUEL SYSTEM

Carburettor refer to 'TUNING DATA'.

## GENERAL DATA

### MINI-COOPER 'S' MK. I (970 c.c., 1071 c.c., & 1275 c.c.) & COOPER 'S' MK. II & III (1275 c.c.)—continued

#### CLUTCH

Make and type:	Early type	..	..	..	..	..	..	BMC single dry plate.
	Later type	..	..	..	..	..	..	Diaphragm spring.
Diameter	..	..	..	..	..	..	..	7.125 in. (180.9 mm.).
Facing material:	Standard	..	..	..	..	..	..	Wound yarn, riveted.
Pressure springs (early type):	Inner	..	..	..	..	..	..	6.
	Outer	..	..	..	..	..	..	6.
Colour:	Inner	..	..	..	..	..	..	Green spot.
	Outer	..	..	..	..	..	..	White spot.

#### GEARBOX (3-speed Synchromesh)

	Standard	Optional (close ratio)
Ratios: Top	1.0 : 1	1.0 : 1
Third	1.357 : 1	1.242 : 1
Second	1.916 : 1	1.78 : 1
First	3.200 : 1	2.57 : 1
Reverse	3.200 : 1	2.57 : 1

#### Overall gear ratios (as applicable):

##### Standard gearbox

Final drive ratio	1st and reverse	2nd	3rd	4th
3.765 (17/64)	12.05 : 1	7.21 : 1	5.11 : 1	3.765 : 1
3.444 (18/62)	11.02 : 1	6.60 : 1	4.67 : 1	3.444 : 1
3.939 (16/63)	12.06 : 1	7.54 : 1	5.34 : 1	3.939 : 1
4.133 (15/62)	13.27 : 1	7.92 : 1	5.61 : 1	4.133 : 1
4.267 (15/64)	13.65 : 1	8.18 : 1	5.79 : 1	4.267 : 1

##### Optional gearbox (close ratio)

Final drive ratio	1st and reverse	2nd	3rd	4th
3.444 (18/62)	8.84 : 1	6.13 : 1	4.28 : 1	3.444 : 1
3.647 (17/62)	9.37 : 1	6.49 : 1	4.53 : 1	3.647 : 1
3.765 (17/64)	9.66 : 1	6.70 : 1	4.68 : 1	3.765 : 1
3.939 (16/63)	10.12 : 1	7.02 : 1	4.89 : 1	3.939 : 1
4.133 (15/62)	10.61 : 1	7.35 : 1	5.13 : 1	4.133 : 1
4.267 (15/64)	10.90 : 1	7.61 : 1	5.30 : 1	4.267 : 1
4.35 (15/65)	11.18 : 1	7.74 : 1	5.40 : 1	4.35 : 1

#### Road speed in top at 1,000 r.p.m.

Ratio	
3.444	16.07 m.p.h. (25.71 km.p.h.).
3.647	15 m.p.h. (24.14 km.p.h.).
3.765	14.7 m.p.h. (23.52 km.p.h.).
3.939	14.06 m.p.h. (22.5 km.p.h.).
4.133	13.4 m.p.h. (21.44 km.p.h.).
4.267	12.96 m.p.h. (20.74 km.p.h.).
4.35	12.57 m.p.h. (20.23 km.p.h.).

#### DIFFERENTIAL

Ratio—standard:	970 c.c.	..	..	..	..	..	..	3.765 : 1.
	1071 c.c.	..	..	..	..	..	..	3.765 : 1.
	1275 c.c. (Mk. I and II)	..	..	..	..	..	..	3.444 : 1.
Alternative ratios	..	..	..	..	..	..	..	3.939 : 1, 4.267 : 1, and 4.35 : 1.

## GENERAL DATA

### MINI-COOPER 'S' MK. I (970 c.c., 1071 c.c., & 1275 c.c.) & COOPER 'S' MK. II & III (1275 c.c.)—continued

#### GEARBOX (4-speed Synchromesh)

	Standard (close ratio)
Ratios: Top .. .. .	1.0 : 1
Third .. .. .	1.35 : 1
Second .. .. .	2.07 : 1
First .. .. .	3.30 : 1
Reverse .. .. .	3.35 : 1

#### Overall gear ratios (4-speed synchromesh)

	Reverse	1st	2nd	3rd	4th
<b>Final drive ratio</b> 3.65 : 1 (17/62) .. .. .	12.21	12.04	7.56	4.93	3.65
Road speed in top at 1,000 r.p.m. <b>Ratio</b> 3.65 : 1 .. .. .	15 m.p.h. (24.14 km.p.h.).				

#### DIFFERENTIAL

Ratio—standard: 1275 c.c. .. .. .	3.65 : 1.
Alternative ratios .. .. .	3.939 : 1, 4.267 : 1, and 4.35 : 1.

#### BRAKES

Type .. .. .	Lockheed hydraulic with vacuum servo.
<b>Servo Unit</b> Type: (Mk. I and II models) .. .. . (Mk. III models) .. .. .	Lockheed 5½ in. (140 mm.). Lockheed type 6.
<b>Front</b> Type .. .. .	Disc.
Disc diameter .. .. .	7½ in. (190.5 mm.).
Pad material (Up to Commission No. 000573A) (From Commission No. 000574A) .. .. .	Ferodo DA6. Mintex M78 (Red/green/red/green/red).
Pad area (total) .. .. .	17.3 sq. in. (111.4 cm. <sup>2</sup> ).
Swept area (total) .. .. .	122 sq. in. (787 cm. <sup>2</sup> ).
Minimum pad thickness .. .. .	⅛ in. (1.6 mm.).

#### FRONT HUBS

Bearings .. .. .	Timkin taper roller.
------------------	----------------------

#### WHEELS

Type: Ventilated disc .. .. .	3.50B x 10 or 4.5J x 10.
-------------------------------	--------------------------

#### TYRES

Size: Standard .. .. .	145-10 SP, tubed, or 5.20-10 C41 tubed.
Optional .. .. .	500L-10, tubed.
Tyre pressures (145-10SP and 5.20-10 C41 only):	
Front .. .. .	28 lb./sq. in. (1.97 kg./cm. <sup>2</sup> ).
Rear .. .. .	26 lb./sq. in. (1.83 kg./cm. <sup>2</sup> ).



## GENERAL DATA

### MINI-COOPER 'S' MK. I (970 c.c., 1071 c.c., & 1275 c.c.), & COOPER 'S' MK. II & III (1275 c.c.)—continued

#### CAPACITIES

Fuel tank: (early models) .. .. .	5½ galls. (25 litres).
Twin tanks (later Mk. II and Mk. III models) .. .. .	11 galls. (50 litres).

#### GENERAL DIMENSIONS

Track: Front:	3.5 in. rim .. .. .		47 $\frac{17}{32}$ in. (1.207 m.).
	4.5 in. rim .. .. .		48 $\frac{17}{32}$ in. (1.233 m.).
	Rear: 3.5 in. rim .. .. .		46 $\frac{5}{16}$ in. (1.176 m.).
	4.5 in. rim .. .. .		47 $\frac{5}{16}$ in. (1.202 mm.).
Kerbside weight:	Rubber suspension models .. .. .		1,411 lb. (640 kg.) approx.
	Hydrolastic suspension models .. .. .		1,540 lb. (698 kg.) approx.

#### TORQUE WRENCH SETTINGS

	lb. ft.	kg. m.
Cylinder head nuts (10 off) .. .. .	42	5.8
Cylinder head bolt (front, 1 off) .. .. .	25	3.5
Connecting rod big-end nuts (assemble dry only) .. .. .	40	5.5
Main bearing set screws (early type) .. .. .	67	9.3
Main bearing nuts (later type) .. .. .	57	7.9
Drive shaft nut .. .. .	150	20.7

# GENERAL DATA

## MINI AUTOMATIC (848 c.c. & 998 c.c.)

The following information is applicable to the Mini Automatic and should be used in conjunction with the preceding specification for the Mini Mk. I and II (848 c.c.) and Mk. II (998 c.c.).

ENGINE	(848 c.c.)	(998 c.c.)
Type .. .. .	8AH.	9AG.
B.H.P. .. .. .	39 at 5,250 r.p.m.	41 at 4,850 r.p.m.
B.M.E.P. .. .. .	.. .. .	130 lb./in. <sup>2</sup> (9.14 kg./cm. <sup>2</sup> ) at 2,750 r.p.m.
Torque .. .. .	44 lb. ft. (6.08 kg. m.) at 2,500 r.p.m.	52 lb. ft. (7.19 kg. m.) at 2,750 r.p.m.

### LUBRICATION SYSTEM

#### Oil pump

Type .. .. . Hobourn-Eaton.

#### Oil filter

Type .. .. . Full-flow.

Capacity .. .. . 1 pint (1.2 U.S. pints, .57 litre).

#### Oil pressure

Normal running speed and temperature .. .. . 60 lb./sq. in. (4.22 kg./cm.<sup>2</sup>).

Idling (minimum) at normal running temperature .. .. . 15 lb./sq. in. (1.05 kg./cm.<sup>2</sup>).

### COOLING SYSTEM

Pressure cap (up to 1974) .. .. . 13 lb./sq. in. (0.91 kg./cm.<sup>2</sup>).

(To ECE 15 regulations—1974 on) .. .. . 15 lb./sq. in. (1.05 kg./cm.<sup>2</sup>).

### FUEL SYSTEM

Carburetter refer to 'TUNING DATA'.

### IGNITION SYSTEM

Coil

Distributor

Sparking plugs

} Refer to 'TUNING DATA'.

### DIFFERENTIAL

Ratio .. .. . 3.27 : 1.

### AUTOMATIC TRANSMISSION

Ratios: Top .. .. .	1.0 : 1.
Third .. .. .	1.46 : 1.
Second .. .. .	1.845 : 1.
First .. .. .	2.69 : 1.
Reverse .. .. .	2.69 : 1.
Overall ratios: Top .. .. .	3.76 : 1.
Third .. .. .	5.49 : 1.
Second .. .. .	6.94 : 1.
First .. .. .	10.11 : 1.
Reverse .. .. .	10.11 : 1.
Speedometer .. .. .	7/17.

# GENERAL DATA

## MINI AUTOMATIC—continued

### TORQUE CONVERTER

Type .. .. .	3-element.
Ratio .. .. .	2 : 1 maximum.
Converter output gear ratio .. .. .	1.15 : 1.
End-float .. .. .	.0035 to .0065 in. (.089 to .164 mm.).

### DRIVE SHAFTS

Make and type of joint .. .. .	Hardy Spicer, flange joint.
--------------------------------	-----------------------------

### CAPACITIES

Transmission casing (including filter) .. .. .	13 pints (7.38 litres, 16 U.S. pints).
Refill capacity (approx.) .. .. .	9 pints (5 litres, 11 U.S. pints).

### WEIGHT OF COMPONENTS

Engine and transmission assembly .. .. .	357 lb. (162 kg.).
Automatic transmission .. .. .	112 lb. (50.8 kg.).

### GENERAL DIMENSIONS

Kerbside weight: Mini Mk. I Saloon .. .. .	1,390 lb. (630.8 kg.).
Mini Mk. II Saloon .. .. .	} 1,442 lb. (654 kg.).
Mini 850/1000 Saloon .. .. .	
Mini Clubman Saloon .. .. .	

### TORQUE WRENCH SETTINGS

	lb. ft.	kg. m.
Converter centre bolt .. .. .	110 to 115	15.2 to 15.9
Converter (six central bolts) .. .. .	22 to 24	3.0 to 3.3
Converter drain plugs .. .. .	18 to 20	2.5 to 2.8
Converter housing bolts .. .. .	18	2.5
Differential driving flange securing bolts .. .. .	40 to 45	5.5 to 6.2
Gear train bearing caps .. .. .	12	1.6
Gear train carrier strap .. .. .	12	1.6
Governor to auxiliary pump housing bolts .. .. .	10 to 15	1.4 to 2
Kickdown control assembly to transmission casing (on nyloc housing) .. .. .	5	.7
Oil filter bowl .. .. .	12 to 16	1.6 to 2.2
Input shaft nut .. .. .	70	9.6
Servo unit securing bolts .. .. .	17	2.4
Top and reverse clutch hub nut .. .. .	150	20.7
Transmission to engine securing nut .. .. .	12	1.6
Valve block securing bolts .. .. .	10	1.4
Valve block bolts (securing three sections) .. .. .	7	0.97
$\frac{5}{16}$ in. UNF. bolts .. .. .	18 to 20	2.5 to 2.8
$\frac{3}{8}$ in. UNF. bolts .. .. .	30	4.1

# GENERAL DATA

## MINI 850/1000 SALOON, VAN, & PICK-UP

The following information refers specifically to new or modified components fitted to the above Mini range coincident with the introduction of NEGATIVE earth electrical systems and must be used in conjunction with the preceding specifications for the Mini Mk. I (848-c.c. engine) and the Mini Mk. II (998-c.c. engine).

### ENGINE

Type (848c.c.)	..	..	..	..	..	..	..	..	..	85H.
(998c.c.)	..	..	..	..	..	..	..	..	..	99H.

### COOLING SYSTEM

Pressure cap (up to 1974)	..	..	..	..	..	..	..	..	13 lb./sq. in. (0.91 kg./cm. <sup>2</sup> ).
(To ECE 15 regulations—1974 on)	..	..	..	..	..	..	..	..	15 lb./sq. in. (1.05 kg./cm. <sup>2</sup> ).

### ENGINE LUBRICATION SYSTEM

#### Oil filter

Type	..	..	..	..	..	..	..	..	..	Full flow, renewable element or cartridge.
Capacity	..	..	..	..	..	..	..	..	..	1 pint (1.2 U.S. pints, 0.57 litre).

### IGNITION SYSTEM

Coil	}	Refer to 'TUNING DATA'.
Distributor		
Sparking plugs		

### FUEL SYSTEM

Carburetter refer to 'TUNING DATA'.

#### Fuel pump

Make/type	..	..	..	..	..	..	..	..	S.U. mechanical; AUF 700 (AUF 705 model).
Suction (min.)	..	..	..	..	..	..	..	..	6 in. (152 mm.) Hg.
Pressure (min.)	..	..	..	..	..	..	..	..	3 lb./sq. in. (.21 kg./cm. <sup>2</sup> ).

### TRANSMISSION (Fitted to 998 c.c.)\*

#### Gearbox

Number of forward speeds	..	..	..	..	..	..	..	..	4.
Synchromesh	..	..	..	..	..	..	..	..	All forward gears.
Ratios: Top	..	..	..	..	..	..	..	..	1.00 : 1.
Third	..	..	..	..	..	..	..	..	1.43 : 1.
Second	..	..	..	..	..	..	..	..	2.21 : 1.
First	..	..	..	..	..	..	..	..	3.52 : 1.
Reverse	..	..	..	..	..	..	..	..	3.54 : 1.
Overall ratios: Top	..	..	..	..	..	..	..	..	3.44 : 1.
Third	..	..	..	..	..	..	..	..	4.93 : 1.
Second	..	..	..	..	..	..	..	..	7.63 : 1.
First	..	..	..	..	..	..	..	..	12.13 : 1.
Reverse	..	..	..	..	..	..	..	..	12.19 : 1.
Road speed at 1,000 r.p.m. in top gear	..	..	..	..	..	..	..	..	16.2 m.p.h. (25.75 km.p.h.).
Speedometer gear ratio	..	..	..	..	..	..	..	..	4/14.

#### Final drive

Type	..	..	..	..	..	..	..	..	..	Helical gears and differential.
Ratio	..	..	..	..	..	..	..	..	..	3.44 : 1 (18/62).

\* Up to 1974 (ECE 15 regulations)—Van and Pick-up as 848 c.c.

# GENERAL DATA

## MINI 850/1000 SALOON, VAN, & PICK-UP—continued

### TRANSMISSION (Fitted to 848 c.c.)

#### Gearbox

Number of forward speeds .. .. .	4.
Synchromesh .. .. .	All forward gears.
Ratios: Top .. .. .	1.00 : 1.
Third .. .. .	1.43 : 1.
Second .. .. .	2.21 : 1.
First .. .. .	3.52 : 1.
Reverse .. .. .	3.54 : 1.
Overall ratios: Top .. .. .	3.76 : 1.
Third .. .. .	5.40 : 1.
Second .. .. .	8.32 : 1.
First .. .. .	13.25 : 1.
Reverse .. .. .	13.30 : 1.
Road speed at 1,000 r.p.m. in top gear .. .. .	15.2 m.p.h. (24.3 km.p.h.).
Speedometer gear ratio .. .. .	4/16.

#### Final drive

Type .. .. .	Helical gears and differential.
Ratio .. .. .	3.76 : 1 (17/64).

### DRIVE SHAFT

Make .. .. .	Hardy Spicer.
Type of shaft .. .. .	Solid shaft, reverse spline.
Joint at wheel end .. .. .	Constant velocity.
Coupling/joint at differential end: Later models .. .. .	Pre-lubricated offset-sphere joint.
Early models .. .. .	Pre-lubricated sliding joint with rubber coupling and 'U' bolts.

### SUSPENSION

Type .. .. .	Rubber cone spring. (Hydrolastic special market fitment.)
--------------	--

#### Hydraulic dampers

Type: Front and rear .. .. .	Tubular telescopic.
------------------------------	---------------------

### BRAKES

Master cylinder	
Bore diameter .. .. .	0.7 in. (17.78 mm.).
Wheel cylinders	
Bore diameter: Front .. .. .	$\frac{15}{16}$ in. (23.81 mm.).
Rear .. .. .	$\frac{3}{4}$ in. (19.05 mm.).
Tandem master cylinder	
Bore diameter .. .. .	0.7 in. (17.78 mm.).
Brake fluid .. .. .	UNIPART 550 BRAKE FLUID, alternatively use a high-boiling-point brake fluid conforming to specification S.A.E. J1703c, with a minimum boiling point of 260°C. (500°F.).

### ELECTRICAL EQUIPMENT

System .. .. .	12-volt, negative earth
Charging system .. .. .	Compensated voltage control.
<b>Battery:</b>	
Lucas 'Pacemaker' type .. .. .	A7                      A9
Capacity at 20 hr. rate .. .. .	30 amps.              40 amps.
Lucas type .. .. .	CL7                      CLZ7
Capacity at 20 hr. rate .. .. .	34 amps.              34 amps.
Exide battery .. .. .	Type 6 VTP 9—BR.
Capacity at 20 hr. rate .. .. .	35 amps.

## GENERAL DATA

### MINI 850/1000 SALOON, VAN, & PICK-UP—continued

<b>Dynamo</b> .. .. .	Lucas C40.
Maximum output .. .. .	22 amps. at 2,250 r.p.m.
Cut-in speed .. .. .	1,450 r.p.m. at 13.5 volts.
<b>Control box</b> .. .. .	Lucas RB106/2.
Cut-out: Cut-in voltage .. .. .	12.7 to 13.3.
Drop-off voltage .. .. .	8.5 to 11.0.
Reverse current .. .. .	5.0 amps. (max.).
<b>Regulator (at 3,000 r.p.m. dynamo speed):</b>	
Open-circuit setting at 20°C. (68°F.) .. .. .	16.0 to 16.6 volts.
For ambient temperatures other than 20°C. (68°F.) the following allowances should be made to the above setting.	
For every 10°C. (18°F.) above 20°C. (68°F.) subtract .1 volt.	
For every 10°C. (18°F.) below 20°C. (68°F.) add .1 volt.	
<b>Starter motor</b> .. .. .	Lucas M35G or M35J.
M35G Type: Brush spring tension .. .. .	15 to 25 oz. (425 to 709 gm.).
M35J Type: Brush spring tension .. .. .	28 oz. (794 gm.).
Light running current .. .. .	65 amperes at 8,000-10,000 r.p.m.
Lock torque .. .. .	7 lb. ft. (.97 kg. m.) with 350-375 amps.
<b>Alternator</b> .. .. .	Lucas 16ACR.
Nominal output .. .. .	34 amps. at 6,000 r.p.m. (engine—2,800 r.p.m.).
Nominal system voltage .. .. .	14.2 volts at 20% nominal output.
Maximum continuous speed .. .. .	12,500 r.p.m.
Resistance of rotor winding at 20°C. (68°F.) .. .. .	4.33 ohms ±5%.
Brush spring tension .. .. .	7 to 10 oz. (198 to 283 gm.).
<b>Windscreen wiper</b> .. .. .	Lucas 14W.
Light running speeds (rack disconnected) .. .. .	46 to 52 r.p.m. (normal speed), 60 to 70 r.p.m. (fast speed).
Light running current .. .. .	1.5 amps. (normal speed), 2 amps. (fast speed).
Brush spring pressure .. .. .	5 to 7 oz. (140 to 200 gm.).
Minimum brush length .. .. .	$\frac{3}{16}$ in. (4.8 mm.).
Armature end-float .. .. .	.002 to .008 in. (.05 to .2 mm.).
Maximum pull to move rack in tube .. .. .	6 lb. (2.7 kg.).
Windscreen wiper arm spring pressure .. .. .	7 to 9 oz. (200 to 255 gm.).

#### GENERAL DIMENSIONS AND WEIGHTS

Track: Models up to 1974: Front .. .. .	47 $\frac{7}{16}$ in. (1.205 m.).
Rear .. .. .	45 $\frac{7}{8}$ in. (1.164 m.).
Models to ECE 15 regulations—1974 on:	
Front .. .. .	47 $\frac{13}{16}$ in. (1.214 m.).
Rear .. .. .	46 $\frac{13}{16}$ in. (1.180 m.).

#### Kerbside weight:

850 Saloon (Synchromesh) .. .. .	1,363 lb. (619 kg.) approx.
1000 Saloon (Synchromesh) .. .. .	1,410 lb. (640 kg.) approx.
(Automatic) .. .. .	1,442 lb. (654 kg.) approx.
Van .. .. .	1,334 lb. (605 kg.) approx.
Pick-up .. .. .	1,328 lb. (603 kg.) approx.

#### TORQUE TIGHTENING FIGURES

Brakes (split brake system)	lb. ft.	kg. m.
Tandem master cylinder reservoir flange screws .. .. .	5	0.7
Cylinder body outlet plugs .. .. .	20 to 33	2.8 to 4.5
Pressure failure switch .. .. .	12 to 15	1.6 to 2.1
Pressure failure switch body end plug .. .. .	20 to 33	2.8 to 4.5
Inertia valve plug .. .. .	40 to 50	5.5 to 6.8
<b>Alternator (Type 16ACR)</b>		
Shaft nut .. .. .	25 to 30	3.5 to 4.2

Refer to pages **General Data 8 and 9** for all other Torque figures.

# GENERAL DATA

## MINI CLUBMAN

The following information is applicable to the Mini Clubman Saloon and Estate fitted with the 99H engine. Use in conjunction with the preceding specification for the Mini Mk. II.

### ENGINE

Type .. .. .	99H.
Number of cylinders .. .. .	4.
Bore .. .. .	2.543 in. (64.588 mm.).
Stroke .. .. .	3.00 in. (76.2 mm.).
Capacity.. .. .	60.96 cu. in. (998 c.c.).
Compression ratio: High compression .. .. .	8.3 : 1.
Low compression .. .. .	7.6 : 1
B.M.E.P. High compression .. .. .	130 lb/sq. in. (9.14 kg./cm. <sup>2</sup> ) at 2,700 r.p.m.
Low compression .. .. .	-----
Torque: High compression .. .. .	52 lb. ft. (7.28 kg. m.) at 2,700 r.p.m.
Low compression .. .. .	-----

### COOLING SYSTEM

Pressure cap (up to 1974) .. .. .	13 lb./sq. in. (0.91 kg./cm. <sup>2</sup> ).
(To ECE 15 regulations – 1974 on) .. .. .	15 lb./sq. in. (1.05 kg./cm. <sup>2</sup> ).

### ENGINE LUBRICATION SYSTEM

#### Oil filter

Type .. .. .	Full flow, renewable element or cartridge.
Capacity .. .. .	1 pint (1.2 U.S. pints, 0.57 litre).

### IGNITION SYSTEM

Coil	} Refer to 'TUNING DATA'.
Distributor	
Sparking plugs	

### FUEL SYSTEM

Carburettor refer to 'TUNING DATA'.

#### Air cleaner

Type .. .. .	Paper element with warm/cold air intake and silencer tube.
--------------	--

#### Fuel pump

Make/type .. .. .	S.U. mechanical; AUF 700 (AUF 705 model).
Suction (min.) .. .. .	6 in. (152 mm.) Hg.
Pressure (min.) .. .. .	3 lb./sq. in. (.21 kg./cm. <sup>2</sup> ).

### TRANSMISSION

#### Gearbox

Number of forward speeds .. .. .	4.
Synchromesh .. .. .	All forward gears.
Ratios: Top .. .. .	1.00 : 1.
Third .. .. .	1.43 : 1.
Second .. .. .	2.21 : 1.
First .. .. .	3.52 : 1.
Reverse .. .. .	3.54 : 1.
Overall ratios: Top .. .. .	3.44 : 1.
Third .. .. .	4.93 : 1.
Second .. .. .	7.63 : 1.
First .. .. .	12.13 : 1.
Reverse .. .. .	12.19 : 1.
Road speed at 1,000 r.p.m. in top gear .. .. .	16.2 m.p.h. (25.75 km.p.h.).
Speedometer gear ratio .. .. .	4/14.

#### Final drive

Type .. .. .	Helical gears and differential.
Ratio .. .. .	3.44 : 1 (18/62).



# GENERAL DATA

## MINI CLUBMAN—continued

### ● DRIVE SHAFTS

Make .. .. .	Hardy Spicer.
Type of shaft .. .. .	Solid shaft, reverse spline.
Joint at wheel end .. .. .	Constant velocity.
Coupling/joint at differential end: Later models .. .. .	Pre-lubricated offset-sphere joint.
Early models .. .. .	Pre-lubricated sliding joint with rubber coupling and 'U' bolts. ●

### STEERING

Type .. .. .	Rack and pinion.
Steering-wheel turns—lock to lock .. .. .	2.7.
Steering-wheel diameter .. .. .	15.0 in.* (380 mm.).
Front wheel alignment— <i>toe-out</i> .. .. .	$\frac{1}{8}$ in. (1.6 mm.) or } vehicle unladen.
	0° 15' included angle }
● Lock angle: outer wheel at 20°, inner wheel .. .. .	21.50° ± 1.50°. ●

### SUSPENSION

#### Saloon—up to Commission Nos. S 20 S 48644A (Manual gearbox)

#### S 20 S 48267A (Automatic transmission)

Type .. .. .	Hydroelastic suspension.
Fluid capacity .. .. .	4 pints (5 U.S. pints, 2.27 litres), approx.
*Fluid pressure (unladen) .. .. .	292 lb./sq. in. (20.6 kg./cm. <sup>2</sup> ), approx.
Trim height: Front and rear .. .. .	13½ ± ⅜ in. (343 ± 9.5 mm.).

\* Adjust to trim height.

#### Saloon—from Commission Nos. S 20 S 48645A (Manual gearbox)

#### S 20 S 48268A (Automatic transmission)

Type .. .. .	Rubber cone springs.
--------------	----------------------

#### Estate

Type .. .. .	Rubber cone springs.
--------------	----------------------

### HYDRAULIC DAMPERS (Estate car and later saloons)

Type: Front and rear .. .. .	Tubular telescopic.
------------------------------	---------------------

### ELECTRICAL EQUIPMENT

System .. .. .	12-volt, negative earth.
Charging system .. .. .	Compensated voltage control.

#### Battery

Lucas 'Pacemaker' type .. .. .	A7	A9
Capacity at 20 hr. rate .. .. .	30 amps.	40 amps.
Lucas type .. .. .	CL7	CLZ7
Capacity at 20 hr. rate .. .. .	34 amps.	34 amps.
Exide battery .. .. .	Type 6 VTP 9—BR.	
Capacity at 20 hr. rate .. .. .	35 amps.	
Dynamo .. .. .	Lucas C40.	
Maximum output .. .. .	22 amps. at 2,250 r.p.m.	
Cut-in speed .. .. .	1,450 r.p.m. at 13.5 volts.	
Control box .. .. .	Lucas RB106/2.	
Cut-out: Cut-in voltage .. .. .	12.7 to 13.3.	
Drop-off voltage .. .. .	8.5 to 11.0.	
Reverse current .. .. .	5.0 amps. (max.).	

#### Regulator (at 3,000 r.p.m. dynamo speed):

Open-circuit setting at 20°C. (68°F.) .. .. .	16.0 to 16.6 volts.
---	---------------------

For ambient temperatures other than 20°C. (68°F.) the following allowances should be made to the above setting:

For every 10°C. (18°F.) above 20°C. (68°F.) subtract .1 volt. For every 10°C. (18°F.) below 20°C. (68°F.) add .1 volt.

# GENERAL DATA

## MINI CLUBMAN—continued

<b>Starter motor</b> .. .. .	Lucas M35G or M35J.
M35G Type: Brush spring tension .. .. .	15 to 25 oz. (425 to 709 gm.).
M35J Type: Brush spring tension .. .. .	28 oz. (794 gm.).
Light running current .. .. .	65 amperes at 8,000–10,000 r.p.m.
Lock torque .. .. .	7 lb. ft. (.97 kg. m.) with 350–375 amps.
<b>Alternator</b> .. .. .	Lucas 16ACR.
Nominal output .. .. .	34 amps. at 6,000 r.p.m.
Nominal system voltage .. .. .	14.2 volts at 20% nominal output.
Maximum continuous speed .. .. .	12,500 r.p.m.
Resistance of rotor winding at 20° C. (68° F.) .. .. .	4.33 ohms ± 5%.
Brush spring tension .. .. .	7 to 10 oz. (198 to 283 gm.).
<b>Windscreen wiper</b> .. .. .	Lucas 14W.
Light running speeds (rack disconnected) .. .. .	46 to 52 r.p.m. (normal speed), 60 to 70 r.p.m. (fast speed).
Light running current .. .. .	1.5 amps. (normal speed), 2 amps. (fast speed).
Brush spring pressure .. .. .	5 to 7 oz. (140 to 200 gm.).
Minimum brush length .. .. .	$\frac{3}{16}$ in. (4.8 mm.).
Armature end-float .. .. .	.002 to .008 in. (.05 to .2 mm.).
Maximum pull to move rack in tube .. .. .	6 lb. (2.7 kg.).
Windscreen wiper arm spring pressure .. .. .	7 to 9 oz. (200 to 255 gm.).

### GENERAL DIMENSIONS

<b>Wheelbase: Saloon</b> .. .. .	6 ft. 8 $\frac{5}{8}$ in. (2.036 m.).
Estate .. .. .	7 ft. 0 $\frac{5}{8}$ in. (2.138 m.).
<b>Overall length: Saloon</b> .. .. .	10 ft. 4 $\frac{1}{2}$ in. (3.16 m.).
Estate .. .. .	11 ft. 2 in. (3.4 m.).
<b>Overall width</b> .. .. .	4 ft. 7 $\frac{1}{2}$ in. (1.41 m.).
<b>Overall height: Saloon</b> .. .. .	4 ft. 5 in. (1.35 m.).
Estate .. .. .	4 ft. 5 $\frac{1}{2}$ in. (1.36 m.).
<b>Ground clearance</b> .. .. .	6 $\frac{5}{8}$ in. (15.63 mm.).
<b>Turning circle: Saloon</b> .. .. .	28 ft. 6 in. (8.55 m.).
Estate .. .. .	29 ft. (8.84 m.).
<b>Track: Models up to 1974:</b> Front .. .. .	47 $\frac{7}{16}$ in. (1.205 m.).
Rear .. .. .	45 $\frac{7}{8}$ in. (1.164 m.).
<b>Models to ECE 15 regulations—1974 on:</b>	
Front .. .. .	47 $\frac{13}{16}$ in. (1.214 m.).
Rear .. .. .	46 $\frac{13}{16}$ in. (1.180 m.).

### WEIGHTS

<b>Kerbside weight: Saloon</b> .. .. .	1406 lb. (638 kg.) approx.
Estate .. .. .	1514 lb. (686 kg.) approx.
<b>Maximum towing weight: Saloon</b> .. .. .	8 cwt. (406.4 kg.)
Estate .. .. .	6 cwt. (304.7 kg.)

} (suitable for 1 in 8 gradient in bottom gear).

### CAPACITIES

<b>Transmission casing (including filter)</b> .. .. .	8 $\frac{1}{2}$ pints (10.2 U.S. pints, 4.83 litres).
<b>Cooling system</b> .. .. .	5 $\frac{1}{4}$ pints (6.3 U.S. pints, 3 litres).
With heater .. .. .	6 $\frac{1}{4}$ pints (7.5 U.S. pints, 3.55 litres).
<b>Fuel tank: Saloon</b> .. .. .	5 $\frac{1}{2}$ gallons (6.6 U.S. gallons, 25 litres).
Estate .. .. .	6 gallons (7.2 U.S. gallons, 27.3 litres).

### TORQUE TIGHTENING FIGURES

<b>Alternator (type 16ACR)</b>	
Shaft nut .. .. .	25 to 30 lb. ft. (3.5 to 4.2 kg. m.).

Refer to pages **General Data 8 and 9** for all other Torque figures.

# GENERAL DATA

## MINI 1275 GT

### ENGINE

Type .. .. .	12H.
Number of cylinders .. .. .	4.
Bore .. .. .	2.78 in. (70.61 mm.).
Stroke .. .. .	3.2 in. (81.28 mm.).
Capacity .. .. .	77.8 cu. in. (1274.86 c.c.).
Firing order .. .. .	1, 3, 4, 2.
Valve operation .. .. .	Overhead by push-rod.
Compression ratio: H.C. .. .. .	8.8 : 1.
L.C. .. .. .	8 : 1.
B.M.E.P.: H.C. .. .. .	134 lb./sq. in. (9.4 kg./cm. <sup>2</sup> ) at 3,500 r.p.m.
Torque: H.C. .. .. .	69 lb. ft. at 3,500 r.p.m.
Oversize bore: 1st .. .. .	.010 in. (.25 mm.).
Max. .. .. .	.020 in. (.51 mm.).

### Crankshaft

Main journal diameter .. .. .	2.0005 to 2.0010 in. (50.81 to 50.82 mm.).
Crankpin journal diameter .. .. .	1.7504 to 1.7509 in. (44.45 to 44.47 mm.).
Crankshaft end thrust .. .. .	Taken in thrust washers at centre main bearing.
Crankshaft end-float .. .. .	.002 to .003 in. (.05 to .07 mm.).

### Main bearings

Number and type .. .. .	Three thin-wall; split shells copper-lead-indium.
Material .. .. .	VP3, lead-indium at NFM/3B.
Length .. .. .	.975 to .985 in. (24.76 to 25.02 mm.).
Diametrical clearance .. .. .	.001 to .0027 in. (.025 to .07 mm.).
Undersizes .. .. .	.020 in. (.51 mm.) and .040 in. (1.02 mm.).

### Connecting rods

Type .. .. .	Horizontally split lug end, plain small end.
Length between centres .. .. .	5.748 to 5.792 in. (21.36 to 21.59 mm.).

### Big-end bearings

Type and material .. .. .	Thin-wall; steel-backed, copper-lead-indium plated.
Length .. .. .	.840 to .850 in. (21.33 to 21.59 mm.).
Diametrical clearance .. .. .	.001 to .0025 in. (.02 to .06 mm.).
End-float of crankpin .. .. .	.006 to .010 in. (.15 to .25 mm.).

### Pistons

Type .. .. .	Aluminium, solid skirt, dished crown.
Clearance in cylinder: Top of skirt .. .. .	.0029 to .0037 in. (.07 to .09 mm.).
Bottom of skirt .. .. .	.0015 to .0021 in. (.04 to .05 mm.).
Number of rings .. .. .	4 (3 compression, 1 oil control).
Width of ring grooves: Top, second, third .. .. .	.0484 to .0494 in. (1.23 to 1.25 mm.).
Oil control .. .. .	.1578 to .1588 in. (4.01 to 4.03 mm.).
Gudgeon pin base .. .. .	.8125 to .8129 in. (20.64 to 20.65 mm.).

# GENERAL DATA

## MINI 1275 GT—continued

### Piston rings

Compression: Type: Top .. .. .	Internally chamfered chrome.
Second and third .. .. .	Tapered cast iron.
Width Top .. .. .	} .0615 to .0625 in. (1.57 to 1.60 mm.).
Second and Third .. .. .	
Fitted gap: Top .. .. .	.011 to .016 in. (.28 to .40 mm.).
Second and third .. .. .	.008 to .013 in. (.20 to .33 mm.).
Ring to groove clearance: Top .. .. .	} .0015 to .0035 in. (.04 to .09 mm.).
Second and third .. .. .	
Oil control:	
Type .. .. .	Duaflex 61.
Fitted gap: Rails .. .. .	} .012 to .028 in. (.30 to .70 mm.).
Side spring .. .. .	

### Gudgeon pin

Type .. .. .	Pressed in connecting rod.
Fit in piston .. .. .	Hand push fit.
Diameter (outer) .. .. .	.8123 to .8125 in. (20.63 to 20.64 mm.).
Fit to connecting rod .. .. .	.0008 to .0015 in. (.02 to .04 mm.) interference.

### Camshaft

Journal diameters: Front .. .. .	1.6655 to 1.6660 in. (42.304 to 42.316 mm.).
Centre .. .. .	1.62275 to 1.62325 in. (41.218 to 41.231 mm.).
Rear .. .. .	1.37275 to 1.37350 in. (34.866 to 34.889 mm.).
Bearing liner inside diameter:	
Un-reamed after fitting: Front .. .. .	1.652 in. (41.98 mm.).
Centre .. .. .	1.61 in. (40.89 mm.).
Rear .. .. .	1.36 in. (34.52 mm.).
Reamed after fitting: Front .. .. .	1.6670 to 1.6675 in. (42.34 to 42.35 mm.).
Centre .. .. .	1.62425 to 1.62475 in. (41.25 to 41.37 mm.).
Rear .. .. .	1.3745 to 1.3750 in. (34.91 to 34.92 mm.).
Bearings: Type .. .. .	White-metal-lined, steel-backed.
Diametrical clearance .. .. .	.001 to .002 in. (.02 to .05 mm.).
End-thrust .. .. .	Taken on locating plate.
End-float .. .. .	.003 to .007 in. (.07 to .18 mm.).
Cam lift .. .. .	.318 in. (8.07 mm.).
Drive .. .. .	Duplex chain and gear from crankshaft.
Timing chain .. .. .	$\frac{3}{8}$ in. (9.52 mm.) pitch x 52 pitches.

### Tappets

Type .. .. .	Bucket.
Outside diameter .. .. .	.81125 to .81175 in. (20.60 to 20.62 mm.).
Length .. .. .	1.495 to 1.505 in. (37.97 to 38.23 mm.).

### Rocker gear

Rocker shaft: Diameter .. .. .	.5615 to .5625 in. (14.26 to 14.29 mm.).
Rocker arm: Bore .. .. .	.686 to .687 in. (17.45 mm.).
Bush inside diameter .. .. .	.5630 to .5635 in. (14.3 to 14.31 mm.).

# GENERAL DATA

## MINI 1275 GT—continued

### Valves

Seat angle: Inlet and exhaust .. .. .	45°.
Head diameter: Inlet .. .. .	1.307 to 1.312 in. (33.2 to 33.21 mm.).
Exhaust .. .. .	1.1515 to 1.1565 in. (29.24 to 29.37 mm.).
Stem diameter: Inlet .. .. .	.2793 to .2798 in. (7.09 to 7.11 mm.).
Exhaust .. .. .	.2788 to .2793 in. (7.08 to 7.09 mm.).
Stem to guide clearance: Inlet and exhaust .. .. .	.0015 to .0025 in. (.04 to .08 mm.).
Valve lift: Inlet and exhaust .. .. .	.318 in. (8.07 mm.).

### Valve guides

Length: Inlet .. .. .	1.6875 in. (42.87 mm.).
Exhaust .. .. .	1.8437 in. (46.83 mm.).
Fitted height above seat: Exhaust .. .. .	} .540 in. (13.72 mm.).
Inlet .. .. .	

### Valve springs

Free length .. .. .	1.95 in. (49.13 mm.).
Fitted length .. .. .	1.383 in. (34.715 mm.).
Load at fitted length .. .. .	79.5 lb. (36.03 kg.).
Load at top of lift .. .. .	124 lb. (56.3 kg.).
No. of working coils .. .. .	4½.

### Valve timing

Timing marks .. .. .	Dimples on timing gears.
Rocker clearance: Running .. .. .	.012 in. (.305 mm.) cold.
Timing .. .. .	.021 in. (.533 mm.).
Inlet valve: Opens .. .. .	5° B.T.D.C.
Closes .. .. .	45° B.B.D.C.
Exhaust valve: Opens .. .. .	51° B.B.D.C.
Closes .. .. .	21° A.T.D.C.

## ENGINE LUBRICATION SYSTEM

### Oil pump

Type .. .. .	Internal gear, splined drive from camshaft.
Oil pressure relief valve .. .. .	50 lb./sq. in. (3.5 kg. cm. <sup>2</sup> ).
Relief valve spring: Free length .. .. .	2.86 in. (72.64 mm.).
Fitted length .. .. .	2.156 in. (54.77 mm.).
Load at fitted length .. .. .	13 to 14 lb. (5.90 to 6.35 kg.).

### Oil filter

Type .. .. .	Full flow, renewable element or cartridge.
Capacity .. .. .	1 pint (1.2 U.S. pints, .57 litre).

### System pressure

Running .. .. .	70 lb./sq. in. (4.92 kg. cm. <sup>2</sup> ) approx.
Idling .. .. .	15 lb./sq. in. (1.05 kg. cm. <sup>2</sup> ) approx.

# GENERAL DATA

## MINI 1275 GT—continued

### IGNITION SYSTEM

Coil	}	Refer to 'TUNING DATA'.
Distributor		
Sparking plugs		

### COOLING SYSTEM

#### Thermostat settings

Standard .. .. .	82° C. (180° F.).
Hot countries .. .. .	74° or 77° C. (165° or 170° F.).
Cold countries .. .. .	88° C. (190° F.).
Pressure cap: (engines up to 1974) .. .. .	13 lb./sq. in. (.91 kg./cm. <sup>2</sup> ).
(engines to ECE 15 Regulations) .. .. .	15 lb./sq. in. (1.05 kg./cm. <sup>2</sup> ).

### FUEL SYSTEM

**Carburettor** refer to 'TUNING DATA'.

#### Air cleaner

Type: (engines up to 1974) .. .. .	Paper element with warm/cold air intake and silencer tube.
(engines to ECE 15 Regulations) .. .. .	Paper element with air temperature control.

#### Fuel pump

Make/type .. .. .	S.U. mechanical; AUF 700 (AUF 705 model).
Suction (min.) .. .. .	6 in. (152 mm.) Hg.
Pressure (min.) .. .. .	3 lb./sq. in. (.21 kg./cm. <sup>2</sup> ).

### CLUTCH

Make and type .. .. .	Borg & Beck diaphragm type.
Clutch plate diameter .. .. .	7 $\frac{1}{8}$ in. (180.9 mm.).
Facing material .. .. .	Wound yarn.
Diaphragm-spring colour code .. .. .	Green/Blue.
Clutch fluid .. .. .	Unipart 410 or 550 Brake Fluid.

### TRANSMISSION

#### Gearbox

Number of forward speeds .. .. .	4.	
Synchromesh .. .. .	All forward gears.	
	<b>From Engine No.</b>	
	<b>12H 389S, H6901</b>	<b>Early cars</b>
Ratios: Top .. .. .	1.00 : 1	1.00 : 1.
Third .. .. .	1.35 : 1	1.35 : 1.
Second .. .. .	2.07 : 1	2.07 : 1.
First .. .. .	3.30 : 1	3.30 : 1.
Reverse .. .. .	3.35 : 1	3.35 : 1.
Overall ratios: Top .. .. .	3.44 : 1	3.65 : 1;
Third .. .. .	4.66 : 1	4.93 : 1.
Second .. .. .	7.21 : 1	7.64 : 1.
First .. .. .	11.47 : 1	12.14 : 1.
Reverse .. .. .	11.53 : 1	12.21 : 1.
Road speed at 1,000 r.p.m. in top gear .. .. .	16.2 m.p.h. (25.75 km.p.h.)	15 m.p.h. (24.14 km.p.h.)
Speedometer gear ratio .. .. .	4/14	4/16.

# GENERAL DATA

## MINI 1275 GT—continued

### Final drive

Type .. .. .	Helical gears and differential.
Ratio .. .. .	3.44 : 1 (18/62)      3.65 : 1 (17/62).

### DRIVE SHAFTS

Make .. .. .	Hardy Spicer.
Type of shaft .. .. .	Solid shaft, reverse spline.
Joint at wheel end .. .. .	Constant velocity.
Coupling/joint at differential end (later models)	Pre-lubricated offset-sphere joint.
(early models) .. .. .	Pre-lubricated sliding joint with rubber coupling and 'U' bolts.

### STEERING

Type .. .. .	Rack and pinion.
Steering-wheel turns—lock to lock .. .. .	2.7.
Steering-wheel diameter .. .. .	15.0 in. (380 mm.).
Front wheel alignment— <i>toe-out</i> .. .. .	$\frac{1}{16}$ in. (1.6 mm.) or } car unladen. 0° 15' included angle

### SUSPENSION—up to Commission No. S 20 D 8155A

Type .. .. .	Hydroelastic suspension.
Fluid capacity .. .. .	4 pints (5 U.S. pints, 2.27 litres) approx.
*Fluid pressure (unladen) .. .. .	292 lb./sq. in. (20.6 kg./cm. <sup>2</sup> ), approx.
Trim height—front and rear .. .. .	$13\frac{1}{2} \pm \frac{3}{8}$ in. (343 $\pm$ 9.5 mm.).

\* Adjust to trim height.

### Later cars—from Commission No. S 20 D 8156A

Type .. .. .	Rubber cone springs.
--------------	----------------------

### HYDRAULIC DAMPERS (Later cars only)

Type: Front and rear .. .. .	Tubular telescopic.
------------------------------	---------------------

### BRAKES

Type .. .. .	Lockheed hydraulic.
Servo unit (Models up to 1974) .. .. .	Lockheed (Type 6).
Master cylinder bore diameter .. .. .	.7 in. (17.9 mm.).

#### Split brake system

(Tandem master cylinder) .. .. .	Refer to Mini 850/1000 Data.
Brake fluid .. .. .	Unipart 550 BRAKE FLUID, alternatively use a high-boiling-point brake fluid conforming to specification S.A.E. J1703c, with a minimum boiling point of 260° C. (500° F.).



# GENERAL DATA

## MINI 1275 GT—continued

### Front

Type .. .. .	Disc.
Disc diameter (Models up to 1974) .. .. .	7.5 in. (190.5 mm.).
(Models to ECE 15 Regulations) .. .. .	8.4 in. (213.4 mm.).
Pad material (Models up to 1974) .. .. .	Mintex M78 (Red/green/red/green/red).
(Models to ECE 15 Regulations) .. .. .	Mintex M121 (LDB 751).
Pad area—total (Models up to 1974) .. .. .	17.3 sq. in. (111.6 cm. <sup>2</sup> ).
(Models to ECE 15 Regulations) .. .. .	16.6 sq. in. (107 cm. <sup>2</sup> ).
Swept area—total (Models up to 1974) .. .. .	122 sq. in. (787 cm. <sup>2</sup> ).
(Models to ECE 15 Regulations) .. .. .	134.46 sq. in. (864.5 cm. <sup>2</sup> ).
Minimum pad thickness .. .. .	$\frac{1}{16}$ in. (1.6 mm.).

### Rear

Drum size .. .. .	7 in. (17.8 cm.) diameter.
Lining dimensions .. .. .	6.75 x 1.5 in. (17.4 x 3.18 cm.).
Lining area total .. .. .	40.5 sq. in. (261.29 cm. <sup>2</sup> ).
Lining material .. .. .	Don 202.
Wheel cylinder diameter (Models up to 1974) .. .. .	.75 in. (19.05 mm.).
(Models to ECE 15 Regulations) .. .. .	.50 in. (12.7 mm.).

### WHEELS

Type .. .. .	Pressed steel disc.
Size (Models up to 1974) .. .. .	4.5J x 10.
(Models to ECE 15 Regulations) .. .. .	4.5J x 12.

### TYRES

Size .. .. .	145—10 Radial ply (tubed).
Pressures all conditions: Front .. .. .	28 lb./sq. in. (1.97 kg./cm. <sup>2</sup> ).
Rear .. .. .	26 lb./sq. in. (1.83 kg./cm. <sup>2</sup> ).
Size (Models to ECE 15 Regulations) .. .. .	145/70SR—12.
Pressures all conditions: Front and Rear .. .. .	28 lb./sq. in. (1.97 kg./cm. <sup>2</sup> ).

### DENOVO WHEELS AND TYRES

#### Wheels

Type .. .. .	Divided inner and outer pressed steel rim with replaceable lubricant canisters.
Size .. .. .	80 mm.x 310 mm.

#### Tyres

Size .. .. .	155/65 SF—310.
Pressures (cold) all conditions: Front .. .. .	26 lb./sq. in. (1.8 kg./cm. <sup>2</sup> ).
Rear .. .. .	24 lb./sq. in. (1.7 kg./cm. <sup>2</sup> ).

### ELECTRICAL EQUIPMENT

System .. .. .	12-volt, negative earth.
Charging system .. .. .	Compensated voltage control.

#### Battery:

Lucas 'Pacemaker' type .. .. .	A9	A11/9.
Capacity at 20 hr. rate .. .. .	40 amps.	50 amps.
Lucas type .. .. .	C9	CZ9.
Capacity at 20 hr. rate .. .. .	43 amps.	43 amps.

# GENERAL DATA

## MINI 1275 GT—continued

<b>Dynamo</b> .. .. .	Lucas C40.
Maximum output .. .. .	22 amps. at 2,250 r.p.m.
Cut-in speed .. .. .	1,450 r.p.m. at 13.5 volts.
<b>Control box</b> .. .. .	Lucas RB106/2.
Cut-out: Cut-in voltage .. .. .	12.7 to 13.3.
Drop-off voltage .. .. .	8.5 to 11.0.
Reverse current .. .. .	5.0 amps. (max.).
<b>Regulator (at 3,000 r.p.m. dynamo speed):</b>	
Open-circuit setting at 20° C. (68° F.) .. .. .	16.0 to 16.6 volts.
For ambient temperatures other than 20° C. (68° F.) the following allowances should be made to the above setting:	
For every 10° C. (18° F.) above 20° C. (68° F.) subtract .1 volt.	
For every 10° C. (18° F.) below 20° C. (68° F.) add .1 volt.	
<b>Starter motor</b> .. .. .	Lucas M35G or M35J.
<b>M35G Type</b>	
Brush spring tension .. .. .	15 to 25 oz. (425 to 709 gm.).
<b>M35J Type</b>	
Brush spring tension .. .. .	28 oz. (794 gm.).
Light running current .. .. .	65 amperes at 8,000–10,000 r.p.m.
Lock torque .. .. .	7 lb. ft. (.97 kg. m.) with 350–375 amps.
<b>Alternator</b> .. .. .	Lucas 16ACR.
Nominal output .. .. .	34 amps. at 6,000 r.p.m. (engine—2,800 r.p.m.).
Nominal system voltage .. .. .	14.2 volts at 20% nominal output.
Maximum continuous speed .. .. .	12,500 r.p.m.
Resistance of rotor winding at 20° C. (68° F.) .. .. .	4.33 ohms ± 5%.
Brush spring tension .. .. .	7 to 10 oz. (198 to 283 gm.).
<b>Windscreen wiper</b> .. .. .	Lucas 14W.
Light running speeds (rack disconnected) .. .. .	46 to 52 r.p.m. (normal speed), 60 to 70 r.p.m. (fast speed).
Light running current .. .. .	1.5 amps. (normal speed), 2 amps. (fast speed).
Brush spring pressure .. .. .	5 to 7 oz. (140 to 200 gm.).
Minimum brush length .. .. .	$\frac{3}{16}$ in. (4.8 mm.).
Armature end-float .. .. .	.002 to .008 in. (.05 to .2 mm.).
Maximum pull to move rack in tube .. .. .	6 lb. (2.7 kg.).
Windscreen wiper arm spring pressure .. .. .	7 to 9 oz. (200 to 255 gm.).

### GENERAL DIMENSIONS

Wheelbase .. .. .	6 ft. 8 $\frac{5}{8}$ in. (2.036 m.).
Overall length .. .. .	10 ft. 4 $\frac{3}{8}$ in. (3.16 m.).
Overall width .. .. .	4 ft. 7 $\frac{1}{2}$ in. (1.41 m.).
Overall height (Models up to 1974) .. .. .	4 ft. 5 in. (1.35 m.).
(Models 1974 on with standard 12 in. wheels) .. .. .	4 ft. 5 $\frac{1}{2}$ in. (1.358 m.).
(Models with DENOVO wheels/tyres) .. .. .	4 ft. 5 $\frac{3}{8}$ in. (1.354 m.).
Ground clearance (Models up to 1974) .. .. .	6 in. (152.4 mm.).
(Models with standard 12 in. wheels) .. .. .	6 $\frac{1}{2}$ in. (165 mm.).
(Models with DENOVO wheels/tyres) .. .. .	6 $\frac{3}{8}$ in. (161 mm.).
Turning circle .. .. .	28 ft. 6 in. (8.55 m.).

## GENERAL DATA

### MINI 1275 GT—continued

Track (Models up to 1974):	Front	..	..	48½ in. (1232 mm.).
	Rear	..	..	47½ in. (1210 mm.).
(Models with 12 in. wheels):	Front	..	..	48¾ in. (1238 mm.).
	Rear	..	..	47⅞ in. (1205 mm.).
(Models with DENOVO wheels/tyres):	Front	..	..	48⅞ in. (1234 mm.).
	Rear	..	..	47¾ in. (1200 mm.).

#### WEIGHTS

Kerbside weight (Models with standard wheels)	..	..	..	1,555 lb. (707 kg.) approx.
(Models with DENOVO wheels)	..	..	..	1,481 lb. (671 kg.) approx.
Maximum permissible towing weight (suitable for 1 in 8 gradient in bottom gear):	..	..	..	8 cwt. (406.4 kg.).

#### WEIGHT OF COMPONENTS

Engine and transmission assembly	..	..	..	..	339 lb. (154 kg.).
----------------------------------	----	----	----	----	--------------------

#### Capacities

Transmission casing (including filter)	..	..	..	..	8½ pints (10.2 U.S. pints, 4.83 litres).
Cooling system	..	..	..	..	5¼ pints (6.3 U.S. pints, 3 litres).
With heater	..	..	..	..	6¼ pints (7.5 U.S. pints, 3.55 litres).
Fuel tank (Models up to 1974)	..	..	..	..	5½ gallons (6.6 U.S. gallons, 25 litres).
(Models to ECE 15 Regulations)	..	..	..	..	7½ gallons (9 U.S. gallons, 43 litres).

#### TORQUE TIGHTENING FIGURES

Engine		lb. ft	kg. m.
Cylinder head nuts	.. .. .	50	7
Connecting rod bolt nuts (including multi-sided type nuts—oiled)	.. .. .	31 to 35	4.3 to 4.8
<b>Alternator (type 16ACR):</b>			
Shaft nut	.. .. .	25 to 30	3.5 to 4.2
<b>Brakes</b>			
Calliper retaining bolts	.. .. .	35 to 40	4.8 to 5.5
<b>Suspension and steering</b>			
Drive shaft nut	.. .. .	150	20.7
Steering lever ball joint	.. .. .	25 to 30	3.5 to 4.2

Refer to pages **General Data 8 and 9** for all other Torque figures

# GENERAL DATA

## MINI CLUBMAN 1100

The following information is applicable to the Mini Clubman 1100 Saloon and Estate fitted with the 10H engine. Use in conjunction with the specification for the Mini Clubman.

### ENGINE

Type .. .. .	10H
Number of cylinders..	4
Bore .. .. .	2.543 in (64.58 mm)
Stroke .. .. .	3.296 in (83.72 mm)
Capacity .. .. .	1098 cm <sup>3</sup> (67 in <sup>3</sup> )
Firing order .. .. .	1, 3, 4 2
Valve operation .. .. .	Overhead by push-rod
Compression ratio .. .. .	8.5 : 1
Oversize bores .. .. .	0.020 in (0.51 mm)
Torque (gross).. .. .	60 lbf ft (8.3 kgf m) at 2,450 rev/min

### Crankshaft

Main journal diameter .. .. .	1.7505 to 1.7512 in (44.46 to 44.48 mm)
Minimum regrind diameter .. .. .	1.7105 in (43.45 mm)
Crankpin journal diameter .. .. .	1.6252 to 1.6259 in (41.28 to 41.29 mm)
Minimum regrind diameter .. .. .	1.5852 in (40.27 mm)
Crankshaft end-thrust .. .. .	Taken on thrust washers at centre main bearing
Crankshaft end-float .. .. .	0.001 to 0.005 in (0.03 to 0.13 mm)

### Main bearings

Number and type.. .. .	3 thin wall type
Width .. .. .	1 $\frac{1}{8}$ in (27 mm)
Diametrical clearance .. .. .	0.001 to 0.0027 in (0.03 to 0.07 mm)
Undersizes .. .. .	0.010 in 0.020 in 0.030 in 0.040 in (0.25 mm 0.51 mm 0.76 mm 1.02 mm)

### Connecting rods

Type .. .. .	Diagonally split big-end, bushed small end
Length between centres .. .. .	5.75 in (146.1 mm)

### Big-end bearings

Type .. .. .	Thin wall
Diametrical clearance .. .. .	0.001 to 0.0025 in (0.03 to 0.06 mm)
Undersizes .. .. .	0.010 in 0.020 in 0.030 in 0.040 in (0.25 mm 0.51 mm 0.76 mm 1.02 mm)

### Gudgeon pin

Type .. .. .	Fully floating
Fit in piston .. .. .	Hand push-fit

# GENERAL DATA

## MINI CLUBMAN 1100—continued

### Pistons

Type .. .. .	Solid skirt
Clearances:	
Bottom of skirt .. .. .	0.0005 to 0.0015 in (0.01 to 0.04 mm)
Top of skirt .. .. .	0.0021 to 0.0033 in (0.05 to 0.08 mm)
Oversizes .. .. .	0.020 in (0.51 mm)

### Piston rings

Compression:	
Type: Top .. .. .	Chrome-faced
Second and third .. .. .	Tapered, cast iron alloy
Width .. .. .	0.0615 to 0.0625 in (1.57 to 1.60 mm)
Fitted gap .. .. .	0.007 to 0.012 in (0.18 to 0.30 mm)
Ring to groove clearance .. .. .	0.002 to 0.004 in (0.05 to 0.10 mm)
Oil control:	
Type .. .. .	Duaflex
Fitted gap: Rails .. .. .	0.012 to 0.028 in (0.30 to 0.71 mm)
Side spring .. .. .	0.10 to 0.15 in (2.5 to 3.8 mm)

### Camshaft

Journal diameters: Front .. .. .	1.6655 to 1.6660 in (42.30 to 42.32 mm)
Centre .. .. .	1.62275 to 1.62325 in (41.22 to 41.23 mm)
Rear .. .. .	1.3725 to 1.3735 in (34.87 to 34.89 mm)
Bearing liner inside diameter (reamed after fitting):	
Front .. .. .	1.6670 to 1.6675 in (42.34 to 42.35 mm)
Centre .. .. .	1.62425 to 1.62475 in (41.26 to 41.27 mm)
Rear .. .. .	1.3745 to 1.3750 in (34.91 to 34.93 mm)
Diametrical clearance .. .. .	0.001 to 0.002 in (0.02 to 0.05 mm)
End-thrust .. .. .	Taken on locating plate
End-float .. .. .	0.003 to 0.007 in (0.08 to 0.18 mm)

### Rocker gear

Rocker shaft diameter .. .. .	0.5615 to 0.5625 in (14.26 to 14.29 mm)
Rocker bush inside diameter (reamed in position) .. .. .	0.5630 to 0.5635 in (14.30 to 14.31 mm)

### Tappets

Type .. .. .	Barrel
Outside diameter .. .. .	0.812 in (20.64 mm)
Length .. .. .	1.5 in (38.10 mm)

### Valves

Seat angle: Inlet .. .. .	45°
Exhaust .. .. .	45°
Head diameter: Inlet .. .. .	1.151 to 1.156 in (29.23 to 29.36 mm)
Exhaust .. .. .	1.0 to 1.005 in (25.4 to 25.53 mm)
Stem diameter: Inlet .. .. .	0.2793 to 0.2798 in (7.09 to 7.11 mm)
Exhaust .. .. .	0.2788 to 0.2793 in (7.08 to 7.09 mm)
Stem to guide clearance: Inlet and exhaust .. .. .	0.0015 to 0.0025 in (0.04 to 0.06 mm)
Valve lift: Inlet and exhaust .. .. .	0.285 in (7.24 mm)

# GENERAL DATA

## MINI CLUBMAN 1100—continued

### Valve guides

Length: Inlet and exhaust	.. .. .	1.531 in (38.89 mm)
Outside diameter: Inlet and exhaust	.. .. .	0.4695 to 0.4700 in (11.93 to 11.94 mm)
Inside diameter: Inlet and exhaust	.. .. .	0.2813 to 0.2818 in (7.15 to 7.16 mm)
Fitted height above spring seat: Inlet and exhaust	.. .. .	0.5938 in (15.08 mm)
Interference fit in head: Inlet and exhaust	.. .. .	0.0005 to 0.0015 in (0.01 to 0.04 mm)

### Valve springs

Free length	.. .. .	1.750 in (44.45 mm)
Fitted length	.. .. .	1.258 in (31.95 mm)
Load at fitted length	.. .. .	55.5 lbf (25.2 kgf)
Load at top of lift	.. .. .	88 lbf (39.9 kgf)
Number of working coils	.. .. .	4½

### Valve timing

Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel
Rocker clearance:		
Running	.. .. .	0.012 in (0.31 mm) cold
Timing	.. .. .	0.029 in (0.74 mm)
Inlet valve: Opens	.. .. .	5° B.T.D.C.
Closes	.. .. .	45° A.B.D.C.
Exhaust valve: Opens	.. .. .	51° B.B.D.C.
Closes	.. .. .	21° A.T.D.C.

### ENGINE LUBRICATION SYSTEM

System	.. .. .	Wet sump, pressure fed
System pressure: Running	.. .. .	60 lbf/in <sup>2</sup> (4.21 kgf/cm <sup>2</sup> )
Idling	.. .. .	15 lbf/in <sup>2</sup> (1.05 kgf/cm <sup>2</sup> )
Oil pump	.. .. .	Rotor type
Oil filter	.. .. .	Full flow, with renewable cartridge
Oil pressure relief valve	.. .. .	60 lbf/in <sup>2</sup> (4.21 kgf/cm <sup>2</sup> )
Relief valve spring: Free length	.. .. .	2.86 in (72.62 mm)
Fitted length	.. .. .	2.156 in (54.77 mm)

### IGNITION SYSTEM

Coil	}	Refer to 'TUNING DATA'.
Distributor		
Sparking plugs		

### FUEL SYSTEM

**Carburettor** refer to 'TUNING DATA'.

#### Air cleaner

Type	.. .. .	Paper element with air temperature control
------	---------	--

#### Fuel pump

Make/type	.. .. .	S.U. mechanical; AUF 700 (AUF 722 model)
Suction (min.)	.. .. .	6 in (152 mm) Hg
Pressure (min.)	.. .. .	3 lbf/in <sup>2</sup> (.21 kgf/cm <sup>2</sup> )

# GENERAL DATA

## MINI CLUBMAN 1100—continued

### COOLING SYSTEM

Pressure cap .. .. . 15 lbf/in<sup>2</sup> (1.05 kgf/cm<sup>2</sup>)

### GENERAL DIMENSIONS

Track: Front .. .. . 47 <sup>11</sup>/<sub>16</sub> in (1.214 m)  
 Rear .. .. . 46 <sup>11</sup>/<sub>16</sub> in (1.180 m)

### CAPACITIES

Fuel tank: Saloon .. .. . 7½ gallons (9 U.S. gallons, 34 litres)  
 Estate .. .. . 6 gallons (7.2 U.S. gallons, 27.3 litres)

### TORQUE WRENCH SETTINGS

Engine	lbf ft	kgf m
Cylinder head stud nuts .. .. .	50	6.91
Connecting rod big-end bolts .. .. .	37	5.11
Main bearing bolts .. .. .	63	8.70
Flywheel centre-bolt .. .. .	113	15.61
Rocker bracket nuts .. .. .	24	3.32
Cylinder side cover bolt .. .. .	4	0.55
Timing cover—¼ in U.N.F. bolt .. .. .	6	0.83
⅜ in U.N.F. bolt .. .. .	12	1.66
Water pump bolts .. .. .	16	2.21
Water outlet elbow nuts .. .. .	8	1.10
Oil filter centre bolt .. .. .	14	1.94
Oil filter head nuts .. .. .	14	1.94
Oil pump bolts .. .. .	8	1.10
Manifold to cylinder head nuts .. .. .	14	1.94
Rocker cover nuts .. .. .	4	0.55
Crankshaft pulley nut .. .. .	75	10.37
Sump drain plug .. .. .	25	3.46
Flywheel housing bolts and stud nuts .. .. .	18	2.5

# ENGINE TUNING DATA

Model: MINI Mk. I —Saloon and variants }  
   —Moke }  
 MINI Mk. II —Saloon and variants }  
 MINI 850 —Saloon and variants }

(848 c.c.)

Year: 1959—67  
 1965—69  
 1967—69  
 1969—72

## ENGINE

Type: Mk. I and II models .. .. .	8AM.	
850 models .. .. .	85H.	
Capacity .. .. .	848 c.c. (51.7 cu. in.).	
Compression ratio .. .. .	8.3 : 1.	
Firing order .. .. .	1, 3, 4, 2.	
Compression pressure .. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).	
Idling speed .. .. .	500 r.p.m.	
Fast idle speed .. .. .	900 r.p.m.	
Valve rocker clearance .. .. .	.012 in. (.305 mm.) (cold).	
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.	
Ignition timing:	PREMIUM FUEL	REGULAR (COMMERCIAL)
Static .. .. .	DISTRIBUTOR	FUEL DISTRIBUTOR
Static .. .. .	T.D.C.	7° B.T.D.C.
*† Stroboscopic at 600 r.p.m. .. .. .	3° B.T.D.C.	10° B.T.D.C.

## DISTRIBUTOR

Make/type: Early type .. .. .	Lucas DM2 or 25D4.	
Later type .. .. .	Lucas 45D4.	
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).	
Rotation of rotor .. .. .	Anti-clockwise.	
Dwell angle: DM2 and 25D4 .. .. .	60° ± 3°.	
45D4 .. .. .	51° ± 5°.	
Condenser capacity .. .. .	.18 to .24 mF.	
Serial No.: DM2 and 25D4 .. .. .	40768, 41026	40767, 41007.
45D4 .. .. .	41411	41410.
Centrifugal advance	PREMIUM FUEL	REGULAR (COMMERCIAL)
Decelerating check*† .. .. .	DISTRIBUTOR	FUEL DISTRIBUTOR
Decelerating check*† .. .. .	30° to 34° at 3,400 r.p.m.	22° to 26° at 5,000 r.p.m.
Decelerating check*† .. .. .	24° to 28° at 2,500 r.p.m.	15° to 19° at 3,900 r.p.m.
Decelerating check*† .. .. .	16° to 20° at 1,300 r.p.m.	1° to 5° at 1,700 r.p.m.
Decelerating check*† .. .. .	9° to 15° at 900 r.p.m.	
Decelerating check*† .. .. .	1° to 7° at 700 r.p.m.	
No advance below .. .. .	500 r.p.m.	850 r.p.m.
Vacuum advance		
Starts .. .. .	7 in. (17.7 cm.) Hg.	5 in. (12.7 cm.) Hg.
Finishes† .. .. .	10° at 13 in. (33 cm.) Hg.	16° at 11 in. (27.9 cm.) Hg.

## SPARK PLUGS

Make .. .. .	Champion.
Type .. .. .	N9Y or N5.
Gap .. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS2.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.29 mm.).
Needle: Standard .. .. .	EB.
Rich .. .. .	M.
Weak .. .. .	GG.

\* Crankshaft degrees and r.p.m.

† Vacuum pipe disconnected.



# ENGINE TUNING DATA

Model: **MINI Mk. II—Saloon and variants**  
**MINI 1000—Saloon** }

(998 c.c.)

Year: **1967—69**  
**1969—72**

## ENGINE

Type .. .. .	99H.
Capacity .. .. .	998 c.c. (60.96 cu. in.).
Compression ratio .. .. .	8.3 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	500 r.p.m.
Fast idle speed .. .. .	900 r.p.m.
Ignition timing:	
Static .. .. .	5° B.T.D.C.      Van/Pick-up 7° B.T.D.C.
*† Stroboscopic at 600 r.p.m.	8° B.T.D.C.      10° B.T.D.C.
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold) .. .. .	.012 in. (.305 mm.)

## DISTRIBUTOR

Make/type .. .. .	Lucas 25D4 or 45D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle: 25D4 .. .. .	60° ± 3°
45D4 .. .. .	51° ± 5°
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No.: 25D4 .. .. .	40931, 41030      Van/Pick-up 41007.
45D4 .. .. .	41412              41410.
<b>Centrifugal advance</b>	
Decelerating check*† .. .. .	22° to 26° at 5,000 r.p.m.    22° to 26° at 5,000 r.p.m. 16° to 20° at 3,400 r.p.m.    15° to 19° at 3,900 r.p.m. 9° to 13° at 1,600 r.p.m.    1° to 5° at 1,700 r.p.m. 6° to 10° at 1,300 r.p.m. 0° to 4° at 900 r.p.m.
No advance below .. .. .	600 r.p.m.                      850 r.p.m.
<b>Vacuum advance</b>	
Starts .. .. .	5 in. (12.7 cm.) Hg.              5 in. (12.7 cm.) Hg.
Finishes† .. .. .	14° at 11 in. (27.9 cm.) Hg.    16° at 11 in. (27.9 cm.) Hg.

## SPARK PLUGS

Make .. .. .	Champion.
Type .. .. .	N5 or N9Y.
Gap .. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS2.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.29 mm.).
Needle: Standard .. .. .	GX.
Rich .. .. .	M.
Weak .. .. .	GG.

\* Crankshaft degrees and r.p.m.      † Vacuum pipe disconnected.

# ENGINE TUNING DATA

Model: MINI Mk. I and II AUTOMATIC

(848 c.c.)

Year: 1965-69

## ENGINE

Type .. .. .	8AH.
Capacity .. .. .	848 c.c. (51.7 cu. in.).
Compression ratio .. .. .	8.9 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	160 lb./sq. in. (11.25 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	650 r.p.m.
Fast idle speed .. .. .	1,050 r.p.m.
Ignition timing:	
Static .. .. .	3° B.T.D.C.
*† Stroboscopic at 600 r.p.m. .. .. .	6° B.T.D.C.
Timing marks .. .. .	Dimples on timing wheels, marks on converter.
Valve rocker clearance (cold) .. .. .	.012 in. (.305 mm.)

## DISTRIBUTOR

Make/type .. .. .	Lucas 25D4 or 45D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle: 25D4 .. .. .	60° ± 3°.
45D4 .. .. .	51° ± 5°.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No.: 25D4 .. .. .	41134, 41242, 41251.
45D4 .. .. .	41417.

### Centrifugal advance

Decelerating check*† .. .. .	26° to 30° at 5,500 r.p.m. 24° to 28° at 4,800 r.p.m. 15° to 19° at 1,800 r.p.m. 12° to 16° at 1,600 r.p.m. 0° to 4° at 800 r.p.m.
No advance below .. .. .	600 r.p.m.

### Vacuum advance

Starts .. .. .	3 in. (7.62 cm.) Hg.
Finishes† .. .. .	18° at 15 in. (38.1 cm.) Hg.

## SPARK PLUGS

Make .. .. .	Champion.
Type .. .. .	N5 or N9Y.
Gap .. .. .	.025 in. (.625 mm.)

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS4.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.29 mm.).
Needle: Standard .. .. .	AN.
Rich .. .. .	H6.
Weak .. .. .	EB.

\* Crankshaft degrees and r.p.m.    † Vacuum pipe disconnected.

# ENGINE TUNING DATA

Model: **MINI Mk. II AUTOMATIC**  
**MINI 1000 and CLUBMAN AUTOMATIC**

(998 c.c.)

Year: **1967-69**  
**1969-74**

## ENGINE

Type	.. .. .	9AG, 99H.
Capacity	.. .. .	998 c.c. (60.96 cu. in.).
Compression ratio	.. .. .	8.9 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Compression pressure	.. .. .	160 lb./sq. in. (11.25 kg./cm. <sup>2</sup> ).
Idling speed	.. .. .	650 r.p.m.
Fast idle speed	.. .. .	1,050 r.p.m.
Ignition timing:		
Static	.. .. .	4° B.T.D.C.
*† Stroboscopic at 600 r.p.m.	.. .. .	6° B.T.D.C.
Timing marks	.. .. .	Dimples on timing wheels, marks on converter.
Valve rocker clearance (cold)	.. .. .	.012 in. (.305 mm.)

## DISTRIBUTOR

Make/type	.. .. .	Lucas 25D4 or 45D4.
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle: 25D4	.. .. .	60° ± 3°.
45D4	.. .. .	51° ± 5°.
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.: 25D4	.. .. .	41134, 41242.
45D4	.. .. .	41417.

## Centrifugal advance

Decelerating check*†	.. .. .	26° to 30° at 5,500 r.p.m. 24° to 28° at 4,800 r.p.m. 15° to 19° at 1,800 r.p.m. 12° to 16° at 1,600 r.p.m. 0° to 4° at 800 r.p.m.
No advance below	.. .. .	600 r.p.m.

## Vacuum advance

Starts	.. .. .	3 in. (7.62 cm.) Hg.
Finishes†	.. .. .	18° at 15 in. (38.1 cm.) Hg.

## SPARK PLUGS

Make	.. .. .	Champion.
Type	.. .. .	N5 or N9Y.
Gap	.. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type	.. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.)	.. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on	.. .. .	3.9 amps.

## CARBURETTER

Make/type	.. .. .	S.U. Type HS4.
Piston spring	.. .. .	Red.
Jet size	.. .. .	.090 in. (2.29 mm.).
Needle: Standard	.. .. .	AC.
Rich	.. .. .	M1.
Weak	.. .. .	HA.

\* Crankshaft degrees and r.p.m.

† Vacuum pipe disconnected.





# ENGINE TUNING DATA

Model: MINI COOPER 'S' (970 c.c. and 1071 c.c.)

Year: 1963-65

## ENGINE

Type .. .. .	9FC, 10F.
Capacity: 970 c.c. .. .. .	59.1 cu. in.
1071 c.c. .. .. .	63.35 cu. in.
Compression ratio: 970 c.c. .. .. .	10 : 1.
1071 c.c. .. .. .	9.0 : 1.
Firing order .. .. .	1,3,4,2.
Compression pressure .. .. .	190 to 200 lb./sq. in. (13.36 to 14.07 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	600 r.p.m. approx.
Fast idle speed .. .. .	1,000 r.p.m.
Ignition timing:	
Static: 970 c.c. .. .. .	12° B.T.D.C.
1071 c.c. .. .. .	3° B.T.D.C.
Stroboscopic at 600 r.p.m.*: 970 c.c. .. .. .	14° B.T.D.C. at 600 r.p.m.
1071 c.c. .. .. .	5° B.T.D.C. at 600 r.p.m.
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance: Standard .. .. .	.012 in. (.30 mm.) cold.
Competition .. .. .	.015 in. (.38 mm.) cold.

\* Crankshaft degrees and r.p.m.

## DISTRIBUTOR

Make/type .. .. .	Lucas 23D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle .. .. .	60° ± 3°.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No. .. .. .	40819.

### Centrifugal advance

Decelerating check* .. .. .	28° to 32° at 7,000 r.p.m.
	22° to 26° at 5,200 r.p.m.
	10° to 14° at 1,600 r.p.m.
	6° to 12° at 1,000 r.p.m.
	0° to 3° at 600 r.p.m.
No advance below .. .. .	450 r.p.m.

\* Crankshaft degrees and r.p.m.

## SPARKING PLUGS

Make .. .. .	Champion.
Type .. .. .	N9Y.
Gap .. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas HA 12.
Primary resistance at 20° C. (68° F.) .. .. .	3.0 to 3.4 ohms. (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTORS

Make/type .. .. .	Twin S.U. Type HS2.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.29 mm.).
Needle: 970 c.c. .. .. .	AN (Standard).
1071 c.c. .. .. .	H6 (Standard).



# ENGINE TUNING DATA

Model: MINI CLUBMAN

Year: 1969-72

## ENGINE

Type .. .. .	99H.
Capacity .. .. .	998 c.c. (60.96 cu. in.).
Compression ratio .. .. .	8.3 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	500 r.p.m.
Fast idling speed .. .. .	900 r.p.m.
Ignition timing :	
Static .. .. .	5° B.T.D.C.
*† Stroboscopic at 600 r.p.m. .. .. .	8° B.T.D.C.
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold) .. .. .	.012 in. (.305 mm.).

## DISTRIBUTOR

Make/type .. .. .	Lucas 25D4 or 45D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle: 25D4 .. .. .	60° ± 3°.
45D4 .. .. .	51° ± 5°.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No.: 25D4 .. .. .	41030.
45D4 .. .. .	41412.

## Centrifugal advance

Decelerating check*† .. .. .	22° to 26° at 5,000 r.p.m. 16° to 20° at 3,400 r.p.m. 9° to 13° at 1,600 r.p.m. 6° to 10° at 1,300 r.p.m. 0° to 4° at 900 r.p.m.
No advance below .. .. .	600 r.p.m.

## Vacuum advance

Starts .. .. .	5 in. (12.7 cm.) Hg.
Finishes* .. .. .	14° at 11 in. (27.9 cm.) Hg.

## SPARK PLUGS

Make .. .. .	Champion.
Type .. .. .	N9Y or N5.
Gap .. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS2.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.29 mm.).
Needle: Standard .. .. .	GX.
Rich .. .. .	M.
Weak .. .. .	GG.

\* Crankshaft degrees and r.p.m.    † Vacuum pipe disconnected.



# ENGINE TUNING DATA

Model: MINI 1275 GT

Year: 1969-72

## ENGINE

Type	.. .. .	12H.
Capacity	.. .. .	1274.86 c.c. (77.8 cu. in.).
Compression ratio:	HC .. .. .	8.8 : 1.
	LC .. .. .	8 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Compression pressure	.. .. .	175 lb./sq. in. (12.3 kg./cm. <sup>2</sup> ).
Idling speed	.. .. .	650 r.p.m.
Fast idle speed	.. .. .	1,050 r.p.m.
Ignition timing:		
Static	.. .. .	8° B.T.D.C.
*† Stroboscopic at 600 r.p.m.	.. .. .	10° B.T.D.C.
Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold)	.. .. .	.012 in. (.305 mm.).

## DISTRIBUTOR

Make/type	.. .. .	Lucas 25D4 or 45D4.
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle:	25D4 .. .. .	60° ± 3°.
	45D4 .. .. .	51° ± 5°.
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.:	25D4 .. .. .	41257.
	45D4 .. .. .	41419.

## Centrifugal advance

Decelerating check*†	.. .. .	18° to 22° at 4,000 r.p.m. 11° to 15° at 2,800 r.p.m. 6° to 10° at 2,000 r.p.m. 4° to 8° at 1,600 r.p.m. 0° to 3° at 800 r.p.m.
No. advance below	.. .. .	300 r.p.m.

## Vacuum advance

Starts	.. .. .	3 in. (7.62 cm.) Hg.
Finishes*	.. .. .	18° to 22° at 10 in. (25.4 cm.) Hg.

## SPARK PLUGS

Make	.. .. .	Champion.
Type	.. .. .	N9Y.
Gap	.. .. .	.025 in. (.625 mm.).

## IGNITION COIL

Make/type	.. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.)	.. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on	.. .. .	3.9 amps.

## CARBURETTER

Make/type	.. .. .	S.U. type HS4.
Piston spring	.. .. .	Red.
Jet size	.. .. .	.090 in. (2.29 mm.).
Needle:	Standard .. .. .	AC.
	Rich .. .. .	BQ.
	Weak .. .. .	HA.

\* Crankshaft degrees and r.p.m. † Vacuum pipe disconnected.

# ENGINE TUNING DATA

Model: **Mini 1000 (CANADA)**

Year: **1970 on**

## ENGINE

Type .. .. .	99H.
Capacity .. .. .	998 c.c. (60.96 cu.in.).
Compression ratio .. .. .	8.9 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	120 lb/sq. in. (8.44 kg./cm <sup>2</sup> ).
Idling speed .. .. .	800 r.p.m. (to 1973), 850 r.p.m. (1973 on)
Fast idle speed .. .. .	1,200 to 1,300 r.p.m.
Ignition timing:	
Static .. .. .	1° B.T.D.C. (to 1972), 2° B.T.D.C. (1972), 6° B.T.D.C. (1973 on).
*† Stroboscopic: at 1,000 r.p.m. .. .. .	9° B.T.D.C.
at 1,500 r.p.m. .. .. .	8° B.T.D.C. (1973 on).
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel
Valve rocker clearance (cold) .. .. .	.012 in. (.30 mm.).

## DISTRIBUTOR

Make/type .. .. .	Lucas 25D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle .. .. .	60° + 3°
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No. .. .. .	41134 (to 1972), 41395 (1972 only), 41532 (1973 on).
<b>Centrifugal advance</b>	<b>Up to 1972</b> <b>1973 on</b>
Decelerating check*† .. .. .	24° ± 2° at 3,000 r.p.m.      32° ± 2° at 5,200 r.p.m.
	16° at 1,400 to 1,600 r.p.m.    18° at 2,800 to 3,400 r.p.m.
	4° at 600 to 800 r.p.m.        8° at 1,500 to 2,100 r.p.m.
<b>Vacuum advance</b>	<b>Up to 1972</b> <b>1972 only</b> <b>1973 on</b>
Starts .. .. .	3 in. Hg.                              5 in. Hg.                              10 in. Hg.
Finishes .. .. .	15 in. Hg.                             8 in. Hg.                             15 in. Hg.
Total crankshaft degrees .. .. .	18° ± 2°;                             6° ± 2°                             10° ± 2°.

\* Crankshaft degrees and r.p.m.

† Vacuum pipe disconnected.

## SPARK PLUGS

Make/type .. .. .	Champion N 9Y.
Gap .. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type .. .. .	A.C. Delco or Lucas 11C 12.
Primary resistance at 20°C (68°F) .. .. .	1.43 to 1.58 ohms.
Consumption—ignition on .. .. .	4.5 to 5 amps.
Ballast resistance .. .. .	1.3 to 1.4 ohms.

## CARBURETTER

Make/type .. .. .	S.U. HS4.
Type specification .. .. .	AUD 398 (up to 1972), AUD 548 (1972 only), AUD 618 (1973 on).
Choke diameter .. .. .	1½ in. (38 mm.).
Jet size .. .. .	.090 in. (3 mm.).
Needle .. .. .	AAG (to 1973), ABJ (1973 on).
Piston spring .. .. .	Red.
Initial jet adjustment .. .. .	11 flats from bridge.
Throttle to damper .. .. .	.080 in. (2.0 mm.).

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed .. .. .	4.5% CO (maximum).
---	--------------------

# ENGINE TUNING DATA

Model: MINI CLUBMAN (SWEDEN)

Year: 1972 on

## ENGINE

Type .. .. .	99H.
Capacity .. .. .	998 c.c. (60.96 cu. in.).
Compression ratio .. .. .	8.3 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	150 lb/sq. in. (10.5 kg./cm <sup>2</sup> ).
Idling speed .. .. .	800 r.p.m.
Fast idle speed .. .. .	1,100 to 1,200 r.p.m.
Ignition timing:	
Static .. .. .	1° B.T.D.C.
*† Stroboscopic at 1,000 r.p.m. .. .. .	9° B.T.D.C.
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold) .. .. .	.012 in. (.30 mm.) (cold).

\* Crankshaft degrees and r.p.m.

† Vacuum pipe disconnected.

## DISTRIBUTOR

Make/type .. .. .	Lucas 25D4.
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle .. .. .	60° ± 3°.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No. .. .. .	41212.

### Centrifugal advance

Decelerating check*† .. .. .	24° to 28° at 5,000 r.p.m.
	20° to 24° at 3,400 r.p.m.
	12° to 16° at 1,600 r.p.m.
	7° to 11° at 1,300 r.p.m.
	1° to 4° at 900 r.p.m.
No advance below .. .. .	600 r.p.m.

### Vacuum advance

Starts .. .. .	3 in. (7.62 cm.) Hg.
Finishes* .. .. .	18° at 15 in. (38.1 cm.) Hg.

† Vacuum pipe disconnected.

\* Crankshaft degrees and r.p.m.

## SPARK PLUGS

Make/type .. .. .	Champion N9Y.
Gap .. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. type HS4.
Specification .. .. .	AUD 450.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (2.3 mm.).
Needle .. .. .	AAG.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed .. .. .	3.5 to 4.5% CO.
---	-----------------

# ENGINE TUNING DATA

Model: MINI 850 Saloon and variants

(848 c.c.)

Year: 1972-74 ●

## ENGINE

Type	.. .. .	85H.
Capacity	.. .. .	848 c.c. (51.7 cu. in.).
Compression ratio	.. .. .	8.3 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Compression pressure	.. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed	.. .. .	800 r.p.m.
Fast idle speed	.. .. .	1,100 to 1,200 r.p.m.
Valve rocker clearance	.. .. .	.012 in. (.30 mm.) (cold).
Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel.
Ignition timing:		
Static	.. .. .	T.D.C.
*† Stroboscopic at 1,000 r.p.m.	.. .. .	19° B.T.D.C.      ‡ $\begin{cases} 9^\circ \text{ B.T.D.C.} \\ 14^\circ \text{ B.T.D.C.} \end{cases}$

## DISTRIBUTOR

Make/type	.. .. .	Lucas 25D4 or 45D4.
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle: 25D4	.. .. .	60° ± 3°
45D4	.. .. .	51° ± 5°
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.: 25D4	.. .. .	41026.                      ‡ 41569. ‡
45D4	.. .. .	41411.                      ‡ 41570. ‡

## Centrifugal advance

Decelerating check*†	.. .. .	30° to 34° at 3,400 r.p.m. 18° to 22° at 4,000 r.p.m. 24° to 28° at 2,500 r.p.m. 11° to 15° at 2,800 r.p.m. 16° to 20° at 1,300 r.p.m. 4° to 8° at 1,600 r.p.m. 9° to 15° at 900 r.p.m. 0° to 3° at 800 r.p.m. 1° to 7° at 700 r.p.m.
No advance below	.. .. .	500 r.p.m.                      300 r.p.m.

## Vacuum advance

Starts	.. .. .	7 in. (17.8 cm.) Hg.                      5 in. (12.7 cm.) Hg.
Finishes*	.. .. .	10° at 13 in. (33 cm.) Hg. 20° at 13 in. (33 cm.) Hg.

## SPARK PLUGS

Make/type	.. .. .	Champion N9Y.
Gap	.. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type	.. .. .	Lucas LA 12.
Primary resistance at 20°C. (68°F.)	.. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on	.. .. .	3.9 amps.

## CARBURETTER

Make/type	.. .. .	S.U. Type HS2.
Specification	.. .. .	AUD 449.
Piston spring	.. .. .	Red.
Jet size	.. .. .	.090 in. (3 mm.).
Needle	.. .. .	AAV.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed	.. .. .	3.5 to 4.5% CO.
---	---------	-----------------

\* Crankshaft degrees and r.p.m.      † Vacuum pipe disconnected.      ‡ 1974 on: Fitted to a limited number of manual transmission engines.

# ENGINE TUNING DATA

Model: MINI CLUBMAN  
MINI 1000—Saloon and variants

(998 c.c.)

Year: 1972—74

## ENGINE

Type	.. .. .	99H.
Capacity	.. .. .	998 c.c. (60.96 cu. in.).
Compression ratio	.. .. .	8.3 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Compression pressure	.. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed	.. .. .	800 r.p.m.
Fast idle speed	.. .. .	1,100—1,200 r.p.m.
Ignition timing:		
Static	.. .. .	5° B.T.D.C.
†* Stroboscopic at 1,000 r.p.m.	.. .. .	11° B.T.D.C.
		‡ { 10° B.T.D.C. 13° B.T.D.C.
Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold)	.. .. .	.012 in. (.30 mm.)

## DISTRIBUTOR

Make/type	.. .. .	Lucas 25D4 or 45D4.
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle: 25D4	.. .. .	60° ± 3°.
45D4	.. .. .	51° ± 5°.
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.: 25D4	.. .. .	41254.                   41246. ‡
45D4	.. .. .	41212.                   41418. ‡
<b>Centrifugal advance</b>		
Decelerating check*†	.. .. .	22° to 26° at 5,000 r.p.m. 18° to 23° at 5,600 r.p.m. 16° to 20° at 3,400 r.p.m. 14° to 18° at 4,000 r.p.m. 9° to 13° at 1,600 r.p.m. 9° to 13° at 2,400 r.p.m. 6° to 10° at 1,300 r.p.m. 6° to 10° at 1,500 r.p.m. 0° to 4° at 900 r.p.m. 0° to 1° at 900 r.p.m.
No advance below	.. .. .	600 r.p.m.                   800 r.p.m.
<b>Vacuum advance</b>		
Starts	.. .. .	5 in. (12.7 cm.) Hg.           6 in. (15.2 cm.) Hg.
Finishes*	.. .. .	14° at 11 in. (27.9 cm.) Hg. 16° at 14 in. (35.6 cm.) Hg.

## SPARK PLUGS

Make/type	.. .. .	Champion N9Y.
Gap	.. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type	.. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.)	.. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on	.. .. .	3.9 amps.

## CARBURETTER

Make/type	.. .. .	S.U. Type HS2.
Specification	.. .. .	AUD 509.
Piston spring	.. .. .	Red.
Jet size	.. .. .	.090 in. (3 mm.).
Needle	.. .. .	AAV.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed	.. .. .	3.5 to 4.5% CO.
* Crankshaft degrees and r.p.m.	† Vacuum pipe disconnected.	‡ 1974 on: Fitted to a limited number of manual transmission engines.

# ENGINE TUNING DATA

To European emission control requirements (ECE 15)

Model: MINI 1275 GT

Year: 1972-74  
1974 on

## ENGINE

Type	..	..	..	..	..	..	..	..	..	12H.
Capacity	..	..	..	..	..	..	..	..	..	1274.86 c.c. (77.8 cu. in.).
Compression ratio	..	..	..	..	..	..	..	..	..	8.8 : 1.
Firing order	..	..	..	..	..	..	..	..	..	1, 3, 4, 2.
Compression pressure	..	..	..	..	..	..	..	..	..	175 lb./sq. in. (12.3 kg./cm. <sup>2</sup> ).
Idling speed	..	..	..	..	..	..	..	..	..	750 r.p.m.
Fast idle speed	..	..	..	..	..	..	..	..	..	1,100 to 1,200 r.p.m.
Ignition timing:										
Static	..	..	..	..	..	..	..	..	..	8° B.T.D.C.
*† Stroboscopic at 1,000 r.p.m.	..	..	..	..	..	..	..	..	..	13° B.T.D.C.
Timing marks	..	..	..	..	..	..	..	..	..	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold)	..	..	..	..	..	..	..	..	..	.012 in. (.30 mm.)

## DISTRIBUTOR

Make/type	..	..	..	..	..	..	..	..	..	Lucas 25D4 or 45D4.
Rotation of rotor	..	..	..	..	..	..	..	..	..	Anti-clockwise.
Dwell angle: 25D4	..	..	..	..	..	..	..	..	..	60° ± 3°
45D4	..	..	..	..	..	..	..	..	..	51° ± 5°
Contact breaker gap	..	..	..	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	..	..	..	..	..	..	..	..	..	.18 to .24 mF.
Serial No.: 25D4	..	..	..	..	..	..	..	..	..	41257, 41214.
45D4	..	..	..	..	..	..	..	..	..	41419.

## Centrifugal advance

Decelerating check*†	..	..	..	..	..	..	..	..	..	18° to 22° at 4,000 r.p.m. 11° to 15° at 2,800 r.p.m. 6½° to 10° at 2,100 r.p.m. 4° to 8° at 1,600 r.p.m. 0° to 3° at 800 r.p.m.
No advance below	..	..	..	..	..	..	..	..	..	300 r.p.m.

## Vacuum advance

Starts	..	..	..	..	..	..	..	..	..	3 in. (7.6 cm.) Hg.
Finishes*	..	..	..	..	..	..	..	..	..	20° at 10 in. (25.4 cm.) Hg.

## SPARK PLUGS

Make/type	..	..	..	..	..	..	..	..	..	Champion N9Y.
Gap	..	..	..	..	..	..	..	..	..	.025 in. (.65 mm.).

## IGNITION COIL

Make/type	..	..	..	..	..	..	..	..	..	Lucas LA 12.
Primary resistance at 20°C. (68°F.)	..	..	..	..	..	..	..	..	..	3.2 to 3.4 ohms (cold).
Consumption—ignition on	..	..	..	..	..	..	..	..	..	3.9 amps.

## CARBURETTER

Make/type	..	..	..	..	..	..	..	..	..	S.U. Type HS4.
Specification	..	..	..	..	..	..	..	..	..	AUD 567.
Piston spring	..	..	..	..	..	..	..	..	..	Red.
Jet size	..	..	..	..	..	..	..	..	..	.090 in. (3 mm.).
Needle	..	..	..	..	..	..	..	..	..	ABB.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed	..	..	..	..	..	..	..	..	..	3 to 4.5% CO.
---	----	----	----	----	----	----	----	----	----	---------------

\* Crankshaft degrees and r.p.m. † Vacuum pipe disconnected.

# ENGINE TUNING DATA

To European emission control requirements (ECE 15)

Model: MINI 850—Saloon and variants

(848 c.c.)

Year: 1974 on

## ENGINE

Type .. .. .	85H.
Capacity .. .. .	848 c.c. (51.7 cu. in.).
Compression ratio .. .. .	8.3 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	800 r.p.m.
Fast idle speed .. .. .	1,100 to 1,200 r.p.m.
Valve rocker clearance .. .. .	.012 in. (.30 mm.) (cold).
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Ignition timing:	
Static .. .. .	6° B.T.D.C.
*† Stroboscopic at 1,000 r.p.m. .. .. .	11° B.T.D.C.

## DISTRIBUTOR

Make/type .. .. .	Lucas 45D4.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Rotation of rotor .. .. .	Anti-clockwise.
Dwell angle .. .. .	51° ± 5°.
Condenser capacity .. .. .	.18 to .24 mF.
Serial number .. .. .	41570.

### Centrifugal advance

Decelerating check*† .. .. .	18° to 22° at 4,000 r.p.m. 11° to 15° at 2,800 r.p.m. 4° to 8° at 1,600 r.p.m. 0° to 3° at 800 r.p.m.
No advance below .. .. .	300 r.p.m.

### Vacuum advance

Starts .. .. .	5 in. (12.7 cm.) Hg.
Finishes* .. .. .	20° at 13 in. (33 cm.) Hg.

## SPARK PLUGS

Make/type .. .. .	Champion N9Y.
Gap .. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA 12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS4.
Specification .. .. .	AUD 611.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (3 mm.).
Needle .. .. .	ABS.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed .. .. .	3.5 to 4.5% CO.
---	-----------------

\* Crankshaft degrees and r.p.m. † Vacuum pipe disconnected.

# ENGINE TUNING DATA

To European emission control requirements (ECE 15)

Model: MINI CLUBMAN (Manual and Automatic)  
MINI 1000—Saloon and variants (Manual)  
—Saloon (Automatic)

(998 c.c.)

Year: 1974 on

## ENGINE

Type .. .. .	99H.
Capacity .. .. .	998 c.c. (60.96 cu. in.).
Compression ratio .. .. .	8.3 : 1.
Firing order .. .. .	1, 3, 4, 2.
Compression pressure .. .. .	150 lb./sq. in. (10.5 kg./cm. <sup>2</sup> ).
Idling speed .. .. .	750 r.p.m.
Fast idle speed .. .. .	1,100—1,200 r.p.m.
Ignition timing:	
Static .. .. .	4° B.T.D.C.
*† Stroboscopic at 1,000 r.p.m. .. .. .	7° B.T.D.C.
Timing marks .. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold) .. .. .	.012 in. (.30 mm.)

## DISTRIBUTOR

Make/type .. .. .	Lucas 45D4.
Rotation of rotor .. .. .	Anti-clockwise
Dwell angle .. .. .	51° ± 5°.
Contact breaker gap .. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity .. .. .	.18 to .24 mF.
Serial No. .. .. .	41418.

### Centrifugal advance

Decelerating check*† .. .. .	14° to 18° at 4,000 r.p.m. 9° to 13° at 2,400 r.p.m. 6° to 10° at 1,500 r.p.m. 0° to 1° at 900 r.p.m.
No advance below .. .. .	800 r.p.m.

### Vacuum advance

Starts .. .. .	6 in. (15.2 cm.) Hg.
Finishes* .. .. .	16° at 14 in. (35.6 cm.) Hg.

## SPARK PLUGS

Make/type .. .. .	Champion N9Y.
Gap .. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type .. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.) .. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on .. .. .	3.9 amps.

## CARBURETTER

Make/type .. .. .	S.U. Type HS4.
Specification .. .. .	AUD 679.
Piston spring .. .. .	Red.
Jet size .. .. .	.090 in. (3 mm.).
Needle .. .. .	ABX.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed .. .. .	3.5 to 4.5% CO.
---	-----------------

\* Crankshaft degrees and r.p.m. † Vacuum pipe disconnected.



# ENGINE TUNING DATA

To European emission control requirements (ECE 15)

Model: MINI CLUBMAN

(1098 c.c.)

Year: 1974 on

## ENGINE

Type	.. .. .	10H.
Capacity	.. .. .	1098 c.c. (67 cu. in.).
Compression ratio	.. .. .	8.5 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Cranking pressure	.. .. .	165 lb./sq. in. (11.6 kg./cm. <sup>2</sup> ).
Idling speed	.. .. .	750 r.p.m.
Fast idle speed	.. .. .	1,100 to 1,200 r.p.m.
Ignition timing:		
Static	.. .. .	9° B.T.D.C.
*† Stroboscopic at 1,000 r.p.m.	.. .. .	12° B.T.D.C.
Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (cold)	.. .. .	.012 in. (.30 mm.).

## DISTRIBUTOR

Make/type	.. .. .	Lucas 25D4 or 45D4.
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle: 25D4..	.. .. .	60° ± 3°.
45D4..	.. .. .	51° ± 5°.
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.: 25D4..	.. .. .	41246.
45D4..	.. .. .	41418.
<b>Centrifugal advance</b>		
Decelerating check*†	.. .. .	20 to 24° at 6,000 r.p.m. 14 to 18° at 4,000 r.p.m. 9 to 13° at 2,400 r.p.m. 6 to 10° at 1,500 r.p.m. 0 to 1° at 900 r.p.m.
No advance below	.. .. .	800 r.p.m.
<b>Vacuum advance</b>		
Starts	.. .. .	6 in. (15.2 cm.) Hg.
Finishes*	.. .. .	16° at 14 in. (35.6 cm.) Hg.

## SPARK PLUGS

Make/type	.. .. .	Champion N9Y.
Gap	.. .. .	.025 in. (.65 mm.).

## IGNITION COIL

Make/type	.. .. .	Lucas LA12.
Primary resistance at 20°C. (68°F.)	.. .. .	3.2 to 3.4 ohms (cold).
Consumption—ignition on	.. .. .	3.9 amps.

## CARBURETTER

Make/type	.. .. .	S.U. Type HS4.
Specification	.. .. .	AUD 508.
Piston spring	.. .. .	Red.
Jet size	.. .. .	.090 in. (3 mm.).
Needle	.. .. .	ABP.

## EXHAUST EMISSION

Exhaust gas analyser reading at engine idle speed	.. .. .	3 to 4.5% CO.
		* Crankshaft degrees and r.p.m.      † Vacuum pipe disconnected.

# MAINTENANCE

## CONTENTS

	PAGE
Service Operations Summary . . . . .	Maintenance 2-3
Lubrication Diagram and Key . . . . .	Maintenance 4-5
Service Lubricants . . . . .	Maintenance 6
Recommended Fluids, Anti-Freeze, Capacities . . . . .	Maintenance 7
Lubrication – Routine Maintenance	
Engine and Transmission . . . . .	Maintenance 8-9
Carburetter . . . . .	Maintenance 10
Front, Rear Suspension, Hand Brake . . . . .	Maintenance 10
Cooling System:	
Fan belt adjustment . . . . .	Maintenance 11
Topping up . . . . .	Maintenance 11
Clutch:	
Release lever clearance . . . . .	Maintenance 11
Brake and Clutch Reservoirs:	
Fluid levels . . . . .	Maintenance 12
Engine/Transmission:	
Air cleaner . . . . .	Maintenance 12-13
Valve rocker clearances . . . . .	Maintenance 13
Ignition – 25D4 Distributor . . . . .	Maintenance 14
– 45D4 Distributor . . . . .	Maintenance 22
Carburetter Tuning – Single . . . . .	Maintenance 15
– Twin . . . . .	Maintenance 16-17
Brakes:	
Adjustment, Checking linings . . . . .	Maintenance 18
Disc brake pads . . . . .	Maintenance 19
Servo filter . . . . .	Maintenance 19
Preventive Maintenance . . . . .	Maintenance 19
Wheels and Tyres . . . . .	Maintenance 20
Steering . . . . .	Maintenance 20
Electrical – Routine Maintenance:	
Headlamp beam . . . . .	Maintenance 20
Battery . . . . .	Maintenance 20-21
Body and General Inspection . . . . .	Maintenance 23

# MAINTENANCE


## SERVICE OPERATIONS—SUMMARY

After sales service = 1,000 miles (1500 km)

A Every 6,000 miles (10000 km) or 6 months

B Every 12,000 miles (20000 km) or 12 months

Items included in the 3,000 miles (5000 km) or 3 months interval Optional Inspection Check are indicated in column C


After Sales	A	B	C	ACTION ●		<b>Leycare Service</b>
				OPERATION X		
●	●	●	●	Fit seat cover		
	X	X	X	Check condition and security of seats and seat belts		
●	●	●	●	Drive on lift; stop engine		
X	X	X	X	Check operation of lamps		
X	X	X	X	Check operation of horn(s)		
X	X	X	X	Check operation of warning indicators		
X	X	X	X	Check/adjust operation of windscreen washers		
X	X	X	X	Check operation of windscreen wipers		
X	X	X	X	Check operation of hand brake; release fully after checking		
X	X	X	X	Check rear view mirrors for cracks and crazing		
X	X	X	X	Check operation of window controls		
X	X	X	X	Check steering-column clamp bolt		
●	●	●	●	Open bonnet, fit wing covers. Raise lift to convenient working height with wheels free to rotate		
●	●	●	●	Remove hub cap		Starting at the right-hand front complete these operations at each wheel
	●	●	●	Mark stud to wheel relationship		
	●	●	●	Remove road wheel		
	X	X	X	Check tyre complies with manufacturer's specification		
	X	X	X	Check tyre for tread depth		
X	X	X	X	Check tyre visually for external cuts in fabric		
X	X	X	X	Check tyre visually for external exposure of ply or cord		
X	X	X	X	Check tyre visually for external lumps or bulges		
X	X	X	X	Check/adjust tyre pressures		
		X		Front: Remove brake drum, wash out dust, inspect linings for wear and drum for condition, refit drum		
X	X	X	X	Front: Adjust brakes		
X	X	X	X	Front: Inspect brake pads for wear and discs for condition		
		X		Check for oil leaks from steering and fluid leaks from suspension system		
X	X	X	X	Check condition and security of steering unit joints and gaiters		
		X		Rear: Remove brake-drum, wash out dust, inspect linings for wear and drum for condition, refit drum		
X	X	X	X	Rear: Adjust brakes		
X	X	X	X	Lubricate all grease points (excluding hubs)		
	●	●	●	Refit road wheel in original position		
X	X	X	X	Check tightness of road wheel nuts		
●	●	●	●	Refit hub cap		
●	●	●	●	Raise lift to full height		
X	X	X	X	Drain engine/transmission oil		
X	X	X	X	Check visually brake pipes and unions for chafing, leaks and corrosion		
X	X	X	X	Check visually fuel and clutch pipes for chafing, leaks and corrosion		
X	X	X	X	Check exhaust system for leakage and security		
	X	X		Lubricate hand brake mechanical linkage and cables		
X				Check security of accessible engine mountings		
X				Check security of suspension fixings		
	X	X		Renew engine oil filter element (Manual gearbox)		
●	●	●	●	Refit engine drain plug		
●	●	●	●	Lower lift		
●	●	●	●	Fit exhaust extractor pipe		
●	●	●	●	Remove ignition shield (Clubman and 1275 GT)		
	X	X		Renew engine oil filter element (Automatic transmission)		
X				Check/adjust torque of cylinder head nuts		
X				Check/adjust torque of rocker shaft nuts		
X				Check security of manifold nuts		
X		X		Check/adjust valve clearance		

# MAINTENANCE

After Sales	A	B	C	ACTION ● OPERATION X
X	X	X	X	Fill engine with oil
				Check/top up engine oil
		X		Lubricate water pump (early models only)
	X	X		Lubricate dynamo bearing (early models only)
X	X	X		Top up carburetter piston damper(s)
X	X	X		Lubricate accelerator control linkage and pedal pivot
		X		Renew air cleaner element(s)
X				Check security of accessible engine mountings
X	X	X	X	Check driving belt; adjust or renew
	X			Clean/adjust spark plugs
		X		Renew spark plugs
X	X	X	X	Check/top up clutch fluid reservoir
X	X	X	X	Check/top up brake fluid reservoir
X	X	X	X	Check/top up windscreen washer reservoir
X	X	X	X	Check/top up cooling system
		X		Clean brake servo filter
		X		Clean and test crankcase breather valve (when fitted)
		X		Renew engine breather filter/oil filler cap (when fitted)
		X		Clean engine breather filter (when fitted)
	X	X		Check/adjust clutch return stop clearance
X	X	X		Check cooling and heating systems for leaks
X	●	●		Run engine and check sealing of oil filter; stop engine
●	X	X		Recheck/top up engine oil
X	●	●		Connect electronic instruments
X	X	X		Check visually distributor points; renew if necessary
X	X	X		Check volt drop between coil CB and earth
X	X	X		Lubricate distributor
●	●	●		Run engine
X	X	X		Disconnect vacuum pipe, check dwell angle, adjust points as necessary
X	X	X		Check stroboscopic ignition timing
X	X	X		Check distributor automatic advance
X	X	X		Check advance increase as vacuum pipe is re-connected
X	X	X		Check throttle operation, set to fast idle until engine reaches normal running temperature
X	X	X		Lubricate all locks and hinges (not steering lock)
X	X	X	X	Check and if necessary renew windscreen wiper blades
●	X	X		Check/adjust engine idle speed and carburetter mixture settings
●	●	●		Stop engine and disconnect instruments
●	●	●	●	Refit ignition shield (Clubman and 1275 GT)
●	●	●	●	Remove wing covers
●	●	●	●	Fill in details and fix appropriate Unipart underbonnet stickers
●	●	●	●	Close bonnet
●	●	●	●	Remove exhaust extractor pipe
●	●	●	●	Remove spare wheel
	X	X	X	Check spare tyre complies with manufacturer's specification
	X	X	X	Check depth of tread
X	X	X	X	Check visually for external cuts in tyre fabric
X	X	X	X	Check visually for external exposure of ply or cord
X	X	X	X	Check visually for external lumps or bulges
X	X	X	X	Check/adjust tyre pressure
●	●	●	●	Refit spare wheel. Drive car off lift
X	X	X	X	Check/top up battery electrolyte
	X	X		Clean and grease battery connections
X	X	X	X	Check/adjust headlamp alignment
X	X	X		Check/adjust front wheel alignment
X	X	X		Carry out road or roller test and check function of all instrumentation
X	X	X	X	Report any additional work required
X	X	X	X	Ensure cleanliness of controls, door handles, steering-wheel, etc.
●	●	●	●	Remove seat cover

Refer  
to  
Engine  
Tuning  
Data

LUBRICATION DIAGRAM



2NC 504

KEY TO LUBRICATION DIAGRAM

Every 3,000 miles (5000 km.) or 3 months Optional Lubrication

- (1) ENGINE/TRANSMISSION. Inspect the oil level with the dipstick, and top-up if necessary.

Every 6,000 miles (10000 km.) or 6 months

- (2) ENGINE/TRANSMISSION. Drain off the old oil and refill with new oil.
- (3) OIL FILTER. Fit a new cartridge or filter element.
- (4) CARBURETTER. Remove the cap from the top of the suction chamber and top up to the correct level with oil.
- (5) ACCELERATOR. Lubricate accelerator control linkage and pedal fulcrum.
- (6) DISTRIBUTOR. Lubricate the cam, contact breaker pivot, weights and centre spindle.  
**Do not oil the cam wiping pad.**
- (7) DYNAMO. Add a few drops of recommended engine oil through the oil hole in the commutator end bearing.  
An alternator does not require periodic lubrication.
- (8) HAND BRAKE. Lubricate the sector pivots and cable linkages.

- (9) STEERING JOINTS. } Lubricate as detailed in 'MAINTENANCE'.
- (10) REAR SUSPENSION }  
RADIUS ARMS. }

LOCKS AND HINGES. Lubricate the bonnet release, safety catch, and all locks and hinges.  
**Do not oil the steering lock.**

NOTES:

The lubricating nipple shown on indicator 11 is fitted to earlier vehicles and only requires attention at major overhaul periods when grease should be used. Later cars are fitted with the single rod change mechanism and a lubricating nipple is not fitted.

Recommended oils and greases are given overleaf.

# MAINTENANCE

## SERVICE LUBRICANTS

Component	Engine/Transmission Unit Distributor, Carburetter Dashpot, Oil Can			Grease Points	Upper Cylinder Lubrication
	Climatic conditions	Temperatures 10°C to -20°C (50°F to -5°F)	All temperatures below -10°C (15°F)		
Minimum performance level	British Leyland Service Fill Lubricating Oil Specification for Passenger Car and Light Commercial Petrol Engines B.L.S. OL.02			Multipurpose Lithium Grease N.L.G.1 Consistency No. 2	Upper Cylinder Lubricant
<b>MOBIL</b>	Mobiloil Special 20W/50 or Super 10W/50	Mobiloil Super 10W/50	Mobiloil 5W/20	Mobilgrease M.P.	Mobil Upperlube
<b>SHELL</b>	Shell Super 20W/50	Shell Super 10W/50	Shell Super 5W/30	Shell Retinax A	Shell Upper Cylinder Lubricant
<b>BP</b>	BP Super Visco-Static 20/50 or 10W/40	BP Super Visco-Static 10W/30 or 10W/40	BP Super Visco-Static 5W/20	BP Energrease L 2	BP Upper Cylinder Lubricant
<b>CASTROL</b>	Castrol GTX	Castrolite	Castrol GTZ	Castrol LM Grease	Castrollo
<b>DUCKHAMS</b>	Duckhams Q. 20-50	Duckhams Q. 5500	Duckhams Q. 5-30	Duckhams L.B. 10 Grease	Duckhams Adcoild Liquid
<b>ESSO</b>	Esso Uniflo 10W/50	Esso Uniflo 10W/50	Esso Extra Motor Oil 5W/20	Esso Multipurpose Grease H	Esso Upper Cylinder Lubricant
<b>TEXACO</b>	Havoline 20W/50 or 10W/40	Havoline 10W/40	Havoline 5W/30	Marfak All purpose	Special Upper Cylinder Lubricant
<b>PETROFINA</b>	Fina Supergrade 20W/50 or 10W/50 or 10W/40	Fina Supergrade 10W/50 or 10W/40	Fina Supergrade 5W/20	Fina HTL 2	Fina Cyltonic

## LUBRICATION


The lubrication systems of your new car are filled with a high quality oil. You should always use a high quality oil of the correct viscosity range in the engine/transmission during subsequent maintenance operations or when topping up. The use of oils not to the correct specification can lead to high oil and fuel consumption and ultimately to damage to the engine or gear-box components.

Oils to the correct specification contain additives which disperse the corrosive acids formed by combustion and also prevent the formation of sludge which can block oilways. Additional oil additives should not be used. Servicing intervals must be adhered to.

### Engine/transmission unit

Use a well-known brand of oil to B.L.S. OL.02 or MIL-L-2104B or A.P.1, SE quality with a viscosity band spanning the temperature range of your locality.

### S.A.E. VISCOSITY



4NA 051

### Steering rack

Use E.P. 90 (MIL-L-2105) above -15°C (10°F).  
Use E.P. 80 (MIL-L-2105) below -15°C (10°F).

### Grease points

Use Multipurpose Lithium Grease N.L.G.1. consistency No. 2.

**RECOMMENDED FLUIDS, ANTI-FREEZE, CAPACITIES**

**ANTI-FREEZE SOLUTIONS**

Use Bluecol Anti-freeze or an anti-freeze conforming to B.S. 3151 or B.S. 3152. The correct quantities of anti-freeze for different degrees of frost protection are given below:

ANTI-FREEZE	AMOUNT OF ANTI-FREEZE			COMMENCES TO FREEZE		FROZEN SOLID	
	%	PTS.	U.S. PTS.	LITRES	°C.	°F.	°C.
25	1½	1.8	.85	-13	9	-26	-15
33½	2	2.5	1.2	-19	-2	-36	-33
50	3¼	3.75	1.8	-36	-33	-48	-53

**BRAKE AND CLUTCH FLUID**

**Vehicles with all drum system:** Use UNIPART 410 or 550 Brake Fluid; alternatively use a brake fluid conforming to specification S.A.E. J1703c.

**Vehicles with disc/drum system:** Use UNIPART 550 Brake Fluid or alternatively use a fluid to specification S.A.E. J1703c with a minimum boiling-point of 260°C. (500°F.) DO NOT use any other type of brake fluid.

**CAPACITIES**

	PINTS	U.S. PINTS	LITRES
Engine with manual gearbox (including filter) ..	8½	10.2	4.82
Engine with automatic transmission (including filter):			
Total capacity .. .. .	13	16	7.38
Refill capacity .. .. .	9	11	5
Cooling system: Without heater .. .. .	5¼	6.3	3
With heater .. .. .	6¼	7.5	3.55



ROUTINE MAINTENANCE—  
LUBRICATION

ENGINE AND TRANSMISSION (Synchromesh)

Checking oil level

NOTE: Ensure that the vehicle is standing on a level surface.

1. Maintain the level at the 'MAX' mark on the dipstick; the difference in quantity between the 'MIN' and 'MAX' marks is approximately 1 pint (0.6 litre).

Draining and refilling


2. Drain the oil while the engine is warm; clean the magnetic drain plug, and fit a new sealing washer if necessary. Tighten the plug to the torque figure given in 'GENERAL DATA'.
3. Refill with a recommended oil, see 'RECOMMENDED LUBRICANTS', up to the 'MAX' mark on the dipstick. Run the engine for a short while, then allow it to stand for a few minutes before re-checking the level; top up if necessary.

Filter element renewal


4. Unscrew the filter bowl securing bolt and remove the filter assembly.
5. Discard the used element.
6. Remove the circlip from the centre bolt.
7. Withdraw the centre bolt and remove the pressure plate, rubber and steel washers, and the spring.
8. Thoroughly wash the casing and components in a cleaning fluid.
9. Examine the sealing washers, and replace if necessary.
10. Extract the sealing ring from the filter head recess and fit a replacement.
11. Reassemble the filter bowl components and fit a new element.
12. Refit the filter assembly; rotate the bowl while tightening to ensure that it is correctly located on the sealing ring. Tighten the retaining bolt to the torque figure given in 'GENERAL DATA'.
13. Check for oil leakage immediately the engine is started.

Disposable cartridge filter


14. Unscrew the filter cartridge from the filter head and discard the used cartridge and seal.
15. Lubricate the seal on the new cartridge with engine oil and screw the cartridge onto the filter head. **TIGHTEN BY HAND FORCE ONLY; DO NOT OVERTIGHTEN.**



2NC 478



2NC 477




3NC 059A

ENGINE AND TRANSMISSION (Automatic)

Checking oil level

**NOTE:** Ensure that the vehicle is standing on a level surface.

1. Start the engine and run it for 1-2 minutes. Stop the engine and wait for 1 minute, then check the oil level with the dipstick. Maintain the oil level up to the 'MAX' mark on the dipstick; the difference in quantity between the 'MIN' and the 'MAX' marks is approximately 1 pint (0.6 litre).




Draining and refilling

2. Draining the oil is as detailed for the 'Synchromesh' transmission except that the full quantity will not drain out at each oil change.
3. Refill the engine with the correct quantity of oil, see 'GENERAL DATA'. Use one of the oils listed in the 'RECOMMENDED LUBRICANTS' chart.
4. Run the engine for 1-2 minutes, check the oil level, and top up if necessary.


Filter element renewal

5. All models except 'Clubman'. Remove the front grille (16 screws) and place a container beneath the filter bowl. On 'Clubman' models sufficient clearance exists for filter bowl removal.
6. Filter element renewal is as detailed for the 'Synchromesh' transmission except that the filter bowl is removed and refitted through the grille aperture (where applicable).




DYNAMO

1. Add a few drops of oil through the central hole in the rear bearing housing. Avoid over-lubricating.



**CARBURETTOR**


1. Unscrew the damper cap and withdraw the damper.
  2. Check the oil level, and top up if necessary until the level is ½ in. (13 mm.) above the top of the hollow piston rod.
- NOTE:** Under no circumstances should a heavy-bodied lubricant be used.
3. Push the damper assembly back into position and screw the cap firmly by hand into the suction chamber.



**FRONT SUSPENSION**

**Swivel hub ball joints**

1. Use one of the recommended greases shown in the 'RECOMMENDED LUBRICANTS' chart and charge the two nipples on each swivel hub with grease. If the joints are already filled with grease, no further grease can usually be forced in.




**Upper support arm inner pivot**

2. Apply grease to the lubricating nipple on each unit on both sides of the vehicle.

**REAR SUSPENSION**


**Radius arms**

1. Using the same recommended grease as used for 'FRONT SUSPENSION' lubrication, charge the nipple on each unit with grease until excess grease appears from the inner bush on the opposite end of the radius arm.



**HAND BRAKE CABLE**

1. Smear grease around the cable guide channels.
2. Lubricate the swivel sector pivots with oil.
3. Smear grease around the operating lever clevis pin and the cable adjacent to the spring anchor brackets.




ROUTINE MAINTENANCE—  
MECHANICAL

COOLING SYSTEM

The cooling system is under pressure while the engine is hot. Allow the system to cool before removing the filler cap.

**NOTE:** If it is essential to remove the filler cap while the engine is HOT, take great care to protect the hands and arms from scalding by the escaping steam, and turn the cap to the safety stop to release pressure.

1. Remove the radiator filler cap.
2. Top up with sufficient coolant to bring the level up to the 'level indicator' inside the header tank. When the system contains anti-freeze ensure that the specific gravity of the coolant is maintained.




FAN BELT ADJUSTMENT

When correctly tensioned it should be possible, under moderate hand pressure, to deflect the longest run of the belt by ½ in. (13 mm.).

Adjusting

1. Slacken the dynamo or alternator securing bolts.
2. Slacken the adjusting link nut.
3. Move the dynamo or alternator to the required position; apply any leverage necessary to the drive-end bracket and not to any other part of the alternator. The lever used should preferably be of wood or soft metal. **DO NOT OVERTENSION** as this will impose an excess loading on the drive bearings and stretch the belt.
4. Tighten the adjusting link bolt, the dynamo or alternator securing bolts and re-check the tension.



CLUTCH

Release lever clearances

A clearance of 0.020 in. (0.5 mm.) must be maintained between the clutch release lever and its return stop. Use a feeler gauge to check the clearance.

Checking



1. Pull the release lever outwards until all movement is taken up and check the clearance 'A'.

Adjusting

2. Slacken the locknut.
3. Turn the stop until the correct clearance is obtained, and retighten the locknut.

Master cylinder reservoir

Refer to 'BRAKE AND CLUTCH RESERVOIRS'.



**BRAKE AND CLUTCH RESERVOIRS**

**Fluid levels**

**Brake.** One of three types of master cylinder may be fitted, according to the regulations of the country for which the vehicle was produced.

**Checking**

1. The fluid level in the brake 'B' and clutch 'C' master cylinder reservoirs must be maintained at the bottom of the filler necks.
2. **BRAKE RESERVOIR WITH TRANSLUCENT EXTENSION:** The fluid must be maintained up to the 'FLUID LEVEL' mark on the translucent extension.
3. **SPLIT BRAKING SYSTEM RESERVOIR:** The fluid must be maintained up to the 'FLUID LEVEL' mark on the side of the reservoir (arrowed).

**Topping up**




4. Remove the plastic filler cap and top up with UNIPART 410 or 550\* BRAKE FLUID. Alternatively, use a high-boiling-point brake fluid conforming to specification S.A.E. J1703c with a minimum boiling point of 260°C. (500°F). DO NOT use any other type of fluid.

Frequent topping-up is indicative of a leak in the system which must be detected and rectified immediately.

**NOTE:** Brake fluid can have a detrimental effect on paintwork. Ensure that fluid is not allowed to contact paint-finished surfaces.

5. Check that the breather holes in the filler caps are clear and screw on the caps.

\*Use UNIPART 550 BRAKE FLUID for disc brake models.




**AIR CLEANER**

Renew the air cleaner element at the intervals given in the 'MAINTENANCE SUMMARY'. In dusty operating conditions the element may require renewal more frequently than recommended.

**Element replacement**

1. Unscrew the wing nut(s) and disconnect the breather hose (when fitted).
2. **METAL CASE TYPE:** Lift off the top cover.  
**PLASTIC CASE TYPE:** Use a screwdriver in the slots (arrowed) to lever up the top cover, then release it from its locating lug (arrowed) adjacent the air intake pipe.
3. Remove and discard the old element(s) and thoroughly clean the container.




4. Ensure that the rubber seal is correctly positioned; on the plastic-type cleaner it should be in the groove on the underside of the top cover, and on the metal-type around the central boss of the container.

5. Fit new element(s) and refit the cover as detailed below:

**SMALL PLASTIC TYPE:** Engage the locating lug (5) into the top cover (arrowed) and snap-fit the cover onto the container. Refit and tighten the wing nut.

**LARGE PLASTIC TYPE:** Align the 'arrow' marked on the cover with the locating lug (5) and snap-fit the cover onto the container. Refit and tighten the two wing nuts.



2NC502

6. Reconnect the breather hose (when fitted).


**VALVE ROCKER CLEARANCES**

**Checking**

1. Disconnect the breather hose (when fitted).
2. Unscrew the rocker cover securing screws and lift off the cover.
3. Turn the engine; on automatic models rotate the starter ring gear using a screwdriver inserted through the aperture on the converter housing (adjacent to the oil dipstick).
4. Insert a 0.012 in. (0.305 mm.) feeler gauge between the valve rocker arms and the valve stems and check the clearances in the following order:

Check No. 1 valve with No. 8 fully open.


”	”	3	”	”	6	”	”
”	”	5	”	”	4	”	”
”	”	2	”	”	7	”	”
”	”	8	”	”	1	”	”
”	”	6	”	”	3	”	”
”	”	4	”	”	5	”	”
”	”	7	”	”	2	”	”




2NC503

**Adjusting**

5. Slacken the adjusting screw locknut and turn the screw, clockwise to reduce the clearance or anti-clockwise to increase it. Retighten the locknut when the feeler gauge is a sliding fit, holding the adjusting screw against rotation with a screwdriver.
6. Check that its cork gasket is serviceable, refit the rocker cover and connect up the breather hose (when fitted).



1NC348A



2NC 491

## IGNITION

### Distributor

#### Contact breaker—cleaning

1. Remove the ignition shield (Clubman and 1275 GT).
2. Remove the distributor cap and rotor arm.
3. Turn the engine until the contact points are fully open.
4. Inspect the contact points and if burned or blackened, clean them with fine emery-cloth or a fine carborundum file. The points are easier cleaned if the contact set is removed, see operations 13 to 20.
5. After cleaning, wipe the contact points with a fuel-moistened cloth and check the gap setting.

#### Contact breaker—gap setting

6. With the contact points fully open, check the gap setting with a feeler gauge, it should be 0.014 to 0.016 in. (0.35 to 0.40 mm.).

#### Contact breaker—adjusting

7. Slacken the contact plate securing screw.
8. Insert a screwdriver into the notched hole of the plate and turn it clockwise to decrease and anti-clockwise to increase the gap.
9. Tighten the securing screw and re-check the gap setting.

#### Contact breaker—lubrication

10. Lightly smear the pivot post and spindle cam with grease.
11. Lubricate the centrifugal weights with a few drops of oil through the hole in the base plate.
12. Remove the rotor arm and add a few drops of engine oil around the screw in the cam spindle. Do not remove the screw as clearance is provided for oil to pass.

**IMPORTANT.** Avoid over-lubrication, wipe away all surplus lubricant and ensure that the contact points are clean and dry.

#### Contact breaker—renewing

13. Remove the nut and lift off the top insulating bush and both electrical leads from the pivot stud.
14. Remove the contact plate securing screw, spring and plain washer.
15. Remove the contact set.
16. Before fitting a new contact set, wipe the points clean.
17. Lubricate the contact set and spindle cam as detailed in operations 10 to 12.
18. Position the contact set on the distributor base plate and refit the securing screw and washers.
19. Locate the electrical terminals onto the top insulating bush and fit the bush so that the terminals make contact with the moving contact spring. Refit and tighten the pivot nut.
20. Adjust the gap setting as detailed in operations 6 to 9.

**NOTE:** Whenever a new contact set has been fitted, re-check the gap after the first 500 miles (800 km.). During this period the heel of the moving contact will have bedded in on the spindle cam and consequently reduced the gap setting.

### Sparking plugs

#### Servicing

1. Remove the sparking plugs and clean them, preferably with an air-blast service unit.
2. Clean the exterior insulators.
3. Check and re-set the points gap to 0.025 in. (0.65 mm.). Use a plug gauge setting tool and move the side electrode to obtain the correct setting.
4. Replacement. When fitting new plugs ensure that only the recommended type is used, see 'GENERAL DATA'. Check the gap setting before installation. Tighten to a torque figure of 18 lb. ft. (2.5 kg. m.).

**CARBURETTER TUNING (SINGLE)**

The efficient operation of the engine and any exhaust emission control equipment which may be fitted depends not only on correct carburetter adjustment but also on correct ignition timing, rocker clearance, distributor contact breaker and plug gaps. It is essential that these items are checked before adjusting the carburetter.


Carburetter tuning must be confined to setting the idle and fast idle speeds and the mixture at idle speed. A reliable tachometer should be used if possible.

**IMPORTANT.** Where vehicles must conform to exhaust emission control regulations, adjustments should only be carried out if the use of a reliable tachometer and an exhaust gas analyser (CO meter) are available.


1. Top up the carburetter piston damper if necessary.
2. Check that the throttle functions correctly.
3. Ensure that the mixture control (choke) will return fully, that the cable (3) has  $\frac{1}{16}$  in. (2 mm.) free play before it starts to pull on the lever.
4. Check that a small clearance exists between the fast idle screw and the cam.
5. Check that the piston falls freely onto the bridge of the carburetter. Raise the piston lifting pin (5); when released, the piston should fall freely, indicated by a distinct metallic click.
6. On vehicles fitted with Automatic Transmission select 'N' on the gear quadrant and apply the hand brake.
7. Start the engine and run it at a fast idle speed until it attains normal running temperature, and continue for a further five minutes.
8. Increase the engine speed to 2,500 r.p.m. for 30 seconds.

**NOTE:** Tuning can now be commenced. If delay prevents the adjustments being completed within three minutes, increase the engine speed to 2,500 r.p.m. for 30 seconds and then continue tuning. Repeat this clearing procedure at three-minute intervals until tuning is completed.

9. Check the idle speed with a tachometer (see 'TUNING DATA'), and adjust by turning the throttle adjusting screw.  
If a smooth idle at the correct speed is not obtainable, adjust the idle speed mixture setting as follows:
10. Turn the jet adjusting nut up to weaken, or down to enrich, one flat at a time, to obtain the fastest speed. Turn the nut up slowly until the speed just commences to fall, then turn the nut down to the weakest position for maximum speed.
11. Re-check the idle speed and adjust as necessary.
12. Pull the mixture control knob until the linkage is about to move the carburetter jet.
13. Turn the fast idle screw (4) to give the correct fast idling speed (see 'TUNING DATA').



IND184B



2HC503




**CARBURETTER TUNING (TWIN)**

The efficient operation of the engine and any exhaust emission control equipment which may be fitted depends not only on correct carburetter settings but also on correct ignition timing, tappet clearance, distributor contact breaker and plug gaps. It is essential that these items are checked before adjusting the carburetters.

Carburetter tuning must be confined to setting the idle and fast idle speeds and mixture at idle speed. A reliable tachometer and a carburetter intake balancing meter should be used if possible.

**IMPORTANT.** Where a vehicle must conform to exhaust emission control regulations, adjustments should only be carried out if a reliable tachometer, balancing meter and an exhaust gas analyser (CO meter) are available.

1. Top up the carburetter piston dampers if necessary.
2. Check that the throttle functions correctly.
3. Remove the air cleaner assembly.
4. Remove the air intake manifold.
5. Ensure that the mixture control (choke) will return fully, that the cable (5) has  $\frac{1}{8}$  in. (2 mm.) free play before it starts to pull on the lever.
6. Check that a small clearance exists between the fast idle screws and their cams.
7. Raise each carburetter piston lifting pin (7), release the pin and check that the piston falls freely onto the bridge of the carburetter, indicated by a distinct metallic click.
8. Start the engine and run it at a fast idle speed until it attains normal running temperature and continue for a further five minutes.
9. Increase the engine speed to 2,500 r.p.m. for thirty seconds.




IND184B

**NOTE:** Tuning can now be commenced. If delay prevents the adjustment being completed within three minutes, increase the engine speed to 2,500 r.p.m. for 30 seconds and then continue tuning. Repeat this clearing procedure at three-minute intervals until tuning is completed.

**Slow running adjustment and synchronization**

10. Check the idle speed with a tachometer, see 'TUNING DATA', and check the carburetters for balanced air intake using a balance meter.
  11. If the balance is not correct, adjust by turning the throttle adjusting screw on one of the carburetters. Then adjust the idle speed by turning the throttle adjusting screw on each carburetter by the same amount until the correct idle speed is obtained.
  12. Check the throttle shaft pin clearance and adjust if necessary—see items 21 to 23.
- If a smooth idle at the correct speed and balance is not obtainable, stop the engine, and adjust the idle speed mixture setting as follows.




1 NC 211A

**Mixture setting**

13. Slacken the clamp bolt on one of the throttle spindle interconnections.
14. Disconnect the clamp bolt on one of the jet control interconnections.
15. Remove each suction chamber and piston and screw the jets up until they are flush with the bridge of the carburetter or as fully up as possible.
16. Turn down the jet adjusting nut on each carburetter two complete turns.
17. Refit the piston and suction chambers and top up the piston damper oil levels.

**NOTE:** Operations 15 to 17 need not be carried out if it is known that the jets are in the same relative position.

18. Restart the engine and run at idle speed.



I NC 240A


**Adjusting**

19. Turn the jet adjusting nut, 16, on both carburetters in the same direction, one flat at a time, up to weaken or down to enrich, until the fastest speed is recorded on the tachometer. Now turn the nuts up slowly until the speed just commences to fall; finally, turn each nut down equally very slowly by the minimum amount until maximum speed is regained.
20. Re-check the idle speed and carburetter intake balance; adjust as necessary with the throttle adjusting screws, 11.

**EMISSION CONTROLLED CARS:** Use the exhaust gas analyser and check that the percentage CO reading is within the prescribed limits. If the reading falls outside the limits, reset both jet adjusting nuts equally by the minimum amount necessary to bring the reading just within the limits.

**Throttle linkage adjustment**

21. Slacken the throttle shaft lever clamping screws.
22. Place a 0.012 in. (0.31 mm.) feeler gauge between the tail of the throttle shaft operating lever and the choke control interconnecting rod.
23. Move each throttle shaft lever downwards until the lever (or pin) rests on the lower arm of the throttle spindle operating fork. Maintain this position, and with the feeler gauge still in position, tighten both throttle shaft lever clamping screws, 21, and withdraw the feeler gauge. The levers (or pins) should now have a clearance 'A' in the forks.



I NC 241B

**Fast idle adjustment**

24. Pull out the mixture control knob (choke) until the linkage is about to move the carburetter jets. Lock the knob in this position.
25. Turn each fast idle screw, 6, until it just contacts its cam.
26. Re-start the engine and turn each fast idle screw equally to give the correct fast idle speed, see 'TUNING DATA'. Stop the engine.
27. Refit the air intake manifold.
28. Refit the air cleaner assembly.


**BRAKES**

**Adjustment**

1. Jack up the vehicle and place supports under the sub-frames. Deal with one adjuster at a time.

**FRONT**


2. Turn the adjuster in the same direction as the forward rotation of the road wheel until the wheel is locked. Back off the adjuster the minimum amount necessary to allow the wheel to revolve freely.
3. Spin the wheel, apply the foot brake hard to centralize the brake-shoes, and re-check the adjustment.
4. Repeat this procedure with each adjuster and repeat the same operation on the other front wheel.



2NC 482

**REAR**


5. Turn the single squared adjuster in a clockwise direction (when viewed from under the centre of the vehicle) until the wheel is locked. Back off the adjuster the minimum amount necessary to allow the wheel to revolve freely.
6. Repeat the above operation on the other rear wheel.



2NC 483

**Hand brake**

7. Adjust the brake-shoes as detailed in 1 to 6.
8. Apply the hand brake to the third notch on the ratchet.
9. Turn each cable adjusting nut at the lever trunnion until both wheels can only just be turned by heavy hand pressure.
10. Ensure that the wheels rotate freely when the hand brake is released.



2NC 494

**BRAKE LININGS**

**Checking**

1. Jack up the vehicle and place supports under the sub-frames.
2. Back off the brake adjusters and release the hand brake when dealing with the rear brakes.
3. Remove the brake-drum securing screws and pull off the drums.
4. Examine the linings for wear or contamination and clean dust from the linings, backplate and brake-drum.

**IMPORTANT.** Ensure that sufficient lining material remains to allow the vehicle to be used until the next service interval for this check without the lining thickness wearing below the safe limit.

5. Fit replacement brake-shoe assemblies as complete axle sets if replacements are required, and refer to Section M.
6. Refit the brake-drums, adjust the shoes, and refit the road wheels.



**DISC BRAKE PADS**

**Inspecting**

1. Jack up the front of the car, place supports under the sub-frame and remove the road wheels.
2. Check the thickness of the pads, and renew them if the pad linings are approaching the minimum thickness of  $\frac{1}{16}$  in. (1.6 mm.). Always ensure that sufficient pad material remains for the car to be used until the next service interval.

**Replacing**

3. Remove the pad-retaining split pins.
4. Withdraw the pads and anti-squeak shims.
5. Press the pistons into the calliper, using Service tool 18G 672.
6. Refit the new pads, with the anti-squeak shims correctly located, and fit new split pins. **DO NOT** renew the pads on one side of the car only.
7. Apply the brakes hard several times to adjust the pad to disc clearance. No other adjustment is necessary.
8. Check and correct the fluid level in the brake master cylinder reservoir.



**BRAKE SERVO FILTER**

The filter should be cleaned at the intervals recommended in the 'MAINTENANCE SUMMARY'.

**Removing**

1. Lever the dome off the valve cover with a screwdriver (a rrowed).
2. Remove the filter and clean it with compressed air at low pressure. **DO NOT** use cleaning fluid or lubricant of any description on the filter.

**Refitting**

3. Ensure that the air valve spring is securely located onto the valve.
4. Refit the filter and snap-fit the dome onto the valve cover.

**BRAKES (PREVENTIVE MAINTENANCE)**

In addition to the recommended periodical inspection of brake components it is advisable as the car ages and as a precaution against the effects of wear and deterioration to make a more searching inspection and renew parts as necessary.

It is recommended that:

1. Disc brake pads, drum brake linings, hoses, and pipes should be examined at intervals no greater than those laid down in the 'MAINTENANCE SUMMARY'.

2. Brake fluid should be changed completely every 18 months or 18,000 miles (30000 km.) whichever is the sooner.
3. All fluid seals in the hydraulic system and all flexible hoses should be examined and renewed if necessary every three years or 36,000 miles (60000 km.) whichever is the sooner. At the same time the working surfaces of the pistons and of the bores of the master cylinder, wheel cylinders, and other slave cylinders should be examined and new parts fitted where necessary.

Care must be taken always to observe the following points:


- a. At all times use the recommended brake fluid.
- b. Never leave fluid in unsealed containers; it absorbs moisture quickly and can be dangerous if used in your braking system in this condition.
- c. Fluid drained from the system or used for bleeding is best discarded.
- d. The necessity for absolute cleanliness throughout must be over-emphasized.

WHEELS AND TYRES

Checking

1. Check that the tyres on the same axle are of the same size and make and that cross-ply and radials have not been incorrectly mixed, see 'NOTES'.
2. Examine all tyres for cuts in the fabric, exposure of ply or cord, structure, lumps or bulges.
3. Check the depth of the tyre tread; those which are approaching the minimum tread depth of 1 mm. or will have worn to this limit before the next service interval should be replaced.
4. Check and adjust the tyre pressures, including the spare, when the tyres are cold, see 'GENERAL DATA'.
5. Check the wheel nuts for tightness—torque tightening figure is 42 lb. ft. (5.8 kg. m.).

**NOTES:** Radial-ply tyres should only be fitted in sets of four, although in certain circumstances it is permissible to fit a pair on the rear wheels; tyres of different construction **MUST NOT** be used on the same axle. Radial-ply tyres must never be fitted to the front wheels with conventional cross-ply tyres at the rear.



2NC 500

STEERING

Wheel alignments

1. Check the front wheel alignment with the car unladen and with the tyres at their correct pressures, see 'GENERAL DATA'.
2. Carry out the alignment check as detailed in Section J.4.

Checking for wear

3. Check all moving parts for wear and security.
4. Examine the steering rack and drive shaft gaiters for condition and oil leakage.
5. Check tightness of the column to rack pinion clamp bolt; the torque tightness is 8 to 9 lb. ft. (1 to 1.2 kg. m.).

ROUTINE MAINTENANCE—  
ELECTRICAL

General checks


1. Check the functioning of all lamps, horns, direction indicators and windscreen wipers.
2. Examine the windscreen wiper blades, and replace if showing signs of deterioration.

Headlamp beam alignment

The headlamp beams should be set with the normal load on the car. They should be set parallel to each other in the straight-ahead position and  $\frac{1}{2} \pm \frac{1}{4}$  below horizontal or in accordance with local regulations of the country for which the car was produced.

Adjusting

1. Clubman and 1275 GT models: To obtain access to the beam adjusting screws, remove the front grille extensions (four screws each).
2. All other models: Remove the rim retaining screw, pull the rim forwards and upwards to release it from the lamp retaining lugs.
3. Use beam setting equipment to check the alignment; turn the top screw for vertical adjustment.
4. Turn the screw on the side of the lamp unit for horizontal adjustment.
5. Refit the headlamp rims or the grille extensions as applicable to the model.



2NC 485

Battery


GENERAL MAINTENANCE

1. Wipe away all dirt and moisture from the top of the battery. Check that the terminals are secure, and smear with petroleum jelly.

**NOTE:** One of two types of battery may be fitted, therefore refer to the applicable procedure for topping-up.

TOPPING-UP

2. Lucas Pacemaker (type A7, A9, A11/9). The electrolyte levels (1) are visible through the translucent battery case or may be checked by fully raising the vent cover (2) and tilting it to one side. The electrolyte level in each cell must be maintained so that the separator plates (3) are just covered. To avoid flooding, the battery must not be topped up within half an hour of it having been charged from any source other than the generating system fitted to the car.



2 NC 480

To top up the levels, raise the vent cover and pour distilled water into the trough (4) until all the rectangular filling slots (5) are full and the bottom of the trough is just covered. Press the cover firmly into position: the correct quantity of distilled water will automatically be distributed to each cell. In extremely cold conditions, run the engine immediately after topping-up to mix the electrolyte.

**IMPORTANT.** The vent cover must be kept closed at all times, except when topping-up. The electrolyte will flood if the cover is raised while trickle charging the battery. A single-cell heavy discharge tester cannot be used on this type of battery. On no occasion should the vent cover be detached from the battery.

The figures given are corrected to an electrolyte temperature of 16 °C. (60 °F.) and readings obtained must also be corrected to suit the temperature of the electrolyte.

For every 3 °C. (5 °F.) above 16 °C. (60 °F.) add 0.002 S.G. (0.2 °B.).

For every 3 °C. (5 °F.) above 16 °C. (60 °F.) subtract 0.002 S.G. (0.2 °B.).


TOPPING UP

3. Lucas (Type CL7, CL9). Remove the manifold (1) and check the electrolyte level (2) in each cell.

Top up if necessary with distilled water until the separator guard is just covered; do not overflow.

**NOTE:** Do not use tap-water and do not use a naked light when examining the condition of the cells. More frequent topping-up may be necessary in hot climates or if long daily runs are made.

5. All cells should give approximately the same readings. A cell that differs unduly from the rest, in its level or specific gravity, may be damaged.



2 NC 479

CHECKING SPECIFIC GRAVITY

4. Take hydrometer readings from each cell. If the electrolyte level is low, top up with distilled water and recharge the battery for at least 40 minutes.


HYDROMETER READINGS:

Climates below 27 °C. (80 °F.):

	Specific gravity	Degrees Baumé
Cell fully charged .. ..	1.270-1.290	30.5-32.5
Cell about half-charged ..	1.190-1.210	23.0-25.0
Cell completely discharged ..	1.110-1.130	14.5-16.5

Climates frequently above 27 °C. (80 °F.):

	Specific gravity	Degrees Baumé
Cell fully charged .. ..	1.210-1.230	25.0-27.0
Cell about half-charged ..	1.130-1.150	16.5-19.0
Cell completely discharged ..	1.050-1.070	7.0-9.5



●IGNITION

Distributor—type 45D4

Contact breaker—cleaning

1. Remove the ignition shield (Clubman and 1275 GT).
2. Remove the distributor cap and rotor arm.
3. Turn the engine until the contact points are fully open.
4. Inspect the contact points and if burned or blackened, clean them with fine emery-cloth or a fine carborundum file. The points are easier cleaned if the contact set is removed, see operations 13 to 19.
5. After cleaning, wipe the contact points with a fuel moistened cloth and check the gap setting.

Contact breaker—gap setting

6. With the contact points fully open, check the gap setting with a feeler gauge, it should be 0.014 to 0.016 in. (0.35 to 0.040 mm).

Contact breaker—adjusting

7. Slacken the contact plate securing screw.
8. Insert a screwdriver into the notched hole of the plate and lever against the pip provided on the base plate.
  - a. Turn anti-clockwise to decrease the gap.
  - b. Turn clockwise to increase the gap.
9. Tighten the securing screw and re-check the gap setting.
10. Turn the crankshaft until the heel of the contact is on the highest point of an alternative cam lobe.
11. Re-check the contact gap.
12. Repeat 10 and 11 for each remaining cam lobe.

Contact breaker—renewing

13. Remove the contact plate securing screw, spring and plain washer.

14. Press the contact breaker spring from the insulated post and release the terminal plate.
15. Remove the contact set.
16. Wipe the points of the new contact set clean, using a fuel-moistened cloth.
17. Connect the terminal plate to the contact breaker spring.
18. Position the contact set on the base plate and fit the retaining screw and washers.
19. Position the spring on the insulated post between the two locating shoulders.


Lubrication

20. Very lightly smear the cam and pivot post with grease.
21. Add a few drops of oil to the felt pad in the top of the cam spindle and through the gap between the contact plate and the cam spindle to lubricate the centrifugal weights. **Do not oil the cam wiping pad.**
22. Every 24,000 miles (40000 km): Add a drop of oil to the two holes in the base plate to lubricate the centre bearing.
23. Wipe away all surplus lubricant and ensure the contact points are clean and dry.
24. Refit the rotor arm, wipe the inside and outside of the distributor cover clean, refit the distributor cover.

General

After fitting a new contact breaker set the contact breaker should be checked, adjusted, and lubricated according to the instructions given.

Whenever a new contact set has been fitted, re-check the gap after the first 500 miles (800 km). During this period the heel of the contact will have bedded to the spindle cam and reduced the initial contact gap setting.



## BODY AND GENERAL INSPECTION

### Lubrication

1. Inject a small quantity of engine oil through the key slots and around the push-buttons.
2. Lubricate the door hinges with engine oil.
3. Apply grease to the moving surfaces of the bonnet release mechanism and oil to the release lever and safety-catch pivot points.

### General checks

4. Check the condition and security of seats and seat belts; report if attention is required.
5. Check the rear view mirror for looseness, cracks or crazing.
6. Check that the body and door drain holes are clear; use a piece of stiff wire to probe the apertures and remove any obstruction.

## GENERAL INSPECTION

### Visual checks

1. Check the fuel and clutch pipes and unions for chafing, leaks and corrosion.
2. Check the exhaust system for security, leakage, or severe corrosion likely to cause leakage before the next check is called for.





# SECTION A


## THE ENGINE

	SECTION
Air cleaner .. .. .	A.1
†Camshaft .. .. .	A.23
Carburetter .. .. .	A.2
Crankcase closed-circuit breathing .. .. .	A.27
Crankshaft and main bearings .. .. .	A.25
†Cylinder head .. .. .	A.6
†Decarbonizing .. .. .	A.7
Distributor drive shaft .. .. .	A.10
Engine and sub-frame .. .. .	A.12
Engine/transmission (direct and remote control types) .. .. .	A.13
Engine/transmission (rod-change type) .. .. .	A.33
Engine mountings .. .. .	A.14
Exhaust manifold .. .. .	A.4
Exhaust pipe .. .. .	A.3
Flywheel and clutch .. .. .	A.11
Flywheel housing and primary gear .. .. .	A.18
Flywheel retaining screw thread .. .. .	A.31
Flywheel with diaphragm clutch .. .. .	A.28
Oil cooler (Cooper 'S') .. .. .	A.29
Oil pressure .. .. .	A.20
Oil pressure relief valve .. .. .	A.21
Oil pump .. .. .	A.22
Pistons and connecting rods .. .. .	A.24
Primary drive gear train (rod-change transmission) .. .. .	A.32
Primary gear oil seal replacement .. .. .	A.30
†Rocker shaft .. .. .	A.5
†Tappets .. .. .	A.9
Timing cover .. .. .	A.15
Timing gears and chain .. .. .	A.16
Transmission housing .. .. .	A.19
†Valve timing .. .. .	A.17
†Valves .. .. .	A.8

† These operations must be followed by an exhaust emission check



THE POWER UNIT AND SYNCHROMESH TRANSMISSION ASSEMBLY



A2013C

## Section A.1

## AIR CLEANER

## Removing

1. Disconnect the breather hose from the rocker cover, unscrew the wing nut and lift off the cleaner.

## COOPER

## Removing

1. Disconnect the breather pipe from the rocker cover.
2. Remove the four securing screws to remove the gauze-type cleaner, unscrew the two wing nuts to remove the paper-element-type cleaner.

## Section A.2

## CARBURETTER

## Removing

1. Remove the cleaner.
2. Disconnect the mixture and throttle cables.
3. Disconnect the suction advance pipe.
4. Disconnect the fuel delivery hose.
5. Unscrew the two nuts and lift off the carburetter cable abutment plate and two gaskets.

When refitting, make sure the gaskets are in good condition.

## COOPER

## Removing

1. Remove the bonnet and disconnect the battery.
2. Disconnect the choke and throttle cables and the main flexible feed pipe.
3. Disconnect the interconnecting pipe support clip.
4. Unhook the three return springs.
5. Disconnect the vacuum advance pipe.
6. Remove the nuts and withdraw both carburetters together.

## Refitting

Reverse the removing instructions and adjust the linkage as in Section D.6 (35).

## Section A.3

## EXHAUST PIPE

## Removing

Slacken the exhaust pipe to manifold clamp and disconnect the fixing points on the gear change extension and the rear sub-frame.

## Refitting

1. Disconnect the engine tie-rod from the cylinder block.
2. Assemble the exhaust pipe to the engine leaving the fixing bolts and the manifold clamp loose.
3. Push the engine forward to line up the tie-rod bolt holes and wedge it in position with a wooden block. If necessary, slacken the two engine to sub-frame bolts and then retighten them.
4. Reconnect the tie-rod.
5. Insert slip packings, as required, between the transmission case and the pipe bracket, and then tighten the bolt, the sub-frame fixings, and the manifold clamp.
6. Remove the wooden block.

## COOPER

## Removing

1. Remove the screw securing the exhaust pipe to manifold clamp from the front end of the gear change extension.
2. Unscrew the nuts and bolts at the intermediate and rear mountings and withdraw the pipe.

## Refitting

Reverse the removing instructions.




Fig. A.1

The front sub-frame and transmission casing viewed from beneath the car, showing (1) the gear change lever retaining screws, (2) the exhaust system fixing point, (3) the front sub-frame rear mounting point (four set screws)

## Section A.4

## EXHAUST MANIFOLD

## Removing

1. Carry out instructions in Sections A.1 and A.2.
2. Slacken the pipe clamp, unscrew the six nuts and withdraw the manifold.

## COOPER

3. Jack up the vehicle and remove the bonnet.
4. Remove the exhaust pipe assembly, Section A.3, and carburetters, Section A.2.
5. Remove the inlet manifold.
6. Unscrew the 'U' bolts and withdraw them from the right-hand universal joint.
7. Remove the right-hand wheel and disconnect the steering tie-rod.
8. Disconnect the top and bottom swivels, partly withdraw the hub and drive shaft.
9. Support the hub to avoid damage to the brake hose.
10. Turn the differential flange until it is upright, withdraw the exhaust manifold from the studs, manoeuvre it to the right to clear the sub-frame and transmission casing and lift upwards.

## Refitting

Reverse the removing instructions.

## Section A.5

## ROCKER SHAFT



## Removing and dismantling

1. Remove the air cleaners (Section A.1).
2. Drain the cooling system (Section C.1).
3. Remove the rocker cover.
4. Slacken the rocker shaft bracket and cylinder head nuts gradually in the order shown in Fig. A.4. When the load is released remove the rocker shaft bracket nuts and the shaft and brackets.




Fig. A.2  
The pressed-steel type of valve rocker




Fig. A.3  
The forged-type valve rocker

5. Remove the shaft locating screw from the front bracket.
6. Withdraw the split pin and washers from the front end of the shaft.
7. Slide the rockers, brackets and springs from the shaft, noting their relative positions for correct refitting.
8. Unscrew the plug from the front end of the shaft and clean out the oilways.

## Rockers and bushes

Check the rockers for wear. Two types of rocker are in use—pressed steel or forged; if the forged type is fitted the rockers can be rebushed, but worn pressed-steel rockers must be renewed.

## To fit new bushes

9. Remove the old and press in new bushes with Service tool 18G 226 and 18G 226 A.
10. Locate the joint of the bush at the top as shown in Fig. A.3.
11. Remove the adjuster screw.
12. Drill out the plug in the end of the rocker with a No. 43 drill (2.26 mm.) and continue the oilway through the bush.
13. Replug the end hole with a rivet welded in position.
14. Continue the hole in the top of the rocker barrel with a No. 47 drill (1.98 mm.).
15. Burnish-ream the bush to the dimension given in 'GENERAL DATA'.

## Reassembling

16. Reverse the dismantling procedure.
17. Fit the plugged end of the shaft and the tapped bracket at the front of the engine.
18. Tighten the cylinder head and rocker shaft nuts to the recommended torque and in the order shown in Fig. A.4.

**Adjustment**

19. Remove the sparking plugs, engage top gear and push the car forward to rotate the crankshaft. This operation can be also effected by jacking up one side of the front suspension until the road wheel can be rotated, and thus turn the crankshaft to the required position.
20. Rotate the crankshaft until the valve being checked has its tappet resting opposite the peak on the camshaft, i.e. valve completely closed. This cannot be observed accurately, therefore if checking is carried out according to the adjustment chart, this will avoid turning the crankshaft more than is necessary. The valve rocker clearance is given in 'GENERAL DATA'.
21. Hold the adjusting screw against rotation while slackening the locknut, insert the feeler gauge and turn the adjustment screw until the gauge is a sliding fit, tighten the locknut and recheck the clearance.
22. Refit the rocker cover with a new joint washer if necessary, and lower the car (if jacked up).

Adjust No. 1 rocker with No. 8 valve fully open

”	”	3	”	”	”	6	”	”	”
”	”	5	”	”	”	4	”	”	”
”	”	2	”	”	”	7	”	”	”
”	”	8	”	”	”	1	”	”	”
”	”	6	”	”	”	3	”	”	”
”	”	4	”	”	”	5	”	”	”
”	”	7	”	”	”	2	”	”	”

7. Release the automatic advance suction pipe and remove the rocker cover.
8. **Cooper 'S'**. Remove the bolt (A) and nut (B) before releasing the remaining cylinder head nuts.
9. Progressively slacken and remove the cylinder head nuts in the reverse sequence shown in Fig. A.4.
10. Remove the rocker shaft, push-rods, and the radiator tie-plate from the thermostat housing.
11. Disconnect the top water hose and slacken the clip securing the water pump to cylinder head by-pass hose.
12. Disconnect the heater hose and cable from the water valve on the rear of the cylinder head.
13. Lift the cylinder head squarely off the studs; if the head does not release easily from the block, tap each side of the head with a soft-faced mallet. Lift the gasket from the studs.

**Refitting**

14. Reverse the removing procedure, noting the following points:
  - a. Thoroughly clean the faces of the cylinder head and the top of the block; fit a new gasket without jointing compound or grease, it is marked 'TOP' and 'FRONT'.
  - b. Progressively tighten the cylinder head and rocker shaft nuts, and finally tighten to the torque figures given in 'GENERAL DATA' and in the sequence shown on Fig. A.4.  
**Cooper 'S'**. The additional bolt and nut (Fig. A.4) must be tightened last.
15. Adjust the valve rocker clearances as detailed in 'Adjustment' (Section A.5). Start the engine, and when at normal running temperature re-check the clearances.

**Section A.6**

**CYLINDER HEAD**



**Removing**

1. Remove the bonnet.
2. Drain the cooling system (Section C.1).
3. Disconnect the battery and electrical connections from the cylinder head.
4. Remove the carburetter air cleaner (Section A.1).
5. Remove the carburetter (with cables attached) from the manifold and position it clear of the cylinder head.
6. Disconnect the exhaust pipe from the manifold flange.  
**Cooper 'S'**. Remove the exhaust manifold as detailed in Section A.4.

**Section A.7**

**DECARBONIZING**



1. Remove the cylinder head and gasket (Section A.6) and the valves (Section A.8).
2. Scrape the carbon from the piston crowns, cylinder head, valves, and cylinder block, leaving a ring of carbon around the periphery of each piston and the top of each bore. Blow all deposits of carbon from the head and block.
3. Refit the cylinder head (Section A.6).




Fig. A.4

The releasing and tightening sequence of the cylinder head retaining nuts. Arrows 'A' and 'B' indicate the additional bolt and nut on the Cooper 'S' head




Fig. A.5

The component parts of the valve assembly

1. Early 'Mini' type.
2. Later 'Mini' type.
3. Cooper and Cooper 'S' type.

## Section A.8

## VALVES



## Removing

1. Remove the cylinder head and gasket (Section A.6).
2. Withdraw the cotter clip (when fitted).
3. Compress the spring and extract the two halves of the cotter.
4. Slowly release the spring, remove the spring compressor and withdraw the retaining cap, shroud valve spring, and rubber seal.
5. Remove the valve. If the heads of the valves are not numbered, store them in such a way that they can be replaced in their original positions.

The Cooper 'S' has no cotter clips or shroud, and the rubber seal is fitted over the valve guide. Double valve springs are fitted.

## Grinding

Clean the valves and seatings and examine them for pitting and unevenness. If the valves are in a very poor condition, fit new, otherwise reface them on a valve grinder. Reface the valve seats if necessary, using special cutters, see Service tools Section 'S'. Confine valve seat and valve refacing to the minimum and finally grind the valves onto their respective seats with fine grinding paste. Thoroughly clean the valves and seats with petrol (fuel) or paraffin (kerosene) before reassembling.

## Valve seat inserts

When it becomes necessary to fit inserts, machine the cylinder head to the dimensions given in Fig. A.7. The inserts should have an interference fit of .0025 to .0045 in. (.063 to .11 mm.) and must be pressed, not driven, into the cylinder head.

## Valve guides

Remove by drifting the guide(s) downwards into the combustion chambers. Drift in the new guide(s) to the

depth illustrated, see Fig. A.6.

Fit the inlet guides with the largest chamfer at the top, and the exhaust with the counterbore at the bottom.

## Refitting

Reverse instructions 1 to 5 above.

## Section A.9

## TAPPETS



(Engines with tappet side-covers)

## Removing

1. Remove the air cleaner(s) and carburetter(s) (Sections A.1 and A.2).
2. Remove the rocker cover and shaft assembly (Section A.5).
3. Remove the manifold (Section A.4) and the push-rods.
4. Remove the tappet covers and tappets.
5. Fit new tappets by selective assembly so that they just fall into their guides under their own weight, when lubricated.

## Refitting

Reverse the removing operations, taking care to refit the tappets in their original positions.

## Section A.10

## DISTRIBUTOR DRIVE SHAFT



## Removing

1. Remove the distributor (Section B.1).
2. Take out the screw securing the distributor housing to the cylinder block and carefully withdraw the housing to avoid damage to the 'O' ring seal (later models only). The upper end of the shaft is drilled and tapped with a  $\frac{5}{16}$ -in. UNF. thread; screw in a suitable bolt and withdraw the shaft.





Fig. A.6

Using a drift (1) to fit the valve guide (2) to the correct depth. 'A' =  $\frac{13}{16}$  in (15.08 mm)




Fig. A.7  
Valve seat insert machining dimensions. Machine the throats of the inserts to blend with those of the cylinder head

EXHAUST 'A'					
	C	D	E	F	H
MINI	1.124 to 1.125 in. (28.55 to 28.58 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	Maximum radius 0.015 in. (0.38 mm.)	1.0235 to 1.0435 in. (25.99 to 26.50 mm.)	45°
997-c.c. COOPER	1.124 to 1.125 in. (28.55 to 28.58 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.0235 to 1.0435 in. (25.99 to 26.50 mm.)	45°
998-c.c. COOPER	1.124 to 1.125 in. (28.55 to 28.58 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.0235 to 1.0435 in. (25.99 to 26.50 mm.)	45°
970-c.c. COOPER 'S'	1.2465 to 1.2475 in. (31.6 to 31.7 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.2065 to 1.2265 in. (30.65 to 31.16 mm.)	45°
1071-c.c. COOPER 'S'	1.2465 to 1.2475 in. (31.66 to 31.7 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.2065 to 1.2265 in. (30.65 to 31.16 mm.)	45°
1275-c.c. COOPER 'S'	1.2465 to 1.2475 in. (31.66 to 31.7 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.2065 to 1.2265 in. (30.65 to 31.16 mm.)	45°

INLET 'B'					
	J	K	L	M	P
MINI	1.187 to 1.188 in. (30.16 to 30.17 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	Maximum radius 0.015 in. (0.38 mm.)	1.0855 to 1.1055 in. (27.58 to 28.07 mm.)	45°
997-c.c. COOPER	1.3075 to 1.3085 in. (33.21 to 33.23 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.116 to 1.136 in. (28.34 to 29.2 mm.)	45°
998-c.c. COOPER	1.3745 to 1.3755 in. (34.90 to 34.95 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.206 to 1.226 in. (30.60 to 31.15 mm.)	45°
970-c.c. COOPER 'S'					
1071-c.c. COOPER 'S'					
1275-c.c. COOPER 'S'	1.4365 to 1.4375 in. (36.5 to 36.52 mm.)	0.186 to 0.188 in. (4.72 to 4.77 mm.)	0.015 in. (0.38 mm.)	1.3935 to 1.4135 in. (35.41 to 35.91 mm.)	45°






Fig. A.8

The distributor drive shaft. Inset 'A', shows the position of the slot to engage the shaft. Inset 'B', shows the correct fitted position

1. Drive shaft.
2. Housing.
3. Screw-housing.
4. Bolt— $\frac{1}{8}$  in UNF (used to remove and refit shaft).

### Refitting

3. Turn the crankshaft until No. 1 piston is at T.D.C. on the compression stroke (No. 4 cylinder exhaust and inlet valves rocking and the 1/4 mark on the flywheel against the pointer).
4. Hold the spindle so that the drive slot is in the position shown (Fig. A.8) with the large offset uppermost, and enter the gear. As the gear engages the camshaft the spindle will turn anti-clockwise.
5. Refit the distributor (Sections B.1 and B.2).

## Section A.11

### FLYWHEEL AND CLUTCH

#### Removing

1. Disconnect the coil (or solenoid) leads and remove the coil (or solenoid).
2. Remove the starter (Section N.3).
3. Unhook the clutch lever spring, withdraw the lever pivot pin, pull the push-rod from the slave cylinder and remove the lever from the clutch housing.
4. Take off the slave cylinder.
5. Disconnect the exhaust pipe/manifold clamp.
6. Detach the radiator support bracket from the thermostat housing.
7. Unscrew the two nuts and set screws securing the right-hand engine mounting to the sub-frame side-member.
8. Take out the clutch cover screws.
9. Raise the engine just enough to allow the removal of the clutch cover. Do not let the fan blades damage the radiator.
10. Remove the three nuts and the clutch thrust plate


A.8

from the pressure spring housing. When a diaphragm clutch is fitted, release the spring retainer to detach the thrust plate.

11. Bring Nos. 1 and 4 pistons to T.D.C. to prevent the primary gear 'C' washer from falling and being wedged behind the flywheel. With the crankshaft in any other position this could happen and result in damage as the flywheel is withdrawn.
12. Tap up the locking washer and slacken the flywheel retaining screw three or four threads. Use Service tools 18G 304 and 18G 304 M to free the flywheel from the taper on the crankshaft. Remove the tool as soon as the flywheel is free.
13. Unscrew the flywheel retaining screw and take off the key plate.
14. Withdraw the flywheel and clutch together.
15. Dismantle the clutch as described in Section E.1.

#### NOTES:

- A. As the flywheel is pulled from the shaft, oil from the annulus behind the flywheel oil seal may spill down the face of the flywheel onto the clutch driven plate. Look out for this when dismantling to avoid assuming that the oil has passed the seal during normal running.
- B. In early engines a rubber plug was fitted into the rear end of the crankshaft as an added precaution against oil leaking past the normal brass taper plug. An improved brass plug is now fitted and the rubber is discontinued.
- C. Later engines have non-lubricated bushes in the crankshaft primary gear and the flywheel oil seal is not fitted.



A21891A

Fig. A.9  
The flywheel and clutch assembly  
(Coil spring type clutch)




Fig.A.10  
The engine and front suspension assembly

### Starter ring

If a new starter ring is needed, split the old one with a cold chisel. Clean the bore of the new ring and the mating surface of the flywheel, heat the ring to a temperature of 300 to 400°C. (575 to 752°F.), indicated by a light blue colour, and fit it to the flywheel with the lead of the teeth towards the flywheel register. Allow it to cool naturally.

### Refitting

16. Assemble the clutch.
17. Lubricate the flywheel oil seal (if fitted).
18. Ensure that the 'C' washer is correctly positioned and then turn the crankshaft to bring Nos. 1 and 4 pistons to T.D.C.
19. The crankshaft primary gear splines should be lightly wiped with Duckham's M-B grease.
20. Clean and dry the crankshaft and flywheel tapers; they must be assembled dry.
21. Fit the flywheel and clutch assembly to the shaft, replace the washer and retaining screws.
22. Tighten the screw to the recommended torque (see 'GENERAL DATA') and tap over the locking washer.
23. Refit the clutch thrust plate.
24. Lower the engine and carry out the removal operations 1 to 8 in reverse order.

### Section A.12

#### ENGINE AND SUB-FRAME ASSEMBLY

#### Removing

1. Remove the bonnet, drain the cooling system and remove the front grille.
2. Disconnect the battery.
3. Disconnect the electrical connections from the engine.
4. Disconnect the speedometer cable from the instrument.
5. Disconnect the heater hoses.
6. Disconnect the brake pipes at the three-way union.
7. Use Service tool 18G 1063 and disconnect the steering-rack ball joints.
8. Disconnect the tie-rod from the cylinder block and swing the rod away from the engine.
9. COOPER 'S'. Detach the servo vacuum pipe from the inlet manifold.
10. Remove the front hydraulic dampers (fitted to non-Hydrolastic suspension vehicles only).
11. Remove the exhaust pipe (Section A.3).
12. Remove the air cleaner and carburetter (Sections A.1 and A.2).
13. COOPER AND MK. II MODELS. Remove the remote control gear-change extension (Section A.32).
14. Remove the hexagon plug with the anti-rattle spring and plunger from the gear change extension.




Fig. A.11

Use the individual front lifting eye of the attachment to give an angled lift when removing and refitting the power unit

15. Remove the gear lever retaining plate; pull the lever out of the casing into the car.
16. Remove the slave cylinder securing bolts and attach the unit to the bulkhead (do not disconnect the hose).
17. Depressurize and evacuate the models fitted with Hydrolastic suspension (Section H.7) and disconnect both hoses.
18. Support the body with slings under the front wings, and the engine below the transmission casing.
19. Knock back the locking tabs and withdraw the four body to sub-frame bolts (nuts if studs are fitted), two on each side of the bulkhead cross-member. Take out the four set screws securing the rear of the sub-frame to the front floor and the two screws securing the front of the frame to the bottom of the grille panel.
20. Lift the body clear of the engine and withdraw the sub-frame and engine assembly.

#### Removing engine from sub-frame

21. Remove the rocker cover nuts and fit the engine lifting bracket (Fig. A.11).
22. Drain the oil. Disconnect the drive shafts at the differential (Section G).
23. Support the sub-frame under both side-members and take the weight of the engine on the lifting equipment. Take out the two screws securing each engine mounting to the sub-frame.
24. Lift the engine out of the frame.

A.10

#### Refitting

25. Reverse the removal instructions.

**NOTE.**—On vehicles NOT fitted with the remote control gear-change pull the gear lever up into the interior of the car before the body is lowered onto the frame. Bleed the brakes and clutch.

#### Section A.13

### ENGINE AND TRANSMISSION

#### Removing

1. The engine and transmission assembly can be taken out through the bonnet aperture as follows:
2. Refer to Section A.12 and carry out instruction Nos. 1 to 5, 8 and 12 to 16.
3. Remove the windscreen washer bottle and bracket (if necessary).
4. Disconnect the drive shafts at the differential.
5. Disconnect the exhaust pipe from the manifold and secure the pipe against the bulkhead.
6. Remove the rocker cover nuts and fit the engine lifting bracket (Fig. A.11).
7. Take the weight of the engine on the lifting equipment and unscrew the two set screws securing each engine mounting to the sub-frame and lift out the engine.

#### Refitting

8. Reverse the removal instructions.

**NOTES.**—On vehicles NOT fitted with the remote control gear-change pull the gear lever up into the interior of the car before the engine is lowered into position. Keep the sliding joints pushed well onto the drive shaft splines while the flexible couplings are moved into position.

#### COOPER

#### Removing

1. Carry out the instructions 1 to 9 and 16 in Section A.12.
2. Remove the fresh-air motor (when fitted).
3. Disconnect the oil gauge pipe.
4. Take off the distributor cap.
5. Remove the carburetters and air cleaners (Sections A.1 and A.2).
6. Remove the exhaust pipe assembly (Section A.3).
7. Remove the three bolts securing the rear extension mounting to the floor (Fig. A.12).

8. Unscrew the gear lever knob and take out the screws with the rubber cover and plate.
9. Remove the gear-change extension. Disconnect the hydraulic and vacuum pipe and remove the brake servo (Cooper 'S').

**Refitting**

Reverse the removing instructions.

**Section A.14****ENGINE MOUNTINGS****Removing****LEFT-HAND**

1. Remove the radiator (Section C.3).
2. Support the engine with the attachment shown in Fig. A.11; use the central 'straight lift' position and take the weight off the mounting.
3. Remove the nuts securing the mounting bracket to the transmission casing and the two set screws securing the mounting to the sub-frame side-members; withdraw the bracket and mounting assembly.

**RIGHT-HAND**

4. Remove the clutch cover and engine mounting together as detailed in Section A.11.

**Refitting**

Reverse the removing instructions.




Fig. A.12

The securing points for the remote control gear-change extension

**Section A.15****TIMING COVER****Removing**

If the fan cowling is not the later split-type the engine will have to be removed as in Section A.13; otherwise proceed as follows

1. Remove the radiator (Section C.3).
2. Slacken the dynamo or alternator bolts and remove the fan belt.
3. Withdraw the crankshaft pulley.
4. Remove the cover securing screws and lift off the cover.

**Refitting**

5. Reverse the removing instructions when refitting the cover. The oil seal in the cover must be renewed if it shows signs of deterioration, using Service tool 18G 134 together with adaptor 18G 134 BD.
6. The oil thrower behind the crankshaft pulley must be fitted with the face marked 'F' away from the engine. Fill the annular groove of the seal with grease and use Service tool 18G 1044 to centralize the cover to the crankshaft.  
**NOTE.—The early type front cover and oil thrower must only be used together. The oil thrower must be fitted with its concave side facing away from the engine.**
7. Use Service tool 18G 138 to centralize the seal to the crankshaft or use the crankshaft pulley.
8. Fill the groove of the seal with grease, lubricate the pulley hub and rotate the hub through the cover oil seal.
9. To ensure correct centralization the cover and hub should now be fitted together, aligning the keyway in the pulley with the key in the crankshaft.
10. Insert the cover retaining screws and tighten them evenly.
11. Refit and tighten the crankshaft pulley bolt to the torque figure given in 'GENERAL DATA' and tap over the locking washer.

**Section A.16****TIMING GEARS AND CHAIN****Removing**

1. Remove the timing cover (Section A.15).
2. Withdraw the oil thrower.
3. Unlock the camshaft chain wheel nut, unscrew and remove the nut and lock washer.




Fig. A.13

The timing gears assembled into the timing chain with the two marks on the gears opposite each other

4. Pull both chain wheels, with the chain at the same time. Note the thickness of the packing shims behind the crankshaft wheel.
5. Extract the wheels from the chain.

#### Refitting

6. Place the crankshaft gear packing shims in position and turn the shaft to bring the key to the top.
7. Bring the camshaft keyway to the position shown in Fig. A.13 (approx. 1 o'clock).
8. Assemble the two wheels in the chain with the marks opposite each other as in Fig. A.13. Push the wheels onto the shafts, turning the camshaft slightly as required to line up the key. Push the wheels as far as they will go and secure the camshaft gear with the lock washer and nut.
9. Check the alignment of the wheels by placing a straight-edge across the teeth of the camshaft and crankshaft gears and measuring the gap between the straight-edge and the crankshaft gear. Adjust with shims behind the crankshaft gear as required.
10. Refer to Section A.15 'Refitting' items 5 to 11.

#### Section A.17

### VALVE TIMING

#### Checking

1. Adjust the rocker clearance of No. 1 inlet valve to .019 in. (.48 mm.), .021 in. (.53 mm.) Cooper 'S', and turn the crankshaft until the valve is about to open.

A.12

2. Take off the flywheel inspection hole cover. The pointer should now be opposite the 5° mark on the flywheel.
3. After checking, reset the rocker clearance of No. 1 inlet valve to .011 in. (.28 mm.)—engine hot.

#### Section A.18

### FLYWHEEL HOUSING AND PRIMARY GEAR

#### Removing

1. Remove the engine (Section A.13).
2. Remove the flywheel and clutch assembly (Section A.11).
3. Remove the screws and nuts securing the housing; note their positions for correct replacement.
4. When withdrawing the housing and to avoid damage to the oil seal use Service tool 18G 570, or 18G 1043 if a red silicon rubber oil seal is fitted (Fig. A.15).
5. Extract the circlip and remove the primary gear.




Fig. A.14

The engine and transmission assembly with the flywheel housing removed, showing the gear train to the first motion shaft

- |                              |                                     |
|------------------------------|-------------------------------------|
| 1. Oil pump.                 | 5. First motion shaft bearing.      |
| 2. Crankshaft primary gear.  | 6. First motion shaft driving gear. |
| 3. Idler gear.               | 7. Roller bearing.                  |
| 4. Idler gear thrust washer. |                                     |




Fig. A.15

The Service tool 18G 1043 positioned over the clutch splines of the crankshaft primary gear to prevent damage to the lip of the oil seal




Fig. A.16

The crankshaft primary gear with lubricated bushes must be assembled with the correct running clearance of between .003 and .006 in. (.076 and .152 mm.). Measure the gap indicated and use the following table to determine the correct thickness of the thrust washer required to obtain this clearance

WHEN GAP IS	USE WASHER THICKNESS
.1295 to .1315 in. (3.27 to 3.34 mm.)	.125 to .127 in. (3.17 to 3.22 mm.)
.1315 to .1335 in. (3.34 to 3.39 mm.)	.127 to .129 in. (3.22 to 3.27 mm.)
.1335 to .1345 in. (3.39 to 3.42 mm.)	.129 to .131 in. (3.27 to 3.32 mm.)

**Refitting**

6. Check the primary gear running clearance (Fig. A.16). Fit the inner thrust washer with its chamfered bore against the crankshaft flange.
7. Renew the crankshaft primary gear oil seal if it shows signs of damage or oil leakage, using Service tool 18G 134 and adaptor 18G 134 BC.  
This seal can also be renewed without removing the housing or draining the engine/transmission unit (see Section A.30).
8. Refit the housing, using 18G 1043 to protect the red silicon rubber oil seal. Service tool 18G 570 must only be used for assembly with the old-type oil seal. Lubricate the oil seal before assembly. Fit a new joint washer.
9. Tighten the nuts and set screws to the recommended torque see 'GENERAL DATA'. It is important to return the set screws to the positions from which they were removed.

Later engines were fitted with non-lubricated bushes in the primary gear. No oil feed is provided from the crankshaft and no oil seal is fitted in the flywheel.

10. Remove the primary gear as described in Section A.18.
11. When refitting, check the running clearance (Fig. A.17).
12. Adjust by fitting the appropriate thrust washer with the chamfered inner edge of the washer to face the crankshaft (see Fig. A.17).

**Primary gear bushes**

If new bushes are fitted, line-ream them to the dimensions given in Fig. A.18.

**First motion shaft outer race**

**Removing**

1. Extract the spring ring from above the outer race.
2. Expand the housing by immersion in very hot water. **Do not use other methods of heating the housing.**




Fig. A.17

The correct running clearance is .0035 to .0065 in. (.0885 to .1645 mm.). Measure the gap indicated and fit the appropriate thrust washer as given below to obtain this clearance

WHEN GAP IS	USE WASHER THICKNESS
.1175 to .119 in. (2.875 to 3.025 mm.)	.112 to .114 in. (2.848 to 2.898 mm.)
.119 to .121 in. (3.025 to 3.076 mm.)	.114 to .116 in. (2.898 to 2.949 mm.)
.121 to .123 in. (3.076 to 3.127 mm.)	.116 to .118 in. (2.949 to 3.000 mm.)
.123 to .125 in. (3.127 to 3.18 mm.)	.118 to .120 in. (3.000 to 3.051 mm.)




Fig. A.18

A section through the crankshaft primary gear. The bushes (A) must be line-reamed to 1.3775 to 1.3780 in. (34.98 to 35.00 mm.) after fitting (lubricated bushes only)

3. Withdraw the race with Service tool 18G 617 A. This operation may also be carried out using Service tool 18G 617 B with the sleeve from the original Service tool 18G 617.

#### Refitting

4. Reverse the removal instructions, driving the race into position with Service tool 18G 617 A.

#### Section A.19

### TRANSMISSION HOUSING

#### Removing

1. Remove the engine from the car (Section A.13).
2. Remove the flywheel and clutch (Section A.11), and the flywheel housing (Section A.18).
3. Remove the starter motor.
4. Lift the engine to separate it from the transmission.

#### Dismantling

See Section F.1.

#### Refitting

Reverse the removing instructions.

**NOTE.**—It is important to insert the short transmission housing to crankcase screw before the crankcase is lowered onto the transmission housing and to screw it in as far as possible before the two housings are finally brought together.

#### Section A.20

### OIL PRESSURE

The differential pressure switch fitted to the oil filter head on later models gives an indication when an oil change is required. If the warning light in the instrument panel A.14

appears and continues to glow when the engine is running at or above idling speed, both the engine oil and the filter element must be changed as soon as possible within a maximum of the next 300 miles (500 km.).

If the oil pressure falls appreciably, check:

1. The quantity of oil in the sump.
2. The condition of the pump.
3. The union on the suction side of the pump.
4. The pick-up filter for sludge.
5. The condition of the bearings.

#### Section A.21

### OIL PRESSURE RELIEF VALVE

To examine, unscrew the hexagonal domed nut and remove the folded copper washer, the valve and the spring. Check the length of the spring against the dimensions given in 'GENERAL DATA'.

If the valve cup is worn reseal it using metal polish with Service tool 18G 69.

#### Section A.22

### OIL PUMP

#### Removing

1. Remove the engine as detailed in Section A.13.
2. Remove the flywheel and clutch assembly and the flywheel housing as detailed in Sections A.11 and A.18.
3. Bend back the lock washers, remove the bolts securing the pump to the crankcase, and withdraw the pump.




Fig. A.19  
The oil pressure relief valve




Fig. A.20

Two types of oil pump which may be fitted to this engine. 'A' indicates the lobe positions for checking clearances

- |   |  |
|---|--|
| <p>HOBOURN-EATON</p> <ol style="list-style-type: none"> <li>1. Body</li> <li>2. Shaft and rotor.</li> <li>3. Cover.</li> <li>4. Screw—cover to body.</li> </ol> | <p>CONCENTRIC PUMPS LTD.</p> <ol style="list-style-type: none"> <li>5. Pump (serviced as an assembly only).</li> </ol> |
|---|--|

#### Dismantling and reassembling (Hobourn-Eaton)

4. The pump cover is located on the pump body by two dowels and a machine screw. When the screw is removed the pump can be separated for examination and replacement where necessary.
5. Install the rotors in the pump body.
6. Place a straight-edge across the joint face of the pump body, and measure the clearance between the top face of the rotors and the underside of the straight-edge. The clearance should not exceed .005 in. (.127 mm.). In cases where the clearance is excessive this may be remedied by removing the two cover locating dowels and lapping the joint face of the pump body.
7. Install the rotors in the pump body and measure the clearance between the rotor lobes when they are in the position shown in Fig. A.20. If the clearance is in excess of .006 in. (.152 mm.) the rotors must be renewed.
8. Reassembly is a reversal of the dismantling procedure.
9. After reassembling, check the pump for freedom of action.

#### Refitting

The refitting of the pump to the cylinder block is a reversal of the removal procedure; ensure that the intake and delivery ports are not obstructed when fitting a new paper joint washer.

MINI. Issue 3. 26562

#### Section A.23

#### CAMSHAFT



#### Removing

1. Remove the engine (Section A.13), the rocker shaft assembly (Section A.5), the push-rods and tappets (Section A.9), and the distributor (Section A.10).
2. Unscrew the camshaft locating plate and withdraw the camshaft.
3. If the camshaft bearings are worn, remove the flywheel housing and transmission case (Sections A.18 and A.19).

#### FRONT LINER

Extract worn liners and fit new with Service tool 18G 124 A and adaptor 18G 124 K. Line ream the new liners with Service tools 18G 123 A, 18G 123 AH, 18G 123 AJ.

#### COOPER

#### FRONT AND REAR LINERS

Extract worn liners and fit new using Service tools 18G 124 A with adaptor 18G 124 K for the front liner, and adaptor 18G 124 M for the rear liner. Line ream the new liners with Service tools 18G 123 A, 18G 123 BA, 18G 123 AP, 18G 123 AT, 18G 123 AN, and 18G 123 AQ.

#### CENTRE LINER

Use Service tool 18G 124 A with adaptors 18G 124 K and 18G 124 B to extract the worn liner and fit a new one. Line ream the new liner, using Service tools 18G 123 A, 18G 123 BB, 18G 123 B, and 18G 123 BC.

#### Refitting

Reverse the dismantling and removing instructions.

#### Section A.24

#### PISTONS AND CONNECTING RODS

Pistons and bores are stamped with a number in a diamond and the number on the piston must be the same as that on the bore to which it is fitted.

Oversize pistons are marked on the crown with the oversize; this is the boring dimension and running clearance has been allowed for. Pistons are available in the sizes shown in 'GENERAL DATA'.

#### Removing

1. Remove the engine (Section A.13), the flywheel and clutch (Section A.11), the flywheel housing (Section A.18), the transmission (Section A.19), and the cylinder head (Section A.6).
2. Unlock and unscrew the big-end bolts; remove the bearing caps and push the connecting rod assemblies upwards through the bores.

A.15



**Dismantling**

3. Lift the rings out of their grooves and slide them off the piston. Always remove and refit rings over the top of the piston.
4. Hold the gudgeon pin in a vice between two plugs and unscrew the clamp bolt. Push out the gudgeon pin.

**Reassembling**

5. With the piston and gudgeon pin cold, the pin must be thumb push-fit for three-quarters of its travel and finally be tapped in with a hide mallet. Tighten the clamp bolt to the recommended torque (see 'GENERAL DATA').
6. Use new locking plates and tighten the connecting rod bolts to the recommended torque (see 'GENERAL DATA').

**NOTE.** -The second and third rings are tapered and the upper sides are marked 'T'.




Fig. A.21  
The piston markings

**COOPER**

(998-c.c. engine)

The gudgeon pins are fully floating with a bush in the small end of the connecting rod. The pins are retained in the piston by a circlip at either end. Should damage or wear occur, the gudgeon pin must not be renewed independently of the piston, and the small-end bush must not be renewed on its own, but only as a new connecting rod assembly.

**Cooper 'S'**

The gudgeon pin is a press fit in the small end of the connecting rod, and the bearing surfaces for the pin are in the piston bosses. The interference fit of the pin in the small end is the only method used to retain the gudgeon pin in its correct relative position. It is essential that the specified interference fit is maintained (see 'GENERAL DATA').

Service tool 18G 1002 must be used to remove and replace the gudgeon pin and great care is necessary to avoid damage to the piston. Mark the piston and pin before A.16

dismantling to ensure that the pin is replaced in the same side of the piston from which it was removed.

**Refitting**

Reverse the removal instructions, items 1 and 2.

**Cylinder liners**

Dry liners may be fitted and machining dimensions are given below.

A press capable of 3 tons (3000 kg.) is required to fit new liners, and of 8 tons (8000 kg.) to press out old. The dimensions of the pilots needed are given in Fig. A.22.




Fig. A.22

Cylinder liner pilots should be made to the above dimensions from case-hardening steel and case-hardened. The pilot extension should be made from 55-ton hardening and tempering steel, hardened in oil, and then tempered at 550°C. (1,020°F.)

**DIMENSIONS: PRESSING-OUT PILOT**

Illustration application	Engine (c.c.)	Inches (in.)	Metric (mm.)
A.	848	2.578	65.48
	997	2.593	65.88
	998	2.625	66.68
	1070	2.778	70.56
	1275		
B.	848	2.465	62.61
	997	2.452	62.28
	998	2.537	64.44
	1070	2.859	72.63
	1275		
C.	All engines	1.75	44.45
D.	All engines	.75	19.05
E.	All engines	¾ B.S.W. Thread	

**DIMENSIONS: PRESSING-OUT PILOT**

F.	848	3.00	76.20
	997		
	998		
	1070		
	1275		
G.	848	2.625	66.68
	997		
	998		
	1070		
	1275		
H.	848	2.455	62.35
	997		
	998		
	1070		
	1275		
J.	All engines	1.25	31.75
K.	All engines	.75	19.05
L.	All engines	.015	.38

**DIMENSIONS: PILOT EXTENSION**

M.	All engines	10.5	317.5
N.	All engines	.875	22.22
O.	All engines	.625	15.87
Q.	All engines	.625	15.87
R.	All engines	1.00	25.4
S.	All engines	¾ B.S.W. thread	
T.	All engines	1.25	31.75

Engine type	Liner Part No.	Machine bores of cylinder block to this dimension before fitting liner	Outside diameter of liner	Interference fit of liner in cylinder block bore	Machine liner bore to this dimension after fitting
848 c.c.	2A 784	2.6035 to 2.604 in. (66.128 to 66.14 mm.)	2.606 to 2.60675 in. (66.19 to 66.21 mm.)	.002 to .00325 in. (.05 to .08 mm.)	2.477 to 2.4785 in. (62.915 to 62.954 mm.)
997 c.c. (9F)	12A 391				2.4570 to 2.4585 in. (62.408 to 62.445 mm.)
998 c.c. (9FA) 998 c.c. (99H)	12G 164	2.64075 to 2.64125 in. (67.076 to 67.099 mm.)	2.64325 to 2.644 in. (67.139 to 67.158 mm.)		2.542 to 2.5435 in. (64.571 to 64.608 mm.)
1070 c.c. (9FD/SA) 1275 c.c. (12FA, 12H)	AEG 239 AEG 428	2.8750 to 2.8755 in. (73.0 to 73.0012 mm.)	2.8775 to 2.87825 in. (73.179 to 73.306 mm.)		2.779 to 2.7805 in. (70.58 to 70.622 mm.)

Section A.25

CRANKSHAFT AND MAIN BEARINGS

Removing

1. Carry out the operations described in Section A.24, items 1 and 2, and remove the timing cover (Section A.16).
2. Check the crankshaft end-float.
3. Prise out the circlip and slide the primary gear from the shaft.
4. Note that the main bearing caps and crankcase are numbered; withdraw the caps and bearing shells. Do not interchange caps and shells. The bottom halves of the two thrust washers will be removed with the centre bearing cap.
5. Lift out the crankshaft with the remaining halves of the thrust washer and the top half-shells of the main bearings.
6. Inspect the crankpins and journals, and the bearing shells; regrind the shaft and renew the bearings as necessary. Permissible regrind dimensions and undersize bearing sizes are given in 'GENERAL

**DATA**. Ensure that all oilway countersinks are machined to their original dimensions.

7. Inspect the thrust washers, and fit new if necessary.
8. Thoroughly clean the crankshaft and bearings.

Refitting

Reverse the removal instructions.

Section A.26

CRANKSHAFT AND PRIMARY GEAR

See Section A.18.

Section A.27

CRANKCASE CLOSED-CIRCUIT BREATHING  
(When fitted)

Fresh air enters the engine through two holes and a filter in the filler cap on the rocker cover. The air then passes to the crankcase down the push-rod drillings. The crankcase fumes leave the engine through a breather outlet pipe on the front engine side cover. Oil droplets and mist are trapped in an oil separator before the fumes pass through a breather control valve and to the intake manifold, thus providing closed-circuit crankcase breathing.

Testing

With the engine at normal running temperature, run it at idling speed. Remove the oil filler cap. If the valve is functioning correctly the engine speed will increase by approximately 200 r.p.m. as the cap is removed, the change in speed being audibly noticeable. If no change in speed occurs, service the valve as follows.

Servicing

The crankcase breather unit should be serviced at the periods recommended in the Driver's Handbook or the Passport to Service.




Fig. A.23

The correct assembly of connecting rods to the pistons and crankshaft


### OIL FILLER CAP

1. Remove the combined oil filler cap and breather filter and fit a replacement at the recommended servicing period.

### BREATHER CONTROL VALVE

2. Remove the retaining clip 1, and dismantle the valve.
3. Clean all metal parts with solvent (trichlorethylene, fuel, etc.). If deposits are difficult to remove, immerse in boiling water before applying the solvent. Do not use an abrasive.
4. Clean the diaphragm (3) with detergent or methylated spirit.
5. Replace components showing signs of wear or damage.
6. Reassemble the valve, ensuring the metering needle (4) is in the cruciform guides (6) and the diaphragm is seated correctly.

**NOTE.**—The 1st type valve assembly (without the cruciform guides) is serviced as an assembly.




B4507

Fig. A.25

A section through the flywheel and diaphragm clutch assembly

- |                             |                             |
|-----------------------------|-----------------------------|
| 1. Starter ring.            | 12. Driving pin.            |
| 2. Flywheel.                | 13. Lock washer.            |
| 3. Pressure plate.          | 14. Driving strap           |
| 4. Driven plate.            | 15. Flywheel hub.           |
| 5. Driven plate hub.        | 16. Thrust plate.           |
| 6. Circlip.                 | 17. Plate retaining spring. |
| 7. Crankshaft.              | 18. Thrust bearing.         |
| 8. Crankshaft primary gear. | 19. Flywheel screw.         |
| 9. Primary gear bearing.    | 20. Keyed washer.           |
| 10. Thrust washer.          | 21. Cover.                  |
| 11. Flywheel hub bolt.      | 22. Diaphragm spring.       |

4. Slacken the three clutch driving pins evenly to release the spring pressure. Replace the pins as they are removed one at a time with three  $\frac{5}{16}$  in. UNF. x 2 in. studs to prevent the pressure plate moving out of alignment.
5. Remove the cover and spring assembly.
6. Bring Nos. 1 and 4 pistons to T.D.C. to prevent the primary gear 'C' washer falling and being wedged behind the flywheel. With the crankshaft in any other position this could happen and result in damage as the flywheel is withdrawn.
7. Knock up the locking washer and remove the flywheel retaining screw using Service tool 18G 587. Remove the keyed washer and insert the plug from Service tool adaptor set 18G 304 N in the screw hole.



A968OAW

Fig. A.24

The crankcase closed-circuit breathing installation. (Inset) the oil filler cap filter

- |                    |                      |
|--------------------|----------------------|
| 1. Retaining clip. | 4. Metering needle.  |
| 2. Cover.          | 5. Spring.           |
| 3. Diaphragm.      | 6. Cruciform guides. |

8. Use Service tools 18G 304 with adaptor set 18G 304N (cadmium-plated) to remove the flywheel.  
**NOTE.**—The black screws from set 18G 304 M must not be used on the diaphragm clutch.
9. Screw the three adaptor screws into the flywheel and fit the plate of tool 18G 304 over the screws with the retaining nuts screwed on evenly to keep the plate parallel with the flywheel.
10. Screw the centre bolt of adaptor set 18G 304 N through the plate of tool 18G 304. Hold the flywheel from turning and tighten the centre bolt against the adaptor set plug until the flywheel is released from the crankshaft taper.
11. Withdraw the flywheel assembly and remove the Service tool.




Fig. A.26  
The 13 tube oil cooler fitted to the Cooper 'S'. The arrow indicates the angled hose connection

### Inspecting

12. Inspect the cover for elongation of the driving pin holes.
13. Inspect the driving pins for ridging and wear; fit three new pins if any are worn.
14. Inspect the driving straps; fit three new ones if any are worn.

### Refitting

15. If the driving straps have been removed from the flywheel ensure that the spacing washers are fitted between the straps and the flywheel face.
16. Refer to instruction 6.
17. Locate the cover and spring assembly with the clutch balance mark 'A' adjacent to the 1/4 timing mark on the flywheel (see Fig. E.2). Fit the driving pins in their original positions, tightening each a turn at a time by diametrical selection to the torque figure given in 'GENERAL DATA'.  
Ensure that the dowel portion of the driving pins has entered the holes in each pair of driving straps. Incorrect assembly can cause 'clutch judder'.
18. Tighten the flywheel retaining screw to the torque figure given in the 'GENERAL DATA', tap up the locking washer and refit the clutch cover.
19. Refit the engine (see Section A.13).

## Section A.29

### OIL COOLER (Cooper 'S')

#### Removing

1. Remove the front grille, taking care not to lose the spacers used for each securing screw.
2. Hold each union on the cooler from turning and disconnect both hoses from the cooler unit.
3. Complete removal of both hoses is effected in this manner—holding each union in turn on the oil filler head and the crankcase whilst releasing the hoses.

4. Remove the cooler unit securing screws and remove the unit through the grille aperture.

### Refitting

5. Refit the cooler unit and tighten the securing screws.
6. Connect each hose to its respective position on the oil cooler. If replacement hoses are fitted connect the hose with the angled connection to the oil cooler with its other end connected to the filter head. Ensure that the hoses are not under stress from twist—hold each union with a spanner whilst tightening the hose connections.
7. Start and run the engine and check for oil leakage.
8. Top up the engine oil to the 'MAX' level on the dipstick.
9. Refit the front grille, see item 1.

## Section A.30

### PRIMARY GEAR OIL SEAL REPLACEMENT

#### Removing

1. a. Remove the engine/transmission assembly (Section A.13).
- b. Remove the engine/rod change-type transmission assembly (Section A.33).
2. Remove the flywheel and clutch, Section A.11 (coil spring type) or Section A.28 (diaphragm spring type).
3. Remove the 'C' shaped thrust washer and backing ring securing the primary gear to the crankshaft.
4. Screw the centre bolt of tool 18G 1068B securely into the crankshaft, Fig. A.27.




Fig. A.27

Showing tool in position to withdraw the primary gear and oil seal.

- |                            |                  |
|----------------------------|------------------|
| 1. Service tool 18G 1068B. | 3. Primary gear. |
| 2. Tool collets.           | 4. Oil seal.     |

5. Pull the primary gear outwards as far as possible.
6. Pull the body of tool 18G 1068B over the centre bolt until the groove in the primary gear is visible inside the tool body, Fig. A.27.
7. Fit the two half collets of the tool into the groove in the gear, Fig. A.27.
8. Turn the winged nut anti-clockwise to withdraw the primary gear and oil seal clear of the housing, Fig. A.27.

### Refitting

9. Fit tool 18G 1043 over the primary gear.
10. Liberally lubricate the new oil seal with engine oil and fit it over the protector sleeve onto the primary gear.
11. Smear the primary gear front thrust washer with grease and refit it (with its chamfered inner edge against the shoulder on the crankshaft).
12. Locate the primary gear onto the crankshaft until the gear teeth are starting to engage with those of the idler gear, and with the oil seal contacting the housing bore whilst still seated on the sealing surface of the gear.
13. Pass the body of tool 18G 1068B over the crankshaft and screw the winged nut in a clockwise direction down the centre bolt to press the seal into the housing, Fig. A.28. The seal is correctly fitted when the base of the tool contacts the lip of the housing bore.
14. Refit the backing ring and 'C' shaped thrust washer (with the back of the 'C' washer adjacent to the timing marks on the flywheel).
15. Refit the clutch/flywheel assembly, Section A.11 or A.28.
16.
  - a. Refit the engine/transmission assembly (Section A.13).
  - b. Refit the engine/rod change-type transmission assembly (Section A.33).●

### Section A.31

#### FLYWHEEL RETAINING SCREW THREAD

The flywheel retaining screw thread in the end of the crankshaft is not Standard Whitworth but is Whitworth form:

Diameter  $\frac{5}{8}$  in. 16 T.P.I.  $1\frac{1}{8}$  in. full thread

If it is found necessary to clean up the thread, the operation must be confined to cleaning up. This thread is highly stressed and must always be up to full size.

### Section A.32

#### PRIMARY DRIVE GEAR TRAIN (Rod change transmission)

### Removing

1. Remove the clutch/flywheel assembly, Section A.28.
2. Remove the flywheel housing, Section A.18.
3. Remove the primary gear rear thrust washer and backing ring, Fig. A.29.
4. Pull off the primary gear, Fig. A.29.
5. Remove the primary gear front thrust washer.
6. Remove the circlip retaining the first motion shaft roller bearing, using tool 18G 1004, Fig. A.29.




Fig. A.28

Refitting the primary gear and oil seal

- |                            |                  |
|----------------------------|------------------|
| 1. Service tool 18G 1068B. | 2. Primary gear. |
|----------------------------|------------------|





Fig. A.30  
Showing make up of tool to hold the gear train.

- |                        |               |
|------------------------|---------------|
| 1. Idler gear.         | 2. Steel bar. |
| A. = 5 1/4 in (133 mm) |               |
| B. = 1 1/2 in (38 mm)  |               |
| C. = 3/8 in (9.5 mm)   |               |
| D. = 3/4 in (19.05 mm) |               |
| E. = 3/4 in (19.05 mm) |               |




Fig. A.29  
Removing the primary and idler gear assemblies. Inset shows Service tools fitted to remove the first motion shaft spigot roller bearing.

**Inspecting**

- Examine all gears for undue wear or damage, and replace as a complete set if necessary. Check the thrust washers and replace as required with those selected after checking the idler gear and primary gear end-float.

- Rear thrust washer.
- Primary gear.
- Backing ring.
- Front thrust washer.
- Idler gear thrust washers.
- Idler gear.
- Circlip—first motion shaft bearing.
- Roller bearing—first motion shaft.
- Service tool 18G 705.
- Service tool 18G 705C.

- Use tool 18G 705 and 18G 705C to pull off the first motion shaft roller bearing, Fig. A.29.
- Remove the idler gear and thrust washers.
- Make up and use a tool to lock the gear train while the first motion shaft gear retaining nut is slackened. Make the tool using an old idler gear and a piece of steel bar to the dimensions given in Fig. A.30.
- Drill a 3/4 in (19.05 mm) dia. hole in the bar as shown in Fig. A.30 and arc-weld the bar to the old idler gear. Wrap several thicknesses of tape around the bar where it will contact the crankshaft.
- Position the tool into the idler gear bearing with the handle against the crankshaft, Fig. A.31.
- Knock back the lock washer tab securing the first motion shaft gear retaining nut.
- Remove the retaining nut and lift off the first motion shaft gear.




Fig. A.31  
Using tool to hold the gear train to enable the first and third motion shaft nuts to be removed and refitted.

- Made-up tool.
- First motion gear and retaining nut.

### Refitting

15. Fit the first motion shaft gear with a new lock washer.
16. Position the gear train holding tool on the opposite side of the crankshaft, Fig. A.31.
17. Refit and tighten the first motion shaft gear retaining nut to 150 lbf ft (20.7 kg m).
18. Remove the gear train holding tool.
19. Primary gear end-float: Refit the primary gear with its front thrust washer, with the chamfered side of the washer (arrowed) towards the crankshaft.
20. Refit the rear backing ring and thrust washer.
21. Check the primary gear end-float with feeler gauges, see Fig. A.32; the amount of end-float should be from 0.0035 to 0.0065 in (0.089 to 0.165 mm). Adjust if necessary by fitting the correct thickness thrust washer from the range given below.

#### Primary gear thrust washer chart

0.112 to 0.114 in (2.84 to 2.89 mm)
0.114 to 0.116 in (2.89 to 2.94 mm)
0.116 to 0.118 in (2.94 to 2.99 mm)
0.118 to 0.120 in (2.99 to 3.04 mm)






Fig. A.33

Using Service tool 18G 1089 to determine the thickness of thrust washers required. Inset shows the assembly of tool and thrust washer onto the idler gear.

- |                   |   |
|-------------------|---|
| 1. Thrust washer. | 3. Service tool 18G 1089 (two washers). |
| 2. Idler gear.    | 4. Dental wax washer.                   |

22. Remove the primary gear assembly after adjustment.
23. Idler gear end-float: Assemble the idler gear to the transmission (longer spindle into the transmission) with a nominal washer from the range available, onto the transmission side of the idler gear, Fig. A.33.
24. Assemble the thin washers of tool 18G 1089 interposed with a dental wax washer onto the flywheel side of the idler gear.
25. Fit a new flywheel housing joint washer.
26. Refit the flywheel housing and tighten the securing bolts and nuts to 18 lbf ft (2.5 kgf m).
27. Remove the housing and discard the joint washer.
28. Remove the tool 18G 1089 (washers with dental wax interposed) and measure the thickness of the assembly with a micrometer. From the measurement figure taken, subtract 0.004 to 0.007 in (0.102 to 0.178 mm). Select and fit a thrust washer of the required thickness from the chart given below.

#### Idler gear thrust washer chart

0.132 to 0.133 in (3.35 to 3.37 mm)
0.134 to 0.135 in (3.40 to 3.42 mm)
0.136 to 0.137 in (3.45 to 3.47 mm)
0.138 to 0.139 in (3.50 to 3.53 mm)




Fig. A.32

Checking the primary gear end float with feeler gauges. Fit thrust washer with chamfered side 'arrowed' towards the crankshaft.

- |                              |                         |
|------------------------------|-------------------------|
| 1. Primary gear.             | 4. Rear backing ring.   |
| 2. Feeler gauges.            | 5. Front thrust washer. |
| 3. 'C' shaped thrust washer. | 6. Crankshaft.          |

29. Fit a new flywheel housing joint washer; do not re-use the one used when carrying out the idler gear adjustment.
30. Refit the primary gear with its selected front thrust washer, backing ring, and rear thrust washer, Fig. A.32.
31. Fit tool 18G 1043 over the primary gear and screw the two guides into the two bottom holes in the crankcase.
32. Refit the flywheel housing, Section A.18.
33. Refit the clutch/flywheel assembly, Section A.28.




Fig. A.34  
Disconnect the rod gear change remote control from the transmission.

- |                            |                                  |
|----------------------------|----------------------------------|
| 1. Extension rod.          | 4. Steady rod.                   |
| 2. Roll pin—extension rod. | 5. Nut and bolt—steady rod fork. |
| 3. Selector shaft.         |                                  |

### Section A.33

#### ENGINE AND GEARBOX ASSEMBLY (Rod-change gearbox)

##### Removing

1. Disconnect the battery.
2. Remove the bonnet.
3. Remove the air cleaner.
4. Disconnect the petrol feed hose, vacuum advance pipe and the breather hose from the carburetter.
5. Remove the carburetter and place it to one side clear of the power unit.
6. Disconnect both hoses from the fuel pump.
7. Disconnect the two-piece type speedometer cable at its centre joint.
8. Remove the cylinder block drain plug and drain the coolant.
9. Disconnect the heater hose from the radiator bottom hose connection.
10. Remove the heater water control valve from the cylinder head and place to one side.
11. Disconnect the exhaust down pipe from the exhaust manifold flange.
12. Disconnect and remove the horn.
13. From beneath the right hand front wing, release the pipe from the air intake.
14. Remove the air intake from the wing valance.
15. Disconnect the starter cable connection from the starter solenoid.
16. Disconnect the engine earth cable from the clutch cover.
17. Remove the distributor cap and rotor arm.
18. Disconnect the alternator plug connector and the electrical connections from the ignition coil and oil pressure switch.
19. Disconnect the clutch operating lever return spring, remove the slave cylinder securing bolts and place the unit clear of the power unit.
20. Release the engine tie-rod from the rear of the cylinder block, slacken the bolt securing the opposite end and swing the rod clear of the power unit.
21. Remove the rocker cover and fit the engine lifting attachment, see Fig. A.11.

22. Follow the procedure 1, 2 and 4 to 9 in Section G.5 to withdraw the drive shafts out of the inboard joints.
23. Drift out the roll-pin securing the remote control extension rod to the selector shaft, see Fig. A.34.
24. Remove the securing nut and bolt from the remote control steady fork on the final drive housing and detach the fork, see Fig. A.34.
25. Disconnect the exhaust steady bracket from the final drive end-cover.
26. Remove the four bolts and nuts securing the engine mountings to the sub-frame.
27. Attach lifting equipment to the front lifting eye of the attachment to give an angled lift, and lift the power unit out of the vehicle.

##### Refitting

28. Reverse the removing procedure noting the following:
  - a. Remove the engine lifting attachment; refit and tighten the cylinder head nuts to the torque figure given in 'GENERAL DATA'.
  - b. Refill the cooling system.





## SECTION Aa

### THE ENGINE

The information given in this Section refers specifically to engines fitted with automatic transmission and must be used in conjunction with Section A

	Section
†Camshaft .. .. .	Aa.9
Converter output gear .. .. .	Aa.13
Converter housing oil seal replacement .. .. .	Aa.15
Crankshaft and main bearings .. .. .	Aa.11
Cylinder liners .. .. .	Aa.14
Distributor driving spindle .. .. .	Aa.6
Engine and transmission .. .. .	Aa.3
Engine mountings .. .. .	Aa.12
Exhaust system .. .. .	Aa.5
Lubrication .. .. .	Aa.1
Oil filter .. .. .	Aa.2
Oil pump .. .. .	Aa.8
Pistons and connecting rods .. .. .	Aa.10
Transmission unit .. .. .	Aa.4
†Valve timing .. .. .	Aa.7

These operations must be followed by an exhaust emission check



## Section Aa.1

## LUBRICATION

## Checking oil level

**NOTE:** Ensure that the vehicle is standing on a level surface.

1. Start the engine and run it for 1-2 minutes. Stop the engine and wait for 1 minute, then check the oil level with the dipstick.
2. Maintain the oil level up to the 'MAX' mark on the dipstick; the difference in quantity between the 'MIN' and 'MAX' marks is approximately 1 pint (0.6 litre).

## Draining and refilling

The oil should be renewed at the periods given in the **MAINTENANCE SUMMARY**. Drain the oil while the engine is warm, and clean the magnetic drain plug using lint-free cloth.

3. Remove the drain plug and allow the oil to drain, clean the drain plug and fit a new sealing washer if necessary. Tighten the plug to the torque figure given in **GENERAL DATA**.
4. Refill with a recommended oil, see **'RECOMMENDED LUBRICANTS'**, up to the 'MAX' mark on the dipstick.
5. Repeat the procedures in 1 and 2.

## Section Aa.2

## OIL FILTER

## Filter element renewal

## REMOVING

1. All models except 'Clubman'. Remove the front grille (16 screws).  
On 'Clubman' models sufficient clearance exists for filter bowl removal.
2. Place a suitable container beneath the oil filter.
3. Unscrew the central retaining bolt and remove the bowl and element assembly.

## CLEANING

4. Thoroughly clean the filter bowl with petrol (fuel) and dry off.
5. Wipe the filter head clean and fit a new sealing ring in the filter head recess.

## REFITTING

6. Reassemble the filter bowl with a new element and the internal components fitted in the order shown in Fig. Aa.1. Ensure that the internal sealing washer is in good condition and a snug fit on the retaining bolt.




Fig. Aa.1

The engine/automatic transmission oil filter. (Inset) the filter components

- |                    |                                |
|--------------------|--------------------------------|
| 1. Filter element. | 6. Spring                      |
| 2. Circlip.        | 7. Sealing washer.             |
| 3. Steel washer.   | 8. Sealing plate.              |
| 4. Sealing ring.   | 9. Filter head retaining bolts |
| 5. Centre bolt.    | 10. Oil pressure check plug.   |

7. Refit the filter bowl assembly and tighten the central retaining bolt to the torque figure given in **'GENERAL DATA'**.
8. Check for oil leakage immediately the engine is started.
9. Top up the engine oil level following the instructions in Section Aa.1.
10. Refit the front grille (where applicable).

Filter head and bowl assembly  
REMOVING

11. Release the distributor cap.




Fig. Aa.2

The correct location of the later-type filter head/front cover joint washer

12. Unscrew the filter head retaining bolts and remove the assembly.

**NOTE.**—The oil filter head to front cover joint washer (with copper inserts) fitted to later units is **not** interchangeable with those fitted to the earlier units. The two 'O' ring oil seals are not used on the later units (see Fig. Aa.2 for correct location of the later-type joint washer).

## REFITTING

13. Reverse the removal instructions, fitting a new joint washer and seals (if fitted). Tighten the securing bolts to the torque figure in 'GENERAL DATA'.
14. Carry out items 8 and 9.




Fig. Aa.3

The main components to be disconnected or removed from inside the engine compartment before removing the engine and transmission unit

- |                 |                    |                        |
|-----------------|--------------------|------------------------|
| 1. Air cleaner. | 3. Horn.           | 5. Heater water valve. |
| 2. Carburettor. | 4. Engine tie-rod. | 6. Exhaust pipe clamp. |

## Section Aa.3

## ENGINE AND TRANSMISSION

## Removing

1. Disconnect the battery earth cable.
2. Mark the fitted position of the bonnet to its hinges and remove the bonnet.
3. Raise the front of the car until the wheels are free to rotate and remove the drive shaft flange securing nuts.
4. Remove the bellcrank lever guard or, on early units, pull back the rubber boot; disconnect the selector cable yoke from the bellcrank lever.
5. Remove the exhaust bracket from the final drive cover. The larger nut is secured by a locking tab (see Fig. Aa.4).
6. Drain the cylinder block and release the heater control water valve from the rear of the cylinder head and retain it clear of the engine.




Fig. Aa.4

The main components to be disconnected or removed from below the car before removing the engine and transmission unit

- |  |  |                                |
|--|--|--------------------------------|
| 1. Drive shaft universal joints.             | 3. Gearchange cable and cover (early type) | 5. L.H. front engine mounting. |
| 2. Gearchange cable and cover (latest type). | 4. Exhaust pipe bracket.                   | 6. R.H. front engine mounting. |

- |   |   |
|---|---|
| 7. Disconnect the heater hose from radiator bottom hose adaptor.  | 12. Release the carburettor from the engine and attach it to the bulkhead clear of the engine.  |
| 8. Release the heater air intake tube (when fitted) from the front grille and wing valance and retain it clear of the engine. | 13. Unscrew and release the speedometer cable from its pinion on the transmission casing, or from the rear of the speedometer on models where the instrument is centrally situated. |
| 9. Disconnect all electrical connections from the engine.   | 14. Disconnect the oil pressure hose (when fitted).   |
| 10. Remove the distributor cap.   | 15. Disconnect and remove the horn (when attached to the bonnet locking platform).  |
| 11. Remove the air cleaner as in Section Da.1.  |   |




Fig. Aa.5

Use the individual front lifting eye of the attachment to give an angled lift when removing and refitting the power unit

16. Disconnect the exhaust pipe from the manifold and secure the pipe against the bulkhead.
17. Detach the engine tie-rod from its locations on the cylinder block and bulkhead bracket.  
Early models: Release the tie-rod from the rear of the cylinder head and swing it away from the engine.
18. Remove the rocker cover nuts and fit the engine lifting bracket (Fig. Aa.5).
19. Remove the set screws securing each engine mounting to the sub-frame.
20. Lift the engine sufficiently to release the drive shafts from the driving flanges, and remove the engine/transmission unit from the car.




Fig. Aa.6

Removing the converter centre bolt, using Service tool 18G 587. A suitable screwdriver inserted through the converter housing to stop the converter turning, and the converter drain plugs, are indicated by arrows

**Refitting**

21. Reverse the removal instructions with particular attention to the following points.
22. Lower the engine/transmission unit to a position where the drive shafts can engage the driving flange studs and screw the securing nuts on approximately four threads. Lower the unit completely into the car.
23. Adjust the selector lever cable and transverse rod as detailed in Section Fa.2.
24. Tighten all hose connections and refill the cooling system.
25. Top up the engine with oil as described in Section Aa.1.

**Section Aa.4**

**TRANSMISSION UNIT**

**Removing**

1. Remove the engine and transmission (see Section Aa.3).
2. Remove the radiator mounting bracket from the transmission case.
3. Remove the starter motor, with the distance piece (if fitted) and the converter cover.
4. Drain the transmission.
5. Knock back the lock washer on the converter centre bolt. Hold the converter from turning with a suitable screwdriver inserted through the hole in the converter housing. Using Service tool 18G 587, remove the centre bolt (Fig. Aa.6).




Fig. Aa.7

Removing the converter using Service tool 18G 1086. A screwdriver to stop the converter turning, and the low pressure valve, are indicated by the arrows




Fig. Aa.8

Using Service tool 18G 1088 to hold the converter output gear when removing the input gear nut

6. Knock back the locking tabs and remove three equally spaced set screws from the converter centre. Ensure that the slot in the end of the crankshaft is horizontal. Using Service tool 18G 1086 with the adaptor correctly positioned, remove the converter (Fig. Aa.7). Remove the Service tool and refit the three screws.
7. Remove the low pressure valve from the converter housing. Note that later valves are fitted with a screwed plug, which replaces a welch plug and must not be removed.
8. Fit Service tool 18G 1088 onto the converter output gear and remove the input gear self-locking nut (Fig. Aa.8).
9. Disconnect the transverse rod from the bell-crank assembly, remove the nut securing the bell-crank to its pivot and withdraw the bell-crank. Knock back the locking washer securing the bell-crank pivot, unscrew and remove the pivot.
10. Fit the nylon protector sleeve Service tool 18G 1098 over the converter output gear.
11. Remove the nuts and set screws securing the converter housing to the transmission and lift away the housing. Remove the converter oil outlet pipe from the housing.
12. Lever the main oil feed pipe from the transmission and oil pump.
13. Remove the idler gear, thrust washers, and the converter output gear assembly.
14. Remove the oil filter assembly and disconnect the engine oil feed pipe together with (on early units) its rubber seal and spring washer (see Fig. Aa.9).
15. Remove the nuts and set screws securing the engine to the transmission and with suitable lifting equipment lift the engine away from the transmission.

### Inspecting

Ensure that the oil rings fitted to the main oil pipe, oil filter, transmission to engine oil feed pipe, and the main oil

strainer pipe are in perfect condition. All joint faces must be free from burrs and new joint washers should be used. Check that the converter housing bush has not come loose in its housing.

Inspect the idler gear bearings and renew if necessary, using Service tool 18G 581 to remove the bearings from the casings. Inspect the input gear bearing and renew if necessary by removing the circlip and pressing the bearing from the housing.

Check the main oil seals and renew if necessary. If it is necessary to renew the converter housing oil seal this operation is detailed in Section Aa.15. To renew the converter output gear oil seal, remove the rear case assembly and carefully remove the seal. Lubricate the new seal and press into the casing, using Service tools 18G 134 and 18G 134 CN (Fig. Aa.11).

**NOTE.**—Before refitting the transmission unit, check the casing to determine whether it is the later type with a cast-in oil reservoir (to improve idler gear bearing lubrication). Should it be an earlier type casing, it is advisable to modify the unit as detailed in Section Fa.17.

### Refitting

16. Immerse the front main bearing cap moulded rubber oil seal in oil and fit with the lip facing the rear of the engine.




Fig. Aa.9

Inset 'A'—Pipe assembly fitted to early units  
Inset 'B'—Pipe assembly to be used to enable the later transmission unit, with the screwed union (2), to be fitted to an early type engine not fitted with items 1 and 4




Fig. Aa.10

The converter housing removed showing:

- |                           |                   |
|---------------------------|-------------------|
| 1. Main oil pump.         | 4. Input gear.    |
| 2. Converter output gear. | 5. Oil feed pipe. |
| 3. Idler gear.            | 6. Sealing rings. |




Fig. Aa.11

Replacing the converter output gear oil seal. Pressing the seal in, using Service tools 18G 134 and adaptor 18G 134 CN, with (inset) showing exploded view

**NOTE.**—Two types of input gears have been used, those fitted to earlier units have two thrust washers (Fig. Aa.14). The later gear (of increased hub thickness) has a number of thin shims fitted to the outer hub face of the gear for adjustment (see Fig. Aa.19).

17. Fit the rubber sealing ring on to the main oil strainer pipe and fit new gaskets to the transmission case.
18. Lower the engine on to the transmission. Ensure that the moulded rubber seal is correctly located. Tighten the set screws and nuts as the transmission is being lowered in position.
19. Refit the transmission to engine oil feed pipe (both types of pipe assemblies are shown in Fig. Aa.9).
20. Refit the oil filter assembly (see 'NOTE' in Section Aa.2 regarding joint washer location).
21. Refit the main oil pump to transmission oil pipe.
22. Trim off any excess transmission joint from the rear of the unit. Clean the surfaces and fit a new converter housing gasket.
23. Refit the converter output gear. When refitting, make certain that the correct running clearance of .0035 to .0065 in. (.089 to .165 mm.) is maintained between the inner thrust washer and the converter output gear. If the clearance is outside these limits, select and fit the appropriate washer from the size range, with the chamfered inner edge of the washer to face the crankshaft.

**Converter output gear thrust washers**

- .112 to .114 in. (2.848 to 2.898 mm.)
- .114 to .116 in. (2.898 to 2.949 mm.)
- .116 to .118 in. (2.949 to 3.0 mm.)
- .118 to .120 in. (3.0 to 3.051 mm.)

**Idler and input gear adjustment (Early Models)**

24. Assemble the idler gear to the transmission with a nominal washer (from the range fitted), on the transmission side of the idler gear. Assemble Service tool 18G 1089 with a dental wax washer interposed on to the converter housing side of the idler gear. To cut the holes in the wax strip, place the larger washers of 18G 1089 one on either side of the wax, opposite each other, and press together.




Fig. Aa.12

The converter output gear. Measure the gap indicated and fit the appropriate thrust washer



25. Fit input Service tool 18G 1098 interposed with a dental wax washer (Fig. Aa.13).

**NOTE.**—If the input gear will not fully mesh with the idler gear, this indicates that the third speed reaction gear thrust washer has become displaced. Therefore it is necessary to remove, dismantle, and reassemble the gear train as detailed in Section Fa.12 (all items except (1) ).

26. Screw the two pilot bars of Service tool 18G 1043 into the two bottom tapped holes in the crankcase. Fit the nylon protector sleeve Service tool 18G 1098 over the converter output gear and refit the converter housing; tighten into position to the correct torque figure given in 'GENERAL DATA'. The input shaft nut must not be fitted.




Fig. Aa.13

The idler and input gears fitted with the Service tool 18G 1089 (two sets of special washers, each set interposed with wax washer)

27. Remove the converter housing.  
 28. Measure the thickness of the idler gear thrust washer plus the thickness of the Service tool 18G 1089 and its dental wax washer. From this figure subtract .004 to .007 in. (.102 to .178 mm.) to give the total thickness of the thrust washers to be fitted to provide the correct idler gear end-float.

#### Idler gear thrust washer

- .130 to .131 in. (3.30 to 3.32 mm.)
- .132 to .133 in. (3.35 to 3.37 mm.)
- .134 to .135 in. (3.40 to 3.42 mm.)
- .136 to .137 in. (3.45 to 3.47 mm.)
- .138 to .139 in. (3.50 to 3.53 mm.)




Fig. Aa.14

The converter output 1, idler 2, and input gear 3 with their respective thrust washers

29. Measure the thickness of the input gear Service tool 18G 1089 plus its dental wax washer. Add .001 to .003 in. (.025 to .076 mm.) to the figure to give the total thickness of the thrust washers to be fitted to provide the required 'nip' on the input gear bearing.




Fig. Aa.15

Using Service tools 18G 1088 to hold the converter output gear and 18G 592 to tighten the input gear nut to the correct torque figure




Fig. Aa.16

Using Service tools 18G 191 and 18G 191 A, with the dial test indicator set at zero

**Input gear thrust washers**

- .128 to .130 in. (3.25 to 3.30 mm.)
- .132 to .134 in. (3.35 to 3.40 mm.)
- .140 to .142 in. (3.55 to 3.61 mm.)
- .148 to .150 in. (3.76 to 3.81 mm.)
- .152 to .154 in. (3.86 to 3.91 mm.)

30. a. Fit one washer on each side of the idler gear as calculated in item 28.
- b. Fit two washers to make up the calculated thickness onto the input gear shaft. Both washers must be fitted to the outside of the input gear (see Fig. Aa.14), with the chamfered inside edge of one washer towards the gear.

**Idler and input gear adjustment (Later Models)**

31. Carry out item 24.
32. Place the input gear on a surface plate or onto Service tool 18G 191 A and use a dial test indicator gauge, Service tool 18G 191, to take a mean reading. Set the dial gauge to zero as shown in Fig. Aa.16.
33. Fit Service tool adaptor 18G 1089 A over the input shaft. Use Service tool 18G 1089/1 to cut a dental wax washer, and fit the wax washer with Service tool 18G 1089/1 over the input shaft (see Fig. Aa.17).
34. Carry out items 26 and 27.
35. Fit a new converter housing joint washer and ensure that NO shims are sticking to the input gear bearing. Lubricate the oil seal lip, refit the housing and tighten to the torque figure given in 'GENERAL DATA'. The input shaft nut must not be fitted.

36. Remove the converter housing and withdraw the adaptor assembly 18G 1089 A, wax washer, and 18G 1089/1. Substitute this complete assembly for the input gear on the surface plate (see Fig. Aa.18).
37. Use the dial test indicator gauge. Service tool 18G 191, and measure the thickness of this assembly (see Fig. Aa.18). The mean reading obtained indicates the total thickness of shims required to eliminate end-float. To this figure add shims to the value of .001 to .003 in. (.025 to .076 mm.) to give the required input bearing preload.

**Input gear adjustment shims**

- .003 in. (.076 mm.)
- .012 in. (.305 mm.)

38. Measure the thickness of the idler gear thrust washer plus the thickness of the Service tool 18G 1089 and its dental wax washer. From this figure subtract .004 to .007 in. (.102 to .178 mm.) to give the total thickness of the thrust washers to be fitted to provide the correct idler gear end-float.

**Idler gear thrust washers**

- .132 to .133 in. (3.35 to 3.37 mm.)
- .134 to .135 in. (3.40 to 3.42 mm.)
- .136 to .137 in. (3.45 to 3.47 mm.)
- .138 to .139 in. (3.50 to 3.53 mm.)

39. a. Fit the required thickness of shims as calculated in item 37 onto the outside of the input gear (see Fig. Aa.19).
- b. Fit one washer on each side of the idler gear (see Fig. Aa.19) as calculated in item 38.




Fig. Aa.17

1. Service tool 18G 1089 A.
2. Wax washer.
3. Service tool 18G 1089/1.
4. Service tool 18G 1089 with wax washer interposed.
5. Service tool 18G 1098.

## Refitting

40. Refit and align the converter outlet pipe.
41. Discard the converter housing joint washer used during the idler and input gear adjustment operations. Refit the converter housing with a new joint washer, remove the pilot bars of Service tool 18G 1043 and tighten the securing nuts and set screws to the torque figure given in 'GENERAL DATA'.
42. Refit the input gear shaft nut and tighten to the correct torque figure (see 'GENERAL DATA'), using Service tools 18G 1088 and 18G 592.
43. Remove each pair of bolts in turn from the converter and fit new locking plates. Tighten the bolts to the torque figure given in 'GENERAL DATA', and tap up the locking tabs.  
**NOTE.—Do not remove all six screws from the converter centre at one time.**
44. Lubricate the converter oil seal and refit the converter. Refit the washer (offset pegs) and the centre bolt with its lock washer. Tighten the bolt to the correct torque figure (see 'GENERAL DATA') with Service tools 18G 587 and 18G 592 and lock up the lock washer.
45. Refit the low pressure valve and gasket.
46. Refit the gear selector bell-crank lever and its pivot, and reconnect it with the transverse rod. See that either the rubber boot (early models) or guard (later models) is refitted.
47. Refit the converter cover, the starter motor, and the rear engine mounting.
48. For refitting the engine and transmission to the car (see Section Aa.3).




Fig. Aa.18

Measuring the adaptor assembly

1. Service tool 18G 1089/1.
2. Wax washer.
3. Service tool 18G 1089 A.




Fig. Aa.19

The converter output 1, idler 2, and input gear 3 with their respective thrust washers and shims

## Section Aa.5

## EXHAUST SYSTEM

## Removing

1. Slacken the exhaust pipe to manifold clamp.
2. Release the pipe from the bracket on the final drive casing (Fig. Aa.3) and from the two locations on the rear sub-frame.

## Refitting

3. Refit the exhaust system to the car with the intermediate and rear support clips loose to allow articulation at the manifold spherical flange.
4. Align the pipe flange with the manifold, refit and tighten the manifold clamp.
5. Ensure correct alignment of the system and tighten the remaining fixing points.

## Section Aa.6

## DISTRIBUTOR DRIVING SPINDLE



## Removing

1. Remove the distributor and driving spindle as detailed in Section A.10.

## Refitting

2. Refitting is described in Section A.10 with the following exceptions.

3. To rotate the crankshaft, insert a screwdriver through the aperture (adjacent the oil dipstick) on the converter housing or end cover, and turn the converter starter ring gear to the position described in Section A.10.
4. Check that the correct timing mark on the converter is in line with the pointer on the converter housing (see Figs. Ba.1 and Ba.2).

Section Aa.7

VALVE TIMING



1. Follow the instructions given in Section A.17 with the following exceptions.
2. Rotate the crankshaft as described in Section Aa.6 until the 5° B.T.D.C. timing mark on the converter is opposite the pointer on the converter cover.

Section Aa.8

OIL PUMP

Removing

1. Remove the engine and transmission as detailed in Section Aa.3.
2. Remove the converter and converter housing as detailed in Section Aa.4, items 3 to 12.
3. Remove the pump securing screws and withdraw the pump.

Dismantling and reassembling

4. Follow the instructions given in Section A.22 for the Hobourn-Eaton pump.

Refitting

5. Reverse the removal instructions fitting new joint washers as required.




Fig. Aa.20

The oil pump components. 'A' indicates the lobe positions for checking clearances

Section Aa.9

CAMSHAFT



NOTE.—Extreme care is necessary when removing the camshaft. The oil pump drive coupling may stick by oil adhesion to the camshaft and possibly fall into the transmission unit. Ensure therefore when refitting the camshaft that this drive coupling is fully located on the splined oil pump spindle.

Removing

1. Follow the instructions given in Section A.23 with the following exceptions.
2. Remove the engine and transmission as detailed in Section Aa.3.
3. Should the front camshaft bearing clearance be excessive, a new bearing liner must be fitted and as this will entail line-reaming after fitting, both the converter, converter housing, and the transmission unit must be removed as in Section Aa.4.
4. For removing, fitting, and reaming a new liner follow the instructions in Section A.23.

Refitting

5. Refitting is a reversal of the removal procedure given in Section A.23.

Section Aa.10

PISTONS AND CONNECTING RODS

Removing

1. Follow the instructions given in Section A.24 with the following exceptions.
2. Remove the engine and transmission unit as detailed in Section Aa.3.
3. Remove the converter, converter housing, and the transmission unit from the engine as detailed in Section Aa.4.

Refitting

4. Refitting is a reversal of the removing procedure (see Sections A.24 and Aa.3-4).

Section Aa.11

CRANKSHAFT AND MAIN BEARINGS

Removing

1. Follow the instructions given in Section A.25 with the following exceptions.
2. Remove the engine and transmission unit as detailed in Section Aa.3.
3. Remove the converter, converter housing, and the transmission unit from the engine as detailed in Section Aa.4.

### Refitting

- Follow the refitting instructions for installation of the crankshaft and bearings given in Section A.25.
- Carry out the inspection and refitting of the transmission unit as detailed in Section Aa.4.

### Section Aa.12

#### ENGINE MOUNTINGS

#### Removing

##### LEFT-HAND MOUNTING

- Follow the instructions in Section A.14.

##### RIGHT-HAND MOUNTING

- Disconnect the battery earth cable.
- Disconnect the electrical connections from the starter solenoid and remove it from the wing valance.
- Disconnect the engine tie-rod from the rear of the cylinder block and the exhaust down pipe from the manifold flange.
- Remove the two nuts and set screws securing the mounting to the sub-frame.
- Lift the rear of the engine sufficiently to remove the securing nuts and bolts from the converter cover and the starter motor. Turn the cover slightly anti-clockwise and remove the cover complete with the engine mounting.
- Unscrew the set screws to release the mounting from the cover.

#### Refitting

- Refitting is a reversal of the removal procedure.

### Section Aa.13

#### CONVERTER OUTPUT GEAR

#### Removing

- Remove the engine and transmission as detailed in Section Aa.3.
- Carry out the removing instructions as detailed in Section Aa.4, items 3 to 11 and 13.

#### Adjusting

- Carry out the instruction given in Section Aa.4, item 23.

#### Refitting

- Refitting is a reversal of the removal procedure.

Aa.12

### Section Aa.14

#### CYLINDER LINERS

Follow the instructions in Section A.24 with the following exceptions.

- Remove the engine and transmission from the car as detailed in Section Aa.3.
- Remove the transmission unit from the engine as detailed in Section Aa.4.

### Section Aa.15

#### CONVERTER HOUSING OIL SEAL REPLACEMENT

#### Removing

- Remove the engine from the car as detailed in Section Aa.3.
- Remove the starter motor and converter cover.
- Remove the converter (Section Aa.4, items 5 and 6).
- Remove the old seal, using Service tool 18G 1087. Hook the tool into the oil seal groove and tap outwards on the tool, working round the seal until it is removed.

#### Refitting

The new seal must be fitted to the correct depth in order that the oil drain hole behind the seal remains open.

- Take a depth measurement from any convenient point on the periphery of the housing bore of the front face of the housing to the undercut face (see Fig. Aa.21).




Fig. Aa.21

A section through of fitting the converter housing oil seal. A = the depth measurement to be taken

- |                       |   |
|-----------------------|---|
| 1. Converter housing. | 3. Service tool 18G 1068 B.             |
| 2. Oil seal.          | 4. Service tool adaptor set 18G 1068 A. |

This measurement will be approximately  $\frac{3}{8}$  in. (9.5mm.), but should it be more or less than this measurement this must be taken into account and either added to or subtracted from  $\frac{3}{8}$  in. (9.5 mm.).

**EXAMPLE:** If the measurement is  $\frac{3}{8}$  in. (9.5 mm.) fit the new seal to be flush with the front face of the converter housing. If measurement is less than  $\frac{3}{8}$  in. (9.5 mm.) fit the seal proud of the face by the difference of measurement obtained.

**NOTE.**—The converter housing face is not machined, therefore, the initial measurement position and that used when fitting a new seal must always be taken from the same position on the housing.

6. Screw in the short threaded end of Service tool 18G 1068 A securely into the crankshaft.
7. Liberally lubricate the new oil seal.
8. Assemble the new seal together with Service tool 18G 1068 B into position (see Fig. Aa.22).
9. Screw in the wing nut of the tool until the seal is pressed in to the depth of the measurement (see item 5).
10. The remainder is a reversal of the removing procedure.
11. Check and top up oil level (Section Aa.1).




Fig. Aa.22

Fitting the converter output gear oil seal, using Service tool 18G 1068 B with adaptor 18G 1068 A



# SECTION B

## THE IGNITION SYSTEM

Distributor (25D4) – remove and refit	..	..	..	..	..	..	..	..	..	..	..	..	..	B.1
– overhaul	..	..	..	..	..	..	..	..	..	..	..	..	..	B.2
Distributor (45D4) – remove and refit	..	..	..	..	..	..	..	..	..	..	..	..	..	B.3
– overhaul	..	..	..	..	..	..	..	..	..	..	..	..	..	B.4
Spark plugs	..	..	..	..	..	..	..	..	..	..	..	..	..	see 'MAINTENANCE'
Timing	..	..	..	..	..	..	..	..	..	..	..	..	..	B.5






Fig. B.1

The components of the 25D4 distributor

- |                                    |                               |
|------------------------------------|-------------------------------|
| 1. Clamping plate                  | 12. Automatic advance springs |
| 2. Moulded cap                     | 13. Weight assembly           |
| 3. Brush and spring                | 14. Shaft and action plate    |
| 4. Rotor arm                       | 15. Cap-retaining clips       |
| 5. Contacts (set)                  | 16. Vacuum unit               |
| 6. Capacitor                       | 17. Bush                      |
| 7. Terminal and lead (low tension) | 18. Thrust washer             |
| 8. Moving contact breaker plate    | 19. Driving dog               |
| 9. Contact breaker base plate      | 20. Taper pin                 |
| 10. Earth lead                     | 21. Cam screw                 |
| 11. Cam assembly                   | 22. 'O' ring oil seal         |

### Section B.1

#### DISTRIBUTOR (Type 25D4) — Remove and refit

##### Removing

1. Remove the cover or grommet from the timing hole in the clutch/converter cover and rotate the crankshaft until the flywheel/converter is at the correct static setting, see 'ENGINE TUNING DATA'; the appropriate timing mark should be adjacent to the pointer in the timing hole.
2. Unclip the distributor cap and place it to one side.
3. Detach the low tension cable from the terminal blade on the distributor body.
4. Disconnect the vacuum pipe from the vacuum timing control unit.
5. Take out the two screws securing the clamp plate and pull out the distributor. Do not loosen the clamp plate pinch bolt.

### B.2

##### Refitting

6. Reverse the removing procedure, noting the following:
  - a. Position the offset tongues of the driving dog with the larger offset uppermost.
  - b. Later type distributors have an 'O' ring oil seal on the mounting shank.
  - c. Recheck and adjust if necessary the stroboscopic timing to the figure quoted in 'ENGINE TUNING DATA'.

### Section B.2

#### DISTRIBUTOR (Type 25D4) — Overhaul

##### Dismantling

1. Remove the distributor from the engine, Section B.1.
2. Remove the high tension cables from the distributor cap.
3. Withdraw the brush and spring from inside the cap.
4. Withdraw the rotor arm from the top of the cam.
5. Remove the nut from the terminal pillar on the fixed contact plate and detach the upper insulating bush and the two leads from the terminal pillar.
6. Remove the moving contact from the contact breaker moving plate.
7. Remove the lower insulating bush from the terminal pillar.
8. Remove the screw to release the fixed contact plate from the contact breaker moving plate.
9. Remove the screw to release the condenser from the contact breaker moving plate.
10. Detach the vacuum unit link from the contact breaker moving plate.




Fig. B.2

The 25D4 type distributor

1. Clamp screw
2. Vernier scale
3. Knurled adjuster nut

11. Remove the rubber seals and the two screws to release the contact breaker base plate and the earthing lead from the distributor body.
12. Turn the contact breaker base plate clockwise in relation to the contact breaker moving plate and detach the moving plate from the base plate.
13. Remove the circlip from the end of the micrometer adjusting screw and unscrew the micrometer adjusting nut to release the vacuum timing control unit and coil spring from the distributor body.
14. Remove the micrometer adjusting nut ratchet spring from the distributor body.
15. Detach the two springs from the pillars on the cam and the action plate.
16. Remove the screw and withdraw the cam, and the centrifugal timing control weights from the distributor shaft and action plate.
17. Drive the pin out of the distributor driving dog to release the dog and the thrust washer from the distributor shaft.
18. Withdraw the shaft and action plate from the distributor body.
19. Withdraw the distance collar and steel washer(s) from the distributor shaft.
20. Remove the 'O' ring from the distributor body.

**NOTE.**—The Cooper 'S' distributor is not fitted with a suction advance device; therefore items 13 and 14 are not applicable.

#### Inspection

21. Check all components for wear and damage.
22. Inspect the distributor cap for cracks and signs of tracking.

#### Reassembling

23. Reverse the procedure in 2 to 20, noting:
  - a. Lubricate the distributor shaft and bearing with one of the recommended engine lubricants. Add a few drops of this lubricant to the auto-advance mechanism.
  - b. Lubricate the bearing surfaces of the contact breaker base plate and the moving plate with Ragosine molybdenized non-creep oil.
  - c. Fit the cam so that the rotor arm driving slot on the top of the cam is uppermost and the large offset of the distributor shaft driving dog is to the left, when viewed from the base of the distributor.
  - d. Lightly smear the cam and the outside of the contact breaker hollow pivot post with Retinax 'A' or equivalent grease.
  - e. Adjust the contact breaker gap to the dimension given in 'ENGINE TUNING DATA'.
  - f. Rotate the micrometer adjustment nut until it is in the mid position of its adjustment.
24. Check the distributor performance, see 'ENGINE TUNING DATA'.
25. Refit the distributor, Section B.1.

#### Section B.3

##### DISTRIBUTOR (Type 45D4) — Remove and refit

**NOTE.**—This distributor is fitted to engines from 1974 on, see 'ENGINE TUNING DATA' for the particular model application and tuning figures.

#### Removing

1. Follow the removing procedure given in Section B.1, with the following exception:
  - a. Disconnect the low tension cable from the 'Lucar' connector.

#### Refitting

2. Follow the refitting procedure in Section B.1.

#### Section B.4

##### DISTRIBUTOR (Type 45D4) — Overhaul

#### Dismantling

1. Remove the rotor arm and extract the felt pad from the cam.
  2. Remove the two screws retaining the vacuum unit, tilt the unit to disengage the operating arm and remove the vacuum unit.
  3. Push the low tension lead and grommet into the inside of the body.
  4. Remove the base plate securing screw.
  5. Lever the slotted segment of the base plate from its retaining groove and lift out the base plate assembly.
  6. Drift out the parallel pin retaining the drive dog.
  7. Remove the drive dog and thrust washer.
  8. Remove the shaft complete with automatic advance mechanism, steel washer and nylon spacer.
- NOTE.**—Do not dismantle the advance mechanism beyond removing the control springs, see item 12.
9. Push the moving contact spring inwards and detach the low tension connector from the spring loop.
  10. Remove the screw to release the earth lead and capacitor.
  11. Remove the securing screw and lift off the contact set.

#### Inspecting

12. If any of the moving parts or the cam are worn or damaged, renew the complete shaft assembly.
13. Check the fit of the shaft in its bearing, if the bearing allows excessive side play, renew the complete distributor.




Fig. B.3

The components of the 45D4 distributor

- |  |                                  |
|--|----------------------------------|
| 1. Pick-up brush and spring                          | 11. Low tension lead             |
| 2. Rotor arm   | 12. Thrust washer—drive dog      |
| 3. Retaining screw — capacitor                       | 13. Drive dog                    |
| 4. Capacitor   | 14. Retaining pin—drive dog      |
| 5. Retaining screw — base plate                      | 15. Retaining screw—contact set  |
| 6. Base plate  | 16. Contact set                  |
| 7. Felt pad — cam                                    | 17. Low tension lead connector   |
| 8. Cam spindle and automatic advance weight assembly | 18. Retaining screws—vacuum unit |
| 9. Spacer  | 19. Vacuum unit                  |
| 10. Steel washer                                     |                                  |

B.4




Fig. B.4

Fitting the drive dog to a new distributor, note the driving tongues (1) are parallel with the rotor arm electrode (2)

14. Check the base plate assembly; if the spring between the plates is damaged or if the plates do not move freely, renew the assembly.
15. Check the distributor cap for signs of tracking or cracks and check that the pick-up brush moves freely in its holder.
16. Check the rotor arm for damage, electrode security, and burning or tracking.

### Reassembling

17. Reverse the procedure in 1 to 11, noting the following:
  - a. Lubricate the contact pivot post with Retinax 'A' or equivalent grease.
  - b. Ensure that the nylon spacer and steel washer are fitted on the shaft and lubricate the shaft with Rocol MP (Molypad).
  - c. Fit the thrust washer with its raised pips towards the drive dog.
  - d. Fit the drive dog so that the driving tongues are parallel with the rotor arm electrode and to the left of its centre line when the rotor arm points upwards as shown in Fig. 4.
 

**NOTE.**—If a new shaft is fitted, it must be drilled with a  $\frac{3}{8}$  in. (4.76 mm.) drill through the hole in the drive dog. During drilling, push the shaft from the cam end, pressing the drive dog and washer against the body shank.
  - e. Secure the pin in the drive dog by ring punching the holes. If the shaft is new, tap the end of the drive dog with a hammer to flatten the washer pips and ensure the correct end-float.




Fig. B.5

- |                              |               |
|------------------------------|---------------|
| 1. Base plate securing screw | 3. Screw hole |
| 2. Slot in base plate        | 4. Prongs     |
- 'A' = Diameter checking position

- f. Position the base plate assembly so that the two downward pointing prongs will straddle the screw hole below the cap clip, see Fig. B.5. Press the base plate into the body until it engages the undercut.
- g. Take an accurate measurement across the distributor cap register on the body at right angles to the slot in the base plate, Fig. B.5. Position the earth lead and fit and tighten the base plate securing screw. Re-measure across the cap register; if the measurement has not increased by at least 0.006 in. (9.15 mm.), renew the base plate assembly.
- h. Check that the base plate prongs still straddle the screw hole and refit the vacuum unit, engaging the operating arm with the moving plate pin.
- j. Set the contact points gap to 0.014 to 0.016 in. (0.36 to 0.40 mm.).

Section B.5

TIMING

**NOTE.**—The method of checking the 'static' timing given below will give a reasonable degree of accuracy, but to obtain optimum performance from the engine, the 'stroboscopic' timing should be checked using electronic tuning equipment.

Before commencing to check the ignition timing, ensure that the distributor contact points are set to the correct gap; clean and adjust if necessary, see 'MAINTENANCE'.




Fig. B.6

Remove the inspection plate (1) and use a mirror to see the timing marks (2) and pointer (3)

Checking – Static

1. Remove the cover or grommet from the timing inspection aperture in the clutch/converter cover. Use a mirror to see the timing marks on the flywheel/converter, see Fig. B.6 or Figs. Ba.1/Ba.2 (Automatic). Rotate the crankshaft in the direction of engine rotation until the correct static timing mark (see 'ENGINE TUNING DATA') is opposite the timing mark pointer in the inspection aperture.
2. With the pointer opposite the correct timing mark and No. 1 piston on compression, the distributor rotor electrode should be pointing to No. 1 segment in the cap and the contact points just about to break.

Adjusting

3. **Distributor with adjuster nut:** Turn the knurled adjuster (Fig. B.2) towards 'A' or 'R' to correct the adjustment as follows:
  - a. If the points are open, turn the adjuster towards 'R' until they just close.
  - b. If the points are closed, turn the adjuster towards 'A' until they are just about to open.

Each graduation on the vernier scale is equal to approximately 5° of flywheel/converter movement and 55 clicks on the knurled adjuster.

4. **Cooper 'S' and engines with 45D4 type distributor:** Slacken the distributor clamp bolt and turn the distributor clockwise to advance and anti-clockwise to retard the ignition firing point. Tighten the clamp bolt and recheck the setting.

Checking points opening – electrical

5. Connect a 12-volt bulb between the low-tension terminal on the side of the distributor and a good earth point on the engine; switch on the ignition.

6. a. **Distributor with adjuster nut:** If the bulb lights, turn the knurled nut towards 'R' until the light goes out and then back towards 'A' until it just lights.  
If the bulb does not light, turn the nut towards 'A' until it just lights.
  - b. **45D4 distributor and Cooper 'S' type:** Slacken the distributor clamp bolt. If the bulb lights, turn the distributor body anti-clockwise (to retard) until the light goes out and then turn clockwise (to advance) until it just lights.  
If the bulb does not light, turn the distributor body clockwise (to advance) until the bulb just lights.  
Tighten the clamp bolt.
7. Refit the distributor cap.

**Stroboscopic check**

8. Disconnect the vacuum advance pipe from the distributor.
9. Paint the timing marks on the flywheel/converter with white paint.
10. Start and run the engine at the speed recommended in 'ENGINE TUNING DATA' for the particular model application.
11. Adjust as necessary, see operations 3 or 4 as applicable to model and distributor type. Run the engine to above 2,000 r.p.m. and check that the automatic advance is working.
12. Connect up the vacuum advance pipe and refit the inspection plate/grommet.

## SECTION Ba

### THE IGNITION SYSTEM

The information in this Section refers specifically to engines fitted with automatic transmission and must be used in conjunction with Section B

†Timing the ignition .. .. . Section  
.. .. . Ba.1

† This operation must be followed by an exhaust emission check






Fig. Ba.1

The timing mark location on early units. The T.D.C. position is indicated by the 1/4 marking on the converter, 5° and 10° B.T.D.C. marks are also provided. Shown inset, the hole (arrowed) for inserting a suitable tool to turn the converter

### Section Ba.1

#### TIMING THE IGNITION



1. Follow the instructions given in Section B.2 with the following exceptions.
2. To rotate the crankshaft, insert a screwdriver through the aperture (adjacent to the oil dipstick) on the converter housing or end cover, and turn the starter ring gear in the direction of engine rotation to the position described in Section B.2, item 5.
3. The timing marks can be seen on the converter (Figs. Ba.1 and Ba.2) after removal of the rubber grommet on the converter end cover.




Fig. Ba.2

The timing mark location on later units. The converter is marked in degrees from 20° B.T.D.C. to 10° A.T.D.C., the '0' mark indicates the T.D.C. position. Turn the converter with a suitable tool inserted through the hole (arrowed) in the cover

# SECTION C

## THE COOLING SYSTEM

	SECTION
Fan belt .. .. .	C.2
Frost precautions .. .. .	C.4
Radiator .. .. .	C.1
Thermostat .. .. .	C.5
Water pump .. .. .	C.3






Fig. C.1  
The radiator drain plug or tap

## Section C.1

### RADIATOR

The cooling system is under considerable pressure when hot.

Take off the cap slowly, turning it anti-clockwise until you feel the tongues engage the lobes on the end of the filler cam. Allow the pressure to fall before turning further and removing the cap.

#### Draining

1. Drain the system, using the taps (or plugs if fitted) at the base of the radiator and at the rear of the cylinder block.

#### Flushing

2. Flush the system periodically by running water through until it comes out clear. If the radiator is excessively furred up, remove it and flush through in the reverse direction (in through the bottom hose connection) using the reverse flush adaptor 18G 187 with a 1 in. (25 mm.) hose.

#### Filling

3. Close the drain tap(s) or refit the drain plug(s). Fill to the level indicator in the radiator top tank. Use only the recommended anti-freeze when necessary.

#### Removing

4. Remove the bonnet and drain the system.
5. Remove the cowl upper support bracket and the two bolts securing the lower support bracket to the engine mounting.

## C.2

#### One-piece cowling

6. Disconnect the top hose and completely remove the lower.
7. Take out the four screws securing the radiator to the cowling and lift off the radiator and cowling.

#### TWO-PIECE COWLING

8. Disconnect the top and bottom hoses.
9. Take out the six screws securing the radiator to the cowling and remove the top half of the cowling.
10. Bend the lower hose to the outside of the cowling and lift out the radiator.

#### COOPER

##### Removing

11. Drain the system and remove the bonnet and grille.
12. Disconnect the top hose.
13. Detach the upper mounting bracket.
14. Remove the top half of the cowling.
15. Take out the two screws in the bottom half of the cowling securing the lower mounting bracket.
16. Disconnect the heater hose from the bottom radiator hose and the radiator hose.
17. Remove the fan and lift out the radiator.

##### Refitting

Reverse the removal instructions.

## Section C.2

### FAN BELT

#### Removing

1. Slacken the dynamo pivot and adjusting link bolts.
2. Lift the dynamo and run the belt off the crankshaft pulley.
3. Manoeuvre the belt between the fan blades and the right-hand top of the cowling.




Fig. C.2  
The cylinder block drain plug or tap




Fig. C.3

The filler cap of the sealed cooling system removed, showing the water level indicator

- If the fan is 16-bladed, feed the belt between individual blade tips and the cut-out in the cowling flange.

**Refitting**

Reverse the removing instructions.

**Adjusting**

Adjust the tension by moving the dynamo so that the belt can be moved 1 in. (25 mm.) at the centre of its longest run.

**Section C.3**

**WATER PUMP**

**Removing**

- Drain the system and remove the radiator.
- Disconnect the hose from the water pump inlet connection and slacken the top clip of the by-pass hose.
- Unscrew four set screws and lift off the pump.

**Dismantling**

- Withdraw the bearing locating wire through the hole in the top of the pump body.
- Tap the spindle backwards to extract the spindle and bearing assembly.
- Pull the vane from the spindle and remove the seal.

**Reassembling**

Reverse the dismantling instructions.

**Refitting**

Reverse the removing instructions.

**Section C.4**

**FROST PRECAUTIONS**

Damage due to freezing can be prevented by draining the system when the car is not in use, or by the addition of anti-freeze. When a heater is fitted anti-freeze must be used as there is no provision for satisfactorily draining the heater matrix.

Use only the anti-freeze of the ethylene glycol type: Bluecol is recommended. Also, any anti-freeze to B.S.3151 or B.S.3152 is approved.

**Quantity of anti-freeze required**

Anti-freeze %	Commences to freeze		Frozen solid		Amount of anti-freeze		
	°C.	°F.	°C.	°F.	Pts.	US pts	Litres
25	-13	9	-26	-15	1½	1.8	.85
33½	-19	-2	-36	-33	2	2.5	1.18
50	-36	-33	-48	-53	3¼	3.75	1.8

**Section C.5**

**THERMOSTAT**

**Removing**

- Drain the cooling system (Section C.1).
- Disconnect the top hose and remove the cowling upper support bracket.
- Remove the securing nuts and spring washers from the thermostat cover and the cover from its studs.
- Remove the paper joint washer and lift out the thermostat.




Fig. C.4


Turn the fan blades to the position indicated where the fan belt can be extracted through the recess provided in the radiator cowling

**Testing**

5. Test the thermostat opening temperature by immersing it in water and raising the temperature of the water to the thermostat opening temperature as given under 'GENERAL DATA'. If the thermostat valve fails to open or sticks in the fully open position, fit a new one; do not attempt to repair it.

**Refitting**

6. Installation of the thermostat assembly is the reverse of the removal procedure. Fit a new joint washer if the existing one is damaged.
7. A wax-element-type thermostat together with a modified thermostat water outlet cover is fitted to later vehicles.
8. When refitting this type of thermostat it is essential that the threaded stem faces upwards.

**Fig. C.5**

A section through the water pump showing the location of the components. When assembled, the hole (A) in the bearing must coincide with the lubricating hole in the water pump and the face of the hub (B) must be flush with the end of the spindle. The clearance at (C) must be .020 to .030 in. (.508 to .762 mm.)

## SECTION D

### THE FUEL SYSTEM

	SECTION
† Air cleaner .. .. .	D.7
† Carburettor .. .. .	D.6
Fuel pump (Moke) .. .. .	D.8
Fuel pump:	
Type PD .. .. .	D.3
Type SP .. .. .	D.4
Testing .. .. .	D.5
Fuel tank .. .. .	D.1
Fuel tank (Moke) .. .. .	D.9
Tank gauge unit .. .. .	D.2
Twin fuel tanks (Cooper 'S') .. .. .	D.10

† These operations must be followed by an exhaust emission check






Fig. D.1  
The fuel tank located on the left-hand side of the luggage compartment

### Section D.1

#### FUEL TANK

##### Removing

1. Unscrew the tank drain plug (when fitted) approximately three turns, otherwise, disconnect the flexible hose from the pump and drain the tank.
2. Take off the filler cap, disconnect the lead from the gauge unit and unscrew the bolt from the securing strap. Release the vent pipe clip and remove the tank from the luggage compartment, at the same time drawing the fuel and vent pipes through the floor. Note the locating plate fitted below the tank.

#### VAN, PICK-UP, AND LATER TRAVELLER

3. Remove the six flange screws and spacers and lower the tank.

#### TRAVELLER (EARLY MODELS)

4. Remove the trim liner from the body above the tank, and the metal finishers from the rear seat squab support.
5. Lift out the luggage platform, disconnect the battery and ease the trim panel away from the tank.
6. Drain the tank and disconnect the drain and fuel delivery pipes. Take off the filler cap.
7. Disconnect the fuel gauge lead and pull the breather pipe from the tank.
8. Unscrew the support bracket screws and lift the tank from the vehicle.

##### Refitting

#### SALOON

9. Reverse the removal instructions. Note that the vent pipe passes through the same hole as the wiring harness. The seal between the drain pipe housing and the body must be watertight. Refit the locating strip before the strap is tightened.

#### VAN, PICK-UP, AND TRAVELLER

Reverse the removal instructions.

### Section D.2

#### TANK GAUGE UNIT

##### Removing

1. Disconnect the battery earth cable and the electrical connection from the fuel gauge tank unit.
2. Ensure that the fuel level in the tank is below that of the fuel gauge unit aperture.
3. Remove the six securing screws to remove the unit. On later models remove the tank unit locking ring with Service tool 18G 1001 and carefully remove the unit from the tank.

##### Refitting

4. When refitting the gauge unit, use a new joint washer coated with a suitable sealing compound.
5. On later models fit a new rubber sealing ring and tighten the unit locking ring with the Service tool.




Fig. D.2  
The tongue of the fuel tank locating plate must be secured in the slot in the luggage compartment floor

## Section D.3

**FUEL PUMP—TYPE PD**

Apart from cleaning the filter and contact points, no servicing is possible; if the pump fails a new one must be fitted.

**Removing**

1. Disconnect the leads, slacken the clamp screws, and pull off the fuel pipes. Unscrew the bracket screws and remove the pump and bracket.

**CLEANING THE FILTER**

2. Remove the pump and take off the bottom cover plate. Extract the filter and clean it with a brush and petrol (fuel). Fit a new cover gasket.

**POINTS**

3. Lift off the top cover and clean the points by drawing a piece of clean paper between them.
4. Check that the points make good contact and that the gap between the end of the upper blade and its stop face is not less than .015 in. (.4 mm.).

**Refitting**

5. Reverse the removing instructions.

## Section D.4

**FUEL PUMP—TYPE SP AND AUF 201**

The pump is mounted on the lower left-hand flange of the rear sub-frame.

**Removing**

1. Disconnect the battery, the pump leads, and both hoses.
2. Unscrew the nut securing the pump clamp to the bracket and lift off the pump and clamp.

**Refitting**

3. Reverse the removing instructions.

**Dismantling**

4. Screw the inlet nozzle from the pump body and withdraw the filter and fibre washer.
5. Unscrew the six screws securing the coil housing to the body, separate the housing, diaphragm, and body.
6. Withdraw the retainer screw, retainer, and valves.
7. Unscrew the armature from the inner rocker trunnion and remove the brass rollers, feed spring and impact washer from the armature.
8. Remove the terminal nut, Lucar connector and washer from the terminal screw and take off the bakelite cap.




Fig. D.3  
The PD-type fuel pump

9. Unscrew the spring blade securing screw and disconnect the coil lead. Remove the terminal screw retaining nut; cut the lead washer.
10. Unscrew the two pedestal retaining screws and disconnect the braided copper earth lead.
11. Remove the remaining coil lead from the terminal screw and the screw from the pedestal.
12. Push the rocker pivot pin from the pedestal and remove the rocker assembly. Do not remove the toggle spring.


**Inspecting**

13. Clean and examine all parts.
14. Check the feed spring; test figures are given in 'GENERAL DATA'.
15. Check the condition of the valves and springs.
16. If the points are pitted or burnt, fit a new rocker assembly.

**Assembling**

17. Refit the valves and retainer.
18. Screw the nozzle, with a new washer, into the body.
19. Refit the rocker assembly.
20. Refit the terminal screw, spring washer, short coil lead, new lead washer and nut.
21. Connect the braided copper earth lead to the nearest pedestal screw with the tag next to the head of the screw; screw the pedestal to the coil housing.
22. Refit the remaining coil lead and the spring blade. The blade must bear against the small rib on the top face of the pedestal, and the tag of the solenoid lead must be on top of the blade.
23. Adjust the spring blade so that the points are making good contact and the points on the blade wipe over the centre line of the other points when the rocker arm is moved up and down. Tighten the spring blade screw.

THE AUF 201 and SP FUEL PUMP COMPONENTS




B3463

No.	Description	No.	Description	No.	Description
1.	Pump body (AUF 201 only).	17.	Terminal stud.	35.	Set screw.
2.	Diaphragm and spindle assembly.	18.	Spring washer.	36.	Inlet and outlet nozzles.
3.	Armature centralizing roller.	19.	Lead washer.	37.	Inlet valve.
4.	Impact washer.	20.	Terminal nut.	38.	Outlet valve.
5.	Armature spring.	21.	End-cover seal washer.	39.	Sealing washer.
6.	Coil housing.	22.	Contact blade.	40.	Filter.
7.	Set screw.	23.	Washer.	41.	Gasket.
8.	Earth connector.	24.	Contact blade screw.	43.	Sealing band.
9.	Set screw.	27.	Spring washer.	44.	Pump body.
10.	Spring washer.	28.	Screw.	45.	Outlet valve.
11.	Terminal tag.	29.	End-cover.	46.	Valve retainer.
12.	Terminal tag.	30.	Shakeproof washer.	47.	Screw.
13.	Earth tag.	31.	Connector.	48.	Inlet valve.
14.	Rocker pivot arm.	32.	Nut.	49.	Filter.
15.	Rocker mechanism.	33.	Insulating sleeve.	50.	Washer.
16.	Pedestal.	34.	Clamp plate (AUF 201 only).	51.	Inlet nozzle.

AUF 201 only.

SP type only.

24. The free end of the spring blade must be deflected away from the rib on the pedestal so that a gap exists between the under-side of the blade and the rib.
25. Refit the impact washer and the spring to the armature spindle, pass the spindle through the centre of the coil housing and screw it into the trunnion on the inner rocker.
26. Screw the spindle into the trunnion until a steady pressure on the armature just fails to cause the outer rocker to snap over. Then unscrew the spindle seven holes (for body and coil housing screws).
27. Position the rollers, fit the body to the coil housing and tighten the securing screws.
28. Refit the bakelite cap, spring washers, Lucar connector, nut and terminal screws.
29. Refit the rubber sleeve, and the dust excluders to the inlet and outlet connections.



A9300

Fig. D.5  
The rocker finger settings

- |    |                                       |    |               |
|----|---------------------------------------|----|---------------|
| A. | .035 in.±.005 in. (.89 mm.±.12 mm.).  |    |               |
| B. | .070 in.±.005 in. (1.78 mm.±.12 mm.). |    |               |
| 1. | Pedestal.                             | 4. | Inner rocker. |
| 2. | Contact blade.                        | 5. | Trunnion.     |
| 3. | Outer rocker.                         | 6. | Coil housing. |

**AUF 201 type pump**

This type of pump is fitted to later vehicles. The instructions given for the SP pump apply, with the exception of items, 4, 6, and 18; for item 4 substitute instructions 30 and 31.

30. Unscrew the two screws securing the spring clamp plate which holds the inlet and outlet nozzles. Remove the nozzles, filter and valve assemblies, being careful to note their correct positions for replacement.

**Rocker finger settings (AUF 201)**

31. After reassembly the spring blade of the contacts should rest against the ridge of the pedestal mounting when the outer rocker is pressed onto the coil housing and a gap of .030 in. (.76 mm.) should exist between the points. When the outer rocker is released the spring blade should be deflected away from the ridge. If necessary, set the blade and/or rocker fingers to achieve this position.




Fig. D.4  
The SP-type fuel pump

**Section D.5**

**FUEL PUMP TESTING**

1. Fit the SP adaptor set to a test rig, and a cut-away cap to the pump. Connect the pump to a 12-volt battery with a voltmeter and resistance in circuit.

**Priming**

2. The pump should prime from dry in 10 to 15 seconds and the paraffin (kerosene) should rise in the glass container until it runs from the overflow drain pipe. If the level does not rise above the small hole in the drain pipe, the pump is faulty. Initial air bubbles should cease after a minute or two; if they do not, there is an air leak on the suction side.

**Valves**

3. Run the pump for about 10 minutes and turn off the fuel tap. If the pump beats within 12 seconds, the inlet valve is not seating correctly.

**Minimum delivery**


4. Partly open the fuel tap and gradually depress the spring blade to reduce the stroke. The pump should continue working with increasing frequency until it stops owing to the lack of a gap between the points.

**Reduced voltage**

5. The pump should work satisfactorily at a minimum of 9.5 volts.



## THE CARBURETTOR COMPONENTS



A3958 E

No.	Description	No.	Description	No.	Description
1.	Body.	17.	Jet needle.	34.	Throttle spindle nut.
2.	Piston lifting pin.	18.	Float-chamber body.	35.	Tab washer for nut.
3.	Spring for pin.	19.	Float-chamber securing bolt.	36.	Idling stop screw.
4.	Circlip for pin.	20.	Float and lever assembly.	37.	Spring for stop screw.
5.	Suction chamber and piston assembly.	21.	Lever hinge pin.	38.	Cam lever.
6.	Needle locking screw.	22.	Float-chamber lid assembly.	39.	Washer.
7.	Piston damper assembly.	23.	Washer for lid.	40.	Cam lever spring.
8.	Washer for damper cap (fibre).	24.	Needle and seat assembly.	41.	Cam lever pivot bolt.
9.	Piston spring.	25.	Screw—float-chamber lid to body.	42.	Pivot bolt tube.
10.	Screw—suction chamber to body.	26.	Spring washer.	43.	Spring washer.
11.	Jet assembly.	28.	Throttle spindle.	44.	Pick-up lever assembly.
12.	Jet bearing.	29.	Throttle disc.	45.	Jet link.
13.	Washer for jet bearing (brass).	30.	Screw—throttle disc.	46.	Jet link retaining clip.
14.	Lock screw for jet bearing.	31.	Throttle lever.	47.	Jet link securing screw.
15.	Lock spring	32.	Cam stop screw.	49.	Spring for pick-up lever.
16.	Jet adjusting screw.	33.	Spring for stop screw.		

Section D.6

CARBURETTERS



**IMPORTANT.**—The instructions given in this section for adjusting, dismantling and reassembling the carburetters applies only to cars not fitted with exhaust emission control equipment. Carburetters fitted to cars with exhaust emission control equipment must be tuned and serviced in accordance with the instructions given in Workshop Manual Supplement AKD 4957 A.

**Dismantling**

1. Unscrew the plug and withdraw the piston damper.
2. Take out the two suction chamber securing screws, lift off the suction chamber and withdraw the piston and jet needle.
3. Disconnect the rod from the bottom of the jet, and the nylon feed tube from the base of the float-chamber; pull out the jet and tube.
4. Unscrew and remove the jet adjusting nut and the spring.
5. Unscrew the jet bearing locking nut.
6. Remove the float-chamber securing bolt and the float-chamber.
7. Take out three screws and lift off the top of the float-chamber; withdraw the float.
8. Screw out the needle valve assembly.

**Inspecting**

9. Note the condition of the needle valve and seating; fit a new needle and seating if necessary.
10. If the jet needle is bent or otherwise damaged, withdraw the locking screw in the piston and fit a new needle. Push the needle in until the shoulder is flush with the lower face of the piston.
11. Clean and dry the piston assembly; lubricate the piston rod only with thin oil.

**Reassembling**

Reverse the dismantling instructions and centre the jet.

**Jet centring**

12. Screw the jet adjusting nut up as far as possible, lift the piston with the lifting pin and allow it to drop; it should drop freely onto the bridge with a soft metallic click. Repeat with the adjusting nut screwed fully down. If the piston does not fall freely in either of the tests, proceed as follows.
13. Carry out instructions 3 and 4 above.
14. Refit the adjusting nut without the spring and screw it up as far as possible.
15. Slacken the jet bearing lock nut until the bearing can be turned with the fingers.
16. Remove the piston damper and press the piston down onto the bridge. Tighten the lock nut.




Fig. D.6  
The carburettor adjusting screws

- |                                |                             |
|--------------------------------|-----------------------------|
| 1. Jet adjusting nut.          | 4. Jet locking nut.         |
| 2. Throttle adjusting screw.   | 5. Float-chamber bolt.      |
| 3. Fast-idle adjustment screw. | 6. Jet link securing screw. |

17. Lift the piston and note whether it falls freely; fully lower the adjusting nut and check again. If the second check produces a sharper click than the first, repeat the centring.
18. Refit the parts that have been removed, pour thin oil into the hollow rod of the piston damper to within .5 in. (12.7 mm.) of the top of the rod.

**Adjustments**

**SLOW RUNNING**

19. Turn the throttle adjusting screw as necessary.

**MIXTURE**

20. Run the engine until it is at its normal temperature.
21. Disconnect the choke cable.
22. Unscrew the throttle adjusting screw until the throttle is fully closed and then screw it up about one turn.
23. Hold the jet up against the adjusting nut and then turn the nut until the engine runs smoothly without missing or hunting.
24. Raise the piston about  $\frac{1}{32}$  in. (1 mm.). If there is a momentary increase in speed the adjustment is correct; if the engine stops the mixture is too weak; and if it continues to increase even when the piston is raised  $\frac{1}{4}$  in. (7 mm.) the mixture is too rich.
25. Adjust the idling speed as required.
26. Set the fast idling screw so that there is a clearance of about  $\frac{1}{64}$  in. (.4 mm.) between the cam and the end of the screw when the engine is warm and idling with closed throttle. Alteration may be needed after the mixture has been adjusted. Re-connect the choke cable.




Fig. D.7

A section through the carburettor showing:

- |                       |                            |
|-----------------------|----------------------------|
| 1. Jet locking nut.   | 5. Piston lifting pin.     |
| 2. Jet adjusting nut. | 6. Needle securing screw.  |
| 3. Jet head.          | 7. Piston damper oil well. |
| 4. Nylon fuel pipe.   |                            |

27. Fuel starvation or flooding may be caused by an incorrect float level. To check the level, insert a  $\frac{5}{16}$  in. (8 mm.) bar between the lip of the float-chamber and the hinged lever. Adjust by bending the lever where the curved portion meets the shank. On carburettors fitted with a nylon float use a test bar of  $\frac{1}{8}$  in. (3.18 mm.) diameter.

### Flooding

This may be caused by an incorrect float level or by a faulty needle valve.

28. Remove, clean, and inspect the needle valve and seating; fit a new assembly if necessary.  
29. Check the float level.

### COOPER SLOW-RUNNING

30. As instruction 19 but turn both screws an equal amount. Listen to the hiss at the carburettor intake and adjust the screws until the intensity of the hiss at each is the same.

### MIXTURE

31. Carry out instructions 20 to 23 on each carburettor moving both nuts the same number of turns.  
32. Raise the piston on the left-hand carburettor about  $\frac{1}{32}$  in. (.8 mm.). If the engine speed increases the mixture is too rich; if the engine speed immediately decreases the mixture is too weak; if the engine speed momentarily increases very slightly the mixture is correct.  
33. Repeat 32 on the right-hand carburettor.  
34. Re-adjust the slow-running speed as necessary.

### LINKAGE ADJUSTMENT, FIG. D.8

35. Disconnect the choke cable. With the throttle shaft levers free on the shaft, put a .012 in. (.30 mm.) feeler between the shaft stop and the choke inter-connecting spindle. Move each throttle lever downwards until the pin rests lightly on the lower arm of the fork in the carburettor throttle lever. Tighten the clamp of the throttle shaft lever. When both carburettors are adjusted the pins on the throttle levers should then have the correct clearance in the forks. Re-connect the choke cable and ensure that the jet heads return against the jet adjusting nuts when the choke knob is pushed fully in. Adjust the fast idling screws.

### Section D.7

### AIR CLEANER



Renew the filter element at the recommended periods.

### Removing

1. Unscrew the wing nut at the top of the cleaner, remove the cover and extract the element.

### Refitting

2. Reverse the removal procedure.




Fig. D.8

The feeler between the throttle shaft stop and the choke interconnecting spindle

**COOPER**

**Gauze filters**

**Removing**

3. Detach the breather hose and remove the four retaining screws to remove the air cleaners.

**CLEANING**

4. Wash the gauzes thoroughly in fuel, dry and re-oil with engine oil.

**REFITTING**

5. Reverse the removal procedure, fitting new joint washers if necessary.

**COOPER**

**Dry element filter**

Renew the filter elements at the recommended periods.

**REMOVING**

6. Remove the two wing nuts and washers and remove the cover, lift out the paper elements and wipe the inside of the container to remove all dust deposit. The container may also be removed if required by careful manoeuvring over the carburetters, after releasing the throttle lever return spring and the breather hose (if fitted).

**REFITTING**

7. Reverse the removal procedure, ensuring that the air manifold rubber seals are correctly positioned if the container has been removed.

**Section D.8**

**FUEL PUMP  
(Moke)**

The fuel pump is located in the pannier of the left-hand side-member (Fig. D.9).

**Removing**

1. Disconnect the battery.
2. Remove the pannier side cover (two quick-release fasteners).
3. Disconnect the lead from the pump terminal.
4. Slacken the clips and pull the hose from the delivery pipe, and the suction hose from the pump.
5. Remove two nuts to release the mounting bracket.

**Dismantling and assembling**

6. Follow the instructions in Section D.4.

**Refitting**

7. Reverse the removing instructions, tighten all clips, and secure the earth lead with one of the mounting bracket nuts.




Fig. D.9  
The fuel pump location in the left-hand side-member

**Section D.9**

**FUEL TANK  
(Moke)**

The fuel tank is located in the left-hand side-member. Remove the tank for access to the gauge unit.

**Removing**

1. Remove the forward pannier side cover and disconnect the lead from the fuel gauge unit terminal.
2. Drain the fuel tank (see Fig. D.10).
3. Disconnect the suction hose from the fuel pump.
4. Remove the bottom cover-plate from the side-member.
5. Extract the tank-retaining screw from the top face of the side-member.
6. Remove the support bracket and lower the tank.

**Refitting**

7. Reverse the removal instructions.

**Section D.10**

**TWIN FUEL TANKS  
(Cooper 'S')**

**Removing**

**BOTH TANKS**

1. Remove the trimmed floorboard.
2. Disconnect the battery earth cable.
3. Remove the spare wheel.
4. Remove the fuel filler caps.
5. Unscrew the drain plug on the left-hand tank approximately three turns and allow the fuel to drain from both tanks.

**LEFT-HAND TANK**

6. Disconnect the electrical connections from the tank gauge unit.
7. Remove the tank strap securing bolt.
8. Disconnect the flexible fuel pipe and the vent pipe from the tank.
9. Ease the tank to the centre of the luggage compartment and withdraw it.

**RIGHT-HAND TANK**

10. Disconnect and remove the battery.
11. Carry out instruction 7 and disconnect the flexible hose from the left-hand tank.
12. Move the tank slightly from its mountings, taking care not to damage the flexible fuel pipes. The tank will still retain a small amount of fuel which should be drained off into a small container when the flexible fuel pipe is disconnected.
13. Disconnect the flexible fuel pipe.
14. Release the vent pipe from the tank and withdraw the tank from the luggage compartment.




Fig. D.10  
The fuel tank drain plug access

**Refitting**

15. Reverse the removal instructions.
16. Ensure that the seal around the drain plug housing is watertight.

## SECTION Da

### THE FUEL SYSTEM

The information in this Section refers specifically to engines fitted with automatic transmission and must be used in conjunction with Section D

	SECTION
† Air cleaner .. .. .	Da.1
† Carburetter .. .. .	Da.2

† These operations must be followed by an exhaust emission check



## Section Da.1

## AIR CLEANER



Cars equipped with automatic transmission are fitted with a larger paper-element-type air cleaner.

## Removing

1. Unscrew the wing nuts.
2. Disconnect the breather hose.
3. Lift the air cleaner from the carburetter.

## Element replacement

4. Remove the cover from the container and lift out the paper element.
5. Wipe all dust deposit from inside the container.
6. Fit the new element and refit the cover.

## Refitting

7. Reverse the removal procedure.

**NOTE.**—The air cleaner intake should be positioned adjacent to the exhaust manifold during winter operating conditions in order that the possibility of carburetter icing is reduced to the minimum. It is advisable to move the intake away from the manifold in warmer weather.

## Section Da.2

## CARBURETTER



(Type HS4)

## Description

The HS4 carburetter is fitted to an engine equipped with automatic transmission.

The dismantling and reassembling of the carburetter is as described for the HS2 type in Section D.6.

**IMPORTANT.**—The instructions given in this section for adjusting, dismantling and reassembling the carburetters applies only to cars not fitted with exhaust emission control equipment. Carburetters fitted to cars with exhaust emission control equipment must be tuned and serviced in accordance with the instructions given in **Workshop Manual Supplement AKD 4957 A**.

## Removing

1. Remove the air cleaner as detailed in Section Da.1.
2. Disconnect the mixture and throttle control cables, the suction advance pipe, and the fuel delivery hose from the carburetter.
3. Disconnect the governor control rod fork end from the throttle lever.




Fig. Da.1  
The HS4 carburetter

- |                              |                               |
|------------------------------|-------------------------------|
| 1. Jet adjusting nut.        | 3. Fast idle adjusting screw. |
| 2. Throttle adjusting screw. | 4. Governor control rod.      |
4. Remove the securing nuts and spring washers and lift off the carburetter and the cable abutment plate.

## Refitting

5. Reverse the removal instructions, fitting new joint washers between the manifold face and the abutment plate and carburetter flange if any have been damaged during removal.

## Adjustments

The method of adjusting the jet and slow running is as described in Section D.6 with the following exceptions.

6. Connect a tachometer.
7. Select 'N' on the gear lever quadrant and apply the hand brake.
8. Run the engine until it attains its normal running temperature and adjust the jet as described in Section D.6.
9. With the carburetter correctly tuned, adjust the throttle adjusting screw 2 (Fig. Da.1) until a maximum idling speed of 650 r.p.m. is obtained.
10. Pull out the choke control to the maximum fast idle position. Check, and adjust if necessary, the fast idle adjustment screw 3 (Fig. Da.1), to obtain a maximum fast idle speed of 1,050 r.p.m. Push in the choke control and re-check the idling speed.
11. Adjust the governor control rod as detailed in Section Fa.2.

## **SECTION Db**

### **THE FUEL SYSTEM**

**The information contained in this Section refers specifically to new or modified components fitted to the Mini range coincident with the introduction of NEGATIVE earth electrical systems and must be used in conjunction with Sections D and Da.**

	<b>SECTION</b>
Fuel pump—mechanical (type AUF 705) .. .. .	Db.1
Testing .. .. .	Db.2



## Section Db.1

### MECHANICAL FUEL PUMP (Type AUF 705)

#### General description and operation

The pump is mounted on the rear left-hand side of the crankcase and is driven from the camshaft. The cam lobe actuates the rocker lever which moves the diaphragm downwards. Fuel is drawn in through the filter, down past the inlet valve flap, and into the diaphragm chamber. When the cam lobe passes the rocker lever the diaphragm moves upwards under the influence of the spring and forces fuel through the outlet valve.

When the float needle valve closes, the diaphragm stays in the down position and the rocker arm idles until the pressure drops.

#### Maintenance

##### FILTER CLEANING

1. Clean the outside of the pump and mark the cover and body for alignment when refitting (see Fig. Db.1 for correct positions of the inlet and outlet connections).
2. Remove the outlet cover, sealing washer, and filter.
3. Clean any sediment from the filter chamber and clean the filter (air jet or fuel).
4. Fit a new joint washer (if necessary), refit the outlet cover and tighten the screws evenly.

##### Fault diagnosis

5. To check the fuel flow, disconnect the fuel hose at the carburettor and put the end into a container. Disconnect the (-) connection from the ignition coil and turn the crankshaft by operating the starter.
  - a. Flow normal—examine float needle valve and seating.
  - b. Flow normal, but falls off rapidly—check fuel tank venting. Other causes: choked pump or tank filter.
  - c. Air bubbles emerge—air leak on suction side.
  - d. No flow—dismantle pump, examine valves and diaphragm.

**DO NOT PASS COMPRESSED AIR THROUGH THE PUMP.**

##### Removing

6. Disconnect the battery and remove the air cleaner for access.
7. Disconnect and remove the fuel pump to carburettor feed pipe, disconnect the fuel pump feed pipe.
8. Remove the pump securing nuts and partially pull the pump from the engine. Use a screwdriver and separate the insulating block from the pump; pull out the pump followed by the insulating block.  
**The total thickness of the insulating block with its two joint washers must not be altered.**




Fig. Db.1  
The fuel pump location

- |                      |                          |
|----------------------|--------------------------|
| A. 1275 GT.          | B. 850/1000 and Clubman. |
| 1. Inlet connection. | 2. Outlet connection.    |

#### Dismantling

##### REFER TO FIG. Db.2

9. Mark the outlet cover and the upper and lower bodies for alignment (arrowed).
10. Remove the outlet cover, sealing washer and filter.
11. Unscrew the three short securing screws and remove the upper body.
12. Remove the combined inlet/outlet valve.  
**NOTE.**—The valve is a press fit; take care not to damage the fine edge of the inlet valve.
13. Hold the diaphragm and rocker lever against spring pressure, and tap out the rocker lever pivot pin.
14. Remove the rocker lever and spring.
15. Withdraw the diaphragm and spring, lubricate the crankcase seal to avoid damage as the spindle stirrup is pulled through.
16. Remove the crankcase seal and retaining cup only if the seal is to be replaced.  
**Replacing seal.** Screw centre of service tool 18G 1119 into the retaining cup and withdraw the cup from the lower body.

#### Inspection

Examine components for wear and damage, particularly the diaphragm, the fine edge of the inlet/outlet valve, and the insert in the outlet cover.

#### Reassembling

17. Reverse the dismantling sequence, noting the following:
  - a. Press the retaining cup into the lower body using 18G 1119.
  - b. Remove any sharp edges from the diaphragm spindle and stirrup, lightly oil, position stirrup slot for engagement by the rocker lever.
  - c. Ensure that the inlet/outlet valve groove registers in the housing, and that the fine edge of the inlet valve contacts its seating evenly.




Fig. Db.2  
The fuel pump components. Mark the components (arrowed) for correct reassembly.

- d. Line up the screw holes in the lower body and the holes in the diaphragm, depress the rocker lever so that the diaphragm lies flat, fit the short screws and leave slack. Fit the filter, sealing washer, and outlet cover; tighten all screws evenly.
- e. Test pump—Section Db.2.

### Refitting

18. Reverse the removing procedure, using new joints on the fuel pump insulating block.
19. Switch on the ignition and use the starter continuously for 20 seconds to prime the pump.





Fig. Db.3

Testing the pump for suction (above) and for pressure (below) using Service tool 18G 1116

### Section Db.2

#### TESTING THE FUEL PUMP

Dry test before dismantling a suspect pump and after reassembly (see Fig. Db.3).

#### Testing using 18G 1116

##### SUCTION

1. Connect the gauge to the inlet nozzle.
2. Operate the rocker lever, using the extension lever, through three full strokes. Minimum vacuum reading 6 in. (150 mm.) Hg, must not drop more than 2 in. (50 mm.) in 15 seconds.
3. Disconnect the gauge.

##### DELIVERY

4. Connect the gauge to the outlet nozzle.
5. Operate the rocker lever, using the extension lever, through two full strokes. Minimum pressure reading 3 lb./sq. in. (.2 kg./cm.<sup>2</sup>), must not drop more than ½ lb./sq. in. (.04 kg./cm.<sup>2</sup>) in 15 seconds.

#### Testing without gauge

A reasonable indication of pump condition can be obtained using the following procedure:

##### SUCTION

1. Hold a finger over the inlet nozzle and operate rocker lever through three full strokes.
2. Release finger; a noise caused by suction should be heard.

##### DELIVERY

3. Hold a finger over the outlet nozzle and depress the rocker arm fully. Pressure should hold for up to 15 seconds.

**SECTION E****THE CLUTCH**

	<b>SECTION</b>
Adjustments .. .. .	E.2
Overthrow	
Pedal movement	
Throw-out stop	
Clutch cover alignment .. .. .	E.7
Drag .. .. .	E.3
Master cylinder .. .. .	E.4
Overhaul (coil pressure spring type) .. .. .	E.1
Removal (diaphragm spring type) .. .. .	E.6
Slave cylinder .. .. .	E.5




Fig. E.1

A section through the clutch assembly

- |                              |                              |
|------------------------------|------------------------------|
| 1. Driving strap.            | 14. Driving pin.             |
| 2. Lock washer.              | 15. Lock washer.             |
| 3. Driving pin.              | 16. Driving strap.           |
| 4. Pressure spring.          | 17. Flywheel.                |
| 5. Circlip.                  | 18. Starter ring.            |
| 6. Key plate.                | 19. Pressure plate.          |
| 7. Flywheel screw.           | 20. Driven plate.            |
| 8. Thrust plate.             | 21. Driven plate hub.        |
| 9. Locking washer.           | 22. Crankshaft primary gear. |
| 10. Pressure spring guides.  | 23. Primary gear bearing.    |
| 11. Guide nut.               | 24. Thrust washer.           |
| 12. Lock washer.             | 25. Crankshaft.              |
| 13. Pressure spring housing. |                              |

5. Unscrew the three driving pins.
6. Unscrew the nuts of the Service tool 18G 304 M, gradually releasing the housing. Remove the housing and the springs.

**Inspecting**

7. Inspect the housing for elongation of the driving pin holes.
8. Inspect the driving pins for ridging and wear; fit three new pins if any are worn.
9. Inspect the driving straps; fit three new ones if any are worn.

**Reassembling**

**NOTE.** -When reassembling, fit the pressure plate to the clutch cover with the marks 'A' adjacent to each other and fit the clutch unit to the flywheel as shown in Fig. E.2.

10. Centralize the driven plate and the flywheel hub with Service tool 18G 571.
11. Locate the springs, housing and driving straps, and tighten the nuts evenly (Service tool 18G 304 M).
12. Insert and tighten the driving pins. If the driving straps have been removed from the flywheel, ensure that the spacing washers are refitted between the straps and the flywheel face.

**Refitting**

13. Reverse the removing instructions (Section A.11).

**Section E.2****ADJUSTMENTS****Pedal movement**

1. Pull the operating lever outwards until all free movement is taken up, then check the clearance between the lever and the stop.

**Section E.1**

**OVERHAUL**  
(Coil Pressure Spring Type)

**Removing**

1. See Section A.11.

**Dismantling**

2. Mark the driving pins, driving straps, and the housing so that these parts can be refitted in their original positions. Note the clutch balance mark (Fig. E.2).
3. Insert the three screws (Service tool 18G 304 M) through the recessed holes in the pressure spring housing and screw them into the flywheel.
4. Screw the nuts down against the housing with the fingers and then tighten them one turn at a time until the load is off the driving pins.





Fig. E.2

The fitted position of the clutch cover, with the balance mark 'A' adjacent to the 1/4 timing mark on the flywheel



A9080

Fig. E.3

The clutch pressure springs being compressed with the aid of Service tool 18G 304 M, with Service tool 18G 571 used to keep the driven plate and flywheel hubs centralized during the operation

2. If necessary, adjust the stop to give a clearance of .060 in. (1.52 mm.). On later models with the throw-out stop, adjust to give a clearance of .020 in. (.50 mm.).

#### Throw-out stop (later models)

Adjustment is normally only necessary if the stop has been removed during overhaul.

3. Screw the stop and locknut away from the clutch housing to the limit of its travel.
  4. Fully depress the pedal.
  5. Screw the stop up against the housing, release the pedal and screw up another .007 to .010 in. (.20 to .25 mm.), approximately one flat of the locknut.
- Re-check the pedal movement (items 1 and 2).

#### Clutch over-throw

##### TO TEST

7. Run the engine at its normal temperature and at about 500 r.p.m.
8. Depress and release the pedal three or four times; if the engine stalls or slows down appreciably, over-throw is occurring.

##### TO RECTIFY

9. Check the pedal movement and test for over-throw.
10. Adjust the pedal movement to a maximum of .075 in. (2.0 mm.) and test for over-throw.
11. Fit a stronger lever return spring and test for over-throw.
12. If over-throw persists, fit new pressure springs.

### Section E.3

#### DRAG

With the car stationary, run the engine and hold the clutch out for several seconds; if drag persists, carry out the following test in sequence.

1. Check for air leaks in the hydraulic system.
2. Check the pedal movement.
3. Check the crankshaft end-float (Section A.25).
4. Dismantle the clutch and fit a new flywheel oil seal (if fitted).

### Section E.4

#### MASTER CYLINDER

##### Removing

1. Disconnect the pedal lever from the push-rod.
2. Unscrew the pipe union from the cylinder.
3. Remove the two bolts securing the unit to the bulkhead.

##### Dismantling

4. Drain out the fluid.
5. Pull back the rubber dust cover.
6. Extract the circlip, dished washer, and push-rod.
7. Withdraw the piston cups and spring from the barrel.
8. Use only the fingers to remove the secondary cup from the piston.




Fig. E.4

A clearance of .060 in. (1.52 mm.) or .020 in. (.50 mm.) on later models must exist between the adjustable clutch return stop and the operating lever




Fig. E.5

A section through the clutch master cylinder

- |                     |                    |                      |
|---------------------|--------------------|----------------------|
| 1. Push-rod.        | 6. Washer.         | 11. Piston.          |
| 2. Rubber boot.     | 7. End plug.       | 12. Piston washer.   |
| 3. Mounting flange. | 8. Circlip.        | 13. Main cup.        |
| 4. Supply tank.     | 9. Stop washer.    | 14. Spring retainer. |
| 5. Body.            | 10. Secondary cup. | 15. Return spring.   |

**Reassembling**

9. Clean all rubber parts with brake fluid and remove all traces of petrol (fuel), kerosene, and trichlorethylene from the metal parts.
10. Fit new rubbers and assemble the internal components lubricated with brake fluid.
11. Stretch the secondary cup over the end flange of the piston with the lip of the cup towards the opposite end of the piston; work it round to ensure correct sealing.
12. Insert the return spring, largest coils first. Make sure the spring seat is positioned on the small end of the spring.
13. Insert the main cup, lip first, and press it down onto the spring seat.
14. Push the piston down the bore and refit the push-rod, circlip, and rubber dust cover.

**Refitting**

15. Reverse the removing instructions and fill up with Lockheed Super Heavy Duty Brake Fluid, or (COOPER), Lockheed Disc Brake Fluid. Bleed the system.

3. Disconnect the push-rod from the clutch lever.

4. Unscrew the two securing bolts and remove the cylinder from the housing.

**Dismantling**

5. Clean the exterior before stripping.
6. Withdraw the rubber boot and push-rod.
7. Remove the circlip, piston, piston cup, cup filler, and return spring.
8. Renew all rubber parts: examine the remainder and renew as required.




Fig. E.6

A section through a clutch slave cylinder

- |                |                 |
|----------------|-----------------|
| 1. Spring.     | 5. Body.        |
| 2. Cup filler. | 6. Circlip.     |
| 3. Cup.        | 7. Rubber boot. |
| 4. Piston.     | 8. Push-rod.    |

**Section E.5****SLAVE CYLINDER****Removing**

1. Attach a bleed tube to the cylinder bleed nipple and a container, pump the pedal and drain out the fluid.
2. Disconnect the pressure pipe.

E.4





Fig. E.7

(1) The clutch fully released, with (2) the throw-out stop screwed up to the cover boss. (3) The clutch fully engaged and the stop (4) screwed up a further .007 to .010 in. (.178 to .254 mm.) towards the cover boss



3NC922

Fig. E.8

Removing the release lever, bearing and plunger assembly from the clutch cover

1. Clutch cover.
2. Plunger stop and locknut.
3. Washer and split pin—clevis pin.
4. Clevis pin—release lever.
5. Release lever.
6. Release bearing assembly.

**Reassembling**

Carry out items 5 to 8 in the reverse order.

**Refitting**

Reverse the removal procedure items 1 to 4 and bleed the system.

**Section E.6**

**CLUTCH  
(Diaphragm Spring Type)**

A diaphragm spring replaces the six conventional coil pressure springs on this clutch assembly.

Remove and refit the flywheel and clutch as detailed in Section A.28.

**Section E.7**


**CLUTCH COVER ALIGNMENT  
(Using Service tool 18G 1247)**

**Removing**

1. Remove the engine/transmission assembly from the car, see Section A.13 or A.33 (rod change transmission).
2. Remove the cover retaining screws and pull off the clutch end-cover.
3. Remove the starter motor.
4. Remove the clutch/flywheel assembly, see Section A.28.

5. Remove the split pin and washer and withdraw the release lever clevis pin, Fig. E.8.
6. Pull the release lever out of the release bearing plunger.
7. Unscrew and remove the plunger stop and locknut; pull out the plunger and release bearing assembly.
8. Clean the cover and the crankshaft taper.
9. Apply engineers marking blue or chalk to the clutch cover register.
10. Insert Service tool 18G 1247 into the cover and refit the cover with the tool locating over the crankshaft taper, Fig. E.9.
11. Push the cover up to the flywheel housing to determine the amount of misalignment of the cover with the flywheel housing.
12. Remove the clutch cover and note the subsequent misalignment markings showing on the marking blue. File off the 'high marked' areas of the register as necessary.
13. Repeat the marking and fitting procedure in operations 9 to 12 as necessary; the cover must be able to contact the flywheel housing without any force being used to ensure correct alignment of the cover with the crankshaft.
14. When correct alignment is obtained, secure the cover in position with two retaining bolts.





3NC943

Fig. E.9

Using Service tool 18G 1247 to align the clutch cover with the crankshaft and flywheel housing  
 Inset 'A': File off the high spots 'arrowed' from the cover register. Inset 'B': Drill cover and housing and fit dowels

1. Clutch cover.

2. Service tool 18G 1247.

3. Dowels.

15. In two diametrically opposite locations, use a No. 40 drill (0.098 in diameter) and drill holes through the end cover and flywheel housing flanges, Fig. E.9.
16. Remove the end-cover and take out Service tool 18G 1247.
17. Lubricate the operating surfaces of the release bearing plunger with a graphite grease and refit the release bearing and plunger assembly into the cover; refit the release lever and clevis pin and secure with a new split-pin, Fig. E.8.
18. Refit the clutch assembly, Section A.28.
19. Refit the clutch cover.
20. Fit the cover retaining bolts loosely.
21. Fit two dowels 2.49 mm dia x 21 mm into the drilled holes to retain the alignment of the end-cover with the flywheel housing.  
**NOTE:** The dowels used are needle-rollers from a bearing; any similar size rollers or dowels may be used provided that the correct size drill is used to ensure an interference fit.
22. Tighten the end cover retaining bolts.
23. Check and adjust if necessary, the clutch throw-out stop adjustment and the return stop adjustment, see Section E.2.
24. Refit the engine/transmission, see Section A.13 or A.33 (rod change transmission) as applicable.

# SECTION F

## THE TRANSMISSION

	SECTION
Differential assembly .. .. .	F.4
Gear change lever (rod-change type) .. .. .	F.7
Gear change remote control assembly (early type) .. .. .	F.6
Gear change remote control assembly (rod-change type) .. .. .	F.8
Gear change selector shaft oil seal (rod-change transmission) .. .. .	F.11
Remote control mountings (rod-change transmission) .. .. .	F.9
Synchronizing cones .. .. .	F.5
Third motion shaft	
Three-speed synchromesh transmission .. .. .	F.2
Four-speed synchromesh transmission .. .. .	F.3
Transmission assembly—overhaul (rod-change type) .. .. .	F.10
Transmission—dismantling and reassembling .. .. .	F.1

## NOTE

The gear change remote control shaft lubrication nipple on the differential cover requires attention at major overhaul periods only, when grease should be used.

Not applicable to transmission with rod type gearchange.

## Section F.1

## TRANSMISSION

## Dismantling

1. Remove the transmission casing from the crankcase (Section A.19).
2. Withdraw the idler gear with its thrust washers.
3. Remove the differential assembly (Section F.4).
4. Withdraw the reverse detent plug, plunger, and spring or the reverse light switch and plunger, where fitted.
5. Remove the clamp and key from the inner end of the gear change operating shaft and pull out the shaft.
6. Remove the speedometer pinion bush securing screw and withdraw the bush assembly and pinion.
7. Remove the speedometer gear retaining plate and the gear.
8. Remove the securing nuts and screws, and pull off the front cover.
9. Remove the selector interlocking arm.
10. Disconnect the oil suction pipe from the bracket (where a clip is fitted), and the flange and withdraw the pipe from the strainer.
11. Extract the circlip and withdraw the first motion shaft roller bearing using Service tool 18G 705 and adaptor 18G 705 C.
12. Use the selector shafts and lock first and third gears together.
13. Tap back the locking washers and remove the first motion shaft nut. Use Service tool 18G 587 to remove the final drive gear nut, and withdraw both the input and final drive gears.
14. Tap back the locking plates, remove the four securing screws and the third motion shaft bearing retainer and packing shims.
15. Remove the layshaft and reverse shaft locking plate, push the layshaft from the clutch side of the casing and remove the laygear and thrust washers.
16. Unscrew the plugs from the outside of the casing and withdraw the selector rod interlocking plungers and springs.
17. Remove the first motion shaft bearing circlip and withdraw the bearing and shaft from the casing with Service tools 18G 284 and 18G 284 B.




Fig. F.1

The four-speed synchromesh transmission assembly, with all the gears assembled into the casing




Fig. F.2  
Removing the third motion shaft bearing

18. Refer to Fig. F.2. Drift the third motion shaft backwards, as indicated by the arrow in (B), until a special Service tool 1 can be placed between the first speed gear 2 and the bearing 3 as illustrated in (C). On three-speed synchromesh gearboxes use 18G 613, and on four-speed units 18G 1127 with their relieved side towards the bearing. These two tools must not be interchanged, or the bearing or casing will be damaged. Drift the third motion shaft forward as illustrated in (D), to push the bearing 3 from the web, taking care not to damage the selector forks. Pull the bearing from the shaft, and lift the shaft from the casing.
19. Remove the strainer assembly.
20. Withdraw the reverse shaft, gear and selector fork.

The following operations are only necessary if complete stripping of the casing is required.

21. Unscrew the selector shaft/fork locking screws and withdraw the shafts and forks.
22. Remove the circlip from the reverse gear shifter lever pivot pin and remove the lever.

### Reassembling

23. If the gearbox has been completely stripped, first refit the reverse gear shifter lever and pivot pin. Push in the selector rods from the front of the casing, engage them with the selector forks, tighten the selector screws, and secure the lock nuts.
24. Position the reverse gear and fork, and refit the reverse shaft, with the plain end foremost.
25. Refit the oil strainer and smear some grease onto the sealing ring to assist when fitting the oil suction pipe.
26. Refer to item 18. Refit the third motion shaft assembly with the slotted end passing through the centre web of the casing. Engage the sliding hubs with the selector forks.
27. Refer to item 17. Drift the first motion shaft and bearing assembly into the casing using Service tool 18G 569 (modified).

Use Service tool 18G 569 to gauge the correct thickness of circlip required to retain the bearing assembly. Try the thicker side of the gauge first; the two sizes are marked on the handle. Refer to Fig. F.3, which illustrates this operation, and fit the circlip selected from the chart beneath it.

28. Refer to item 18. Drift the third motion shaft bearing into the central web using Service tool 18G 579 modified, together with the spacer washer.
29. Refit the laygear with the standard sized thrust washer at one end, and measure the gap at the other. Refer to the chart (Fig. F.4) to select the correct variable thrust washer, to give an end clearance of between .002 and .006 in. (.05 and .15 mm.). On three-speed synchromesh gearboxes the small thrust washer is of a standard size, the large one selective, and vice versa on four-speed synchromesh gearboxes.

Use the dummy layshaft, Service tool 18G 471 to position the thrust washer, and refit the layshaft from the clutch side, with its slotted end positioned horizontally and towards that of the reverse shaft. Refit the layshaft and reverse shaft locking plate.




Fig. F.4

The laygear assembly. With the standard-sized thrust washer fitted, use the table below to select the correct size of variable washer. The part numbers of the thrust washers available for the three-speed and four-speed synchromesh gearboxes are given in columns 'A' and 'B' respectively

- |  |                           |
|--|---------------------------|
| 1. Laygear.  | 4. Needle-roller bearing. |
| 2. Layshaft (un-stepped on three-speed synchromesh units).             | 5. Large thrust washer.   |
| 3. Needle-roller bearings (one only on three-speed synchromesh units). | 6. Small thrust washer.   |

Early three-speed synchromesh gearboxes were fitted with uncaged needle-roller bearings, with which the later caged type are inter-changeable.

WHEN GAP IS	A	B
.125 to .127 in. (3.18 to 3.22 mm.)	88G 325	22G 856
.128 to .130 in. (3.25 to 3.30 mm.)	88G 326	22G 857
.131 to .133 in. (3.32 to 3.37 mm.)	88G 327	22G 858
.134 in. (3.41 mm.)	88G 328	22G 859




Fig. F.3

A section through the idler gear and first motion shaft. Measure the gap 'A' between the bearing face and register with Service tool 18G 569, and fit the appropriate circlip as indicated by the chart below

- |                                       |                                     |
|---------------------------------------|-------------------------------------|
| 1. Idler gear.                        | 4. First motion shaft ball bearing. |
| 2. Idler gear thrust washers.         | 5. First motion shaft circlip.      |
| 3. First motion shaft roller bearing. |                                     |

WHEN GAP IS	USE CIRCLIP PART No.
.096 to .098 in. (2.43 to 2.48 mm.)	2A 3710
.098 to .100 in. (2.48 to 2.54 mm.)	2A 3711

30. Refit the third motion shaft bearing retainer without any shims, lightly tighten the bolts and measure the gap, see Fig. F.5. Fit the shims required (see chart), ensure that they are fitted under the layshaft and reverse shaft locking plate, and finally tighten the bolts and turn over the tab washers.
31. Refer to item (10). Insert the oil suction pipe into the oil strainer assembly, and tighten first the external flange securing bolts and then the bracket retaining bolts. Take care not to displace the oil seal from the strainer.
32. Fit new idler gear needle-roller bearings if required. Engage the expandable collets of Service tool 18G 581 with each old bearing and screw up the nut on the tool to extract them, after removing the outer circlip (when fitted) from the transmission casing boss.




Fig. F.5

A section through the third motion shaft bearing and retainer. Use the following table to ensure that the correct thickness of shim is used

WHEN GAP IS	USE SHIMS TOTALLING
.005 to .006 in. (.13 to .15 mm.)	.005 in. (.13 mm.)
.006 to .008 in. (.15 to .20 mm.)	.007 in. (.18 mm.)
.008 to .010 in. (.20 to .25 mm.)	.009 in. (.23 mm.)
.010 to .012 in. (.25 to .30 mm.)	.011 in. (.28 mm.)
.012 to .014 in. (.30 to .35 mm.)	.013 in. (.33 mm.)
.014 to .015 in. (.35 to .38 mm.)	.015 in. (.38 mm.)

Use Service tool 18G 582 (three-speed synchromesh) or 18G 1126 (four-speed synchromesh) to fit the new bearings. Use the collar supplied with each tool to control the depth to which the bearing is pressed into the flywheel housing, the boss of which must be well supported during this operation. These collars are not required when fitting the transmission casing bearing, since each tool's shoulder governs the depth to which it is pressed. Replace the outer circlip, if fitted.

33. Refer to items 12 and 13. Refit the input and final drive gears, and, using new lock washers tighten the first motion shaft and final drive gear nuts, using Service tool 18G 587 for the latter; the torque figures are given in 'GENERAL DATA'.
34. Refit the first motion shaft roller bearing and circlip.
35. Reverse the instruction in item 16.
36. Refit the selector interlocking arm, the front cover, the speedometer gear and cover, pinion, bush, and pinion housing. Push in the gear change operating shaft, refit its key and clamp, and replace the reverse detent plunger and spring, or the reverse light switch (if fitted).
37. Refit the differential and check adjustment as given in Section F.4.

38. Refit the idler gear and thrust washers, with the chamfered side of each washer against the gear.
39. Refit the flywheel housing with a new joint washer and tighten to the torque figure given in 'GENERAL DATA'.  
Check with feeler gauges that the idler gear has an end-float of between .003 and .008 in. (.08 and .2 mm.), see Fig. F.3. Thrust washers ranging in thickness from .132 to .139 in. (3.34 to 3.54 mm.) are available for adjustment.
40. Remove the flywheel housing and gasket, and refit the transmission unit to the engine as detailed in Section A.19, using a new housing gasket to replace the one used for the idler gear end-float check.

Section F.2

THIRD MOTION SHAFT

Three-speed synchromesh transmission

The baulk ring synchromesh is fitted to Mk. I cars from Engine No. 8AM/U/H412992 and to all Mk. II models. The dismantling and reassembling sequences for the early-type transmission are the same as detailed below except that the second and third/top gear synchronizers are not fitted with baulk rings.

Removing

1. Remove the third motion shaft assembly from the transmission as detailed in Section F.1.

Dismantling

2. Remove the first speed gear, hub and baulk ring from the rear of the shaft, and the top and third gear synchromesh hub and baulk rings from the front of the shaft.
3. Remove the front thrust washer by pressing down the spring-loaded locating plunger and rotating the washer until the splines register with those on the shaft. Withdraw the thrust washer and third speed gear, complete with needle-roller bearings on later type gears, and take out the plunger and spring.

EARLY TYPE GEARS. Withdraw the third gear bush and interlocking ring, followed by the second speed gear and bush and the rear thrust washer.

LATER TYPE GEARS. Depress the spring loaded pegs, turn and remove the second speed gear locking collar and take out the two split washers. Pull the gear from the rear of the shaft, and remove the needle-roller bearings from their journal.

If it is necessary to separate the second or third and fourth speed striking dog from its synchromesh hub and cone assembly, press the assembly into Service tool 18G 572, to retain the three balls and springs which are located in each hub.

**Reassembling****EARLY TYPE GEARS**

4. Fit the rear thrust washer, then the plain half of the split bush with its flat end towards the thrust washer.
5. Fit the second speed gear, with the synchronizer cone facing the rear of the shaft, the interlocking ring and the splined half of the split bush. Engage the dogs of the split bushes with the slots in the interlocking ring. New bushes must be fitted, since the interference fit of the old ones will have been lost when they were removed. Heat the bushes to a temperature of 180 to 200° C. (356 to 392° F.), to allow them to be fitted without force, and to obtain a permanent 'shrink fit' on cooling.
6. Refit and depress the spring and locking plunger, refit the third speed gear, plain side first, and the front thrust washer. Turn the thrust washer until the plunger engages the spline and locks the washer.

**LATER TYPE GEARS**

7. Slide the second speed gear on from the rear of the shaft, plain side first, after sticking the needle-roller bearings to their journal with grease. Replace the two split washers, depress the two spring loaded locking pegs, and refit the locking collar, turning it until the pegs are heard to engage the splines.
8. From the front of the shaft refit the third speed gear, plain side first, with its needle-roller bearings. Slide on the front thrust washer and turn it until the spring loaded peg is heard to lock it.




Fig. F.6

The three-speed synchronesh first and second speed gear assembly, showing the plunger (1) in its drilling in the hub (2) aligned with the cut-away tooth (3) in the gear assembly

**EARLY AND LATER TYPE GEARS**

9. The end-float of both the second and third speed gears when assembled on the third motion shaft must be between .0035 and .0055 in. (.09 and .13 mm.).
10. Refit the top and third speed synchronesh hub and baulk rings, with the plain side of the hub towards the rear of the shaft.
11. Refit the speed gear, hub, and baulk ring, with the cone end of the hub towards the front of the shaft.

Should the first and second speed gear assembly have been dismantled, the gear must be correctly repositioned on the hub, otherwise selection of second gear will be impossible. Ensure that the plunger in the hub aligns with the cut-away tooth in the gear assembly (see Fig. F.6), and that the cone end of the hub and the tapered side of the gear teeth are on opposite sides of the assembly.

**Section F.3****THIRD MOTION SHAFT****Four-speed synchronesh transmission****Removing**

1. Remove the shaft assembly from the transmission as detailed in Section F.1.

**Dismantling**

2. Withdraw the top and third gear synchronesh hub and baulk rings from the front end of the shaft.
3. Press the front thrust washer plunger, and turn the washer until its splines register with those on the shaft, enabling it to be removed, complete with plunger and spring. Remove the third speed gear, with its caged needle-roller bearing.
4. Remove the first speed gear, baulk ring, and caged needle-roller bearing from the opposite end of the shaft.
5. Carefully lever the needle-roller bearing journal backwards sufficiently to fit Service tool 18G 2 and pull the journal from the shaft.
6. Remove the reverse mainshaft wheel and first/second speed synchronizer assembly, and the baulk ring.
7. Press in the two plungers securing the rear thrust washer, turn it to align it with the shaft splines and withdraw it from the shaft. Remove the second speed gear, and the split caged needle-roller bearing.




Fig. F.7  
The third motion shaft assembly (four-speed synchromesh transmission)

3NC238A

1. First speed gear.
2. Needle roller bearings.
3. Bearing journal-needle roller.
4. Baulk rings.
5. Reverse mainshaft gear and 1st and 2nd speed synchronizer.
6. Rear thrust washer.
7. Second speed gear.

8. Split-caged needle roller bearing- second speed gear.
9. Third motion shaft.
10. Plunger and spring-rear thrust washer.
11. Plunger and spring-front thrust washer.
12. Third speed gear.
13. Front thrust washer.
14. 3rd and 4th speed synchronizer.

**Reassembling**

8. Carry out the dismantling instructions, but note items 9 to 11 in Section F.2.
9. Use Service tool 18G 572 to prevent the balls and springs from being lost, should it be necessary to separate the striking dogs from the synchromesh hub and cone assemblies. When reassembling the synchronizers, ensure that the long boss on both the sleeve and the hubs are on the same side.
10. When refitting the third and top speed synchronizer assembly, the long boss on the synchronizer sleeve must face the first motion shaft bearing. The first and second speed synchronizer assembly must be fitted with the long boss towards the first speed gear, or second speed synchromesh action will be lost.
11. Use Service tool 18G 186 to drift the first speed gear needle-roller bearing journal onto the third motion shaft.

**Section F.4**

**DIFFERENTIAL ASSEMBLY**


**Removing**

1. Remove the engine and transmission as detailed in Section A.13.
2. Remove the transmission from the engine as detailed

3. Remove the gear-change extension bottom cover plate.
4. Release the control shaft lever from the top of the remote control shaft, which can now be withdrawn.
5. Extract the split pin from the slotted nuts securing both right- and left-hand driving flanges to the differential gear shafts, using Service tool 18G 669 to hold each driving flange in turn, remove the nuts and withdraw the flanges. **Do not under any circumstances use the transmission casing as a stop or leverage point when removing the driving flange nuts or other components of the transmission. Serious damage to the casing can easily result from misuse in this way.**
6. Unscrew the five set screws from each of the final drive end covers, and remove them from the differential housing. Note the number of shims fitted between the differential bearing and the housing.
7. Remove the differential housing stud nuts, withdraw the housing from the transmission case and remove the differential assembly.



THE DIFFERENTIAL COMPONENTS



E2445B

- | No. | Description           |
|-----|-----------------------|
| 1.  | Differential case.    |
| 2.  | Case bush.            |
| 3.  | Drive gear.           |
| 4.  | Gear bush.            |
| 5.  | Gear bolt.            |
| 6.  | Lock washer.          |
| 7.  | Thrust block.         |
| 8.  | Differential pinion.  |
| 9.  | Pinion thrust washer. |

- | No. | Description         |
|-----|---------------------|
| 10. | Centre pin.         |
| 11. | Pin peg.            |
| 12. | Differential gear.  |
| 13. | Gear thrust washer. |
| 14. | Drive gear bearing. |
| 15. | Case bearing.       |
| 16. | Bearing shim.       |
| 17. | End cover.          |

- | No. | Description      |
|-----|------------------|
| 18. | Cover bush.      |
| 19. | Oil seal.        |
| 20. | Cover joint.     |
| 21. | End cover screw. |
| 22. | Washer.          |
| 23. | Driving flange.  |
| 24. | Flange out.      |
| 25. | Washer.          |




Fig. F.8

With the left-hand drive cover fitted without its joint washer, measure the gap at point 'A', and fit shims between the bearing and cover to obtain the required pre-load

### Dismantling

8. Withdraw the two differential bearings, using Service tool 18G 2. Knock back the locking plate tabs and remove the six set bolts securing the driving gear to the cage, which may now be separated after marking them to assist in refitting them in their original positions. Extract the differential gear and thrust washer from the bore of the driving gear.
9. Tap out the taper pin peg to release the pinion centre pin, the thrust block, both differential pinions and thrust washers and the other differential gear and washer.

### Reassembling

10. Reverse the dismantling sequence, making sure that the gear thrust washers are refitted with their chamfered bores against the machined face of the differential gears, and that all parts are refitted in their original positions.

### Refitting

11. Place the differential assembly in the transmission casing with a slight bias towards the flywheel side. Refit the differential housing with its joint washers, and nip up the nuts sufficiently to hold the bearings, yet still allowing the assembly to be moved sideways.
12. Refit the right-hand drive end cover together with its joint washer. Then carefully and evenly tighten up the set screws, to displace the differential assembly away

from the flywheel side and ensuring full contact between the register on the inner face of the cover and the differential bearing.

Fit the left-hand final drive cover, without its joint washer, the compressed thickness of which is .007 in. (.18 mm.). Tighten the set screws sufficiently for the cover register to nip the bearing outer race; overtightening will distort the cover flange. The required preload on the bearings is .001 to .002 in. (.025 to .05 mm.), hence the gap between the cover flange and the differential housing and transmission casing must be between .008 to .009 in. (.2 to .23 mm.). Measure this gap ('A' in Fig. F.8) with feeler gauges, and correct it as necessary by fitting shims between the bearing and the register on the cover. For example if the gap as measured is .005 in. (.13 mm.) a shim of .003 in. (.076 mm.) is required. Measure the gap in several places: any deviations will indicate that the end cover set screws have not been tightened evenly.

Remove and refit the end cover with its joint washer and the selected shims, tighten the cover screws and differential housing nuts.

**NOTE.**—Later assemblies are fitted with increased thrust capacity bearings, which must be fitted with the identification word 'THRUST' facing the outside, towards the end cover. Since the pre-load is increased to .004 in. (.1 mm.), adjust the gap 'A' (see Fig. F.8) with shims until it is .011 in. (.28 mm.) before the joint washer is fitted.

13. Refit the driving flanges, making reference to item 4. The torque tightening figure is given in 'GENERAL DATA'.




Fig. F.9  
Top left: first motion shaft. Lower left: third speed mainshaft gear. Top right: second speed mainshaft gear. Lower right: Cone

#### DIMENSIONS

- |    |   |    |  |
|----|---|----|--|
| A. | Taper 2.150 in. (54.61 mm.) dia. at this line to gauge.                   | I. | 6°   |
| B. | Taper 10°30', to be true and concentric with bore to .001 in. (.025 mm.). | J. | Coarse turning may be either right or left-hand.   |
| C. | .909/.912 in. (23.09/23.16 mm.).  | K. | .015 in. (.38 mm.).  |
| D. | Taper to be true and concentric with bore to .001 in. (.025 mm.).         | L. | 90°  |
| E. | .862/.865 in. (21.8/21.9 mm.).  | M. | One notch to be ground in position shown relative to grooves with indentations.  |
| F. | Taper 2.150 in. (54.61 mm.) dia. at this line to gauge.                   | N. | Synchronizing cone to be heated in oil shrunk onto gear, and punched into holes as shown with centre-line of holes and spaces in cone in line. |
| G. | .837/.840 in. (21.254/21.335 mm.).  |    |  |
| H. | 8°30'.  |    |  |

14. Make certain that both drive shafts are equally free to rotate, otherwise the vehicle's steering may pull to one side.
15. Refer to item 3. Position the remote control shaft lever on the ball end of the operating lever, insert the remote control shaft from underneath and engage it with the splined bore of the former. Insert the set screw after checking that the drilling in the boss and the recess in the shaft are in alignment.
16. Reassemble the transmission, clutch assembly and housing to the engine (if removed, see item 2).
17. Refit the power unit into the car and reassemble the gear-change to the transmission (or refit the remote control assembly).


#### Section F.5

#### SYNCHRONIZING CONES (Non-baulk-ring Transmission)

Cones may be shrunk onto the second, third and fourth gears by heating in oil to 121°C. (250°F.) and quenching in cold water when in position.

See Fig. F.9 for machining dimension.

### GEAR CHANGE REMOTE CONTROL COMPONENTS



B 8899A

No.	Description	No.	Description
1.	Housing.	14.	Cap nut—spring retainer.
2.	Securing screw—short.	15.	Change speed lever.
3.	Securing screw—long.	16.	Lever knob.
4.	Spring washers.	17.	Retainer.
5.	Rubber plug.	18.	Spring.
6.	Rubber dust cover.	19.	Bush—split.
7.	Primary shaft.	20.	Distance piece.
8.	Primary shaft lever.	21.	Flange.
9.	Lever—screw.	22.	Screw—retainer to housing.
10.	Spring washer.	23.	Spring washer.
11.	Damper plunger.	24.	Locating pin.
12.	Plunger spring.	25.	Spring washer.
13.	Washer.	26.	Gaiter—change speed lever.

## Section F.6

## GEAR CHANGE REMOTE CONTROL ASSEMBLY

## Removing

1. Remove the front floor covering, the gear lever knob, and the rubber gaiter.
2. From beneath the car, remove the securing screws and nuts from the extension rear support bracket (see Fig. A.12).
3. Remove the four bolts securing the extension to the transmission casing and detach the extension.

## Dismantling

4. Remove the rubber dust cover, and slacken the lever locating pin.
5. Remove the screws securing the change speed lever retainer and withdraw the lever, retainer, and spring.
6. Lift out the distance piece and spring flange.
7. Remove the remote control shaft damper assembly and the screw securing the remote control shaft to the primary shaft lever. Withdraw the shaft and the lever from the housing.

## Inspection


Clean and examine all components for wear, and fit new parts as required.

## Reassembling

8. Reassemble all components in the reverse order of dismantling. Lubricate the operating surfaces of all components with grease.

## Refitting

9. Reverse the removing procedure, ensuring that the rubber plug is correctly located between the extension and the transmission casing.



3NC921

Fig. F.10  
Removing the gear change lever assembly

- |                  |                                      |
|------------------|--------------------------------------|
| 1. Lever knob.   | 4. Retaining cap<br>-lever assembly. |
| 2. Gaiter.       | 5. Lever assembly.                   |
| 3. Screw-gaiter. |                                      |

## Section F.8

GEAR CHANGE REMOTE CONTROL ASSEMBLY  
(Rod-change transmission)

## Removing

1. Release the gear change lever from the remote control from beneath the car.
2. Drift out the roll-pin retaining the extension rod to the selector rod at the final drive housing, Fig. F.30.
3. Remove the nut and bolt securing the remote control steady rod to the final drive housing on the gearbox.
4. Remove the one nut and bolt securing the remote control housing to the mounting bracket and withdraw the assembly.

## Dismantling

5. Hold the assembly in a vice and remove the bottom cover-plate.
6. Remove the steady rod from the housing.
7. Move the extension rod eye rearwards, and remove the roll-pin retaining the extension rod to the rod eye.
8. Withdraw the extension rod.

## Section F.7

GEAR CHANGE LEVER  
(Rod-change transmission)

## Removing

1. Unscrew the knob from gear-change lever.
2. Remove the front floor carpet.
3. Remove the gaiter retaining ring screws and pull the gaiter up the lever.
4. Press down and turn the bayonet cap fixing to release the lever from the remote control assembly.
5. Remove the gear-change lever.

## Refitting

6. Reverse the procedure in 1 to 5.




Fig. F.11

A dismantled view of the remote control components, the 'arrows' indicate the areas to be lubricated on assembly

- |                         |                         |
|-------------------------|-------------------------|
| 1. Steady rod assembly. | 5. Extension rod.       |
| 2. Selector rod.        | 6. Bush-remote housing. |
| 3. Eye-extension rod.   | 7. Cover plate.         |
| 4. Roll pins.           | 8. Screw-cover plate.   |

9. Move the extension rod eye forward and remove the roll-pin retaining the support rod to the extension rod eye.
10. Drift out the support rod.
11. Lift out the extension rod eye.

**Inspecting**

12. Examine all parts for undue wear, and replace as necessary.

**Reassembling**

13. Use ½ oz (14 g) of Duckhams Laminoid 'O' Grease and apply with a brush onto the following parts and locations (arrowed), see Fig. F.11 when reassembling:
  - a. To the hemispherical fulcrum surface in the housing.
  - b. Into the selector rod eye.
  - c. Into the two selector rod bearing locations.
  - d. To the inner surface of the bottom cover-plate and particularly onto the reverse lift plate.
14. Refit the extension rod eye into the housing.
15. Insert the support rod.
16. Reverse the procedure in 7 to 9 to reassemble the support and extension rods to the eye.
17. Reverse the procedure in 5 and 6.

**Refitting**

18. Reverse the procedure 1 to 4.




Fig. F.12

Removing the gear change remote control mountings

- |              |                                |
|--------------|--------------------------------|
| 1. Mounting. | 2. Retaining nuts and washers. |
|--------------|--------------------------------|

**Section F.9**

**REMOTE CONTROL MOUNTINGS  
(Rod-change transmission)**

**Removing**

1. Remove the front floor carpet.
2. Remove the nuts and spring washers securing the remote control mountings to the tunnel panel and lower the assembly.
3. Remove the nuts and spring washers securing the mountings to the support bracket.
4. Remove the mountings.

**Refitting**

5. Reverse the procedure 1 to 4.

**Section F.10**

**TRANSMISSION ASSEMBLY—OVERHAUL  
(Rod-change type)**

**Removing**

1. Remove the engine/transmission assembly, Section A.33.
2. Remove the transmission from the engine, Section A.19.

**Dismantling**

3. Remove the securing screws and detach the final drive end covers.
4. Extract the selector shaft detent spring, sleeve and ball.




Fig. F.13  
Removing the first motion shaft gear

1. Retaining circlip-roller bearing.
2. Roller bearing-first motion shaft.
3. Nut-first motion shaft.
4. Lockwasher.
5. First motion shaft gear.




Fig. F.14  
Showing the selector shaft (1) rotated out of engagement with the selector bellcrank levers (2)

5. Knock back the lock washer tabs from the final drive housing securing nuts; remove the nuts and lock washers.
6. Locate the oil seal protector sleeve (tool 18G 1236) over the selector shaft.
7. Remove the final drive housing.
8. Remove the final drive gear assembly.
9. Remove the speedometer drive pinion.
10. Remove the engine mounting adaptor housing.
11. Remove the speedometer drive housing.
12. Tap back the lock washer tabs and remove the screws securing the oil suction pipe to the gearbox casing; pull out the pipe.
13. Remove the circlip retaining the first motion shaft roller bearing, using tool 18G 1004.
14. Use tools 18G 705 and 18G 705C to pull off the first motion shaft roller bearing.
15. Knock back the lock washer tab from the first motion shaft securing nut.
16. Knock back the lock washer tab from the third motion shaft final drive gear securing nut.
17. Rotate the selector shaft anti-clockwise to disengage the operating stub and the interlock spool from the bellcrank levers, Fig. F.14.
18. Engage first and fourth gears simultaneously to lock the gear train.
19. Use tool 18G 587 and remove the third motion shaft final drive gear nut.
20. Pull off the lock washer and final drive gear.
21. Remove the first motion shaft gear nut.
22. Pull off the lock washer and the first motion shaft gear.
23. Move first and fourth gears to neutral position.

24. Knock back the lock washer tabs on the third motion shaft bearing retainer bolts and remove the bolts.
25. Remove the retainer complete with the adjustment shim(s).
26. Remove the reverse locking plate.
27. Withdraw the layshaft.




Fig. F.15  
An exploded view of the laygear and shaft assembly

1. Laygear and bearings.
2. Layshaft.
3. Thrust washer (selective)-small.
4. Thrust washer-large.




Fig. F.16  
Removing the third motion shaft bearing (1)

3NCO87A

28. Take out the small thrust washer from the laygear, remove the laygear and the larger thrust washer, Fig. F.15.
29. Use tool 18G 257 to remove the first motion shaft bearing retaining circlip.
30. Use tools 18G 284 and 18G 284B and withdraw the first motion shaft and bearing from the end casing.
31. Refer to removing procedure 'A', 'B' and 'C' on Fig. F.16 to remove the third motion shaft bearing:

'A': Use a soft drift and drift the third motion shaft towards the clutch end of the gearbox. Take care not to disengage the third/fourth speed synchronizer from its hub and release the balls and springs.

'B': Insert tool 18G 1127 with its relieved side against the bearing.

'C': Drift the other end of the third motion shaft in the opposite direction to remove the third motion shaft bearing from the centre web of the casing.

**NOTE:** Should the bearing not be completely removed from the centre web by the procedures given, it can be carefully levered out by using a screwdriver between the casing and the bearing circlip.

32. Lift out the third motion shaft assembly.
33. Remove the oil strainer.
34. Withdraw the reverse idler shaft and gear, Fig. F.17.




Fig. F.17  
Removing the reverse idler gear (1) and shaft (2)

3NC171A






Fig. F.18  
The selector shaft and forks.

- |                                      |                         |
|--------------------------------------|-------------------------|
| 1. First speed selector fork.        | 3. Roll pin.            |
| 2. Third/fourth speed selector fork. | 4. Selector fork shaft. |




Fig. F.20  
Showing the bellcrank lever pivot post (1) and 'O' ring seal (2) drifted out of the transmission casing

35. Drift out the roll-pin securing the third/fourth speed selector fork to its shaft, Fig. F.18.  
36. Remove the selector shaft and forks, Fig. F.18.

37. Remove the bellcrank lever pivot post nut and washer.  
38. Lift out the bellcrank levers, washers and pivot sleeve, Fig. F.19. Note the location and markings on the levers for reassembly.  
39. Withdraw the interlock spool and selector shaft from inside the casing, Fig. F.19.  
40. Drift the bellcrank lever pivot post out of the gearbox casing if the 'O' ring oil seal is to be renewed, Fig. F.20.  
41. Remove the two circlips retaining the idler gear needle-roller bearing in the gearbox casing.




Fig. F.19  
An exploded view of the selector shaft and bellcrank lever assemblies

- |  |
|--|
| 1. Interlock spool.                          |
| 2. Selector shaft.                           |
| 3. Detent ball, spring, sleeve and oil seal. |
| 4. Oil seal-selector shaft.                  |
| 5. Bellcrank lever assembly.                 |
| 6. Pivot post nut and washer.                |




Fig. F.21  
Removing the idler gear bearing from the transmission case

- |                           |                        |
|---------------------------|------------------------|
| 1. Retaining circlips.    | 2. Idler gear bearing. |
| 3. Service tool 18G 1126. |                        |




Fig. F.22  
Extracting the idler gear bearing from the flywheel housing using (1) Service tool 18G 581. Turn the nut with the spanner (2) in the direction 'arrowed'.

42. Use tool 18G 1126 (without its outer sleeve) and drift out the idler gear bearing, Fig. F.21.
43. Remove the other idler gear bearing from the flywheel housing, using tool 18G 581, Fig. F.22.
44. Extract the circlip retaining the outer race of the first motion shaft spigot bearing in the flywheel housing.
45. Use tool 18G 617A to pull out the outer race (arrowed), Fig. F.23.
46. Remove the primary gear oil seal from the flywheel housing.




Fig. F.24  
Refitting the primary gear oil seal into the flywheel housing

1. Service tool 18G 134.
2. Service tool adaptor 18G 134BC.
3. Primary gear oil seal.

**Inspecting**

47. Clean all assemblies and examine for wear. Completely dismantle the main assemblies and thoroughly examine their components, refer to the overhaul procedure for each main assembly given in the reassembling procedure.

**Reassembling**

48. Fit a new primary gear oil seal into the flywheel housing, using tools 18G 134 and 18G 134BC, Fig. F.24.
49. Use the 'replacer' of tool 18G 617A and drift the first motion shaft spigot bearing outer race into the flywheel housing, Fig. F.25.
50. Refit the bearing retaining circlip.
51. Use tool 18G 1126 with its outer sleeve and drift the idler gear bearing into the housing to the depth governed by the outer sleeve of the tool, Fig. F.26.
52. Refit the inner circlip into the gearbox casing, drift in the new idler gear bearing using tool 18G 1126, and refit the outer retaining circlip, Fig. F.21.
53. Lubricate and fit a new 'O' ring oil seal onto the bellcrank lever pivot post and drift it into the gearbox casing, Fig. F.20.
54. Insert the selector shaft into the interlock spool and refit the assembly into the gearbox with the operating stub facing away from the pivot post.
55. Refit the sleeve, bellcrank levers (in their correct order) onto the pivot post and tighten the self-locking nut, Fig. F.19.




Fig. F.23  
Extracting the first motion shaft spigot bearing outer race 'arrowed' from the flywheel housing

1. Retaining circlip.
2. Service tool 18G 617A.
3. Bearing outer race.




Fig. F.25

Refitting the first motion shaft spigot bearing outer race into the flywheel housing

1. Service tool 18G 617A (replacer). 2. Bearing outer race.

**NOTE:** DO NOT turn the selector shaft and interlock spool into engagement with the bellcrank levers until the first and third motion shaft gear retaining nuts have been torque-tightened.

56. Refit the third/fourth speed selector fork.
57. Refit the first speed selector fork and drift the selector rod through the casing and forks; align the hole in the shaft with the hole in the third/fourth speed fork, Fig. F.18.
58. Drift in the roll-pin until it is flush with the fork.
59. Refit the reverse idler gear into engagement with the reverse bellcrank lever pivot and refit the shaft, Fig. F.17.
60. Place the oil strainer into its location in the casing.




Fig. F.26

Drifting the idler gear bearing into the flywheel housing to the depth governed by the outer sleeve of the tool

1. Service tool 18G 1126. 2. Sleeve.

F.18

61. Dismantle and overhaul the third motion shaft assembly, see Section F.3.
62. Dismantle and overhaul the first motion shaft assembly.
63. Insert the third motion shaft assembly into the gearbox assembly and locating in the two selector forks.
64. Use tool 18G 579 and drift the third motion shaft bearing into the centre web of the casing.
65. Insert the first motion shaft needle-roller bearing into its location in the gear.
66. Drift the first motion shaft assembly into the casing, using tool 18G 579.
67. Use tool 18G 569 to gauge the correct thickness circlip required, try the thicker side of the tool first; the sizes are marked on the handle.
68. Select the correct circlip from the chart given below and fit it using tool 18G 257.

**When gap is**

**Use Circlip Part No.**

0.096 to 0.098 in (2.43 to 2.48 mm)	2A 3710
0.098 to 0.100 in (2.48 to 2.54 mm)	2A 3711

69. Insert the needle-roller bearings into the laygear.
70. Refit the laygear and shaft with its thrust washers.
71. Use feeler gauges and check the laygear end-float, which should be 0.002 to 0.006 in (0.05 to 0.15 mm). Select and fit the required washer from the chart given below:

**Layshaft thrust washer chart**

Washer thickness		Part No.
inches	mm.	
0.123 to 0.124	3.12 to 3.14	22G 856
0.125 to 0.126	3.17 to 3.20	22G 857
0.127 to 0.128	3.22 to 3.25	22G 858
0.130 to 0.131	3.30 to 3.32	22G 859




Fig. F.27

Checking the laygear end-float adjustment with feeler gauges

1. Laygear. 2. Feeler gauges.  
3. Thrust washer (selective)—small.




Fig. F.28  
Checking the gap between the third motion shaft bearing retainer (1) and housing with feeler gauges (2). Note the location of the reverse and layshaft locking plate (3).




Fig. F.29  
Refitting the final drive assembly and carrying out the bearing preload adjustment. Measure the gap 'A', select and fit shims to give the required bearing preload

1. Final drive assembly.
2. Housing.
3. End cover.
4. Screw—end cover.
5. Retaining nuts and lock plates.
6. Service tool 18G 1236—oil seal protector sleeve.

72. Refit the layshaft and reverse shaft locking plate, turn the shafts if necessary until the slots are correctly positioned.
73. Refit the third motion shaft bearing retainer without any shims, lightly and evenly tighten the retainer bolts.
74. Check the gap with feeler gauges, see Fig. F.28; select the required thickness of shims from the chart given below:

When gap is		Use shims totalling	
inches	mm.	inches	mm.
0.005 to 0.006	(0.13 to 0.15)	0.005	(0.13)
0.006 to 0.008	(0.15 to 0.20)	0.007	(0.18)
0.008 to 0.010	(0.20 to 0.25)	0.009	(0.23)
0.010 to 0.012	(0.25 to 0.30)	0.011	(0.28)
0.012 to 0.014	(0.30 to 0.35)	0.013	(0.33)
0.014 to 0.015	(0.35 to 0.38)	0.015	(0.38)

75. Fit the shims under the layshaft and reverse shaft locking plate.
76. Refit the bearing retainer with new lock washers, tighten the securing screws to the torque figure given in 'GENERAL DATA'. Tap over the lock washer tabs.
77. Engage first and fourth gears simultaneously to lock the gear train.
78. Refit the final drive pinion, a new lock washer and the securing nut onto the third motion shaft.
79. Tighten the final drive gear pinion nut using tool 18G 587 to the torque figure given in 'GENERAL DATA'. Tap over the lock washer tabs.
80. Refit the first motion shaft gear with a new lock washer. Refit and tighten the securing nut to the torque figure given in 'GENERAL DATA'. Tap over the lock washer tab.

81. Refit the first motion shaft roller-bearing and refit the retaining circlip with tool 18G 1004.
82. Move first and fourth gears to the neutral position.
83. Rotate the selector shaft and interlock spool into engagement with the bellcrank levers.
84. Insert the oil suction pipe into the strainer.
85. Fit a new joint washer and locking plates, tighten the external flange securing screws first, then the pipe bracket screws. Tap over the locking plate tabs.
86. Refit the speedometer drive housing with a new joint washer to the gearbox casing. Tighten the securing nuts and screws to the torque figure given in 'GENERAL DATA'.
87. Refit the speedometer drive pinion with a new joint washer.
88. Refit the engine mounting adaptor housing.




Fig. F.30

Disconnect the rod gear change remote control from the transmission.

- |                              |                                    |
|------------------------------|------------------------------------|
| 1. Extension rod.            | 4. Steady rod.                     |
| 2. Roll pin – extension rod. | 5. Nut and bolt – steady rod fork. |
| 3. Selector shaft.           |                                    |

89. Fit oil seal protector sleeve (tool 18G 1236) over the selector shaft.
90. Refit and adjust the final drive gear assembly, see Section F.4.
91. Refit the selector shaft sleeve, ball and spring before fitting the final drive end covers.

### Refitting

92. Refit the transmission to the engine.
93. Refit the engine/transmission assembly.

### Section F.11

#### GEAR CHANGE SELECTOR SHAFT OIL SEAL

### Removing

1. Drain the engine/transmission oil.
2. Raise the front of the vehicle and place supports under the sub-frame side members.




Fig. F.31

Fitting a new gear change selector shaft oil seal

- |                           |  |
|---------------------------|--|
| 1. Oil seal.              | 2. Protector sleeve—service tool 18G 1238. |
| 3. Service tool 18G 1236. |  |

3. Drift out roll pin securing the gear change rod to the selector shaft, see Fig. F.30.
4. Remove the nut and bolt securing the steady rod fork to the final drive casing, see Fig. F.30.
5. Lever out the old oil seal.

### Refitting

6. Place protector sleeve, Service tool 18G 1238 over the selector shaft, see Fig. F.31.
7. Lubricate the new oil seal and drift it into the casing using Service tool 18G 1236, see Fig. F.31.
8. Remove Service tool 18G 1238 from the selector shaft.
9. Reverse the removing procedure 1 to 4.

## SECTION Fa

### THE AUTOMATIC TRANSMISSION

	Section
General description	
Power flow diagram (Mechanical)	
Line pressure and lubrication diagrams	
Adjustments and checks	
Governor control rod (kick-down) adjustment .. .. .	Fa.4
Inhibitor switch adjustment .. .. .	Fa.3
Selector lever cable and transverse rod adjustment .. .. .	Fa.2
Oil pressure and stall speed checks .. .. .	Fa.5
Auxiliary pump and governor .. .. .	Fa.10
Differential assembly .. .. .	Fa.16
Fault diagnosis .. .. .	Fa.1
First gear free-wheel assembly (one-way clutch) .. .. .	Fa.15
Forward clutch .. .. .	Fa.11
Gear train .. .. .	Fa.12
Lubrication reservoir (idler gear bearing) ... .. .	Fa.17
Selector lever mechanism .. .. .	Fa.18
Servo assembly .. .. .	Fa.14
Top and reverse clutch .. .. .	Fa.13
Transmission unit .. .. .	Fa.6
Valve block	
Removing and refitting .. .. .	Fa.7
Dismantling and reassembling (units without the engagement and shuttle valves) .. .. .	Fa.8
Dismantling and reassembling (units with inbuilt engagement and shuttle valves) .. .. .	Fa.9

## GENERAL DESCRIPTION

The automatic transmission incorporates a three-element fluid torque converter with a maximum torque conversion ratio of 2 : 1 coupled to a bevel gear train which provides four forward gears and reverse.

Engine power is transmitted from the crankshaft converter output gear through an idler gear to the input gear which drives the bevel reduction gears in the gear train assembly.

The final drive is transmitted from a drive gear to a conventional-type differential unit (similar to that fitted to a synchromesh transmission unit), which in turn transmits engine power through two flange-type coupling drive shafts employing constant velocity joints to the road wheels.

The complete gear train assembly, including the reduction gear and differential units, runs parallel to, and below, the crankshaft and is housed in the transmission casing which serves also as the engine sump.

The system is controlled by a selector lever within a gated quadrant marked with seven positions, and mounted centrally on the floor of the car. The reverse, neutral, and drive positions are for normal automatic driving, with the first, second, third, and fourth positions used for manual operation or over-ride as required. This allows the system to be used as a fully automatic four-speed transmission, from rest to maximum speed with the gears changing automatically according to throttle position and load. If a lower gear is required to obtain greater acceleration, an instant full throttle position, i.e. 'kick-down' on the accelerator, immediately produces the change.

Complete manual control of all four forward gears by use of the selector lever provides rapid changes. However, it is very important that downward changes are effected at the correct road speeds otherwise serious damage may result to the automatic transmission unit. The second, third, and top gears provide engine braking whether driving automatic or manual; in first gear a free-wheel condition exists when decelerating. Manual selection to third or second gear gives engine braking and also allows the driver to stay in a particular lower gear to suit road conditions or when descending steep hills.

### The hydraulic system

Oil is drawn from the transmission casing through the main gauze strainer and pick-up pipe by the main oil pump which has a high potential output and serves both the engine lubrication and transmission systems with a common oil supply. The oil passes through drillings in the cylinder block and a pipe to the external full-flow filter and thence to the valve block.

The valve block assembly controls pressures to the transmission. Separate valves control the converter and engine pressures. The oil passes from the valve block through a long connecting pipe to the converter stator unit. Three short interconnecting pipes take the necessary line pressure to each of the servos which control brake band operation in manual and automatic selector positions.

Fa.2

The power flow through the bevel reduction gears is coupled to the final drive gear pinion by means of two multi-disc clutch assemblies operated hydraulically in manual and the automatic selector positions.

In the event of tow-starting the engine, an auxiliary oil pump of low capacity is employed which is responsive to vehicle speed only; immediately the engine starts the main pump automatically takes over.

### The governor system

The governor is driven by auxiliary pump gears and is of the spring-loaded mechanical type, with its bobweights mounted on short links. A rod linkage transfers the movement to the governor valve incorporated in the valve block chest.

A spring-loaded rod connected to the carburetter provides an over-ride device. The spring tends to be compressed by accelerator pedal operation, and transfers this load by levers to the governor. The effect is to delay travel of the governor, which in turn delays gear shifts more as the accelerator is depressed.

### The torque converter

This is fitted onto a taper on the rear of the crankshaft. Basically it comprises three elements, i.e. an impeller, a turbine, and a stator, but it is only serviced as a unit.

There is a continuous supply of oil circulating through the unit; this assists in dissipating the heat generated, and the out-flow passes through a low-pressure valve which maintains a 30 lb./sq. in. (2.1 kg./cm.<sup>2</sup>) pressure within the converter to improve efficiency.

### The brake bands and servos

Three brake bands are used. One is for reverse and the others provide second and third speed reactions. The clamping load is applied by three hydraulic servos in a common casing.

### The multi-disc clutches

For forward motion a single-piston multi-disc clutch carries the drive and is engaged at all times during forward motion of the car. This forward clutch unit is fitted on one side of the final drive pinion and on the other side is a top and reverse clutch assembly which has a tandem piston arrangement. This feature is necessary because the clutch is also engaged for reverse and since a greater torque capacity is required in this case both pistons are pressurized.

### The valve block

Two types of valve block may be fitted, the later type is fitted to the Mk.II B type transmission units and these assemblies can be identified by the prefix to the serial number starting at the letter 'K'.

The later type valve block incorporates an engagement control device which comprises an additional control valve and two shuttle valves and these are located together with the various other valves in the valve chest and pipe chest sections of this unit.

The assembly is constructed of three basic units, i.e. the lid, valve chest, and pipe chest, with a separator plate fitted between the lid and the valve chest on the later assembly.

A linkage arrangement locates the selector valve and this in turn is controlled by the selector rod, externally connected by cable to the gear selector lever in the car. The function of the various valves is as follows:

**THE SELECTOR VALVE**, directs oil from the main supply to either the governor valve for automatic gear-shifting or alternatively to the appropriate clutch or servo for manual selection.

**THE REGULATOR VALVE** controls the main line pressure, a secondary piston on the valve boosts this pressure when reverse is selected.

**THE GOVERNOR VALVE** movement is controlled by the mechanical governor and it directs the oil flow to the appropriate clutch or servo for automatic gear-shifts.

**THE RELAY VALVES** are used for shifts from second to third and third to top. They enable the clutch or servo required to be supplied either from the selector valve in 'manual' control or the governor valve in 'automatic'. In addition, pistons are fitted in front of the second and third relay valves to ensure that on up-shifts the engagement of the new ratio and release of the old occur simultaneously to prevent engine overspeeding between shifts. A relay valve is not required for the first gear as the torque reaction is controlled mechanically by a one-way clutch.

**THE TOW START VALVE** is only fitted to the early type valve block; it short-circuits the auxiliary pump under all normal driving conditions but supplies the required line pressure for tow starting. Immediately the engine starts the main pump automatically takes over. **TOW STARTING IS NOT POSSIBLE** when a transmission is fitted with a later type valve block which incorporates the engagement control valve.

**THE ENGAGEMENT CONTROL VALVE** has a primary function of eliminating harsh engagement when selecting 'D' or a forward gear from the rest position.

#### OPERATION OF ENGAGEMENT CONTROL VALVE

When a forward gear is selected, the selector valve in the valve block directs oil to shuttle valves located in the back of the valve block. The oil passes through the shuttle valves and pressurizes the third and reverse gear servos, thus applying the brake bands and bringing the rotating components of the gear train gently to rest. The oil flows simultaneously to the engagement control valve which, at a predetermined pressure, directs oil to the forward clutch; and as there is relatively little movement between the driving and driven members the gear engagement is smooth.

To complete the operating sequence, oil is also fed behind the shuttle valves which move and allow the oil pressure in the third and reverse servos to exhaust, thus releasing the third and reverse gear bands.


#### The low-pressure valve

This valve controls the pressure in the converter to 30 lb./sq. in. (2.1 kg./cm.<sup>2</sup>). When the engine is stopped the valve is seated, preventing the converter draining. This avoids difficulties in checking the combined engine/transmission oil level and prevents a noisy and inefficient converter when restarting the engine.

#### The auxiliary pump

This unit is used for tow-starting. It is of limited capacity and is responsive to road speed only.






A6861

The components of the automatic transmission with the lubrication system and 'power flow' indicated by arrows to the various components

- |                         |  |                                  |
|-------------------------|--|----------------------------------|
| 1. Main oil strainer.   | 6. Converter feed pipe.                  | 11. Governor.                    |
| 2. Oil pump.            | 7. Converter to low pressure valve feed. | 12. Forward clutch.              |
| 3. Oil filter assembly. | 8. Low pressure valve.                   | 13. Servo unit.                  |
| 4. Valve block.         | 9. Gear train.                           | 14. Auxiliary pump oil strainer. |
| 5. Engine oil feed.     | 10. Top and reverse clutch.              | 15. Auxiliary pump.              |

POWER FLOW DIAGRAMS (MECHANICAL)

The power flow diagrams indicate how the various ratios are obtained. Four speeds and reverse are provided and these are brought into operation by engaging the appropriate friction members.



NEUTRAL


NEUTRAL

When in neutral all the bands and clutches are disengaged, therefore there is no drive to the final drive pinion.

B.7675

KEY TO COMPONENTS

- |                           |                             |
|---------------------------|-----------------------------|
| 1. Crankshaft.            | 8. Third gear band.         |
| 2. Converter output gear. | 9. Second gear band.        |
| 3. Idler gear.            | 10. Top and reverse clutch. |
| 4. Input gear.            | 11. Forward clutch.         |
| 5. One-way clutch.        | 12. Final drive pinion.     |
| 6. Gear carrier.          | 13. Final drive gear.       |
| 7. Reverse band.          |                             |



FIRST

FIRST SPEED


In this ratio the forward clutch is applied and the one-way clutch is operative. The carrier is stationary, its reaction being controlled by the one-way clutch. The input bevel drives the planet wheels and the planet pinions drive the forward output pinion and shaft. Thus power is transferred through the planet assemblies to the mainshaft, forward clutch, and the output gear, providing a ratio of 2.69 : 1.

B.76751

### POWER FLOW DIAGRAMS (MECHANICAL)

#### SECOND SPEED

As for all forward gears the forward clutch remains engaged, and in addition the second speed brake band applied. This controls the reaction which is imposed on the reverse drive bevel when in this ratio. With the planet cluster orbiting around the reverse drive bevel power is transmitted from the input bevel through the planets to the mainshaft and provides a ratio of 1.845 : 1.




B.76757

#### KEY TO COMPONENTS

- |                           |                             |
|---------------------------|-----------------------------|
| 1. Crankshaft.            | 8. Third gear band.         |
| 2. Converter output gear. | 9. Second gear band.        |
| 3. Idler gear.            | 10. Top and reverse clutch. |
| 4. Input gear.            | 11. Forward clutch.         |
| 5. One-way clutch.        | 12. Final drive pinion.     |
| 6. Gear carrier.          | 13. Final drive gear.       |
| 7. Reverse band.          |                             |

#### THIRD



B.76753


#### THIRD SPEED

For this ratio the third speed bevel wheel is held by its appropriate drum and brake band, and in this case the planet clusters orbit around this gear. Like second speed, power is transmitted from the input bevel through the planets to the mainshaft and in this case provides a ratio of 1.46 : 1.

POWER FLOW DIAGRAMS (MECHANICAL)

TOP SPEED


In addition to the forward clutch, the top and reverse clutch is engaged. This in effect locks up the bevel gears and the reduction gear assembly then rotates as one unit to provide direct drive.



B.76754

KEY TO COMPONENTS

- |                           |                             |
|---------------------------|-----------------------------|
| 1. Crankshaft.            | 8. Third gear band.         |
| 2. Converter output gear. | 9. Second gear band.        |
| 3. Idler gear.            | 10. Top and reverse clutch. |
| 4. Input gear.            | 11. Forward clutch.         |
| 5. One-way clutch.        | 12. Final drive pinion.     |
| 6. Gear carrier.          | 13. Final drive gear.       |
| 7. Reverse band.          |                             |



B.76755

REVERSE


In this ratio the carrier is held by the reverse band — (the one-way clutch being inoperative because the reaction is in the opposite direction to first speed).

In addition the top and reverse clutch is engaged.

The input bevel wheel drives the planet wheel and the planet pinion drives the reverse drive gear. Thus power is transmitted through the planet assemblies to the top and reverse clutch and thence to the final drive pinion to provide a ratio of 2.69 : 1.

### LINE PRESSURE AND LUBRICATION DIAGRAMS

MK. I AND II  
TRANSMISSIONS




**NEUTRAL**

2NC687

#### KEY TO DIAGRAMS

- |                                     |                                 |   |
|-------------------------------------|---------------------------------|---|
| 1. Main oil pump.                   | 8. Gear train lubrication.      | 15. Forward clutch.                       |
| 2. Oil filter.                      | 9. Engine lubrication.          | 16. Top and reverse clutch.               |
| 3. Regulator valve.                 | 10. Selector valve.             | 17. Second gear brake band.               |
| 4. Engine lubrication relief valve. | 11. Selector valve detent.      | 18. Third gear brake band.                |
| 5. Converter.                       | 12. Second and top gear valves. | 19. Reverse gear brake band.              |
| 6. Low pressure valve.              | 13. Third gear valve.           | 20. Tow start valve.                      |
| 7. To sump.                         | 14. Governor valve.             | 21. Auxiliary pump.                       |
|                                     |                                 | 26. Restrictor valve (in converter pipe). |




**REVERSE GEAR**

2NC688

LINE PRESSURE AND LUBRICATION DIAGRAMS

MK. I AND II TRANSMISSIONS




FIRST GEAR AUTOMATIC

2NC686

KEY TO DIAGRAMS

- |                                     |                                 |   |
|-------------------------------------|---------------------------------|---|
| 1. Main oil pump.                   | 8. Gear train lubrication.      | 15. Forward clutch.                       |
| 2. Oil filter.                      | 9. Engine lubrication.          | 16. Top and reverse clutch.               |
| 3. Regulator valve.                 | 10. Selector valve.             | 17. Second gear brake band.               |
| 4. Engine lubrication relief valve. | 11. Selector valve detent.      | 18. Third gear brake band.                |
| 5. Converter.                       | 12. Second and top gear valves. | 19. Reverse gear brake band.              |
| 6. Low pressure valve.              | 13. Third gear valve.           | 20. Tow start valve.                      |
| 7. To sump.                         | 14. Governor valve.             | 21. Auxiliary pump.                       |
|                                     |                                 | 26. Restrictor valve (in converter pipe). |




FIRST GEAR MANUAL

2NC685


### LINE PRESSURE AND LUBRICATION DIAGRAMS

### MK. I AND II TRANSMISSIONS




#### KEY TO DIAGRAMS

- |                                     |                                 |   |
|-------------------------------------|---------------------------------|---|
| 1. Main oil pump.                   | 8. Gear train lubrication.      | 15. Forward clutch.                       |
| 2. Oil filter.                      | 9. Engine lubrication.          | 16. Top and reverse clutch.               |
| 3. Regulator valve.                 | 10. Selector valve.             | 17. Second gear brake band.               |
| 4. Engine lubrication relief valve. | 11. Selector valve detent.      | 18. Third gear brake band.                |
| 5. Converter.                       | 12. Second and top gear valves. | 19. Reverse gear brake band.              |
| 6. Low pressure valve.              | 13. Third gear valve.           | 20. Tow start valve.                      |
| 7. To sump.                         | 14. Governor valve.             | 21. Auxiliary pump.                       |
|                                     |                                 | 26. Restrictor valve (in converter pipe). |



LINE PRESSURE AND LUBRICATION DIAGRAMS

MK. I AND II TRANSMISSIONS




THIRD GEAR *AUTOMATIC*

2NC682

KEY TO DIAGRAMS

- |                                     |                                 |   |
|-------------------------------------|---------------------------------|---|
| 1. Main oil pump.                   | 8. Gear train lubrication.      | 15. Forward clutch.                       |
| 2. Oil filter.                      | 9. Engine lubrication.          | 16. Top and reverse clutch.               |
| 3. Regulator valve.                 | 10. Selector valve.             | 17. Second gear brake band.               |
| 4. Engine lubrication relief valve. | 11. Selector valve detent.      | 18. Third gear brake band.                |
| 5. Converter.                       | 12. Second and top gear valves. | 19. Reverse gear brake band.              |
| 6. Low pressure valve.              | 13. Third gear valve.           | 20. Tow start valve.                      |
| 7. To sump.                         | 14. Governor valve.             | 21. Auxiliary pump.                       |
|                                     |                                 | 26. Restrictor valve (in converter pipe). |




THIRD GEAR *MANUAL*

2NC681




### LINE PRESSURE AND LUBRICATION DIAGRAMS

### MK. I AND II TRANSMISSIONS




#### KEY TO DIAGRAMS

- |                                     |                                 |   |
|-------------------------------------|---------------------------------|---|
| 1. Main oil pump.                   | 8. Gear train lubrication.      | 15. Forward clutch.                       |
| 2. Oil filter.                      | 9. Engine lubrication.          | 16. Top and reverse clutch.               |
| 3. Regulator valve.                 | 10. Selector valve.             | 17. Second gear brake band.               |
| 4. Engine lubrication relief valve. | 11. Selector valve detent.      | 18. Third gear brake band.                |
| 5. Converter.                       | 12. Second and top gear valves. | 19. Reverse gear brake band.              |
| 6. Low pressure valve.              | 13. Third gear valve.           | 20. Tow start valve.                      |
| 7. To sump.                         | 14. Governor valve.             | 21. Auxiliary pump.                       |
|                                     |                                 | 26. Restrictor valve (in converter pipe). |



LINE PRESSURE AND LUBRICATION DIAGRAMS

MK. IIB TRANSMISSIONS



2NC733


FORWARD CLUTCH ENGAGEMENT

STAGE 1: The selector valve directs oil through the shuttle valves to pressurize the third and reverse gear servos, and simultaneously to the engagement control valve, which at a predetermined pressure directs oil to apply the forward clutch.

KEY TO DIAGRAMS

- |                                     |  |
|-------------------------------------|--|
| 1. Main oil pump.                   | 15. Forward clutch.                                    |
| 2. Oil filter.                      | 16. Top and reverse clutch.                            |
| 3. Regulator valve.                 | 17. Second gear brake band.                            |
| 4. Engine lubrication relief valve. | 18. Third gear brake band.                             |
| 5. Converter.                       | 19. Reverse gear brake band.                           |
| 6. Low pressure valve.              | 20. Engagement control pressure valve (Mk. II B only). |
| 7. To sump.                         | 21. Engagement control shuttle valves (Mk. II B only). |
| 8. Gear train lubrication.          | 22. One-way dump valve (Mk. II B only).                |
| 9. Engine lubrication.              | 23. One-way flap valve (Mk. II B only).                |
| 10. Selector valve.                 | 24. Restrictor valve (in converter pipe).              |
| 11. Selector valve detent.          |  |
| 12. Second and top gear valves.     |  |
| 13. Third gear valve.               |  |
| 14. Governor valve.                 |  |

- |  |                     |
|--|---------------------|
|  | Line pressure.      |
|  | Converter pressure. |
|  | Lubrication.        |
|  | Exhaust.            |



2NC734

MK. IIB TRANSMISSION

FORWARD CLUTCH ENGAGEMENT

STAGE II: With the forward clutch applied, the shuttle valves move and allow the oil pressure in the third and reverse servos to exhaust and thus release the third and reverse gear bands.

### FAULT DIAGNOSIS CHART

FAULTS	RECTIFICATION SEQUENCE
<b>Torque converter</b>	
Excessive creep or engine stalls when selecting gears .. .. .	2
Poor acceleration and difficulty in starting from rest on hills .. .. .	5
Severe overheating and reduced maximum speed in all gears .. .. .	6
Rattle from converter on engagement of gears and frequency increasing with engine speed, particularly when under load .. .. .	6
Rattle or vibration from converter area in neutral and all gears .. .. .	11
Rattle or buzz in 'N' up to approximately 1,250 r.p.m. Noise disappears on engagement of any gear .. .. .	48, 49, 50
Squeal from converter area in neutral and all gears .. .. .	12, 13
<b>Gear selection and change speeds</b>	
Gear selection faulty .. .. .	3, 21
Kick-down change speeds incorrect .. .. .	7, 2
Change speeds incorrect on light throttle driving, possibly no drive in '1' or '4' of automatic 'D' range .. .. .	22, 23
Erratic change speeds in automatic 'D' range .. .. .	24, 25
'Tie-up' in 4 automatic 'D' range and/or transmission slip in automatic 1 and 4 .. .. .	3, 22, 23, 4
Clutch slip or 'flare up' on 3 to 4 change in automatic and manual ranges .. .. .	3, 22, 1, 4, 9, 28, 35, 36, 37, 42, 45
Vehicle moves off in 4 when any of the forward gears are selected and 'ties up' in reverse	41, 42
No automatic gear changes, transmission slip in all forward gears .. .. .	43
<b>Transmission slip/loss of drive</b>	
Complete loss of drive in all gear positions (transmission oil pressure normal), vehicle attempts to drive in 3 and 4 .. .. .	31, 32
Transmission slip in all gear positions .. .. .	1, 4, 9, 27, 28, 29, 30
Slip or no drive in reverse 'R' .. .. .	3, 1, 4, 9, 28, 8, 35, 36, 37
Slip or no drive in all forward gears .. .. .	1, 4, 33, 34
No drive in manual or automatic 1 .. .. .	38
Drive in 1 but 'tie-up' in 2, 3 and 4 manual or automatic .. .. .	38
Transmission slip in manual and automatic 2 or premature wear of second gear band .. .. .	3, 22, 28, 8, 39, 40
Transmission slip in 3 .. .. .	3, 8, 28, 39, 40
Slip or 'tie-up' on intermediate gear changes .. .. .	3, 4, 7, 23, 54
Drag in 4 and 'R' reverse, other gears function normally .. .. .	42
<b>Pressures</b>	
Excessive transmission pressures when starting from cold, with possible oil leakage from oil filter bowl seal .. .. .	28, 44
Low engine oil pressure .. .. .	1, 4
<b>Noise</b>	
Continual whine consistent with road speed but not in top gear .. .. .	51, 52
Continual whine consistent with engine speed except when car is stationary .. .. .	53
Noise or vibration with road speed in all gear positions .. .. .	26, 55
<b>Oil leaks</b>	
Oil leaks from converter area .. .. .	11, 14, 10, 15, 16, 17, 18, 19, 20
Oil leak from filter bowl seal, see 'Pressures' .. .. .	44, 28

DIAGNOSIS RECTIFICATION CHART

SEQ.	RECTIFICATION	SECTION	SEQ.	RECTIFICATION	SECTION
1.	Check oil level.	Aa.1	32.	Check the bevel gear train planetary pinions.	Fa.12
2.	Thoroughly check engine tune, idle and fast idle speeds, choke operation, also that the throttle opens fully.	Da.2	33.	Check fit of forward clutch feed pipe, the condition of all sealing rings (clutch feed) and ensure that correct cast iron sealing rings are fitted to forward clutch/auxiliary pump drive shaft.	Fa.6, Fa.11
3.	Check selector lever cable and transverse rod adjustment.	Fa.2	34.	Check condition of clutch plates and piston in forward clutch. Check and rectify clutch plate end-float.	Fa.11
4.	Carry out oil pressure check.	Fa.5	35.	Check feed pipes and sealing rings to top and reverse clutch and reverse band servo.	Fa.7
5.	Carry out stall test.	Fa.5	36.	Remove the top/reverse clutch from the gear train and check that the bush in the reverse output shaft has not turned and shut off the oil feed to the top/reverse clutch.	Fa.12
6.	Carry out road test.	Fa.1	37.	Check top and reverse clutch piston ring gaps and fit of rings in the piston grooves; check condition of clutch plates.	Fa.13
7.	Check governor control rod (kick-down) adjustment.	Fa.4	38.	Check if free wheel support dowel bolt is loose or sheared; replace if necessary.	Fa.6
8.	Check band adjustment.	Fa.6	39.	Examine servo feed pipes, seals, and servo piston seal.	Fa.11
9.	Check location of sealing rings and/or joint washer under oil filter head.	Aa.2	40.	Examine 2nd gear band and replace if excessively heat darkened or worn. Replace top/reverse clutch if damaged by worn band.	Fa.6, Fa.13
10.	Check tightness of converter drain plugs.	Aa.3	41.	Replace forward clutch.	Fa.11
11.	Check if converter retaining bolt or the six hub bolts are loose.	Aa.4	42.	Check that the gear train thrust washers are correctly positioned, and that the top/reverse clutch circlip is correctly located.	Fa.12, Fa.13
12.	Check converter housing bush for seizure or if loose in housing.	Aa.4	43.	Check the forward clutch—auxiliary pump drive shaft for breakage; also check pump gears, replace forward clutch and auxiliary pump housing assemblies if damaged.	Fa.10, Fa.11
13.	Check converter does not foul converter housing, or housing loose and fouling converter.	Aa.4	44.	Check torque tightness of filter bowl retaining bolt.	'General Data'
14.	Check low pressure valve for flange distortion or core plug leakage.	Aa.4	45.	Incorrect re-assembly of gear train; check and replace any damaged clutch plates and refit gear train correctly.	Fa.12
15.	Check converter housing oil seal for damage or incorrect location.	Aa.15	46.	Check that clutch plates are correctly engaged on hub.	Fa.13
16.	Check for oil leakage from converter housing oil pump cover.	Aa.4	47.	Check condition of auxiliary pump gear thrust washer.	Fa.10
17.	Examine idler gear closed end bearing for leakage.	Aa.4	48.	Remove valve chest and check that correct regulator valve is fitted.	Fa.8
18.	Check for oil leakage from the converter hub bolts (6).	Aa.4	49.	Check torque tightness of camshaft sprocket retaining nut.	'General Data'
19.	Check converter casing seam weld for oil leakage.	Aa.4	50.	Fit replacement oil pump assembly.	Aa.8
20.	Check converter housing for porosity.	Aa.4	51.	Check the bevel input gear preload.	Aa.3
21.	Check for correct assembly of the valve block, i.e. that the selector valve is engaged with the selector fork of the pipe chest.	Fa.7	52.	Check the shim adjustment of the top/reverse clutch—assembly to gear train.	Fa.12
22.	Check setting and alignment of the valve block governor valve with the governor lever (on pipe chest).	Fa.7	53.	Check the helical input and idler gear adjustment.	Aa.3
23.	Check that correct governor/auxiliary pump assembly is fitted in relationship with valve block (two types of each unit have been used).	Fa.7	54.	Check that the interconnecting feed pipe with the restricted bore is connected between the valve block and reverse servo.	Fa.7
24.	Check that the governor and governor valve operate freely; and for correct location of the valve block-governor link with the governor unit.	Fa.7	55.	Check condition of final drive gears and for correct pinion bearing preload.	Fa.16, Fa.6
25.	Check that the governor carrier shaft circlip is correctly positioned.	Fa.10			
26.	Check the auxiliary pump gears and the alignment of the pump housing with the end cover.	Fa.10			
27.	Remove front cover and check 'O' rings on cover to valve block connection.	Fa.6			
28.	Remove and clean valve chest.	Fa.8 or 9			
29.	Check main oil pump; joint washer, retaining screws are tight, drive coupling, examine delivery pipe connections (pump to transmission case).	Aa.8, Aa.9			
30.	Check oil pump pick-up pipe and oil strainer seals.	Aa.4			
31.	Check converter feed pipe for blockage by blowing through with compressed air from the valve block end.	Aa.4, Fa.7			

## CHANGE SPEED CHART

SELECTOR POSITION	THROTTLE POSITION	GEAR SHIFT	M.P.H.	Km.P.H.
'D'	Light	1-2	10-14	16-22
		2-3	15-19	24-30
		3-4	20-24	32-39
'D'	Kick-down	1-2	25-33	40-53
		2-3	37-45	60-72
		3-4	49-57	78-91
'D'	Kick-down	4-3	47-39	76-64
		3-2	39-31	62-50
		2-1	26-18	41-29
'D'	Closed (roll out)	4-3	20-16	32-26
		3-2	14-10	22-16
		2-1	8-4	12-6

## Section Fa.1

## FAULT DIAGNOSIS

It is important to carry out a thorough road test of the vehicle to establish the exact fault symptoms and to confirm which component(s) of the transmission are faulty or require adjustment. **The mechanical power flow diagrams indicate the components in use for each gear.** Always check the engine/transmission oil level and top up if necessary before commencing a road test. It may also be advisable to carry out the other preliminary checks detailed below.

## Preliminary checks and tests

- Check oil level (Section Aa.1).
- Check engine idling speed (Section Da.1).
- Carry out oil pressure check (Section Fa.5).
- Carry out stall test (Section Fa.5).

## Road test procedure

## GEAR SELECTION

- Check operation of gear selector in all seven positions as given below:  
'N'. Check that there is key start in this position only, and not in the drive positions.  
'1'. Confirm that there is drive and NO engine braking.  
'2', '3', '4'. Confirm that there is drive WITH engine braking.  
'D'. See 'CHANGE SPEEDS'.  
'R'. Confirm that there is drive WITH engine braking.

## CHANGE SPEEDS

- Check the 'kick-down' up-change speeds in 'D' position, refer to the 'CHANGE SPEED CHART'.

## Section Fa.2

## SELECTOR LEVER CABLE AND TRANSVERSE ROD ADJUSTMENT


## Checking

- Ensure that the hand brake is applied and start the engine. Move the selector lever to the 'R' position and check that reverse is engaged. Slowly move the lever back towards the 'N' position, checking that the gear is disengaged just before or as soon as the lever drops in the 'N' position on the quadrant. Repeat this procedure in the first gear '1' position. If adjustment is necessary, proceed as detailed below and refer to Fig. Fa.1.

## Adjusting

## SELECTOR LEVER TRANSVERSE ROD (1st TYPE)

- Pull back the rubber boot and remove the clevis pin. Ensure that the transverse selector rod is screwed in tightly and pushed fully into the transmission case.  
**WARNING.—Never start the engine with the transverse selector rod disconnected.**
- Swivel the bell-crank lever arm clear of the transverse selector rod yoke and refit the clevis pin. Check the measurement 'A' as shown in Fig. Fa.2 and, if necessary, adjust the yoke as described in item 4.
- Slacken the locknut and turn the yoke until the correct measurement is obtained. Re-tighten the locknut, ensuring that the yoke is set square to the bell-crank.



2NC461

Fig. Fa.1

Both versions of the pressed-type minimum backlash bell-crank lever assembly, showing 'A' the first exposed type and 'B' the second enclosed type


- |   |                                 |                                    |
|---|---------------------------------|------------------------------------|
| 1. Pressed bell-crank lever arm.                | 3. Bell-crank lever pivot bolt. | 6. Transverse rod.                 |
| 2. Bell-crank lever pivot pin and securing nut. | 4. Collar.                      | 7. Transverse rod bracket (fixed). |
|   | 5. Spherical joint.             | 8. Cable adjusting nuts.           |

**SELECTOR LEVER TRANSVERSE ROD (2nd TYPE)**

The transverse rod is not adjustable and is fitted on units having the later-type minimum backlash bell-crank lever assembly (see Fig. Fa.1).

**Selector lever cable**

5. a. **Transmissions with seven selector positions.**  
Select 'N' in the transmission unit by pulling the transverse rod fully out and then pushing it back in ONE detent.
- b. **Transmissions with six selector positions.**  
Proceed as above except that the transverse rod must be pushed back in TWO detents.
6. a. **EARLY MODELS.** Engage 'N' with the selector lever; adjust the selector cable until the hole in the cable fork aligns with the bell-crank lever and the clevis pin can easily be inserted (see Fig. Fa.2).
- b. **LATER MODELS.** On units fitted with the minimum backlash bell-crank lever, the adjustment procedure is as detailed above except that the cable fork must align with the bore of the spherical joint in the bell-crank lever until the bolt can easily be inserted (see Fig. Fa.1). **NOTE:** Ensure that the yoke end on the selector cable is secured square to the bell-crank lever before reconnecting.



DO888D

Fig. Fa.2

The gear-change cable and transverse rod adjustment (Forged-type bell-crank)

A =  $\frac{25}{32}$  in. (20 mm.) with transverse rod fully in

- |                                 |   |
|---------------------------------|---|
| 1. Rubber boot.                 | 6. Cable adjusting nuts.                    |
| 2. Clevis pin.                  | 7. Forged bell-crank lever arm.             |
| 3. Transverse rod (adjustable). | 8. Bell-crank lever pivot and securing nut. |
| 4. Transverse rod yoke.         |   |
| 5. Yoke locknut.                |   |

7. Carry out the checking procedure in item 1; slight readjustment may be necessary so that the amount of movement to engage or disengage gears is equalized in both directions.
8. Tighten all adjustment/locking nuts and ensure that the clevis pins (when fitted) are secured. Pack the rubber boots (when fitted) with Duckhams Lammol Grease, refit the boots and the bell-crank lever guard.

**NOTE:** The bell-crank lever guard fitted to units having the minimum backlash bell-crank is reshaped, but the earlier-type guard can be modified (see Fig. Fa.3) to use with the later-type bell-crank.

9. Carry out a road test checking the operation in each selector position.




Fig. Fa.4  
The later type selector lever housing and two terminal type inhibitor switch. 'Inset' shows the earlier switch with four connections

### Section Fa.3

#### INHIBITOR SWITCH ADJUSTMENT

The switch is located on the rear of the gear selector housing (Fig. Fa.4) and must be adjusted to ensure that the engine can only be started when the selector lever is in the 'N' position on the quadrant.

The earlier-type switches have four terminals, two of which are connected through the ignition/starter circuit; later-type switches have two terminals only.




Fig. Fa.3

Reset the original bell-crank lever guard for use with the pressed bell-crank by bending it to the revised shape (view 'A') and adding the cut-out (view 'B')

X=1  $\frac{3}{8}$  in. (35 mm.) Y=  $\frac{3}{8}$  in. (9.5 mm.) Z=2  $\frac{3}{8}$  in. (67 mm.)

#### ELECTRICAL CONNECTIONS

Ignition/starter circuit: Connect to 2 and 4 (wiring connections are interchangeable).

Reverse light (when fitted): Connect to 1 and 3.

Check the selector lever cable and transverse rod adjustment before adjusting the inhibitor switch.

#### Checking adjustment

1. Verify that the starter operates only when the selector lever is in the 'N' position, and also that the reversing light (when fitted) operates only when 'R' is selected.

#### Adjusting

2. Select 'N' and disconnect the electrical connections from the switch.
3. Slacken the locknut (arrowed, see Fig. Fa.4), and unscrew the switch almost out of the housing.
4. Connect a test lamp or meter across the switch terminals 2 and 4. Screw the switch into the housing until the circuit is made, and mark the switch body. Continue screwing in the switch and note the number of turns required until the circuit breaks. Remove the test equipment and unscrew the switch from the housing half the number of turns counted.
5. Tighten the locknut and refit the electrical leads to the appropriate terminals.

**NOTE:**—If the switch cannot be adjusted to operate correctly it must be renewed.

Section Fa.4

GOVERNOR CONTROL ROD (KICK-DOWN) ADJUSTMENT

Checking

1. Run the engine to its normal working temperature.
2. Check with a tachometer that the carburetter is adjusted to give an engine idling speed of 650 r.p.m.
3. Disconnect the governor control rod at the carburetter, insert a ¼ in. (6.4 mm.) diameter rod through the hole in the intermediate bell-crank lever and locate the hole in the transmission case (Fig. Fa.5).
4. Check if the control rod can now be re-connected to the carburetter with its fulcrum pin an easy sliding fit through the forked end and with the carburetter linkage.  
Adjust if necessary, as detailed below.




Fig. Fa.5  
The governor control rod adjustment

- |                               |                                   |
|-------------------------------|-----------------------------------|
| 1. Throttle adjustment screw. | 4. ¼ in. (6.4 mm.) diameter rod.  |
| 2. Governor control rod.      | 5. Intermediate bell-crank lever. |
| 3. Locknut.                   | 6. Transmission case hole.        |

Adjusting

5. Slacken the control rod locknut, disconnect the forked end at the carburetter linkage and turn the rod until the correct length is obtained. Connect up at the carburetter end, tighten the locknut and remove the checking rod (see Fig. Fa.5).
6. Road-test the car and check that automatic change speeds corresponds to those given in the 'CHANGE SPEED CHART' in Section Fa.1.

If full throttle change speeds are LOW, disconnect the forked end of the rod, slacken the locknut and SHORTEN the rod; conversely, if full throttle change speeds are HIGH, turn the rod anti-clockwise to LENGTHEN it slightly.

Road-test to ensure correct change speeds can now be obtained.

- a. In all gear positions except 'R' a pressure of between 75 and 85 lb./sq. in. (5.3 and 6 kg./cm.<sup>2</sup>) should register on the gauge.
- b. In 'R' the pressure should be between 115 and 125 lb./sq. in. (8 and 8.8 kg./cm.<sup>2</sup>).

NOTE.—Should the approximate pressures given above not be obtainable, see Section Fa.1, 'FAULT DIAGNOSIS'.

4. Remove the pressure test equipment and refit the plug.

Section Fa.5

OIL PRESSURE AND STALL SPEED CHECKS

In suspected cases of slip or poor acceleration a converter stall speed check should be carried out as detailed below. If there is slip in all gears a low oil pressure is indicated which should be confirmed by a pressure check.

Oil pressure check

1. Check and top up the oil level (see Section Aa.1).
2. Remove the pressure point plug on the engine oil filter, fit Service tool adaptor 18G 677 C, and connect Service tool 18G 677 Z (see Fig. Fa.6) or use pressure gauge (Service tool 18G 502 A with pipe and adaptor 18G 502 K).
3. Start and run the engine until the oil temperature is 80° C. (176° F.) (check with a thermometer inserted into the dipstick hole). Re-start and run the engine at 1,000 r.p.m. and check the following approximate pressures:




Fig. Fa.6  
Checking the pressures and the stall speed with Service tool 18G 677 Z and adaptor 18G 677 C (arrowed)



### Stall speed check

5. Start and run the engine until it reaches its normal working temperature and check the oil level.
6. Connect a suitable tachometer or that of Service tool 18G 677 or 18G 677 Z (see Fig. Fa.6).  
Service tool electrical connections:  
18G 677 – Green to ignition coil CB.  
Red to battery positive.  
Black to battery negative.
- 18G 677 Z – Red to ignition coil CB.  
Black to earth connection.

7. Apply the hand and foot brakes, select any gear position except 'N' or '1', apply maximum throttle for **not more than 10 seconds** and note the tachometer reading. Compare the figure obtained with the 'Stall speed' chart.




Fig. Fa.7

Removing the auxiliary pump and governor assembly

### Stall speed chart

8. Disconnect the tachometer.

MODEL	R.P.M.	Condition	Rectification
848 c.c.	1,300–1,400	Satisfactory	Nil
998 c.c.	1,400–1,500	Satisfactory	Nil
	Under 1,000	Stator free wheel slip	Change torque converter
	Over 1,500	Transmission slips	Check transmission unit (see Road Test note)
848 c.c. and 998 c.c.	Under 1,300	Engine down for power	Check engine

6. Remove the dowel bolt and pull out the auxiliary pump filter outlet pipe.
7. Pull out the auxiliary pump outlet and the forward clutch apply pipes.
8. Remove the set screw and lift out the auxiliary pump filter.
9. Remove Service tool 18G 1097 and withdraw the forward clutch from the casing.

**NOTE.**—For forward clutch dismantling and reassembling see Section Fa.11.

### Section Fa.6

#### TRANSMISSION UNIT

##### Dismantling

1. Remove the engine and transmission from the car, see Section Aa.3.
- 2a. Remove the transmission from the engine as detailed in Section Aa.4 **only** if fitting a replacement engine, transmission case, or if it is necessary to remove the main oil strainer pick-up pipe and seals.
- 2b. Remove the converter and converter housing as detailed in Section Aa.4, items 1 to 11 and 13.
3. Unscrew and withdraw the transverse rod and remove the front cover (the connection is pressed into the later-type cover).
4. Remove the governor control assembly from the transmission case and fit Service tool 18G 1097 (see Fig. Fa.19).
5. Remove the securing nuts and pull the auxiliary pump and governor assembly from the transmission case.

**NOTE.**— For auxiliary pump and governor dismantling and reassembling see Section Fa.10.




Fig. Fa.8

Removing the auxiliary oil pump strainer 1 and pipe 2, with 3 the outlet pipe, and 4 the forward clutch apply pipe




Fig. Fa.9

The forward output shaft and the reverse shut-off valve

- Inset 'A'—1. Reverse shut-off valve } early type
- 2. Shut-off valve piston } early type
- Inset 'B'—3. Reverse shut-off valve } later type
- 4. Shut off valve piston } later type

10. Withdraw the forward output shaft and remove the reverse shut-off valve, which should be identified for reassembly. The Mk. II transmission is fitted with a shut-off valve having a squared bronze thrust pad (see Fig. Fa.9) and a modified valve piston having a square cut shoulder. These can only be interchanged as a pair and the latest type should be fitted when rebuilding the transmission.
11. Insert the dummy output shaft Service tool 18G 1093 or 18G 1093 A.
12. Slacken off the servo band adjusters.




Fig. Fa.10

Removing the gear train assembly. The arrows indicate the dowel bolt and its location in the free-wheel support




Fig. Fa.11

Removing the valve block and servo unit as an assembly

13. Remove the dowel bolt (Fig. Fa.10) and remove the gear train which includes the top and reverse clutch with its Torrington needle thrust bearing and steel washer, and the first gear free-wheel assembly.  
**NOTE.**—For gear train dismantling and reassembling see Section Fa.12.
14. Remove the engine oil feed pipe as shown in Fig. Aa.9. On later transmissions unscrew the adaptor and withdraw the valve block connecting pipe through the adaptor hole.




Fig. Fa.12

Removing the differential assembly




Fig. Fa.13  
The main oil strainer, pick-up pipe and seals

15. Remove the valve block and servo unit securing bolts. Depress the tops of the bands and unhook them from the servos and lift out the valve block and servo unit as an assembly (Fig. Fa.11).  
**NOTE.**—For valve block dismantling and reassembling see Section Fa.8, 9. For servo unit dismantling and reassembling see Section Fa.14.
16. Remove the bands from the transmission case.




Fig. Fa.14  
Using Service tool 18G 1095 to hold the top and reverse splines when removing the forward clutch hub nut




Fig. Fa.15  
Removing the forward clutch hub nut  
1. Service tool 18G 1096. 2. Socket handle.

17. Remove the governor control assembly from the transmission case.
18. Knock back the lock washers and remove the nuts from the differential housing and the differential end cover set screws. Remove the differential and housing assembly.  
**NOTE.**—For differential dismantling and reassembling see Section Fa.16.
19. Remove the main oil feed pipe and strainer (see item 2a).





Fig. Fa.16  
1. Forward clutch splines. 2. Selective thrust washer. 3. Final drive pinion. 4. Top and reverse splines.  
Shown (inset) correctly assembled with the arrow indicating the chamfer on the pinion

20. Knock back the lock washer on the nut on the forward clutch splines and use Service tool 18G 1095 to hold the top and reverse clutch hub (Fig. Fa.14) and remove the nut with 18G 1096 (Fig. Fa.15). Drift out the top and reverse clutch hub and lift out the pinion assembly.
21. Remove both the bearings from the centre webs of the transmission case; each bearing must be drifted out on its outer race and from opposing sides of the webs.

**Reassembling the transmission unit**

Absolute cleanliness is essential, use fuel (petrol) or paraffin (kerosene) where necessary for cleaning. Dry the components with an air pressure line or use non-fluffy rag. Clean all joint faces and fit new joint washers and oil seals. After reassembly of each dismantled unit the complete transmission can now be rebuilt.

Lubricate all components with one of the recommended oils, refer to the 'RECOMMENDED LUBRICANTS' chart shown in the 'MAINTENANCE' Section. Ensure that new 'O' rings and seals are well lubricated when reassembling units or rebuilding the transmission assembly.

22. Refit the top and reverse clutch hub bearings to the centre webs of the transmission casing. Drift each bearing on its outer cage into the web until the bearing register contacts the face of the web.
23. Refit the top and reverse clutch hub, together with the final drive gear pinion but without the selective washer. Lightly tighten the forward clutch hub nut until light friction is felt on the bearings when rotating the hub.




Fig. Fa.18  
Tightening the forward clutch hub nut with Service tools 18G 1096 1, and 18G 592, 2

24. Check the gap existing between the final drive gear and the forward clutch hub bearing face.
25. Subtract .002 in. (.05 mm.) from the gap measurement and select a washer of this thickness from the range available.
26. Remove the hub and refit the assembly with the selected washer and with the chamfer on the final drive pinion facing the gear train (see Fig. Fa.16).
27. Use Service tool 18G 1095 to hold the top and reverse clutch splines (see Fig. Fa.17) and tighten the forward clutch hub nut with Service tool 18G 1096 and 18G 592 (see Fig. Fa.18), to the torque figure given in 'GENERAL DATA'.




Fig. Fa.17  
Using Service tool 18G 1095 to hold the top and reverse splines when tightening the forward clutch hub nut




Fig. Fa.19  
Holding the forward clutch hub in position with Service tool 18G 1097

28. Check that there is light friction on the bearings when rotating the hub, i.e. the bearings should have a preload of .002 in. (.05 mm.).
29. Tap up the locking washer.
30. Insert the forward output shaft with its bi-metal washer (see Fig. Fa.9) through the output gear assembly. Ensure that the correct type of reverse shut-off valve is located in the end of the shaft (see item 10), and that the rings on the shaft are in good condition.
31. Position the plastic sleeve over the rings on the forward clutch shaft and refit the forward clutch unit. If an earlier unit is being replaced by one of a later type, the reverse shut-off valve must also be changed (see item 10). Fit Service tool 18G 1097 to retain the correct position of the forward clutch unit (see Fig. Fa.19).
32. Fit new seals to the valve block connections and fit them into their correct locations in the transmission casing.  
If a new transmission casing is being fitted, check the distance from the front flange of the transmission to the face of the centre connection inside the case. See that the correct connections are fitted according to the chart below, or else the valve block may later prevent the front cover from seating properly.

DISTANCE	CONNECTIONS
2.25 in. (57.2 mm.)	22A 1336
2.48 in. (62 mm.)	22A 812

33. Reassemble the valve block and servo unit as an assembly, fitting new seals to the inter-connecting pipes.
34. Refit the second, third, and reverse gear bands into the transmission casing.




Fig. Fa.20

Using the positioning fixture Service tool 18G 1094 to ensure correct alignment of the pipes




Fig. Fa.21

Engaging the valve block linkage 1 with the spring clip drive mechanism 2 of the later-type governor

35. Refit the valve block and the servo unit as an assembly into the transmission case, ensuring correct location of the valve block with the connections in the case and that the governor linkage is positioned over the web in the transmission casing.
36. Locate the bands on the servo struts.
37. Tighten the valve block and the servo unit securing bolts to the torque figure given in 'GENERAL DATA'.
38. Refit the forward clutch apply pipe into its location in the transmission casing.
39. Refit the auxiliary pump pick-up strainer and pipe; secure the pipe with the dowel bolt (fitted with a copper sealing washer). Refit and tighten the strainer securing screw.
40. Fit a new joint washer to the transmission casing. Fit Service tool 19G 1094 and align the pipes (Fig. Fa.20) and remove the tool.
41. Refit the auxiliary pump and governor assembly and engage the valve block linkage with the later-type governor unit as shown in Fig. Fa.21, also ensuring correct alignment with the oil pipes and the forward shaft. The plastic sleeve fitted over the rings on the shaft is for assembly purposes, and will become safely displaced along the forward clutch shaft. Tighten the securing nuts to the torque figure given in 'GENERAL DATA'.
42. Remove the forward clutch retainer—Service tool 18G 1097.

43. Refit the top and reverse clutch hub washer and the Torrington needle thrust bearing into position with grease.
44. Ensure that the top and reverse clutch friction plates are free to drop before refitting the gear train assembly into the transmission. Correctly position the second, third, and reverse gear bands in the case and refit the gear train, using hand pressure only to push it into position. Quick rotation of the input gear will assist in engaging the top and reverse clutch friction plates. When correctly reassembled the dowel bolt will engage easily in the free-wheel support (Fig. Fa.10).
45. Refit the dowel bolt with a new lock washer.
46. Screw the gear change transverse rod fully into the valve block linkage. Check and reset if necessary the transverse rod adjustment (see Section Fa.2).
47. Adjust the second, third and reverse servos (see Fig. Fa.24). Slacken the locknut 1 and turn the spherical adjuster 2 until each brake band 3 is in contact with the transmission casing stops 4 and all slack is just eliminated. Turn back the adjuster nine flats to obtain the clearance 'A' and tighten the locknut, which should give the minimum clearance.
48. Fit a new seal to the front cover connection, and refit the cover using a new joint washer.  
On early units the front cover connection can be removed and therefore requires two oil seals.  
If the front cover fails to mate correctly with the transmission case check that the correct transmission casing to valve block connections have been fitted as described in item 32.
49. Refit the engine oil feed pipe as shown in Fig. Fa.23.  
On later transmissions refit the valve block connecting pipe through the adaptor hole and screw the adaptor back in.




Fig. Fa.22

The correct position of the kick-down rod assembly




Fig. Fa.23

The engine oil feed pipe assembly. Inset 'A' shows the early type assembly. Inset 'B' shows the adaptor used when a later transmission is fitted to an early type engine

- |                          |                           |
|--------------------------|---------------------------|
| 1. Engine oil feed pipe. | 3. Adaptor 'O' ring seal. |
| 2. Adaptor.              | 4. Banjo union screw.     |

50. Refit the main oil strainer and pick-up pipe using new seals (if these items were removed), see item 2a.
51. Refit the differential assembly as detailed in Section Fa.16.
52. Refit the engine to the transmission as detailed in Section Aa.4 (if removed see item 2a).
53. Refit the converter and components removed in item 2b see Section Aa.4.
54. Refit the engine/transmission unit to the car as detailed in Section Aa.3.




Fig. Fa.24

The servo unit band adjustment

A = .040 to .080 in. (1.02 to 2.03 mm.)




Fig. Fa.25  
The valve block assembly (Mk. I and II transmissions)

1. Lid.
2. Valve chest.
3. Pipe chest.

### Section Fa.7

#### VALVE BLOCK (Removing and Refitting)

##### Early unit (848 c.c. Up to Engine No. 8AH/A/H9733)

The valve block can be removed from the transmission unit with the power unit IN SITU by removing the unit as three individual sections.

It is necessary to clean thoroughly the area around the transmission front cover before any dismantling is commenced. Absolute cleanliness is essential at all times and especially so whilst servicing this unit.

##### Later 848-c.c. and 998-c.c. units (From Engine No. 8AH/A/H9734)

The valve block assembly cannot be removed from the transmission unit with the power unit IN SITU but the lid and valve chest can be removed for dismantling and cleaning. If it is necessary to examine and/or fit new seals to the valve block/servo unit interconnecting pipes or to remove the pipe chest, it is necessary to remove the power unit from the car and remove the converter and housing (see items 25 to 32).





Fig. Fa.26  
The valve block (with inbuilt engagement control and shuttle valves) which is fitted to the Mk. II B transmission unit. This unit may be identified by the exhaust hole in the lid (arrowed)

1. Lid.
2. Valve chest.
3. Separator plate.
4. Pipe chest.



MO448B

Fig. Fa.27

The valve block connections and pipes. Assemble the pipe 4 with its restricted end in the valve block (Mk. I and II transmissions only)

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Connection—top/reverse clutch.</li> <li>2. Connection—forward clutch.</li> <li>3. Connection—auxiliary pump (not fitted on Mk. II B units).</li> </ol> | <ol style="list-style-type: none"> <li>4. Connecting pipe with restrictor to reverse servo(pipe without restrictor fitted to Mk. II B units).</li> <li>5. Connecting pipes (to second and third servos).</li> <li>6. Converter feed pipe.</li> <li>7. Pipe assembly guide.</li> </ol> |
|--|---|

**Removing (early models)**


1. Remove the front grille.
2. Remove the filter assembly as detailed in Section Aa.2.
3. Remove the engine oil feed pipe.
4. Drain the engine/transmission unit.
5. Remove the transmission front cover and valve block connection.
6. Place the gear selector lever in the 'R' position on the quadrant.
7. Remove the bell-crank lever clevis pin. Unscrew and pull out the transverse rod sufficiently to remove the valve block.
8. Loosen the servo unit securing bolts.
9. Remove the valve block assembly as individual components, i.e. the lid, valve chest, and finally (if necessary) the pipe chest (Fig. Fa.25).

The valve block can only be removed as an assembly with the power unit removed from the car.

**VALVE CHEST ONLY—'POWER UNIT IN SITU'**

**Removing (later 848-c.c. and 998-c.c. models)**

10. Carry out items 1, 2, and 4.
11. Disconnect the engine oil feed pipe and remove the adaptor. Withdraw the valve block connecting pipe through the adaptor hole.



2NC670

Fig Fa.28

The valve block fitted to Mk. II B transmissions (with engagement control valve incorporated in the valve block assembly)

- |   |  |   |
|---|--|---|
| <ol style="list-style-type: none"> <li>1. Connections (top/reverse clutch and forward clutch).</li> </ol> | <ol style="list-style-type: none"> <li>2. Connecting pipes (to second, third and reverse servos).</li> </ol> | <ol style="list-style-type: none"> <li>3. Converter feed pipes.</li> <li>4. Guide—converter feed pipe.</li> </ol> |
|---|--|---|






Fig. Fa.29

The removing and refitting sequence of the pipe chest section of the valve block

1. Servo unit.                      2. Connecting pipes.                      3. Pipe chest.

12. Remove the transmission front cover and manoeuvre the cover upwards and out through the grille aperture.
13. Remove the valve block lid and the valve chest.

#### Refitting

14. Refitting is a reversal of the removal procedure; take care to locate the selector valve with the linkage and the governor rod with the governor. The flat on the governor valve must face inwards. Tighten all securing bolts to the torque figures given in 'GENERAL DATA'.
15. Ensure that the new joint washer fitted to the filter head/transmission front cover is correctly fitted.
16. Check the gear change selector lever cable and transverse rod as detailed in Section Fa.2 and adjust if necessary.
17. Refill the engine/transmission unit with one of the recommended oils (see 'RECOMMENDED LUBRICANTS' chart in 'MAINTENANCE' Section). Top up to the 'MAX' mark on the dipstick, see the procedure given in Section Aa.1.

Fa.28

#### VALVE BLOCK ASSEMBLY REPLACEMENT 'POWER UNIT REMOVED'

##### Removing (later 848-c.c. and 998-c.c. models)

18. Remove the engine/transmission unit from the car (Section Aa.3).
19. Remove the converter cover, converter and converter housing as detailed in Section Aa.4, items 3 to 11.
20. Drain the engine/transmission unit.
21. Remove the complete filter assembly as detailed in Section Aa.2.
22. Disconnect the engine oil feed pipe and remove the adaptor. Withdraw the valve block connecting pipe through the adaptor hole.
23. Remove the front cover.
24. Disconnect, unscrew, and pull out the transverse rod.
25. Remove the governor control assembly from the transmission case and fit Service tool 18G 1097 to hold the forward clutch (see Fig. Fa.19).
26. Remove the securing nuts and withdraw the auxiliary pump and governor assembly from the transmission case.




Fig. Fa.30

The valve chest with the locations of the valves and components (Mk. I and II transmissions)

- |                     |                                |
|---------------------|--------------------------------|
| 1. Selector valve   | 4. Tow start valve.            |
| 2. Governor valve.  | 5. Second and top gear valves. |
| 3. Regulator valve. | 6. Third gear valve.           |

27. Remove the valve block lid and valve chest.
28. Remove the pipe chest as shown in the operation sequence in Fig. Fa.29 after pulling it outwards to release it from the connections and to disconnect the governor linkage.
29. Refer to Fig. Fa.29.
  - a. Push the pipe chest fully against the casing.
  - b. Move the servo unit in the opposite direction until the three pipes are clear of the servo unit.
  - c. Pull the servo unit outwards and downwards; lift the pipe chest upwards and (when clear), move it so that the pipes are over the top of the servo and the regulator valve lever is clear of the transmission casing.
  - d. Hold the servo unit down and withdraw the pipe chest after lifting the linkage over the web in the casing.

**Fitting replacement unit**

30. Remove the lid and valve chest from the pipe chest of the new unit. Refit these as individual components in the reverse order of the removing procedure, noting the following points.
31. Fit the connections into their locations in the transmission case.
32. Assemble the three pipes into the pipe chest (together with the nylon guide) before refitting the unit to the transmission casing.

33. Carry out operation 14.
34. Position the plastic sleeve over the rings on the forward clutch shaft.
35. Carry out operations 40 to 42 in Section Fa.6.
36. The remainder is a reversal of the removal procedure.

**Section Fa.8**

**VALVE BLOCK  
(Dismantling and Reassembling)**

**Dismantling**

**NOTE.**— Before dismantling the valve block it must be remembered that the valves are selected for each bore. It is of the utmost importance therefore to reassemble each valve into its original bore and position. Cleanliness is essential at all times.

1. If the valve block has been removed as a complete unit, detach the lid and valve chest from the pipe chest. See Fig. Fa.25.
2. Remove the selector and governor valves.
3. Remove the 'C' clips and the plugs. Remove the regulator valve, spring, and reverse booster piston assembly.
4. Remove the 'C' clip and the plug. Remove the tow-start valve, spring, and spring retainer.




Fig. Fa.31

The valve chest with the 'C' clips correctly positioned (Mk. I and II transmissions)

5. Remove the 'C' clips and the plugs. Remove the second and fourth gear valves, spring, and booster piston.
6. Remove the 'C' clip and plug. Remove the third gear valve booster piston, spring, spring retainer and the plastic plug.




Fig. Fa.33

The locations of the 'C' clips in the valve chest (Mk. II B transmission)

### Inspecting

Clean all parts thoroughly in clean fuel (petrol) or paraffin (kerosene) and dry off using an air pressure line.

Check for burrs on the valves and valve chest and for sticking valves. Place all components in automatic transmission oil before reassembling to the valve block.

### Reassembling

7. Reassemble each valve assembly in the reverse order of dismantling (see Fig. Fa.30). Check that the 'C' clips and plugs are correctly located in the valve chest (see Fig. Fa.31).




Fig. Fa.32

The valve chest fitted to Mk. II B transmission showing the locations of the valves and components

- |   |  |
|---|--|
| 1. Selector valve.                      | 5. The components of the second and top gear valves. |
| 2. Governor valve.                      | 6. One-way dump valve and stop (plug).               |
| 3. Regulator valve.                     | 7. Third gear valve components.                      |
| 4. Engagement control valve components. |  |

Section Fa.9

**VALVE BLOCK—WITH INBUILT  
ENGAGEMENT CONTROL AND SHUTTLE  
VALVES**

(Dismantling and Reassembling)

**Dismantling**

**NOTE.**—Before dismantling the valve block it must be remembered that the valves are selected for each bore. It is of the utmost importance therefore to reassemble each valve into its original bore and position. Cleanliness is essential at all times.

1. If the valve block has been removed as a complete unit, which is essential if the shuttle valves are to be dismantled, detach the lid and valve chest from the pipe chest and also take out the separator plate and flap valve.
2. Pull out the selector and governor valves.
3. To remove the regulator valve components, pull out both 'C' clips and extract the plugs, the regulator valve, spring and reverse booster piston.
4. Pull out both the 'C' clips which secure the engagement control valve components, and extract the plain plug, the plug with the extended stop, the spring and the valve.
5. Pull out both the retaining 'C' clips and extract the plugs, second and top gear valves, spring and booster piston.
6. Pull out the end 'C' clip and extract the plug and the one-way dump valve. Withdraw the centre 'C' clip and remove the third gear valve with the booster piston, spring, spring retainer and the plastic plug.




Fig. Fa.35

It is essential that the flap valve 1 is positioned flat on its seatings 2 before the separator plate 3 is located and the valve block is reassembled

**ENGAGEMENT CONTROL SHUTTLE VALVES**

7. From the back of the pipe chest depress in turn the abutment of each of the shuttle valve components sufficiently to release the retaining washer; then extract the abutment, engagement piston (reverse gear shuttle), shuttle valve and the spring.

**Inspecting**

Clean all parts thoroughly in clean fuel (petrol) or paraffin (kerosene) and dry off using an air pressure line. Check for burrs on the valves and valve chest and for sticking valves. Place all components in automatic transmission oil before reassembling them into the valve block.

**Reassembling**

8. Reassemble for each valve assembly into its correct bore in the reverse order of dismantling (see Fig. Fa.32). Check that the 'C' clips and plugs have been correctly located in the valve chest, as shown in Fig. Fa.33, and then the retaining washers of the shuttle valves are properly seated in their correct locations (see Fig. Fa.34).
9. When reassembling the complete valve block see that the flap valve is fitted, lying flat, in its correct location behind the selector valve as shown in Fig. Fa.35, and that the separator plate is fitted between the valve chest and the pipe chest.




Fig. Fa.34

'A'—Third gear shuttle valve assembly  
'B'—Reverse gear shuttle valve assembly

- |                       |                          |
|-----------------------|--------------------------|
| 1. Spring.            | 4. Abutment.             |
| 2. Shuttle valve.     | 5. Washer.               |
| 3. Engagement piston. | 6. Washer locating ribs. |

### Section Fa.10

#### AUXILIARY PUMP AND GOVERNOR

##### Removing

1. Remove the engine/transmission unit from the car as detailed in Section Aa.3.
2. Remove the governor control assembly from the transmission case and fit Service tool 18G 1097 (see Fig. Fa.19).
3. Remove the securing nuts and pull the auxiliary pump and governor assembly from the transmission case.

##### Dismantling

4. Remove the speedometer drive assembly.
5. Remove the set screws and bolt. Pull out the governor centre shaft, and lift away the governor assembly together with one of the auxiliary pump gears.
6. Remove the circlip, lift off the auxiliary pump gear, and remove the governor.
7. Lift out the governor bearing trunnions and washer.
8. Remove the second auxiliary pump gear from the auxiliary pump housing together with its thrust washer; the earlier type cover is fitted with a bi-metal thrust washer with a plain bush fitted in the housing while the later type cover has a flanged bush and a steel thrust washer, see Fig. Fa.37.




Fig. Fa.36

The speedometer drive, auxiliary pump gears and governor assembly components




Fig. Fa.37

Both types of auxiliary pump housing. 'A' shows the later type housing with a flanged bush (arrowed) and steel thrust washer. 'B' shows the early type housing with a plain bush and bi-metal thrust washer

##### Inspecting

Examine all components for wear or damage.

All units except Mk. II B. Check the condition of the bi-metal thrust washer; if it has broken up and caused the bush in the housing to move deeper into its bore, replace the gears and housing assembly with the Mk. II B assembly which has a flanged bush and a steel thrust washer, see Fig. Fa.37.

##### Reassembling

9. Reassemble the auxiliary pump gear with its thrust washer to the pump casing (see Fig. Fa.37).




Fig. Fa.38

Centralizing the pump and governor unit 1 with the end cover 2 using Service tool 18G 1106 (arrowed)

10. Refit the governor auxiliary pump gear and circlip. Ensure that both gears are seating correctly and will rotate freely after assembly.
11. Refit the governor assembly to the auxiliary pump and refit the centre shaft.
12. Use Service tool 18G 1106 to centralize the auxiliary pump and governor unit with the end cover, tighten the securing bolts to the torque figure given in 'GENERAL DATA' and remove the Service tool.
13. Refit the speedometer drive assembly, with a new joint washer.

**Refitting**

14. Carry out the instructions given in Section Fa.6, items 40 and 42.

**NOTE.**—See 'GENERAL DATA' for all torque figures.




Fig. Fa.40

The fitted position of the toggles and spring ring (fitted to very early units). The arrow indicates location of spring ends exactly opposite the only five tooth section of the clutch unit

**Section Fa.11**

**FORWARD CLUTCH**

Two types of clutch assembly have been fitted. The earlier type has 47 teeth and is shown in Fig. Fa.41. This has now been replaced by a clutch having 30 teeth which is shown in Fig. Fa.43. The two clutches are interchangeable as complete assemblies, although the individual components are not.

**NOTE.**— Later 30 tooth forward clutches are fitted with a modified reverse shut-off valve piston (see item 10, Section Fa.6). If fitting a new clutch having the modified piston, the reverse shut-off valve in the forward output shaft must also be replaced by one of the modified types.

**Removing**

1. Carry out the operations given in Section Fa.6, items 1 and 4 to 9.

**Dismantling**

2. Remove the retaining circlip or Spirolox ring.  
**NOTE.**—Mark the retainer plate and steel clutch plate to assist when reassembling.
3. 30 TOOTH CLUTCH: Remove and discard any shims which have been fitted to rectify clutch plate end-float. A new method of controlling clutch plate end-float using end and intermediate steel plates of varying thicknesses together with a wider section retaining circlip was introduced at the Engine Numbers given below.  
Commencing Engine Numbers: 85H–285E–H347, 99H–285E–H3832, and 99H471E–H1421.

**NOTE.**— Whenever a transmission is dismantled prior to the above Engine Numbers, the assembly may be brought up to the latest specification. Always check the specification of a new forward clutch unit taken from stock; fit the relevant parts required and check the end-float adjustment before fitting.

Refer to 'Adjusting' and the chart giving the range of plates available.





Fig. Fa.39

Fitting the forward clutch piston using Service tool 18G 1102

1. Forward clutch.
2. Service tool 18G 1102.
3. Forward clutch piston.



2NC677

Fig. Fa.41

The early-type (47-tooth) forward clutch components. The arrow indicates the spring ring fitted to very early units only

- |                                       |                               |                                    |
|---------------------------------------|-------------------------------|------------------------------------|
| 1. Circlip (replacing Spirolox ring). | 5. Piston return springs (6). | 9. Circlip-reverse shut-off valve. |
| 2. End plate.                         | 6. Pressure plate.            | 10. Reverse shut-off valve.        |
| 3. Clutch plates (paper faced).       | 7. Toggles.                   | 11. Forward clutch unit.           |
| 4. Intermediate plate.                | 8. Piston.                    |                                    |

4. Lift out the piston return springs and pressure plate.
5. Remove the spring ring (if fitted) and toggles (see Fig. Fa.41).
6. Use an air pressure line to blow out the piston.
7. Remove the circlip and lift out the reverse shut-off valve piston, which should be identified as detailed in item 10 of Section Fa.6, for reassembly.

### Inspecting

Check all parts for wear and renew if necessary. Check the reverse shut-off valve oil seals and renew if necessary.

### Reassembling

8. Refit the reverse shut-off valve piston of the correct type, and fit a new circlip.
9. Assemble the seal onto the piston with the lips of seal facing inwards and lubricated with one of the recommended oils, see 'RECOMMENDED LUBRICANTS'.
10. Insert Service tool 18G 1102 into the clutch unit and press the piston through the tool until it is fully into its bore, see Fig. Fa.39.





Fig. Fa.42

The fitted position of the toggles and springs of the 30-tooth clutch



2NC466A

Fig. Fa.43  
The (30-tooth) forward clutch components


- |                                       |                                |                                    |
|---------------------------------------|--------------------------------|------------------------------------|
| 1. Circlip (replacing Spirolox ring). | 5. Piston return springs (10). | 9. Circlip—reverse shut-off valve. |
| 2. End plate.                         | 6. Pressure plate.             | 10. Reverse shut-off valve.        |
| 3. Clutch plates (paper faced).       | 7. Toggles.                    | 11. Forward clutch unit.           |
| 4. Intermediate plate.                | 8. Piston.                     |                                    |

11. 47-TOOTH CLUTCH. Assemble the toggles and spring ring (early units) with the end of the spring-ring located as shown in Fig. Fa.40, and with the cut-out tooth on the pressure plate in the relative position to the ends of the spring ring (Fig. Fa.41). Assemble the first friction plate and the piston return springs.
12. 47-TOOTH CLUTCH. Assemble the remainder of the components as shown in Fig. Fa.41 with the six

recessed teeth on the end plate positioned relative to the piston return springs.

**NOTE.**— Since selective end and intermediate plates are not available for the 47 tooth clutch unit, the later type 30 tooth clutch must be fitted as a replacement if the clutch plate end-float is not within the tolerance allowed in the 'Adjusting' procedures given below.

13. 30-TOOTH CLUTCH. Assemble the toggles, pressure plate and the piston return springs, see Fig. Fa.42.



2NC672

Fig. Fa.44  
Check the clearance between the end and intermediate—plates with feeler gauges 'A' = 0.010 to 0.035 in. (0.25 to 0.9 mm.) Arrow 'B' shows the drain hole on later-type clutch unit



14. Refit the remaining components in the following order for the purpose of CHECKING THE END-FLOAT ADJUSTMENT ONLY.
  - a. Refit the two paper-faced plates together.
  - b. Refit the intermediate plate, end plate and the retaining circlip.

### Adjusting

15. Check with feeler gauges the clearance 'A' between the intermediate plate and the end plate, see Fig. Fa.44. The end-float required is between .010 and .035 in. (.25 and .9 mm.), proceed with item 16 if adjustment is required.

**NOTE.—Shims MUST NOT be fitted to rectify end-float.**

16. Measure the thickness of the intermediate and end plates and from this measurement, select from the chart below the correct thickness plate(s) to rectify the end-float to within the tolerance given in item 15.


### Intermediate and end plate chart

PLATE	THICKNESS	PART NO.
Intermediate	0.064 in. (1.70 mm.)	27H 7722
Intermediate	0.074 in. (1.88 mm.)	37H 7033
End	0.342 in. (8.22 mm.)	27H 7724
End	0.362 in. (9.21 mm.)	37H 7032

17. Reassemble the components into the clutch unit in the order shown in Figs. Fa.41 and Fa.43. If a Spirolox retaining ring has been fitted, it should be replaced with a solid type circlip, preferably the later (wider section) type, Part No. 37H 7031.

### Refitting

18. Carry out the operations given in Section Fa.6 items 30 and 38 to 42.
19. Refit the governor linkage.



Fa.36

### Section Fa.12

### GEAR TRAIN

Two types of bevel gear train assemblies have been fitted. The later Mk. II type is fitted to all transmission units from Engine Nos. 8AH—A—H10554, 9AG—A—H1603, and the 99H series from outset.

Special equipment is used to obtain the correct backlash for the various gears when assembling the gear train; it is not possible to assemble the gear train with this equipment. The only washer in the gear train that is not selective and can be renewed is the forward output gear bi-metal washer (see Figs. Fa.50 and Fa.52—item 8). In the event of failure of any part of this unit a new gear train assembly must be fitted.

### Interchangeability of assemblies

In the event of the Mk. I gear train assembly not being available, the later type Mk. II assembly may be fitted—together with the following components which must be used with the Mk. II unit and replaces similar parts used in the Mk. I transmission unit.

### Replacement parts

Freewheel housing.

Forward shaft and thrust washer.

Top/reverse clutch with thrust bearing and washers.\*

Top/reverse clutch hub with thrust bearing and washer.

\* Only required if prior to Transmission No. E04859.

### Removing

1. Carry out the operations given in Section Fa.6, items 1 to 2b and 12.

### Dismantling

Dismantling of the gear train is necessary only if the forward output gear bi-metal washer is to be replaced.

Fig. Fa.45  
Removing or refitting the top and reverse clutch

1. Selective washer.
  2. Needle thrust bearing.
  3. Thrust washer.
  4. Top and reverse clutch.
  5. Thrust washer (stepped)
  6. Needle thrust bearing.
  7. Thrust washer.
  8. Thrust washer.
  9. Needle thrust bearing.
- } later type.

2NC678




Fig. Fa.46

Removing the third speed reaction gear. The arrows indicate the bi-metal washer locations

- 1. Bi-metal washer.
- 2. Shim (if fitted).




Fig. Fa.47

Removing the input gear 1, the first gear free-wheel reaction member 2, and the needle-roller bearing 3

- 2. Remove the top and reverse clutch.  
**NOTE.**—For top and reverse clutch dismantling and reassembling see Section Fa.13.
- 3. Remove the thrust race and washers (Fig. Fa.45).
- 4. Remove the third gear reaction member together with its thrust washer and shim (if fitted) (Fig. Fa.46).
- 5. Remove the input gear, and pull off the first gear free-wheel reaction member and needle-roller bearing (Fig. Fa.47).
- 6. Knock back the lock washers and remove the first gear free-wheel housing set screws.
- 7. Pull out the first gear free-wheel assembly, input gear, Torrington thrust race, and washer (Fig. Fa.48).  
**NOTE.**—For first gear free-wheel assembly dismantling and reassembling see Section Fa.15.

- 8. a. Dismantling of the Mk. II gear train assembly is given below in items 9 to 15, with the reassembly sequence in items 20 to 32.
- b. To dismantle the Mk. I gear train assembly, as shown in Figs. Fa.49 and Fa.50, refer to items 16 to 19 with the reassembly sequence given in items 33 to 36.

**Dismantling gear train (Mk. II)**

- 9. Remove the spindle end cover circlips and covers; remove the small locking circlip and unscrew the spindle locking screws.
- 10. Hold the unit on its side until the locking ball rolls out from the hole in the planetary gear spindle. Repeat this operation on the other side.
- 11. Insert Service tool 18G 1093 A into the forward output gear and through the complete assembly to assist the dismantling procedure.
- 12. Screw the Service tool adaptor 18G 284 AJ into one of the planetary gear spindles and using Service tool 18G 284 pull the spindle from the gear. Repeat this operation with the other spindle and withdraw the needle-roller bearings.




Fig. Fa.48

Removing the one-way clutch and the input gear with its Torrington needle thrust bearing and washer

13. Knock back the locking tabs and remove the strap securing bolts.
14. Ease the strap off the dowels and lift the complete assembly from the carrier.  
Retain the respective positions of each planetary gear thrust washer with the carrier.
15. Dismantle the assembly, ensuring that all components are retained in their respective positions for reassembly (see Fig. Fa.51).

### Dismantling gear train (Mk. I)

16. Check the markings on the carrier and the bearing caps, i.e. marked NIL or with the letter 'O'. These are reference marks to fitting dimensions and the caps must be refitted in their original positions as indicated by the markings on reassembly of the unit.
17. Knock back the locking tabs and remove the bearing cap bolts and the strap securing bolts. Lift out the forward output gear, reverse output gear, and the pinions.
18. Lift off the thrust bearings, pinions, and thrust washers.
19. Lift off the forward output gear and thrust washer, the reverse output gear, thrust washer, and thrust race.


### Inspecting

Clean and examine all parts for wear. Fit a new bi-metal washer to the forward output gear if required and renew if necessary the Torrington needle-thrust races.

Fit new rubber seals and replace the locking plates.

Check that the internal bush of the reverse output shaft has not turned and shut off the output feed.

**NOTE.**— Use petroleum jelly when reassembling to secure the various thrust washers and needle thrust races in position.




A 6832

Fig. Fa.49  
Removing the forward and reverse output gears, and the planetary gears from the carrier

Fig. Fa.50  
The early-type gear train completely dismantled

1. Gear carrier.
2. Planetary gears.
3. Forward output gear.
4. Reverse output gear.
5. Steel washer (reverse output gear).
6. Planetary gear washers.
7. Steel shim (forward output gear).
8. Bi-metal washer (forward output gear).



A 6813A




Fig. Fa.51

The later-type gear train, with the forward and reverse output gears and the planetary gears removed from the carrier




Fig. Fa.52

A dismantled view of the later-type gear train assembly

- |                         |   |
|-------------------------|---|
| 1. Gear carrier.        | 5. Steel washer (reverse output gear).    |
| 2. Planetary gears.     | 6. Planetary gear washers.                |
| 3. Forward output gear. | 7. Steel shim (forward output gear).      |
| 4. Reverse output gear. | 8. Bi-metal washer (forward output gear). |

### Reassembling gear train (Mk. II)

20. Assemble the forward output gear with its bi-metal washer and the .004 in. (.10 mm.) shim (if fitted) interposed between the bi-metal washer and the carrier (see Fig. Fa.52).

Assemble the reverse output gear with its Torrington needle thrust bearing and steel washer.

21. Insert Service tool 18G 1093A through the forward output gear and the assembly to ensure correct alignment.

22. Check and reset the timing of the gear train (see Fig. Fa.53) by rotating the planetary gears until the timing marks are in alignment.

23. Retain the timed position of the gear train and refit to the carrier ensuring that both timing marks align with the dowel surface of the carrier.

24. Refit the planetary gear needle-roller bearings and tap in the spindles (with the hole on the centre of the spindle facing downwards).

25. Insert a ball into each spindle and screw in the locking screws. Refit the locking screw circlips, end covers, and the cover circlips.

26. Assemble the third speed reaction gear with its bi-metal washer fitted with the white metal face towards the reverse output gear (see Fig. Fa.54) and with the steel shim(s) located between the bi-metal washer and the gear.

Retain each washer and shim in position with petroleum jelly and refit the assembly to the gear train (see Fig. Fa.54).




Fig. Fa.53  
Timing the gear train




Fig. Fa.54  
Refitting the third speed reaction gear with its bi-metal washer, locations indicated by arrows

1. Bi-metal washer.      2. Shim (if fitted).

27. Assemble the bevel input gear with its Torrington needle thrust bearing and selective steel washer (see Fig. Fa.48).

28. Refit the one-way clutch to the gear train housing (Fig. Fa.48), tighten the securing bolts, and tap up the locking plate tabs.

29. Refit the free-wheel support.

30. Refit the input gear and needle-roller bearing (see Fig. Fa.55).

31. Refit the top and reverse clutch with its selective steel washer and needle thrust bearing onto the reverse output shaft. Use the correct diameter thrust washer and needle bearing required for the particular type of clutch and gear train assembly fitted.




Fig. Fa.55  
Refitting the input gear 1, the first gear free-wheel reaction member 2, and the needle-roller bearing 3




Fig. Fa.56

Checking that the end of the reverse output shaft 1 is level with the internal face of the top and reverse clutch 2

**Mk. II GEAR TRAIN ASSEMBLY.** When the second type clutch (with annular groove) is fitted, use the larger diameter (stepped type) thrust washer 5 and needle thrust bearing 6, see Fig. Fa.45.

**Mk. I GEAR TRAIN ASSEMBLY.** When either clutch assembly (first or second type) is fitted, use the small diameter thrust washer 8 and needle thrust bearing 9, see Fig. Fa.45.

32. Check across the splined end of the reverse output shaft and the adjacent face of the top and reverse clutch (Fig. Fa.56). Both faces must be exactly level with no gap, to ensure that the third speed reaction gear has no end-float and the correct backlash is maintained. If both faces are not level, remove and measure the thickness of the selective steel washer fitted in item 31 and fit the correct selective washer from the range available (see washer chart below).

Selective washer sizes	Part Nos.
.076 to .078 in. (1.93 to 1.98 mm.)	22G 748
.072 to .074 in. (1.83 to 1.88 mm.)	22G 749
.068 to .070 in. (1.73 to 1.78 mm.)	22G 750
.064 to .066 in. (1.63 to 1.68 mm.)	22G 751

**Reassembling gear train (Mk. I)**

33. Carry out items 20 to 23 with the following exceptions: Refer to Fig. Fa.50, and use Service tool 18G 1093 when reassembling this early-type gear train.
34. Refit the bearings caps to their respective positions (see markings) and using new locking plates, refit and tighten the bearing cap and carrier bolts to the torque figure given in 'GENERAL DATA'.
35. Carry out items 26 to 31.
36. Carry out item 32 to determine whether the splined end of the reverse output shaft and the face of the top and reverse clutch are level (see Fig. Fa.56), if they are not, fit the correct selective washer from the range available (see washer chart below).

Note that the selective washers for the early units are not interchangeable with those fitted to later units.

Selective washer sizes	Part Nos.
.116 to .118 in. (2.95 to 3.0 mm.)	22A 777
.112 to .114 in. (2.85 to 2.9 mm.)	22A 778
.108 to .110 in. (2.74 to 2.79 mm.)	22A 779
.104 to .106 in. (2.64 to 2.69 mm.)	22A 780

**Refitting**

37. Carry out the operations given in Section Fa.6, items 44 and 45. The remainder is a reversal of the removal procedure.
38. Refit the power unit to the car as detailed in Section Aa.3.

**Section Fa.13**

**TOP AND REVERSE CLUTCH**


Two types of clutch units have been fitted, the later (second type) is identified by the annular groove machined in the clutch drum. This unit has a shortened flange above the piston return spring retaining circlip to enable it to be suitable for fitment to both the Mk. I and II bevel gear train assemblies.

This unit is fitted to all transmissions from Transmission No. E04859 and can be used for replacement on all Mk. I and II gear train assemblies from the following Engine Nos. 9AG-A-H1630 and the 99H engine range from outset.

Fit the first type clutch when replacement is required on Mk. I transmissions prior to the above change points.

**Removing**

1. Carry out the operations given in Section Fa.6, items 1, 2b, and 12.
2. Remove the top and reverse clutch from the gear train together with the Torrington needle thrust bearing and the steel washer.



2NA096

Fig. Fa.57  
The top and reverse clutch components

- |                                 |                             |                                    |
|---------------------------------|-----------------------------|------------------------------------|
| 1. Housing.                     | 5. Piston return spring.    | 10. Clutch plates (paper-faced).   |
| 2. Reverse gear booster piston. | 6. Spring retainer.         | 11. Pressure plate (intermediate). |
| 3. Top gear cylinder.           | 7. Spirolox retaining ring. | 12. End plate.                     |
| 4. Top gear piston.             | 8. Pressure plate (thin).   | 13. Spirolox retaining ring.       |
|                                 | 9. Separation spring rings. |                                    |

### Dismantling

3. Remove the Spirolox retaining ring.
4. Remove the retainer plate.
5. Lift out the paper plate, spring ring, steel plate, paper plate, spring ring, and the thin steel plate.
6. Remove the circlip, spring retainer, and the piston return coil spring.
7. Lightly shock the assembly against a flat surface to remove the top gear piston and cylinder.
8. Refit the reverse (booster) piston into the bore, easing the piston ring into the bore with a screwdriver.
9. Fit Service tool 18G 1103 into the clutch unit and holding these together, lightly shock the assembly against a flat surface to remove the reverse booster piston.

### Inspecting

Check all parts for wear and renew if necessary. Renew the oil seals in the pistons. Check the piston ring gap which must be .016 to 0.20 in. (.4 to .51 mm.), for both rings when fitted in their respective bores.

### Reassembling

10. Refit the reverse gear booster piston with the boss facing outwards, using Service tool 18G 1103 (see Fig. Fa.58).
11. Refit the top gear piston into its cylinder with the boss facing outwards.
12. Fit the top gear piston and cylinder into the clutch housing, with the cut-aways on the rear outer edge of the cylinder opposite the holes in the clutch housing.




Fig. Fa.58

Using Service tool 18G 1103 (2) to remove or refit the reverse gear piston (3) to the top and reverse clutch unit (1)




Fig. Fa.59

The fitting relationship of the servo levers with the reaction levers and struts

13. Refit the top gear piston return spring, spring retainer, and circlip.
14. Refit the clutch plates in the assembly order shown in Fig. Fa.57, with the cut-away portion of the steel plates in alignment.
15. Refit the retainer plate and circlip.  
**NOTE.—Before refitting the clutch unit, ensure that the friction plates are free to drop.**

**Refitting**

16. Carry out the operations given in Section Fa.12, items 31 and 32.
17. The remainder is a reversal of the removal procedure.

**Section Fa.14**

**SERVO ASSEMBLY**

**Removing**

1. Carry out the operations given in Section Fa.6 items 1 to 13.
2. Remove the servo unit from the valve block assembly.

**Dismantling**

3. Remove the centre shaft and lift out the servo levers, reaction levers, washers, and struts.
4. Hold the servo cover and release the securing screws and the cover.
5. Lift out the springs and pistons.

**Inspecting**

Check all parts for wear and renew if necessary.

**Reassembling**

6. Lubricate the seals and fit the pistons into the correct bores (lips of seals facing downwards).
7. Assemble the springs and cover.
8. Hold the cover in position and fit the drive screws.
9. Assemble the struts, washer(s), reaction levers, and servo levers in the reverse order of dismantling (Figs. Fa.59 and 61).
10. Insert the centre shaft with the cutaway in the shaft correctly positioned.

**Refitting**

11. Carry out the operations detailed in Section Fa.6, items 33 to 48, 53, and 54.




Fig. Fa.60

The servo unit components






Fig. Fa.61  
The brake band and struts correctly positioned




Fig. Fa.63  
The components of the new one-way clutch

5. Lift out the spring ring, first gear free-wheel intermediate spring ring, and thrust bearing (see Fig. Fa.63).




Fig. Fa.64  
Fitting the one-way clutch with the lip (arrowed) correctly positioned uppermost

### Section Fa.15

#### FIRST GEAR FREE-WHEEL ASSEMBLY (ONE-WAY CLUTCH)

##### Removing

1. Carry out the operation given in Section Fa.6, items 1, 2b, and 12.
2. Remove the first gear free-wheel reaction member.
3. Knock back the locking plate tabs and remove the retaining bolts and the first gear free-wheel (one-way clutch) from the housing.

##### Dismantling

4. Remove the circlip.

##### Inspecting

Check all parts for wear and renew if necessary.

##### Reassembling

6. Reassemble the thrust bearing, intermediate spring ring, first gear free-wheel (lip facing outwards, see Fig. Fa.64), spring ring, and refit the circlip.

##### Refitting

7. Refitting is a reversal of the removing procedure.




Fig. Fa.62  
The one-way clutch removed from the gear train, with the input gear, bearings and thrust washer shown in assembly sequence




Fig. Fa.65

The differential components with the arrow indicating the alignment slot in the spacer

## Section Fa.16

### DIFFERENTIAL ASSEMBLY

#### Removing

1. Remove the engine and transmission from the car (see Section Aa.3).
2. Drain the engine/transmission unit.
3. Use Service tool 18G 1100 to hold the driving flanges and remove the centre securing bolts. Withdraw the flanges from the splined shafts.
4. Knock back the lock washers and remove the nuts from the final drive housing.
5. Remove the securing screws and pull the kick-down linkage assembly clear of the transmission case.
6. Remove the two set screws securing the end cover to the transmission, and remove the final drive and housing assembly (Fig. Fa.12).
7. Remove the remaining securing bolts from the end cover and remove the cover and the adjustment shims.

#### Dismantling

8. Remove the differential unit from its casing.
9. Withdraw the oil seal housing, remove the bearings using Service tool 18G 2.
10. Knock back the locking plate tabs and remove the bolts securing the driving gear to the cage. Mark the gear and cage so that they can be refitted in their original positions.
11. Separate the driving gear from the cage and remove the differential gear and thrust washer from the driving gear.
12. Tap out the roll pin and remove both pinions and thrust washers, pinion spacer, and the other differential gear and thrust washer.

#### Inspection

Clean and examine the components for wear and fit new parts as necessary.

**NOTE.**—If any component has suffered damage with the result that swarf has been introduced into the lubricating system the automatic transmission must be removed (Section Aa.4) and dismantled as detailed in Section Fa.6. This also applies if fitting a replacement drive gear pinion into the transmission unit.

**Absolute cleanliness is essential.**

#### Reassembling

13. Reassembly is a reversal of the dismantling procedure. Make sure that the differential gear thrust washers are fitted with their chamfered bores against the machined faces of the differential gears. Refit all components in their original positions.

#### Refitting

14. Refit the differential unit into the transmission case and push the assembly towards the converter, with the slot in the spacer in alignment with the dowel in the transmission case (Fig. Fa.65). Fit a new joint washer coated with Hylomar jointing compound. Ensure that the oil seal is pressed squarely against the face of the spacer and refit the differential housing, fit new locking plates, and lightly tighten the securing nuts.

#### ADJUSTMENT

15. Refit the end cover without a joint washer but with the original adjustment shims, tighten the cover bolts evenly and sufficiently only for the cover register to nip the bearing outer race; overtightening will distort the flange.
16. Take a feeler gauge measurement at varying positions between the side cover flange and the differential housing, any variations in measurement will indicate that the cover bolts are not evenly tightened. Adjust the cover bolts accordingly until identical measurements can be obtained. The compressed thickness of a new cover joint washer is .007 in. (.178 mm.) and the required preload on the bearings is .002 in. (.051 mm.). The correct gap is therefore .009 in. (.229 mm.), any deviation from this figure must be made up by adding or subtracting shims.

**EXAMPLE:** If the feeler gauge measurement is .005 in. (.127 mm.), add a shim of .004 in. (.10 mm.) thickness between the bearing and the end cover.

17. Remove the end cover, fit shims as required, and refit the cover with a new joint washer coated with Hylomar jointing compound. Tighten the differential housing nuts and the cover bolts to the torque figures given in 'GENERAL DATA'. Tap up the locking plate tabs, except the nut which accepts the exhaust pipe bracket (fitted when the engine is in the car).
18. Lubricate the driving flange oil seal and refit the flanges making sure that the split collets are correctly located inside the flanges. Fit new rubber seals to and refit the central securing bolts. Hold the flanges with Service tool 18G 1100 and tighten the flange bolts with Service tool 18G 372 to the torque figure given in 'GENERAL DATA'
19. Refit the governor control linkage to the transmission case with a new washer. Ensure the lever is positioned correctly, relative to the governor (see Fig. Fa.22).
20. Carry out the 'Refitting' instructions given in Section Aa.3.

### Section Fa.17

#### LUBRICATION RESERVOIR (IDLER GEAR BEARING)

To provide additional lubrication to the idler gear bearings, a transmission case incorporating a 'cast in' oil reservoir was introduced at the following Engine Nos: 8AH-A-H11338, 99H-143-H5983 and 99H-147-H834.

Earlier units should be modified by fitting a separate reservoir as detailed below.

#### Fitting

1. Remove the engine/transmission from the car (see Section Aa.3).
2. Remove the transmission unit from the engine (see Section Aa.4).
3. Refer to Fig. Fa.66. Measure down from the joint face on the outside of the casing  $3\frac{19}{32}$  in. (91.3 mm.) and from this point mark a horizontal line across the casing as indicated. Place the reservoir upside-down on the outside of the casing with its spigot located in the idler gear bearing bore and with its securing lug positioned centrally over the horizontal marking. Indent this position; remove the reservoir and drill through the casing using a  $\frac{3}{32}$  in. (7.14 mm.) drill; place a piece of Plasticine inside the casing where the hole will break through to trap any swarf.

Fa.46




Fig. Fa.66

The reservoir fitted upside-down on the outside of the casing with the marked line shown through the centre of the securing lug. An arrow indicates the drilling location, 'A' =  $3\frac{19}{32}$  in. (91.3 mm.)

4. If necessary, file the reservoir casting to ensure that it will fit snugly against the transmission casing.
5. Smear the reservoir spigot with Hylomar jointing compound and fit the reservoir as shown in Fig. Fa.67. It may be necessary to fit a flat washer beneath the securing lug to ensure that the spigot is square in the idler gear bearing bore; later reservoirs have a built-up boss around the securing lug. Leave the idler gear bearing circlip in position and tighten the securing bolt.
6. Refit the transmission unit to the engine (see Section Aa.4).
7. Refit the engine/transmission unit into the car (see Section Aa.3).




Fig. Fa.67

The fitted position of the idler gear bearing reservoir

1. Reservoir.
2. Securing screw.
3. Spring washer.




Fig. Fa. 68

The selector lever mechanism and cable components. Inset 'A' shows the second type (minimum backlash) assembly. Inset 'B' shows the first type assembly

- |                          |                            |                                  |
|--------------------------|----------------------------|----------------------------------|
| 1. Yoke.                 | 6. Cable.                  | 11. Reverse return spring.       |
| 2. Locking nut-yoke.     | 7. Lever plunger.          | 12. Quadrant.                    |
| 3. Rubber ferrules.      | 8. Selector lever housing. | 13. Selector lever.              |
| 4. Cable sleeve.         | 9. Locknut-switch.         | 14. Spring-loaded sleeve.        |
| 5. Cable adjusting nuts. | 10. Inhibitor switch.      | 15. Securing screws and washers. |

Section Fa.18

SELECTOR LEVER MECHANISM

Removing

1. 1ST TYPE BELL-CRANK LEVER ASSEMBLY.

Remove the bell-crank lever guard (later models) from the converter housing or pull back the rubber sleeve (early models) and disconnect the gear-change cable by removing the clevis pin.

2ND TYPE BELL-CRANK LEVER ASSEMBLY.

Remove the modified bell-crank lever guard from the converter housing and disconnect the gear-change cable by removing the nut and bolt from the yoke.

2. Slacken the yoke locknut and remove the yoke, locknut, both rubber ferrules and the cable sleeve. Remove the front adjusting nut from the outer cable and pull the cable clear of the transmission.
3. Release the cable clip from the floor panel.
4. Remove the front floor covering.

5. Disconnect the electrical leads from the inhibitor switch.
6. Remove the screws securing the gear change housing, carefully pull the cable through the rubber dust excluder, and remove the housing and cable assembly.

#### Dismantling

7. Hold the assembly in a vice and remove the set screws securing the quadrant to the housing. Release the reverse return spring from the base of the housing and remove the quadrant and lever assembly.
8. Unscrew the cable securing nut from the front of the housing, pull the cable and plunger from the housing and release it from the gear change lever plunger.

#### Inspection

Clean and inspect moving parts for wear.

#### Reassembly

9. Lubricate all moving parts with grease.
10. Reassembly is a reversal of the dismantling procedure. Refer to Fig. Fa.68 and ensure that the gear selector lever (13) is re-inserted into the relieved side of the plunger (7).

#### Refitting

11. Refitting is a reversal of the removing procedure, but note items 12 to 14.
12. a. If seizure of early versions of the first-type bell-crank lever has occurred due to overtightening of the pivot pin nut (see Fig. Fa.1), replace the pivot pin and distance tube with a modified pivot pin having a shoulder.
- b. If the backlash on the first type of selector lever mechanism is excessive, fit the minimum backlash bell-crank lever assembly (see Fig. Fa.1). Remove the forged bell-crank lever and its pivot pin, the front cover and the transverse rod. Fit the modified type of pivot pin and clevis, the non-adjustable transverse rod (see item 4, Section Fa.2) and the pressed type of bell-crank lever. Refit the front cover and the bell-crank lever guard, which must be reshaped as described in item 8 of Section Fa.2.




Fig. Fa.69

Modifying the selector lever indicator gate to ensure that the reverse gear position can be fully engaged. 'A' =  $\frac{1}{16}$  in. (1.6 mm.)

- c. On transmissions which have been fitted with the minimum backlash bell-crank lever assembly, the reverse position of the selector lever indicator gate should be modified as described below to ensure that the selector valve detent is fully engaged when reverse gear is selected. Unscrew the gear selector handle from its lever and then remove the four screws securing the indicator gate to the quadrant. File a radius  $\frac{1}{16}$  in. (1.6 mm.) deep in the end of the gate, as shown in Fig. Fa.69, and reassemble the quadrant components.

**NOTE.**— If slip or loss of drive in reverse gear occurs on replacement transmissions which incorporate the minimum backlash bell-crank lever, check that the selector gate has been lengthened. If it has not, and adjusting the selector lever cable as described in Section Fa.2 fails to remedy the fault, carry out the above modification.

13. Adjust the selector lever cable and the transverse rod (1st type only) as detailed in Section Fa.2 and the inhibitor switch as detailed in Section Fa.3.

# SECTION G

## THE DRIVE SHAFTS

	SECTION
General description	
Drive shaft:	
Removing .. .. .	G.1
Overhaul .. .. .	G.2
Coupling replacement .. .. .	G.3
Universal joint overhaul .. .. .	G.4
Drive shaft (offset sphere inboard joint type) .. .. .	G.5
Drive shaft boot replacement (offset sphere inboard joint type) .. .. .	G.6
Drive shaft inboard joint (offset sphere type) .. .. .	G.7
Drive shaft inboard joint boot replacement (offset sphere type) .. .. .	G.8

### GENERAL DESCRIPTION

Each of the two drive shafts employed has two principle members incorporating a Hardy Spicer constant-velocity bell joint. The hemispherical interior of the bell joint and the exterior of the inner ball race have six grooves machined in line with the shaft axis, and a ball cage carrying six steel balls is interposed between the two. The steel balls engage the grooves of both members to key them together and at the same time allow the members to hinge freely upon each other.

The joint is packed with special grease and the unit is enclosed in a sealed rubber boot. The inner end of the drive shaft is splined and has a pre-lubricated sliding joint sealed with a rubber boot.

### Section G.1

#### DRIVE SHAFTS

##### Removing

To remove the drive shaft assembly from the vehicle follow the removing instructions given for swivel hubs in Section K.2 or G.5 (offset sphere type).

The constant-velocity bell joint may be removed from the drive shaft for replacement as a unit or to have a Service kit fitted. Under no circumstances must individual components be replaced in the bell joint assembly.

Should a rubber boot enclosing the joint be damaged with a consequent loss of lubricant, it is necessary to remove the joint from the shaft for dismantling and inspection of the components.

If a rubber boot is damaged in the workshop and dirt has not entered the joint, a new boot may be fitted after first repacking the joint with the recommended grease.

To fit a new boot the drive shaft must be removed from the vehicle.

##### Constant-velocity (bell) joint

The bell joint can be removed from the drive shaft for dismantling and inspection of the components.

Service kits are available which include the required amount of lubricant to service a bell joint.

When servicing of the joint becomes necessary, the procedure given in Section G.2 must be followed.

##### Sliding joint flange

On later models the sliding joint is prepacked with  $\frac{3}{4}$  oz. (21 gm.) of Duckham's M.B. grease (pack AKF 1457) and sealed with a rubber housing seal, early models were fitted with lubricating nipple. When servicing the sliding joint or fitting a new seal, refer to Section G.2.


G.2

### Section G.2

#### DRIVE SHAFT OVERHAUL

##### Dismantling the shaft assembly

1. Clean the shaft of road dirt and grease and mount the shaft centrally in a vice fitted with soft jaws.
2. Prise off the boot and housing seal clips or cut the soft iron wire, turn back the housing seal and slide off the joint flange. Remove the housing seal and the rubber boot, if they are worn or damaged, replacements must be fitted on reassembly.
3. The bell joint can only be dismantled after removal of the shaft; a round-section spring ring located in a deep groove in the extreme end of the shaft is expanded into the chamfered end of the inner race bore, and for shaft removal this must be contracted into the groove.
4. Hold the shaft and joint vertically, the bell joint downwards, and give the edge of the outer race a sharp tap with a soft faced mallet (see Fig. G.1). This should contract the spring ring so that the joint can be drawn off the shaft. It should not be necessary to use heavy blows for this operation.




A9509

Fig. G.1

Drive the bell joint from the shaft at the point indicated

**Dismantling the joint**

5. The joint should be dismantled only if there is reason to believe that it is still serviceable.
6. As the components are mated and have operated together, they must be kept in the same mating relationship. The relative positions of the inner and outer races and the cage should be marked with blue marker or a paint which will not wash off when the parts are cleaned.
7. With the shaft withdrawn the inner race can swivel freely, tilt the inner race until one ball is released (Fig. G.2). Note that the cage swivels through half the angle of the inner race. If the joint is sticky with grease each ball may be eased out in turn with a pointed tool.
8. Swivel the cage into line with the axis of the joint and turn it until two opposite elongated windows coincide with two lands of the bell joint. One land will drop into a window, allowing the cage and race assembly to be lifted out (Fig. G.3).
9. Swivel the inner race at right angles to the cage and turn it until two of the lands between the inner race tracks are opposite elongated windows in the cage. One land will drop into a window, allowing the inner race to be extracted from the cage (Fig. G.4).




A9507

Fig. G.3  
Removing the cage and inner race assembly, from the bell joint

**Inspecting**

10. Clean all parts thoroughly in petrol (fuel), paraffin (kerosene), or white spirit and dry off. In normal service, wear should be distributed fairly evenly over all components and the joint will remain serviceable until the amount of end-float exceeds the acceptable wear maximum of .025 in. (.64 mm.).



A9504

Fig. G.2

Tilt the inner race to remove or replace each ball in turn

11. Examine the six balls and if worn, rust-pitted or bearing evidence of flattening, the joint assembly must be replaced.
12. Inspect the inner and outer race tracks, these will be marked on the flanks where the balls roll, but should be free from indentation and the marking should be consistent.
13. Inspect the inner and outer spherical surfaces of the cage and the corresponding surfaces of the inner and outer races; these will be polished by contact but must be free from any sign of 'picking-up'. The edges of the cage windows may show signs of wear towards the outer side. Wear at these points may cause knocking when the joint is operated at high angles.
14. Carefully examine the shaft for cracks, and ensure that the square-section outer circlip is firmly in its groove.

**Replacing the ball cage**

The majority of cages used in the original assembly are of a standard size, although on some shafts two other non-standard oversize cages have also been used, and all three may be encountered in Service.

It is important to note that a joint will only accept a replacement cage of the same size as the original.

To effect easy identification of cage sizes use Service tool 18G 1012. The fitting of a Service kit must not be attempted without this tool.






Fig. G.4

Manoeuvre the inner race in the cage to the required position to allow it to be extracted

The three kits available are as follows:

Kit 'A', Part No. 18G 8000 (Standard)

Kit 'B', Part No. 18G 8002 (.004 in. oversize)

Kit 'C', Part No. 18G 8001 (.010 in. oversize)

It is extremely difficult to check the ball cage internal dimensions and a gauge, Service tool 18G 1012, must be used to determine the size of the cage fitted.

15. The small bore of the gauge is a clearance fit over a standard inner race but will not accept an inner race .004 in. (.100 mm.) oversize. The larger bore of the tool is a clearance fit over a standard cage but will not accept a cage .010 in. (.25 mm.) oversize.

A If the inner race passes through the small bore of the gauge, and the cage passes through the larger bore, the joint is size 'A'.

B If the inner race will not pass through the gauge, the joint is size 'B'. The cage should also be checked, but must be accepted by the gauge.

C If the inner race passes through the gauge, but the cage will not pass through, the joint is size 'C'.

**NOTE.**—Should the gauge 18G 1012 not accept the inner race or cage, the joints must be replaced as a unit.

#### Reassembling the joint

16. This is an exact reversal of the dismantling procedure. All components should be lightly lubricated with Duckham's M-B grease (BMC pack AKF 1457). The components should go together easily and no force should be required.

17. Insert the inner race into the cage by introducing one of the lands into an elongated window in the cage (Fig. G.4).
18. Insert the cage and inner race assembly into the bell joint by fitting one of the elongated windows over one of the lands in the outer race (Fig. G.3). The three parts can now be turned or swivelled freely in relation to each other.
19. Locate the cage and inner race in their original position relative to the bell joint (as marked before dismantling).
20. Keeping this relationship between the parts, tilt the cage until one ball can be inserted in a window. Repeat this operation with the remaining balls (Fig. G.2).
21. Ensure that the inner race articulates freely with the cage in the bell joint, but care must be taken not to release the balls.
22. The joint should be filled with the remainder of the pack of Duckham's M-B grease, before inserting the shaft.
23. Fit a new rubber boot if necessary, smearing the inside with Duckham's M-B grease, take care when easing the boot over the circlip on the shaft.

#### Assembling the shaft to the joint

24. Replace the round-section spring ring with a new one (Fig. G.5). If replacing the shaft, fit a new circlip.




Fig. G.5

The splined bell joint end of the drive shaft showing the circlip and the round-section spring ring




Fig. G.6  
Securing the rubber boot to the drive shaft bell joint. 'Arrows' indicate forward rotation of drive shaft

1. Service tool 18G 1099.      2. Clinching clip.      3. Rubber boot (modified type).

25. Hold the shaft in a vice and locate the inner race on the shaft. Press the joint assembly against the spring ring whilst locating the ring centrally and contracting it in the chamfer of the inner race with screwdrivers. With the spring ring centralized, a sharp tap on the end of the stub shaft with a soft faced mallet will close up the ring, and the assembly can then be tapped on to the drive shaft. Make sure that the shaft is fully engaged, with the inner race against the circlip and that the inner ring has expanded inside the joint.
26. Slide the rubber boot over the bell joint until the radiused rib registers in the locating groove, and secure it with the large clinching clip using Service tool 18G 1099 (Fig. G.6). This is fitted with the tab pulled through away from the direction of forward rotation. Locate the other end of the boot in the groove in the drive shaft and secure it with the small clinching clip using pliers 18G 1099.

**NOTE.**—A modified rubber boot which has axial convolutions (see Fig. G.6) should be fitted when a replacement is required.




Fig. G.7

The lower arm pivot pin. The measurement at the position indicated must be .312 in. (7.9 mm.) to accommodate the rubber boot of later drive shaft assemblies

27. Lubricate the yoke end of the drive shaft and the inside of the yoke housing seal and slide the seal onto the shaft. Fill the cavity in the sliding joint yoke with  $\frac{3}{4}$  oz. (21 gm.) of Duckham's M-B grease and fit the yoke to the shaft. Locate the seal into the groove on the shaft and the other end over the sleeve location. Push the shaft to the bottom of the yoke so that grease is driven into the seal. Hold outer lip of the seal open to allow air and surplus grease to escape, ensure that the diameter of the bellows does not exceed 1.75 in. (44.5 mm.). Secure the yoke seal with clinching clips using pliers 18G 1099.

#### Refitting

28. Refitting is a reversal of the removing procedure given in Section K.2.
29. When fitting a replacement drive shaft assembly (of the type fitted with a rubber boot on the sliding joint) to the left hand side of an early model, it will also be necessary to fit a modified lower arm inner pivot pin to ensure sufficient clearance for the rubber boot. Reference should be made to Fig. G.7 for the dimension of the modified pivot pin.

### Section G.3

#### DRIVE SHAFT COUPLING

##### Removing

1. Jack up the front of the vehicle, place supports under the sub-frame and remove the road wheel.
2. Remove the upper and lower swivel hub ball pin retaining nuts and release the ball pins from the suspension arms using Service tool 18G 1063.
3. Remove the 'U' bolts and nuts securing the drive flange coupling.




Fig. G.8

The sequence of operations when removing the needle bearings from the universal joint

- |                         |                       |                 |
|-------------------------|-----------------------|-----------------|
| 1. Yoke.                | 3. Retaining circlip. | 5. Rubber seal. |
| 2. Needle bearing race. | 4. Journal spider.    |                 |

4. Disconnect the swivel hub assembly from the suspension arms and pull it out sufficiently to release the rubber coupling.

**NOTE.**—Support the swivel hub on a stand or suitable support until it is refitted, do not stretch the hydraulic brake hose.

#### Refitting

5. Before refitting, check that the coupling 'U' bolts will easily engage the drive shaft yoke. If they have opened, squeeze both threaded ends together in a soft jawed vice until they are in alignment.
- NOTE.**—When reassembling, fit new 'U' bolt nuts.
6. Fit the new coupling to the final drive yoke.
7. Refit the swivel hub assembly to the suspension arms and at the same time engage the drive shaft yoke with the new coupling.
8. Tighten the new nuts on the coupling 'U' bolts equally until approximately  $\frac{1}{8}$  in. (1.6 mm.) of thread extrudes through the nuts.
9. Tighten the swivel hub ball pin retaining nuts to the torque figure given in 'GENERAL DATA'.
10. Refit the road wheel and lower the car.

#### Section G.4

##### UNIVERSAL JOINT OVERHAUL (Cooper 'S' and Automatic models)

#### Removing

1. Remove the drive shaft and swivel hub assembly as detailed in Section K.2, operations 1 to 7.
2. Remove the clinching clip securing the yoke housing seal to the drive shaft and pull the yoke housing assembly off the drive shaft splines.

G.6

#### Dismantling


3. Clean the universal joint assembly.
4. Remove the bearing retaining clips with a pair of thin-nosed pliers and prise them out with a screwdriver. If a retaining clip cannot be removed easily, tap the end of the bearing race to relieve pressure on the clip.
5. Hold the joint in one hand and support the underside of the yoke on the top of a vice. Tap the radius of the yoke lightly with a copper mallet, Fig. G.8, until the bearing race emerges from the yoke.
6. Turn the joint over and grip the bearing race in the vice. Tap the underside of the yoke until the bearing race is extracted, Fig. G.8.
7. Repeat operations 5 and 6 on the opposite bearing.
8. Support the two exposed bearing trunnions on the top of the vice (with wood or soft metal packings between the vice and the bearing trunnions). Tap the top lug of the flange yoke as detailed in operations 5 and 6 to extract the two remaining bearing races, Fig. G.8.
9. Withdraw the journal spider from the drive shaft yoke.

#### Inspecting

10. Wash all parts thoroughly in a cleaning fluid.
11. Check the bearing races and spider for signs of wear or load markings. Fit a new journal repair kit if any components are defective. Check that the bearing races are a light drive fit in the yoke trunnions, if any of the races are a loose fit, replace the complete end assembly.

#### Reassembling

12. Ensure that each bearing race has a complete set of needle rollers, smear the inside walls of the races and needle roller bearings with grease, with a  $\frac{1}{8}$  in. (3 mm.) depth of grease in the end of each race.



INC627

Fig. G.9  
The universal joint bearing components

- |                       |                    |
|-----------------------|--------------------|
| 1. Journal spider.    | 3. Needle rollers. |
| 2. Rubber seal.       | 4. Bearing race.   |
| 5. Retaining circlip. |                    |

**Refitting**

- Fit a new rubber boot and refill it with the recommended grease as detailed in operation 27 of Section G.2.
- Refit the drive shaft to the swivel hub and reassemble the complete assembly to the vehicle as detailed in operations 19 to 24 of Section K.2.

**Section G.5**


**DRIVE SHAFT**

(Offset sphere inboard joint type)

**Removing**

- Check that yoke journal bearing apertures are clean and dry and insert the spider into the yoke.
- Use a soft drift slightly smaller in diameter than the bearing race and tap the race into position; hold the spider into the race as it is drifted into position to retain the needle rollers in position.
- Repeat the above operation on the opposite side of the yoke.
- Engage the other journal over the spider and repeat operations 14 and 15.
- Fit the circlips and ensure that they are firmly located in their grooves. If the joint appears to bind, tap the yoke journals lightly with a wooden mallet to relieve pressure of the bearing races on the ends of the journals.


- Remove the one screw retaining the suspension upper arm rebound rubber and place a solid wedge of the same thickness in its place.
- Remove the wheel trim and slacken the road wheel nuts.
- Remove the split pin retaining the drive shaft nut and slacken the nut.
- Jack up the vehicle, place stands under the sub-frame side members and remove the road wheel.
- Remove the nut retaining the steering tie-rod ball joint and release the joint from the steering lever using Service tool 18G 1063.
- Remove the upper swivel hub ball pin retaining nut and spring washer. Release the joint using Service tool 18G 1063 and refit the retaining nut loosely.



3NC863

Fig. G.10  
Removing the suspension rebound rubber and fitting a solid wedge

- |                     |                    |
|---------------------|--------------------|
| 1. Retaining screw. | 2. Rebound rubber. |
| 3. Wedge.           |                    |



3NC896

Fig. G.11  
Showing Service tool 18G 1063 used to disconnect the ball joints

- |                                   |                           |
|-----------------------------------|---------------------------|
| 1. Steering tie-rod ball-joint.   | 3. Service tool 18G 1063. |
| 2. Swivel hub ball-joint (upper). | 4. Wedge.                 |




Fig. G.12  
Using Service tool 18G 1243 to release the drive shaft from the inboard joint. Inset shows the end of the tool hard against the inboard joint 'arrowed'

1. Service tool 18G 1243.
2. Drive shaft.
3. Inboard joint.

7. Assemble Service tool 18G 1243 to the drive shaft with the tool hard against the inboard joint before inserting the taper pin, see Fig. G.12. Insert the 'U' shaped part of the tool into the groove on the shaft, tighten the two bolts evenly until the drive shaft is released from the inboard joint. Remove the tool.
8. Remove the nut and disconnect the swivel hub ball pin from the suspension upper arm.  
**WARNING.** Take care not to stretch the brake hose.
9. Retain the position of the inboard joint boot and at the same time withdraw the shaft out of the joint.
10. Push the shaft inwards and over the top of the final drive assembly; remove the drive-shaft retaining nut and tap the shaft out of the driving flange.
11. Withdraw the drive shaft out of the swivel hub and then outwards away from the vehicle.

#### Refitting

12. Reverse the removing procedure except that the Service tools previously used are not required also noting the following:
  - a. Locate the drive shaft into the swivel hub and screw on the retaining nut.

G.8




Fig. G.13  
Compressing the inboard joint circlip with Service tool 18G 1241

1. Service tool 18G 1241.
2. Drive shaft.
3. Inboard joint.

- b. When assembling the drive shaft into the inboard joint, use Service tool 18G 1241 to compress the inboard joint circlip, see Fig. G.13.
- c. Push the drive shaft smartly into the inboard joint to lock the shaft into the joint.
- d. Tighten the swivel hub ball pin retaining nut to the torque figure given in 'GENERAL DATA'.
- e. Tighten the drive shaft nut to the correct torque figure, see 'GENERAL DATA' for the particular model application.

#### Section G.6

#### DRIVE SHAFT BOOT REPLACEMENT (Offset sphere inboard joint type)

#### Removing

1. Remove the drive shaft, Section G.5.
2. Remove and discard the rings securing the rubber boot to the outer member of the constant velocity joint and the drive shaft.
3. Withdraw the boot off the drive shaft.
4. Thoroughly clean the joint assembly in petrol (fuel) paraffin (kerosene), or white spirit and dry off.

#### Refitting

5. Slide the new rubber boot up the drive shaft.
6. Pack the joint with 1 oz (30 cm<sup>3</sup>) quantity of Duckhams Bentone Grease Q5795.




Fig. G.14

Securing the rubber boot to the drive shaft; outboard joint illustrated. 'Arrows' indicate forward rotation of the drive shaft.

1. Service tool 18G 1099. 2. Clinching clip. 3. Rubber boot.

7. Secure the rubber boot to the drive shaft and constant velocity joint with the service clips using Service tool 18G 1099 and following the procedure detailed below and illustrated in Fig. G.14. If the service clips are not available see alternative method in operation 8.
  - a. The clip must be fitted with the fold in the clip facing toward the forward rotation of the drive shaft, see Fig. G.14.
  - b. Pull the free end of the clip tightly between the front locking tabs of the clip and close the front locking tabs onto the clip.
  - c. Fold the clip back over the front locking tabs and close the rear locking tabs to secure the clip end.
8. Alternative method. Secure the boot to the joint using 20 S.W.G. soft iron wire; wind the wire twice around the boot, twist the ends firmly together several turns and bend the ends away from the direction of rotation.
9. Refit the drive shaft, Section G.5.

**Refitting**


6. Check the condition of the nylon oil flinger on the inboard joint and fit a replacement if it has been damaged in any way.
7. Insert the inboard joint into the final drive and push in until the joint is securely engaged over the retaining circlip on the splined shaft.
8. When refitting the drive shaft into the inboard joint, use Service tool 18G 1241 to compress the inboard joint circlip, see Fig. G.13. Push the shaft smartly into the joint to lock the shaft in the joint.
9. Tighten the swivel hub ball pin retaining nut to the torque figure given in 'GENERAL DATA'.

**Section G.7**

**DRIVE SHAFT INBOARD JOINT  
(Offset sphere type)**

**Removing**

1. Drain the engine/transmission oil.
2. Follow the procedure 1, 2 and 4 to 9 in Section G.5 to withdraw the drive shaft out of the inboard joint.
3. Insert Service tool 18G 1240 with its relieved side against the inboard joint and drift it between the joint and the final drive end cover with the block adjacent the end cover bolt, see Fig. G.15.
4. Give the tool a sharp blow on its flat face (arrowed), inwards towards the final drive to release the joint, see Fig. G.15.
5. Pull the inboard joint off the splined final drive shaft.



3NC1708

Fig. G.15

Using Service tool 18G 1240 to remove the inboard joint; hit the tool on side 'arrowed'

1. Service tool 18G 1240. 2. Inboard joint.  
3. Differential end cover bolt.

## Section G.8

**DRIVE SHAFT INBOARD JOINT  
BOOT REPLACEMENT  
(Offset sphere type)**

**Removing**

1. Remove the drive shaft inboard joint as detailed in Section G.7.
2. Remove and discard the large clip retaining the boot to the joint.
3. Turn the boot inside-out, remove and discard the inner retaining clip and withdraw the boot from the joint.
4. Withdraw the inner joint member and ball cage assembly from the outer member.
5. Prise the balls from the ball cage, then rotate the cage until its internal grooves coincide with the lands on the joint inner member and separate the two, see Fig. G.17.

**Inspecting**

Clean the joint and components thoroughly in a cleaning solvent, paraffin (kerosene) or white spirit and dry off.

7. Inspect the components for wear or damage, if any component is defective, a new offset sphere joint assembly must be fitted.





Fig. G.16

Using Service tool 18G 1251 to fit a new rubber boot with endless type retaining clip onto the inner member of the offset sphere inboard joint. Inset shows the correct fitment of the clip on the rubber boot

- |                                    |                                   |
|------------------------------------|-----------------------------------|
| 1. Rubber boot                     | 4. Sleeve - Service tool 18G 1251 |
| 2. Inner member                    | 5. Retaining clip                 |
| 3. Mandrel - Service tool 18G 1251 |                                   |



2NC305C

Fig. G.17

- |                 |                                 |
|-----------------|---------------------------------|
| 1. Inner member | 4. Internal grooves - ball cage |
| 2. Ball cage    | 5. Lands - inner member         |
| 3. Balls        |                                 |

**Refitting**

8. Fit a new endless retaining clip over the inner neck of the new rubber boot, with the chamfer of the clip towards the inside of the boot, see Fig. G.16.
9. Refer to Fig. G.16. Support the inner member with its boss uppermost, in a soft-jawed vice and insert the mandrel of Service tool 18G 1251. Apply a liberal coating of 'Teepol' or liquid detergent onto the boss and mandrel also to the inside neck of the rubber boot. Slide the boot down the mandrel and then use the sleeve of Service tool 18G 1251 to push the boot (using hand pressure) fully onto the circlip locating register of the joint boss. Thoroughly clean all traces of the 'Teepol' or liquid detergent from the joint and boot.
10. Reverse the procedure in operation 5 to assemble the inner member and balls into the ball cage, see Fig. G.17.
11. Use Shell S7274 Tivella 'A' Grease (in sachet of 50 c.c. capacity) and pack the joint as follows:
  - a. Use half the sachet of grease to load the ball cage.
  - b. Pack the remainder into the interior of the outer member of the joint.
12. Install the inner member and ball cage assembly into the outer member, and locate the rib of the rubber boot over the end of the joint.
13. Fit the retaining clip using Service tool 18G 1099 following the procedure detailed below and illustrated in Fig. G.14.
  - a. The clip must be fitted with the fold in the clip facing toward the forward rotation of the drive shaft, see Fig. G.14.
  - b. Pull the free end of the clip tightly between the front locking tabs of the clip and close the front locking tabs onto the clip.
  - c. Fold the clip back over the front locking tabs and close the rear locking tabs to secure the end.
14. Refit the drive shaft inboard joint. Section G.7.

## SECTION H

### THE REAR SUSPENSION

	SECTION
Hubs .. .. .	H.5
Hydrostatic suspension .. .. .	H.6
Depressurizing, evacuating, pressurizing .. .. .	H.7
Displacer units .. .. .	H.8
Radius arms .. .. .	H.10
Schrader valve extension housing .. .. .	H.14
Sub-frame .. .. .	H.11
Suspension pressures and wing heights .. .. .	H.9
Radius arms .. .. .	H.2
Radius arms (Moke) .. .. .	H.13
Spring units .. .. .	H.3
Sub-frame .. .. .	H.1
Sub-frame (Moke) .. .. .	H.12
Sub-frame mountings .. .. .	H.4






Fig. H.1  
The rear sub-frame assembly (rubber suspension)

## Section H.1

### SUB-FRAME

#### Removing

1. Disconnect the battery.
2. Remove the exhaust pipe (Section A.3).
3. Disconnect the hydraulic pipe from the pressure regulating valve.
4. Remove the end finishers from the sill panels.
5. Release the rear dampers from inside the luggage compartment as in Section L.1.
6. Release the hand brake cable fairleads and disconnect the cables from the lever trunnion. Pull the cables downwards through the floor.
7. Lift the body with padded hooks under the wings.
8. Unscrew the eight sub-frame mounting bolts and withdraw the sub-frame.

#### Refitting

Reverse the removing instructions.

## Section H.2

### RADIUS ARMS

#### Removing

1. Release the rear damper(s) as in Section L.1.
2. Raise the car and support it under the sub-frame side-member.
3. Remove the road wheel.
4. Disconnect the brake hose from the bracket on the radius arm.

5. Prise out the strut assembly (Fig. H.2). The nylon cup may remain in the boss on the radius arm and, unless damaged, it can be removed with the fingers.
6. Disconnect the hand brake cable from the lever on the backplate, prise the guide tube from the clip on the arm and pull the tube away from the arm.  
On later models remove the nut from the cable sector pivot and withdraw the selector and pivot.
7. Remove the end finisher from the sill panel.
8. Unscrew the nut and remove the washer from the radius arm pivot shaft and lift the arm away from the car.

#### Dismantling and overhauling

9. Slide the dust seal and washer from the ends of the pivot.
10. If new bearings are necessary, withdraw the outer bronze bush with Service tool 18G 585 and fit the new bush with Service tool 18G 584.
11. Remove the needle-roller bearing from the inner end with Service tools 18G 583 and 18G 583 B and ream the outer bronze bush with Service tools 18G 588 and 18G 588 A.
12. Refit the needle-roller bearing with Service tool 18G 620, the marked end of the bearing faces outwards.
13. Lubricate all parts with grease.

#### Refitting

14. Reverse the removal instructions, but note:
15. Refers to item 5. Repack the nylon cup and dust seal with Dextragrease Super G.P. Lip the dust seal over the edge of the cup.




Fig. H.2

Extract the strut from the spring unit and pull it rearwards to disengage the ball end from the radius arm

Section H.3

SPRING UNITS

Removing

1. Carry out instructions 1 to 3 and 5 in Section H.2.
2. Remove the spring unit.
3. Prise out the nylon seating.

Refitting

4. Reverse the removing instructions, but note:
5. Make sure that the spring unit and spring strut are correctly located in their spigots while the radius arm is being raised to connect the upper end of the damper.

Section H.4

SUB-FRAME MOUNTINGS

Removing

1. Jack up the car at a point near the bumper and the rear body panel.

FRONT

2. Remove the radius arm (Section H.2).
3. Unscrew and remove the nut securing the mounting support pin to the sub-frame (Fig. H.3). Withdraw the mounting block to body screws. Prise the body and sub-frame apart sufficiently to allow the support pin, blocks, and rubbers to be extracted.

REAR

4. Jack up the car at a point between the bumper and the rear body panel.
5. Withdraw the mounting block to body screws and remove the nut from the end of the mounting support pin.
6. Prise the body and frame apart sufficiently to allow the block and rubbers to be removed.

Refitting

7. Reverse the removing instructions. Insert the mounting block to body screws before tightening the support pin nut.

Section H.5

HUB

Removing

1. Jack up the car and remove the road wheel and the brake-drum.
2. Prise off the hub cap.
3. Extract the split pin and screw the nut from the end of the stub shaft.
4. Withdraw the hub assembly.




Fig. H.3

Removing the rear sub-frame front mounting support pin assembly

**Dismantling**

5. Drift the inner races of both bearings from the hub.
6. Remove the seal.
7. Extract the outer bearing races with Service tool 18G 260 and adaptor 18G 260 C.

**Reassembling**

8. Reverse the dismantling instructions and pack the bearings only with grease.

**Refitting**

9. Reverse the removing instructions, taking care to fit the chamfered bore of the thrust washer on the stub shaft towards the bearing.




Fig. H.4

The rear radius arm, showing a section through the hub assembly

**Section H.6****HYDROLASTIC SUSPENSION**

The system consists of two front and two rear displacer units intercoupled longitudinally. Each is made of sheet steel and rubber and consists of a piston, a diaphragm, a lower and upper chamber housing, and a conical spring of compressed rubber.

Contact of the front wheels with a road irregularity forces the piston to push the diaphragm up; increased pressure displaces some of the fluid from the bottom chamber to the top chamber. The rubber springs deflect due to the pressure increase and fluid displacement, and the resultant pressure increase causes fluid to discharge through the interconnecting pipe into the rear displacer unit.

The fluid entering the rear displacer forces the diaphragm to react against the piston, resulting in the car height at the rear being raised. These events are virtually simultaneous and the car therefore rides an obstruction without pitch motion of the body. The action of the suspension is similar when the rear wheels negotiate the irregularity.

The fluid used in the system is a mixture of water and alcohol into which an anti-corrosive agent has been introduced.

The front suspension also comprises upper and lower arms of unequal length located in the side-members of the front sub-frame with their outer ends attached by ball joints to the swivel hubs.

The rear suspension, in addition to the Hydrolastic units, consists of independent trailing arms with auxiliary coil springs.

**Section H.7****DEPRESSURIZING, EVACUATING, AND PRESSURIZING THE HYDROLASTIC SYSTEM**

Before any major work can be carried out on the suspension and its components the Hydrolastic system must be depressurized and in some cases evacuated. For this operation Service equipment Part No. 18G 703 or 18G 682 must be connected to the pressure valves on the rear sub-frame.

Before using Service equipment 18G 703 check that the pressure/vacuum tank is filled to the level indicated at the rear of the unit. The vacuum and pressure valves are identified by colour only; vacuum (yellow) and pressure (black).

Early Service equipment (18G 682) has separate fillers for the pressure and vacuum tanks and are filled to the level shown on the dipstick. One side of the dipstick shows the level in the pressure tank and the other side the level in the vacuum tank.




Fig. H.5  
The Hydrolastic system pressure valves on the rear sub-frame

Top up to the correct levels with Hydrolastic Fluid, BMC Part No. 97H 2801.

The vacuum and pressure valves are identified by number or colour; vacuum (1) yellow, and pressure (2) black.

**Depressurizing**

1. Remove the pressure valve dust cap and connect the black connector to the valve with the knurled knob unscrewed.
2. Open the black valve (valve 2) and screw in the knurled knob to release the fluid from the suspension system into the unit's pressure tank.
3. Close the black valve (valve 2). The gauge should read zero if all the pressure has been released.
4. Remove the black connector and replace the pressure valve dust cap, and the plug in the black connector.
5. Repeat the above procedure on the second valve to depressurize the other side of the system.

**Evacuating**

After fitting new interconnecting pipes or displacer units it is essential that the air is evacuated from the system and a partial vacuum created. Service equipment 18G 703 or 18G 682 must be used for this purpose as follows:

6. Remove the pressure valve dust cap and connect the yellow connector to the valve on the sub-frame.
7. Close the yellow valve (valve 1) on the service unit.
8. Operate the vacuum pump until a reading of 27 in. (68.6 cm.) of mercury is obtained on the vacuum

gauge and all movement of fluid in the tube has stopped. Subtract .5 in. (1.27 cm.) of mercury for every 500 ft. (152 m.) above sea-level.

9. Open the yellow valve (valve 1). Wait one or two minutes until any further movement in the tube has stopped and remove the yellow connector.
10. Replace the connector plug.




Fig. H.6  
The suspension service unit

- |                                   |                            |
|-----------------------------------|----------------------------|
| 1. Combined vacuum/pressure tank. | 4. Black valve (valve 2).  |
| 2. Pressure gauge.                | 5. Vacuum gauge.           |
| 3. Pressure pump handle.          | 6. Vacuum pump handle.     |
|                                   | 7. Yellow valve (valve 1). |




Fig. H.7  
The suspension service unit connectors

- |   |                    |
|---|--------------------|
| 1. Sealing plugs.                             | 4. Knurled knob.   |
| 2. Evacuating connector.                      | 5. Bleeding screw. |
| 3. Depressurizing and pressurizing connector. | 6. Locking slide.  |

### Pressurizing

Having carried out repairs and evacuated to ensure that all air is out of the system, the pressurization should be carried out as follows with the car in the condition given in Section H.9 and resting on all four wheels.

11. Connect the servicing unit black connector to the pressure valve on the rear sub-frame with the knurled knob unscrewed.
12. Close the black valve (valve 2) and open the bleed valve.
13. Operate the pressure pump until air is evacuated from the connecting tube and fluid appears at the bleed valve.
14. Close the bleed valve and screw in the knurled knob.
15. Increase the pressure until the normal operating pressure is obtained (see 'GENERAL DATA').

If a new displacer unit has been fitted pressurize to 350 lb./sq. in. (24.6 kg./cm.<sup>2</sup>).

16. Unscrew the knurled knob and open the black valve (valve 2) to release the pressure in the connecting pipe.
17. Remove the black connector and refit the sealing plug.
18. When pressurizing above the normal pressure as item 15, wait 30 minutes to allow the vehicle to settle. Reconnect the black connector with the knurled knob unscrewed, close black valve (valve 2), screw in the knurled knob, open black valve (valve 2) until the normal pressure is shown on the gauge.
19. Unscrew the knurled knob, open the black valve (valve 2) to release the pressure in the connecting pipe.
20. Remove the black connector, replace the connecting sealing plug and the valve dust cap.

### Servicing unit maintenance

Should the service equipment be used continuously, it may be necessary to carry out the following maintenance.

#### SERVICE TOOL 18G 682

21. Remove the front panel.
22. Remove the drain plug from the vacuum pump, drain the fluid.
23. Refill with the recommended vacuum oil S.A.E. 10 through the top of the pump. Replace the plug immediately the fluid commences to flow from the drain hole.
24. Lubricate the service unit mechanism periodically.

#### SERVICE TOOL 18G 703

25. Remove the front panel and fill the vacuum pump with the recommended vacuum oil S.A.E. 10 through the filler hole in the top of the pump. Fill only when the level is at the end of its downward stroke.
  26. Lubricate the service unit mechanism periodically.
- IMPORTANT.**—When the equipment is not in use both valves should be left open.

## Section H.8

### DISPLACER UNITS

#### Removal

1. Remove the road wheel and release the helper spring from the radius arm.
2. Raise the car and support it beneath the sub-frame member.




Fig. H.8  
A rear displacer unit separated from the locating plate

- |                    |                    |
|--------------------|--------------------|
| 1. Displacer unit. | 3. Locating plate. |
| 2. Locating lugs.  | 4. Sub-frame.      |

## THE REAR SUSPENSION


3. Remove the bump rubber from the sub-frame.
4. Depressurize the Hydrolastic system (see Section H.7).
5. Disconnect the flexible Hydrolastic hose from its union on the rear face of the sub-frame.
6. Remove the displacer strut and turn the unit anti-clockwise and withdraw it from the frame.

### Refitting

7. Reverse the removal instructions.
8. Rotate the displacer clockwise to lock it into the registers on the locating plate.
9. Lubricate the strut ball and the nylon seat with Dextragrease G.P. and make sure the dust seal is fitted over the lip of the nylon cup.
10. Evacuate and pressurize the system (Section H.7).

### Section H.9

#### SUSPENSION PRESSURE AND WING HEIGHTS



A5996

#### CONDITION OF CAR

Water; oil; petrol (max.) 4 Imp. gal. (4.8 U.S. gal., 18.2 litres)

Wing heights (early models)		Wing heights (later models)	
A	B	A	B
13±¼ in. (330±6.35 mm.)	13½±¼ in. 343±6.35 mm.)	12⅝±¼ in. (320.7±6.35 mm.)	13⅜±¼ in. (333.4±6.35 mm.)

**NOTE.**—It is most important that the Hydrolastic suspension system be pressurized to the figures given in 'GENERAL DATA'.

During the initial assembly, or subsequently if a new displacer unit is fitted, the system should be pressurized for a period of 30 minutes to 350 lb./sq. in. (24.6 kg./cm.<sup>2</sup>) on early models, and to 400 lb./sq. in. (28.1 kg./cm.<sup>2</sup>) on later models (see chart for commencing car numbers).

On all later cars, modified displacer units, helper springs and rear suspension struts are fitted. These components are not interchangeable individually with those fitted to earlier cars. The suspension pressure is also increased to suit the modified units (see 'GENERAL DATA').

#### Commencing car numbers:

Austin	Morris	R.H.D.	L.H.D.
Mini		830899	832055
	Mini	370004	370197
Cooper		830061	829417
	Cooper	830127	829490
Cooper 'S'		820487	820514
	Cooper 'S'	820705	820706

**To check and adjust pressures**

1. Ensure that the car is resting on all four wheels and that the load condition is as described above.
2. Use Service equipment 18G 703 and fit the black connector with the knurled knob unscrewed. Close valve 2 (black valve) and open the bleed valve. Use the pressure pump until air is evacuated from the connection tube and fluid appears. Close the bleed valve, operate the pressure pump until the working pressure is reached (see 'GENERAL DATA'), and then screw in the knurled knob. If the pressure reading is low, operate the pressure pump until the correct working pressure is reached (see 'GENERAL DATA'). If the pressure gauge reading is high, adjust to the correct working pressure by opening valve 2 (black valve). When the pressure reading is correct unscrew the knurled knob, open valve 2 (black valve), and remove the black connector. Replace the sealing plug in the black connector and the pressure dust cap on the suspension unit inter-connecting pipe valve.
3. A check can also be made on the suspension pressure, using Service tool 18G 685. The tool must first be adjusted in the following manner. Connect the pump to a pressure gauge fitted with a Schrader valve from which the core has been removed. Fill the tool with Hydrolastic fluid and operate the hand lever of the tool, noting the pressure registered on the gauge. Adjust the valve seat until the working pressure of the system is registered on the gauge (see 'GENERAL DATA'). Tighten the lock screw replace the washer and screw.

Fit the connector to the suspension unit inter-connecting valve and operate the hand lever until the relief valve in the tool commences to operate. The suspension will now be at its correct working pressure.

**Checking wing heights**

4. Ensure that the load condition is as described above.
5. Measure the wing heights as illustrated.

**NOTE.**—Should the Hydrolastic suspension system suffer damage and the fluid be lost, the suspension arms on the damaged side of the vehicle will contact the bump rubbers at both front and rear. In this condition the car may be driven with complete safety at 30 m.p.h. (50 km.p.h.) over metalled roads.

**Section H.10**

**RADIUS ARMS**  
(Hydrolastic Suspension)

**Removing**

1. Depressurize the Hydrolastic system (see Section H.7).

H.8

2. Remove the road wheel and release the helper spring from the radius arm.
3. Raise the vehicle and support it beneath the sub-frame side-member.
4. Disconnect the brake hose from the radius arm.
5. Disconnect the hand brake cable and release the cable sector from the arm.
6. Remove the bump rubber from the sub-frame and the end finisher from the sill panel.
7. Remove the displacer strut.
8. Remove the nut and washers from the arm pivot shaft and the four set screws to release the outer bracket.
9. Lift the radius arm assembly away from the vehicle, taking care not to lose the thrust washers and rubber seal fitted between the arm and the sub-frame side-member.  
Dismantling is described in Section H.2.

**Refitting**

10. Reverse the removing instructions.
11. Lubricate the strut ball end and the nylon seat with Dextragrease Super G.P. and make sure the dust seal is fitted over the lip of the nylon cup.
12. Bleed the hydraulic brake system.
13. Pressurize the Hydrolastic system (see Section H.7).

**Section H.11**

**SUB-FRAME**  
(Hydrolastic Suspension)

Remove and refit the sub-frame as in Section H.1, with the following additional operations:


1. Depressurize and evacuate the Hydrolastic system prior to any dismantling, follow the instructions in Section H.7.
2. Disconnect both helper springs from the radius arms.
3. Disconnect the pressure valves from the sub-frame.
4. Evacuate and re-pressurize the Hydrolastic system when reassembly is complete, following the instructions in Section H.7.

**Section H.12**

**SUB-FRAME**  
(Moke)

Remove and refit the sub-frame as in Section H.1 with the following exceptions:

Fuel tank and pump removal not necessary.



A8448A

Fig. H.9  
The Hydrolastic displacer unit

- |                          |                             |
|--------------------------|-----------------------------|
| 1. Interconnecting pipe. | 6. Damper valve.            |
| 2. Rubber spring.        | 7. Fluid separating member. |
| 3. Damper bleed.         | 8. Rubber diaphragm.        |
| 4. Butyl liner.          | 9. Tapered cylinder.        |
| 5. Tapered piston.       |                             |




Fig. H.10  
The tail rises in response to upward motion of the front wheel




Fig. H.11  
The nose rises in response to upward motion of the rear wheel



**Section H.13****RADIUS ARMS****(Moke)**

Remove and refit as in Section H.2 with the following exceptions:

Fuel tank and pump removal not necessary.

**Section H.14****SCHRADER VALVE EXTENSION HOUSING****(Hydrolastic Suspension)**

To rectify fluid leakage from the Schrader valve extension housing to the pipe elbow:

1. Depressurize the Hydrolastic system (see Section H.7).
2. Remove the Schrader valve extension housing from the pipe elbow and clean the threads of both the valve extension housing and the elbow.
3. The threads of the valve extension housing must be lightly coated with Loctite Grade A after the housing has been re-started on its threads in the elbow. Under no circumstances must Loctite be applied to the valve extension housing before inserting it in the elbow.
4. Tighten the valve extension housing to a torque of 16 to 20 lb. ft. (2.2 to 2.8 kg.m.) and leave for 24 hours at room temperature before pressurizing the system.
5. Evacuate and pressurize the system (see Section H.7).

## **SECTION J**

### **THE STEERING**

	<b>SECTION</b>
Front wheel alignment .. .. .	J.4
Nylon tie-rod ball ends .. .. .	J.6
Steering-column .. .. .	J.2
Steering rack assembly .. .. .	J.3
Steering-rack lubrication .. .. .	J.5
Steering-wheel .. .. .	J.1

### Section J.1

#### STEERING-WHEEL

##### Removal

1. Disconnect the battery.
2. EARLY MODELS. Withdraw the grub screw in the wheel hub and lift up the horn switch.
3. MK. II MODELS. Carefully prise off the wheel hub centre cover.
4. Unscrew the wheel retaining nut and pull off the wheel.

##### Refitting

Reverse the above removing instructions. Tighten the nut to the recommended torque (see 'GENERAL DATA').

### Section J.2

#### STEERING-COLUMN

##### Removing

1. Disconnect the column switch wiring connectors located below the parcel shelf.
2. Remove the bolt from the lower column clamp/steering rack pinion shaft.
3. Remove the column upper support clamp bolt.
4. Mark the fitted position of the outer column with the upper support bracket.
5. Pull the column assembly upwards and out of the car.

##### Dismantling

6. Remove the steering-wheel as described in Section J.1.
7. Remove both halves of the column cowl.
8. Remove the direction indicator switch and screw out the cancelling stud from the column.
9. EARLY MODELS. Remove the horn connection slip-ring assembly.




Fig. J.1

Using a locator pin to centralize the rack, with (inset) the plastic plug




Fig. J.2

The position of the clamp bolt and direction indicator lever,  $A = 20^\circ$

1. Right-hand-drive models. 2. Left-hand-drive models.

10. Withdraw the inner column from the lower end of the outer column tube.
11. Extract the upper and lower bushes from the outer column tube.

##### Inspection

12. Check the inner column alignment and rectify if required to ensure that when rotated the upper bearing face does not exceed  $\frac{1}{8}$  in. (3 mm.) run-out.
13. Examine the upper and lower felt bushes and use replacements if necessary. Cylindrical polythene upper bushes are now fitted to all later models.

##### Reassembling

14. Soak the lower felt bush in oil.
15. Lubricate the polythene bush with a graphite-based grease and insert it fully into the upper end of the outer column tube.
16. Insert the inner column into the outer column, and at the same time roll the lower felt bush around its fitted position on the inner column until both joint faces butt together, then carefully enter the assembly into the outer column.
17. Reverse the removing procedure for the other components.
18. Before refitting the assembly to the car ensure that the inner column turns freely (see instruction 12).

##### Refitting

19. Slacken the rack 'U' bolts to allow the rack pinion to align with the column.
20. Slacken the column fascia bracket bolts to allow sideways movement.
21. Align the road wheels to the straight-ahead position and refit the assembly to the car.
22. EARLY MODELS. Engage the marked spline of the pinion shaft with the split portion of the inner column clamp. Push down the assembly until the clamp bolt can be easily inserted. The clamp must be positioned as follows:




Fig. J.3

A section through the Mk. II steering-rack assembly, with the damper and pinion components shown inset

**LEFT-HAND-DRIVE.** The clamping bolt axis must be above the steering-column at an angle of  $16^\circ$  to the rack housing.

**RIGHT-HAND-DRIVE.** The clamping bolt axis must be below and parallel to the rack axis.

Tighten the clamping bolt to the correct torque figure (see 'GENERAL DATA').

23. MK. II MODELS. Pull out the plastic plug from the rack casing and insert a locator pin, i.e. a  $\frac{1}{4}$  in. (6 mm.) diameter bolt approximately 2 in. (50 mm.) long into the hole. Centralize the rack until the locator pin fully engages in the rack shaft to lock the centralized assembly in position (see Fig. J.1).
24. MK. II MODELS. Refit the column onto the pinion with the clamp bolt positioned as shown in Fig. J.2, and tighten to the torque figure given in 'GENERAL DATA'.
25. Lift the column and insert the clip into the support bracket, moving the bracket to meet the clip and not vice versa, so that the column remains free of load. Tighten the bracket to fascia rail securing bolts.
26. Refit and adjust the indicator trip stud until the combined measurement of the column and the stud is between 1.176 and 1.195 in. (29.87 and 30.35 mm.). Ensure that the longitudinal head of the stud is parallel to the column and tighten the locknut. Tighten the column clip to the fascia bracket.
27. Ensure that the outer column and direction indicator lever is positioned as shown in Fig. J.2, i.e. with the indicator trip stud exactly between the two cancelling mechanisms of the switch.
28. Tighten each of the rack 'U' Bolts nuts as a pair, turning each nut alternately a half-turn at a time until secure.
29. MK. II MODELS. Remove the locator pin and refit the plastic plug.
30. The remainder is a reversal of the removing procedure.

### Section J.3

#### STEERING RACK ASSEMBLY

The rack fitted to the Mk. II models is not interchangeable as a unit or as individual components with those racks fitted to earlier vehicles. Together with the new rack, modified steering levers are fitted and combine to provide the vehicle with a smaller turning circle. Correct wheel alignment is vitally important (see Section J.4).

#### Removing

1. Remove the air cleaner(s).
2. Slacken the column clamp bolt.
3. Remove the nut, bolt, and spring washer securing the column to the pinion shaft.
4. Mark the lower edge of the column shroud at the clamp bracket so that they can be refitted in line.
5. Pull the column upwards to free it from the pinion shaft.
6. Jack up the front sub-frame and remove the wheels and dampers. Remove the rack ball end retaining nuts and release the ball ends with Service tool 18G 1063.
7. Unscrew the four nuts and bolts securing the rear of the sub-frame to the body.
8. Remove the four bolts securing the sub-frame towers to the bulkhead cross-member.
9. Disconnect the exhaust pipe from the manifold and gear-change extension.
10. Disconnect the engine tie-rod.
11. Slacken the front sub-frame mounting bolts.
12. Remove the nuts from the steering rack 'U' bolts.
13. Support the body and remove the jack from the sub-frame; allow the sub-frame to drop and give clearance for the removal of the steering rack.
14. MK. II MODELS. Disconnect the remote-control gear lever extension from the floor (see Fig. A.12).

### COOPER

- Carry out the instructions detailed above and also:
15. Disconnect the gear lever extension from the floor.
  16. Remove the exhaust pipe and silencer (Section A.3).

#### Dismantling

17. Disconnect the tie-rods from the steering-arms.
18. Remove the rubber gaiters.
19. Remove the damper cover plate, yoke, and spring(s).
20. Remove the pinion shaft tail bearing retaining plate, shims, thrust washer, bearing and bearing race, and withdraw the pinion. Extract the top bearing race, bearing, and thrust washer from behind the rack teeth.
21. Extract the pinion shaft oil seal.
22. Use Service tool 18G 707 to unscrew the ball housing and release the tie-rod, ball seat and tension spring. Remove the second tie-rod.
23. Withdraw the rack from the pinion end of the rack housing to obviate damage to the felt or 'Vulkollan' bush fitted in the opposite end of the rack housing.
24. Remove the bush securing screw from the rack housing, lever the felt bush at its joint and extract it. The felt bush metal sleeve must be removed if a plastic ('Vulkollan') bush is to be fitted as a replacement for the felt bush.

#### Inspecting

25. Clean all parts and examine for wear, particularly the rack and pinion teeth, and the rubber gaiters. Fit new parts where necessary.




Fig. J.4

A section through the steering pinion and rack damper (1st type)

- A. Take a feeler gauge measurement and fit the pinion end cover with shims to the value of the measurement minus .001 to .003 in. (.025 to .076 mm.) before fitting the damper yoke (C).
- B. Measure the gap and fit shims.
- C. Damper yoke.

J.4




Fig. J.5

A section through the steering pinion and rack damper (2nd type)

- A. Take a feeler gauge measurement and fit the pinion end cover with shims to the value of the measurement minus .001 to .003 in. (.025 to .076 mm.) before fitting the damper yoke (C).
- B. Measure the gap and fit shims.
- C. Damper yoke.

#### Reassembling

26. Reverse the dismantling sequence but note: If fitting a new felt bush (early models), soak the bush in E.P. S.A.E. 140 oil.
27. The plastic bush may be used as a replacement for the felt bush and is used together with a steel sleeved bush and spacer. Insert the spacer (plain end first) into the rack housing. Fit the plastic bush into the steel sleeve and insert it into the rack housing (plain end first), with the flats on the plastic bush positioned offset to the retaining screw hole in the rack housing. Ensure that the spacer and bush are correctly positioned and drill through the retaining screw hole and the bush with a  $\frac{7}{64}$  in. (.27 mm.) drill.

Remove all swarf; coat the retaining screw with a jointing compound and refit to secure the bush. Check that the screw does not project into the bore of the plastic bush.

28. PINION ADJUSTMENT (EARLY MODELS). Refit the cover without the shims, but do not over-tighten the screws. Measure the gap between the cover and the housing. Remove the cover and add shims to the thickness of the measurement minus .002 in. (.05 mm.). Refit the cover with jointing compound.
29. PINION ADJUSTMENT (MK. II MODELS). Refit the pinion and bearings as shown in Fig. J.3. Add sufficient shims together with the spacer washer to provide a clearance of approximately .010 in. (.25 mm.) between the rack housing and the cover plate. Fit and lightly tighten the cover plate. Take a feeler gauge measurement of the clearance (A) and reduce the shimming by the measurement taken, less .002 to .005 in. (.05 to .13 mm.), to give the required pre-load.




Fig. J.6

A section through the steering pinion and rack damper (Mk. II models)

- A. Take a feeler gauge measurement and fit the pinion end cover with shims to the value of the measurement minus .002 to .005 in. (.05 to .13 mm.) before fitting the damper yoke (C).
- B. Measure the gap and fit shims.
- C. Damper yoke.

- 30. Refers to item 22. Screw the ball housing locking ring onto the rack end as far as it will go and refit the lock washer. On models not fitted with a lock washer, fit a new locking ring. Refit the seat spring, seat, tie-rod and ball housing, and tighten up until the tie-rod is pinched. Slacken the housing one-eighth of a turn and tighten the locking ring to the recommended torque. Punch the lock washer into the slots of the housing and locking ring. If no lock washer is fitted, punch the lips of the locking ring into the slots of the ball housing and rack.

- 31. DAMPER ADJUSTMENT (1ST TYPE). Refit the yoke with the disc springs but without the packing shims.

With the rack in the straight-ahead position, tighten the cover screws until it is just possible to rotate the pinion with the pre-load gauge, 18G 207 and 18G 207 A set at 15 lb. in. (.17 kg. m.). Measure the gap between the damper housing flange and the rack housing. Remove, and then refit the damper with shims to the thickness of the measurement minus .002 in. (.05 mm.).

- 32. DAMPER ADJUSTMENT (2ND TYPE AND MK. II MODELS). Refit the yoke and cover plate without the spring.

Follow the measurement checking procedure given in item 31 and refit the yoke with its 'O' ring seal (Mk. II models), together with the spring and cover plate, with shims to the value of the measurement plus .002 in. to .005 in. (.05 to .13 mm.).

- 33. Refit the rubber gaiters to the housing and the tie-rods. Before securing the gaiter clip on the tie-rod at the pinion end, stand the assembly upright and pour in approximately  $\frac{1}{3}$  pint (.4 U.S. pint, .19 litre) of Extreme Pressure S.A.E. 90 oil through the end of the gaiter. Refit and tighten the gaiter clip.
- 34. Check that the tie-rods have an equal number of threads visible behind each locknut, i.e. approximately eight threads on early racks and 11 threads on the Mk. II racks.
- 35. EARLY MODELS. Centralize the rack in the housing. The full travel of the rack in each direction is 1.75 in. (44.5 mm.).

**Refitting**

**ALL MODELS**

Reverse the removal instructions, but note:

- 36. Refit the rack to the body with the 'U' bolts lightly tightened to allow the pinion to accept the column alignment.
- 37. Align the road wheels to the straight-ahead position.
- 38. Carry out the operations 20, and 22 to 30 in Section J.2.
- 39. Check and reset the wheel alignment (see Section J.4).

**Section J.4**

**FRONT WHEEL ALIGNMENT**

**Checking**

When checking or adjusting the front wheel alignment it is essential to use equipment designed to work at the specified height and diameter, and preferably a gauge which measures the angles involved rather than the difference in distance between the wheels in front of and behind the centres.

With the car unladen, tyres at the correct pressures, and the steering in the straight-ahead position, each wheel should make an angle of 70' 30" with the longitudinal axis




Fig. J.7

The front wheel alignment check must be taken with the front wheel in the straight-ahead position. Dimension (A) must be  $\frac{1}{16}$  in. (1.6 mm.) greater than (B)

of the car. When this angle is correct the distance between the front of the wheels will be  $\frac{1}{16}$  in. (1.6 mm.) greater than that at the rear (see Fig. J.7).

When measuring distances rather than angles the measurements must be made on a  $14\frac{1}{2}$  in. (368.3 mm.) diameter on the side wall of the tyre at a distance of 9.4 in. (239 mm.) above the ground.

If a base-bar alignment gauge is used, take two measurements; take a measurement at the front, mark the point on the tyres with chalk, push the car forward half a road wheel revolution and take the second measurement at the same points on the tyres and behind the centres.

With an optical gauge, take two readings with the car moved forward  $180^\circ$  and three with it moved forward  $120^\circ$ . The average figure should then be calculated.

#### Adjustment (Early models)

To adjust the track, slacken the tie-rod ball joint locknuts and the rubber gaiter clips, and turn each tie-rod the same number of turns until the adjustment is correct.

The tie-rods must be exactly the same length.

#### MK. II MODELS

The later steering-rack provides a smaller turning circle and it is vitally important that the wheel alignment is checked, and adjusted if necessary, following the correct procedure. Incorrect adjustment could result in excess articulation of the drive shaft constant velocity joints, and subsequent fouling of the suspension tie-rods by the road wheels when on full lock. Checking and adjustment must only be carried out when the vehicle is at 'kerbside' trim, i.e. fully equipped but without occupants or excess luggage.

#### Checking

1. With the vehicle resting on its wheels, turn the steering on each lock and check the clearance between the road wheel and the suspension tie-rod. The minimum clearance should not be less than  $\frac{3}{4}$  in. (19 mm.), or with the suspension at full rebound, not less than  $\frac{1}{4}$  in. (6.5 mm.).

Correct adjustment on each tie-rod will be indicated by the clearance figures given above being approximately the same on each side. Check the wheel alignment with an optical gauge, see item 6.

#### Adjustment

2. Slacken the rack tie-rod locknuts and the gaiter clips. Disconnect the ball joints from the steering levers, using Service tool 18G 1063.
3. Lift the floor covering and remove the rubber grommet from the floor panel (opposite side to the rack pinion).
4. Pull out the plastic plug from the rack body and insert a locator pin, i.e.  $\frac{1}{4}$  in. (6 mm.) diameter bolt into the hole (see Fig. J.1).

5. Centralize the rack until the locator pin fully engages with the rack, to lock the centralized assembly.
6. Use an optical setting gauge and align the road wheels to the straight-ahead position, i.e.  $\frac{1}{16}$  in. (1.6 mm.) toe out, and in alignment with the centre line of the car.
7. Adjust the tie-rods until each ball pin will correctly locate its steering lever without disturbing the alignment given in item 6, and secure in position.
8. Recheck the setting and adjust equally each tie-rod until the setting is obtained and tighten the locknuts. Ensure that the rubber gaiters are not under stress from twist and tighten the securing clips.
9. Remove the locator pin and refit the plastic plug.
10. Recheck the adjustment as detailed in item 1.
11. Refit the floor grommet and covering.

**NOTE.**—The hole in the rack from which the plastic plug was removed **MUST NOT** be utilized for the purpose of 'topping up' with lubricant.

#### Section J.5

##### STEERING RACK LUBRICATION

Lubricating nipples are not provided and rack lubrication is only necessary if leakage is evident from the rack housing or the rubber gaiters.

The following procedure should be followed provided the leakage can be rectified without the assembly being removed.

1. Centralize the steering rack.
2. Remove the gaiter retaining clip on the driver's side.
3. Inject  $\frac{1}{3}$  pint (.2 litre) of E.P. S.A.E. 90 oil into the rubber gaiter.
4. Refit the gaiter clip and turn the steering from side to side to distribute the oil through the housing.

**WARNING.**—If the vehicle is hoisted with its front wheels clear of the ground care should be taken to avoid forceful movement of the wheels from lock to lock, otherwise damage may occur within the steering mechanism.

#### Section J.6

##### NYLON TIE-ROD BALL ENDS

Later ball joints have nylon seats sealed for life and protected by rubber boots; no lubrication is required.

The rubber boots must be maintained in good condition, and if it is found that a boot has become damaged in service both boot and joint must be renewed. However, if a boot is damaged in the workshop during the removal of a joint which has therefore not become contaminated by road dirt, the boot alone may be renewed.

Before fitting a new boot smear the area adjacent to the joint with a little De.:tagrease Super G.P. lubricant.

# SECTION K

## THE FRONT SUSPENSION

	SECTION
Hydrolastic suspension	
Description .. .. .	H.6
Depressurizing, evacuating, pressurizing .. .. .	H.7
Displacer units .. .. .	K.7
Upper suspension arms .. .. .	K.8
Rubber suspension .. .. .	
Lower arm .. .. .	K.5
Spring units .. .. .	K.1
Struts .. .. .	K.6
Upper arm .. .. .	K.4
Swivel hub ball-joints .. .. .	K.3
Swivel hub outer oil seal .. .. .	K.9
Swivel hubs .. .. .	K.2






Fig. K.1  
Compressing the spring unit  
1. Service tool 18G 574 B

## Section K.1

### SPRING UNITS (Rubber Suspension)

#### Compressing

1. Slacken one bolt (or nut) and remove the other securing the sub-frame towers to the engine bulkhead cross-member.
2. Move the locking plate to one side to expose the access hole in the cross-member. Refit the bolt (or nut) and tighten both.
3. Insert Service tool 18G 574 B through the cross-member, locate the body of the tool over the two sub-frame bolts (or nuts), and screw the centre of the tool nine complete turns into the spring unit. Use the ratchet handle to turn the centre nut and make contact with the body of the tool. Hold the centre screw to prevent further rotation and then turn the ratchet handle clockwise to compress the spring sufficiently to allow removal of the spring strut from the tower. Do not over-compress the spring.

#### Removing

4. Jack up the car after compressing the spring, and remove the road wheel.
5. Remove the bump rubber from the tower.
6. Remove the retaining nut and release the upper suspension arm with Service tool 18G 1063.

7. With the spring unit compressed, lever the strut from the spring unit, see Fig. K.4.
8. Detach the hydraulic damper, dismantle the upper arm pivot and remove the upper arm.
9. Hold the centre screw of the tool to prevent it turning, screw the ratchet handle upwards to release the spring compression, remove the tool, and extract the spring unit from the tower.

#### Refitting

10. Reverse the removing instructions.

## Section K.2

### SWIVEL HUBS

#### Removing

1. Jack up the front of the vehicle, place supports under the sub-frame and remove the road wheel.
2. Remove the steering lever ball joint retaining nut and release the ball joint using Service tool 18G 1063.
3. Mark the drive shaft flange for correct reassembly and disconnect the inner flexible joint by removing the four outer 'U' bolts.  
On models which have a universal joint flange, remove the four retaining nuts.
4. Slacken the front brake pipe union from its hose connection and unscrew the nut securing the hose to the anchor bracket. Unscrew the hose from the backplate (it will still remain attached to the anchor bracket and pipe union).  
**Disc brake models.** Remove the brake calliper and support it; **do not** allow it to hang on the hydraulic hose.
5. Disconnect the tie-rod from the lower suspension arm.
6. Remove the upper and lower swivel hub ball pin retaining nuts and release the ball pins from the suspension arms using Service tool 18G 1063.
7. Withdraw the swivel hub and drive shaft from the vehicle.


#### Dismantling

8. Remove the brake-drum (except disc brake models).
9. Extract the split pin and remove the nut, and distance washer (outer taper collar on Disc brake models).
10. Drift the drive shaft from the flange and hub. Drift the driving flange from the hub using Service tool 18G 575.  
**Disc brake models.** Tap the end of the drive shaft with a hide mallet and pull off the driving flange and disc assembly. Remove the drive shaft, the inner and outer bearing and distance ring from the hub.
11. Remove the bearing to flange distance piece and outer seal, the inner seal with water shield (if fitted) and spacer.

Fig. K.2

The swivel hub assembly  
(Mini range with front drum brakes)

1. Drive shaft nut.
2. Driving flange.
3. Distance piece.
4. Brake-drum.
5. Hub assembly.
6. Hub bearings.
7. Bearing distance ring.
8. Outer oil seal.
9. Spacer for oil seal.
10. Inner oil seal.
11. Water shield.
12. Drive shaft.




INC621

Fig. K.3

The swivel hub assembly  
(Cooper 'S' and 1275 GT)

1. Drive shaft nut.
2. Outer tapered collar.
3. Driving flange.
4. Hub and disc assembly.
5. Bearing distance rings.
6. Taper roller bearings.
7. Outer oil seal.
8. Spacer (inner bearing to seal).
9. Inner oil seal.
10. Water shield.
11. Swivel hub.
12. Drive shaft.



INC618




Fig. K.4

Removing the spring strut (1) with the spring unit compressed and the upper support arm (2) removed from the hub ball pin (3)

12. Drift out the inner race of each bearing and remove the distance ring. Use Service tool 18G 260 H to withdraw the outer races.
13. **Disc brake models.** Substitute for operations 11 and 12. Remove the outer seal and the inner seal with water shield (if fitted), drive out the inner and outer bearing cups with a brass drift, note that the hub has recesses for this but take care not to damage the hub bore.

#### Reassembling

14. Reassembling is a reversal of the dismantling procedure but note the following points:
  - a. Pack the bearings only with a high-melting point grease, e.g. (Duckhams L.B.10).

- b. When refitting 'thrust type' bearings, ensure that the sides marked 'THRUST' are facing each other, with the distance ring between them.
- c. When replacing the inner oil seal, ensure that the later type single lipped seal together with its plastic water shield is used. This seal and water shield must be fitted as a pair and replaces all seals previously used for the various models.
- d. Use Service tool 18G 134 and adaptor 18G 134 DO to fit both new seals to the hub. Ensure that the water shield is fitted to the drive shaft as shown in Fig. K.5.

#### Refitting

15. Reverse the removing procedure noting the following points:
  - a. Tighten the ball pin retaining nuts to the torque figure given in 'GENERAL DATA'.
  - b. Tighten the drive shaft nut to the correct torque figure, see 'GENERAL DATA' for the particular model application.
  - c. **Disc brake models.** Check the run-out on the periphery of the disc. If this exceeds .006 in. (.15 mm.) reposition the driving flange assembly on the drive shaft splines until the run-out is within this limit.
  - d. Use a new split pin to lock the drive shaft nut, refit the brake drum or calliper as applicable.
  - e. Bleed the braking system (Section M.8) if the brake pipe has been disconnected.




Fig. K.5

The fitted location of the water shield on the drive shaft before the hub is refitted  
'A' = ¼ in. (6.4 mm.)

Section K.3

SWIVEL HUB BALL JOINTS

Removing

1. Compress the rubber spring unit as detailed in Section K.1 or depressurize the Hydrolastic system, see Section H.7.
2. Carry out operations 1, 2 and 4 in Section K.2.
3. Fit Service tool 18G 304 with adaptor bolts 18G 304 F to the wheel hub studs, ensure that the swivel hub is free of the upper and lower suspension arms and extract the hub from the drive shaft.

Dismantling

4. Remove the Service tool and secure the swivel hub assembly firmly in a vice.
5. Remove the ball housing dust seal and lubricator.
6. Tap back the lock washer and unscrew the upper ball pin retainer using Service tool 18G 587.
7. Repeat operation 6 on the lower ball joint noting the spring fitted under the ball pin seat.
8. Clean and examine the components and fit replacements as necessary.

Adjusting

9. Reassemble the upper ball pin assembly; refit the ball pin seat, pin and retainer without the packing shims and locking washer.
10. Screw down the ball pin retainer until there is no free movement between the ball pin and its seating. Measure the gap between the retainer and the swivel hub, see Fig. K.6.
11. Note that the thickness of a new locking washer is .036 in. (.9 mm.); deduct this figure from the gap measurement taken in operation 10 to obtain the correct thickness of shims required.  
The final assembly must have no nip to .003 in. (.7 mm.) end-float, add a further shim if necessary to obtain the correct adjustment.
12. Pack the joint with grease and refit the assembly complete with shims and a new locking washer to the hub.
13. Tighten the ball pin retainer with Service tool 18G 372 and adaptor 18G 587 to the torque figure given in 'GENERAL DATA'.
14. Repeat operations 9 to 13 for the lower ball pin, except that the spring fitted in the lower assembly must be removed when taking the gap measurement as detailed in operation 10 and refitted under the ball pin seating on final assembly.
15. Tap up the locking washer against three flats of the ball pin retainer (one flat must be adjacent to the brake disc on disc brake models).
16. Fit new ball pin dust seals if required.




Fig. K.6

A section through the swivel hub ball joints. 'A' indicates the gap measured for shim adjustment

- |                       |                                       |
|-----------------------|---------------------------------------|
| 1. Hub assembly.      | 5. Seat spring (lower assembly only). |
| 2. Ball pin retainer. | 6. Dust seal.                         |
| 3. Ball pin.          | 7. Suspension upper arm.              |
| 4. Ball pin seat.     | 8. Suspension lower arm.              |
| 9. Locking washer     | } fitted on final assembly.           |
| 10. Shims             |                                       |

Refitting

17. Refitting is a reversal of the removing procedure, tighten the upper and lower ball pin nuts to the torque figure given in 'GENERAL DATA'.
18. Tighten the drive shaft nut to the correct torque figure, see 'GENERAL DATA' for the particular model application.
19. Release the rubber spring unit from compression as detailed in Section K.1, operation 9; or pressurize the Hydrolastic system as detailed in Section H.7.
20. Tighten the brake pipe connection and bleed the braking system (Section M.8).
21. **Disc brake models.** Refit the brake calliper.
22. Refit the road wheel and lower the car.

## Section K.4

### UPPER ARM (Rubber Suspension)

#### Removing

1. Compress the spring as in Section K.1.
2. Jack up the vehicle and remove the road wheel and damper.
3. Remove the ball-pin retaining nut, release the upper suspension arm with Service tool 18G 1063 and withdraw the strut, see Fig. K.4.
4. Remove the nut and washer from each end of the shaft.
5. Remove the front thrust collar retaining plate, the collar and the seal and push the shaft forward.
6. Remove the rear thrust washer and seal and manoeuvre the arm from the frame.
7. Extract the needle-roller bearings from the arm with Service tool 18G 581.

#### Refitting

Reverse the removing instructions, but note:

8. Lubricate all parts with grease.
9. Fit the needle-roller bearings with the marked ends outwards, using Service tool 18G 582 and adaptor 18G 582 A to push them into position.
10. Lubricate the spring unit strut nylon cup with Dextragrease Super G.P.

## Section K.5

### LOWER ARM

#### Removing

1. Jack up and remove the road wheel and damper.
2. Support the suspension with a jack under the brake-drum.
3. Disconnect the tie-rod from the lower arm.
4. Release the lower arm from the swivel hub with Service tool 18G 1063.
5. Remove the nut and washer from the rear end of the shaft and withdraw the shaft.

**NOTE.**—Later vehicles are fitted with modified lower arms and these are fitted with composite steel/rubber bushes. These new parts can be fitted to earlier vehicles but only as complete sets.

6. Refitting is a reversal of the removing instructions but note the following:

Tighten the shaft securing nut when the vehicle is resting on the road wheels—to prevent pre-loading of the rubber bushes.

K.6

## Section K.6

### SUSPENSION STRUTS (Rubber Suspension)

Some cars have been fitted with struts having a circular-section washer between the body of the suspension strut and the knuckle end. When fitting a new strut to these vehicles, make sure the washer is included.

## Section K.7

### DISPLACER UNITS (Hydrostatic Suspension)

#### Removing

1. Jack up the car and remove the road wheel.
2. Depressurize and evacuate the Hydrostatic system (see Section H.7).
3. Release the displacer strut dust seal from the nylon seat and extract the strut from the displacer unit.
4. Disconnect the displacer hose from the union on the engine bulkhead.
5. Remove the suspension upper arm (see Section K.4).
6. Push the displacer upwards and remove two screws to release the displacer bracket from inside the sub-frame tower.
7. Rotate the displacer anti-clockwise and withdraw it from the sub-frame.




Fig. K.7

The right-hand front displacer hose connector

- |                    |              |
|--------------------|--------------|
| 1. Displacer hose. | 2. Hose nut. |
| 3. Connector.      |              |

**Refitting**

8. Reverse the removing instructions.
9. Rotate the displacer clockwise to lock it into the registers on the locating plate.
10. Lubricate the strut ball end and the nylon seat with Dextragrease Super G.P. and make sure the dust seal is fitted over the lip of the nylon cup.
11. Evacuate and pressurize the system (see Section H.7).

**Section K.8**

**UPPER SUSPENSION ARMS  
(Hydrolastic Suspension)**

**Removal**

Depressurize the Hydrolastic system as in Section H.7 and follow the instruction in K.4 for arm removal.

**Section K.9**

**SWIVEL HUB OUTER OIL SEAL**

The following instructions will permit a leaking outer seal to be replaced when the driving flange is removed.

**NOTE.**—A bearing overhaul will still require swivel hub removal as in Section K.2.

**Removing**

1. Remove the hub cover, extract the split pin, and slacken the drive shaft nut.
2. Slacken the wheel nuts and jack up the vehicle.
3. Take off the road wheel and remove the brake-drum.
4. Remove the drive shaft nut and assemble the Service tool 18G 304 and 18G 304 F to the drive flange.
5. Replace the Service tool centre screw with adaptor 18G 304 P and use the impulse extractor 18G 284 to remove the flange.
6. Should the outer bearing inner race come away with the driving flange, it can be removed with Service tool 18G 705 and adaptor 18G 705 B.

**Refitting**

7. Refit the inner bearing race (if extracted).
8. Fit the new seal and apply a suitable amount of lubricant to the lip to prevent burning.
9. Insert the outer bearing distance piece into the seal with the chamfered bore to the outside.
10. Assemble the drive flange to the hub, drifting it into position gently, turning the flange 180 degrees several times to align the bearing distance piece with the flange boss.
11. Refit the brake-drum.
12. Refit the drive shaft washer, chamfered bore facing inward and refit the nut.
13. Tighten the drive shaft nut to the torque figure given in 'GENERAL DATA' and secure with the split pin.



# SECTION L

## THE HYDRAULIC DAMPERS

	SECTION
Priming .. .. .	L.2
Removal and refitting .. .. .	L.1
Rear (Moke) .. .. .	L.3






Fig. L.1  
The hydraulic dampers

#### REAR

- A. Extended length  $15\frac{3}{8}$  in. (385.76 mm.).  
Van only  $16\frac{1}{8}$  in. (409.6 mm.).  
B. Compressed length  $9\frac{9}{16}$  in. (242.89 mm.).  
Van only 10 in. (254 mm.).

#### FRONT

- C. Compressed length  $8\frac{1}{2}$  in. (215.90 mm.).  
D. Extended length  $12\frac{3}{4}$  in. (323.85 mm.).

### Section L.1

#### REMOVAL AND REFITTING

##### Front

1. Jack up and remove the road wheel.
2. Support the suspension under the brake-drum.
3. Remove the upper and lower securing nuts and pull the damper from the mounting spigots.
4. Hold the damper upright in a vice and compress and extend it six times to expel air. Retain the damper upright until refitted.
5. Fit new rubber bushes as required.
6. Refit.

##### Right-hand damper (rear)

7. Remove the upper damper mounting-nuts from inside the luggage boot.
8. Jack up the vehicle and remove the road wheel. Take off the lower mounting nut and washer collapse the damper, and remove it from its anchorage point on the radius arm.

9. Retain the damper in an upright position after removal from the car.
10. Make certain that the rubber bushes are in good condition; fit new bushes if they are worn or damaged.
11. Before refitting a damper to the vehicle it must be primed (see Section L.2).
12. When refitting the rear dampers make certain that the rubber cone spring and the spring strut are correctly located on their individual spigots whilst the radius arm is being raised to reconnect the upper end of the damper.

##### Left-hand damper (rear)

Access to the damper upper fixing nuts can only be obtained after the fuel tank has either been completely removed, or (as on most cars) it is only necessary to release the tank from its mounting position. On cars produced having a fuel tank with a rigid tube the tank must be drained and removed (see Section D.1).

#### TO RELEASE THE FUEL TANK

13. Remove the fuel filler cap and release the tank securing strap.
14. Pivot the tank around the tank front hose connection, taking care not to damage the hose, and lift the rear of the tank towards the centre-line of the car until access to the damper is obtained.
15. Remove and refit a damper as operation sequence 7 to 12 for right-hand damper.

### Section L.2

#### PRIMING

If air is suspected in a hydraulic damper, remove the damper from the vehicle and stand it in a vertical position for approximately five hours, then prime as follows.

##### Armstrong

Hold the damper vertically, extend to its full travel and then compress slowly. Continue to extend and compress until there is no free travel when changing direction of stroke.

##### Girling

Hold the damper, with the dust shield uppermost, at an angle of  $15^\circ$  to  $20^\circ$  to the vertical. Extend the damper about 76 mm. very slowly and then compress fully. Rotate the dust shield at the same time. Repeat until all free play has disappeared. Do not fully extend the damper during this process.

New dampers need only be held in their vertical position for a few minutes before priming. After priming, always store dampers in a vertical position.

## Section L.3

**REAR DAMPERS  
(Moke)****Removing**

1. Jack up and remove the road wheel.
2. Remove the cover from the upper mounting point inside the vehicle.
3. Remove the nuts from the upper and lower mounting points, collapse the damper, and pull it from its anchorage on the radius arm.



## SECTION M

### THE BRAKING SYSTEM

	SECTION
Adjustment .. .. .	M.2
Bleeding .. .. .	M.8
Disc brake calliper .. .. .	M.7
Intensifier .. .. .	M.6
Master cylinder .. .. .	M.1
Pressure regulating valve .. .. .	M.5
Shoe assemblies (and disc friction pads) .. .. .	M.3
Vacuum servo (Cooper 'S') .. .. .	M.9
Wheel cylinders .. .. .	M.4
Two-leading-shoe front brakes .. .. .	M.10
Preventive maintenance .. .. .	M.11




Fig. M.1  
The front brake-shoe adjuster. One square-headed adjuster is provided on each of the four brake back-plates




Fig. M.2  
The right-hand front brake assembly, showing the fitted positions of the leading and trailing brake-shoes, with the pull-off springs anchored in the correct holes in the shoe web

### Section M.1

#### MASTER CYLINDER

See Section E.4, but note the non-return valve fitted in this cylinder.

### Section M.2

#### ADJUSTMENT

Early models have one square-headed adjuster screw projecting from each brake backplate. For adjustment on cars having two-leading-shoe brakes see Section M.10.

Jack up the car and turn the adjuster in a clockwise direction until the wheel is locked and then slacken the screw until the shoes are just free of the drum.

#### COOPER

Front disc brakes are not adjustable.  
The rear brakes are adjusted as above.

#### Hand brake

##### ALL MODELS

1. Adjust the brake-shoes as detailed above.
2. Apply the hand brake to the third notch on the ratchet.
3. Take up excessive cable movement, turning the nuts at the lever trunnion until the wheels can only just be turned by heavy hand pressure.
4. Ensure that the wheels rotate freely when the hand brake is released.

### Section M.3

#### SHOE ASSEMBLIES

##### Removing (front)

1. Jack up and remove the road wheel.
2. Unscrew the two retaining screws and pull off the drum.
3. Note the position of each spring; release them from the shoe webs and remove the springs and shoes.

**NOTE.**—Do not press the pedal when the shoes and springs have been removed.

##### Removing (rear)

As for the front shoes.




Fig. M.3  
The right-hand rear brake assembly, showing the pull-off springs anchored in the correct holes in the shoe web




Fig. M.4  
A section through the brake master cylinder

- |                     |                    |                       |
|---------------------|--------------------|-----------------------|
| 1. Push-rod.        | 7. End plug.       | 12. Piston washer.    |
| 2. Rubber boot.     | 8. Circlip.        | 13. Main cup.         |
| 3. Mounting flange. | 9. Stop washer.    | 14. Spring retainer.  |
| 4. Supply tank.     | 10. Secondary cup. | 15. Return spring.    |
| 5. Body.            | 11. Piston.        | 16. Non-return valve. |
| 6. Washer.          |                    |                       |

**Refitting (front and rear)**

Reverse the removing instructions.

**COOPER Removing disc brake friction pads**

1. Jack up, remove the wheel.
2. Depress the pad retaining spring and withdraw the split pins (Fig. M.6).
3. Remove the spring and withdraw the pads from the calliper.
4. Thoroughly clean the exposed face of each piston and the recesses in the calliper.

On later cars the pads are retained in the callipers by means of split pins only. The pins pass through the calliper body and the pads, and no pad retaining springs are fitted. To remove the pads, it is only necessary to remove the split pins and extract the pads with a direct pull. Pads for the earlier- and later-type callipers are NOT INTERCHANGEABLE.

**Refitting**

5. Press the pistons back into the calliper with Service tool 18G 672.
6. Check that the cut-away edge of each piston is facing upwards and that anti-squeak shims are correctly placed.
7. Insert the new pads and check that they move easily in the calliper.
8. Remove any high spots from the pressure plate by careful filing.

9. Refit the spring, press it down and insert the split pins.
10. Press the pedal several times to adjust the brakes.

**Section M.4**

**WHEEL CYLINDERS**

**Removing front and rear**

1. Carry out instructions 1, 2, and 3 in Section M.3.
2. Thoroughly clean the backplate.
3. Disconnect the flexible hose.
4. Unscrew and remove the bleed screw.
5. Remove the circlip and dished washer from the cylinder boss protruding through the backplate and withdraw the cylinder.

**COOPER Removing (rear only)**

As instructions 1 to 5 above.

**Dismantling**

6. Remove the dust seals from the ends of the cylinder and extract both pistons.
7. Remove the piston seals with the fingers only.
8. Clean all parts with brake fluid.




Fig. M.5

The hydraulic pressure regulating valve components

#### Reassembling

9. Fit new parts as required and then reverse the dismantling procedure.

#### Refitting

Reverse the removal instructions and bleed the system.

### Section M.5

#### PRESSURE REGULATING VALVE

##### Removing

1. Disconnect the three pressure lines, unscrew the securing nut and withdraw the assembly from the rear sub-frame cross-member.

##### Overhauling

2. Clean the exterior.
3. Remove the end plug and sealing washer.
4. Extract the valve assembly and return spring.
5. If the rubber seals are not in good condition, fit a new piston and seal assembly.
6. Clean all parts with brake fluid, reassemble and refit.

### Section M.6

#### INTENSIFIER

##### COOPER (Early models)

The brake intensifier is only fitted on early models. Later models have a pressure regulating valve incorporated in the system (see Section M.5).

##### Removing

1. Slacken the top pipe union, remove the nuts and washers and take out the mounting bolts.
2. Completely unscrew the top union and withdraw the pipe and union.

M.4

3. Unscrew the bottom pipe union and withdraw the pipe and union.
4. Remove the intensifier.

##### Dismantling

5. Hold the intensifier in a vice and unscrew the large hexagon plug.

**NOTE.**—The plug is under spring pressure.

6. Extract the piston assembly and springs.
7. Thoroughly clean all parts with brake fluid and examine for wear.

##### Reassembling

8. Renew all worn or damaged parts. If the rubber seals have deteriorated, renew the piston assembly.

##### Refitting

Reverse the removing instructions.  
Bleed the system.

### Section M.7

#### DISC BRAKE CALLIPER

##### COOPER

##### Removing and dismantling

Do not separate the two halves of the calliper; each piston assembly must be dealt with individually.

1. Disconnect the tie-rod from the steering-arm.
2. Remove the locking plate from the dust cover.




Fig. M.6

The hydraulic pressure regulating valve

3. Unscrew the two bolts securing the calliper to the hub, detach both parts of the dust cover and remove the calliper without disconnecting the brake pipe.
4. Withdraw the pads.
5. Clean the outside of the calliper.
6. Clamp the piston in the mounting half of the calliper.
7. Apply the brake pedal gently to force the other piston from the calliper.
8. Withdraw the fluid seal and the dust seal.

**Reassembling**

9. Coat a new fluid seal with Lockheed Disc Brake Lubricant and then ease it into its groove.
10. Slacken the bleeder screw one complete turn.
11. Coat the piston with Lockheed Disc Brake Lubricant, insert it into the bore with the cut-away face facing upwards and press it in with Service tool 18G 672 until about  $\frac{5}{16}$  in. (8 mm.) remains protruding.
12. Coat a new, dry dust seal with Lockheed Disc Brake Lubricant, fit it to the retainer and position the seal and retainer on the protruding part of the piston with the seal innermost.
13. Press home the piston and seal.
14. Retighten the bleeder screw.
15. Clamp the piston in the rim half of the calliper and then repeat instructions 7 to 12.
16. Disconnect the hose and then repeat 13 and 14.
17. Reconnect the hose and refit the calliper and the two parts of the dust cover to the hub.




Fig. M.8  
The modified calliper assembly

1. Pad-retaining split pins.
2. Brake pads.
3. Anti-squeak shims.

18. Refit the dust cover locking plate.
19. Reconnect the tie-rod.
20. Tighten the calliper mounting bolts.
21. Fit the pads.
22. Bleed the brakes.
23. Apply the brakes several times to adjust.




Fig. M.7  
The disc brake assembly

- |                |                             |
|----------------|-----------------------------|
| A. Brake disc. | D. Pad retaining spring.    |
| C. Split pins. | E. Calliper mounting bolts. |
| F. Dust cover. |                             |

**Section M.8**

**BLEEDING**

1. Adjust the brakes.
2. Slacken the bleeder screw on the intensifier (COOPER, when fitted) and pump the pedal until fluid comes out free from air.
3. Tighten the bleeder screw and top up the master cylinder.
4. Bleed the wheel cylinders. (Remove the front wheels—early COOPER.)

**Section M.9**

**VACUUM SERVO (Cooper 'S')**

**Removing**

1. Disconnect the heater hose from the grille, release the clip retaining the hose to the slave cylinder and secure the hose out of the way.
2. Disconnect the hydraulic pipes from the slave cylinder, and plug the open ends of the pipes.






Fig. M.9  
The brake cylinder intensifier

- |                        |                               |                          |                       |
|------------------------|-------------------------------|--------------------------|-----------------------|
| 1. Fluid inlet.        | 5. Fluid outlet.              | 8. Piston seal (small).  | 11. Piston.           |
| 2. Valve.              | 6. Intensifier cylinder body. | 9. Valve return spring.  | 12. Copper gasket.    |
| 3. Air relief passage. | 7. Piston return springs.     | 10. Piston seal (large). | 13. Hexagon end plug. |
| 4. Bleed screw.        |                               |                          |                       |

3. Release the rubber vacuum pipe from the slave cylinder.
4. Remove the two retaining nuts and spring washers from the rear mounting bracket, release the servo unit from the front mounting bracket, and lift the unit from the vehicle.
5. Refitting is a reversal of removing. Bleed the brakes as described in Section M.8.

#### Dismantling

6. Remove the five screws and detach the air valve cover, disengaging the pipe from the rubber elbow. Pull the elbow off the pipe in the end cover, and lift out the control valve diaphragm.
7. Remove the four screws and lift off the valve housing and gasket. Expel the valve piston by closing the end connection with the thumb and applying a low air pressure at the smaller connection on the side of the cylinder. Ease the rubber cup off the piston.
8. Remove the bolts from the clamping ring, remove the end cover and diaphragm assembly, and disengage the return spring from the locking plates. Hold the push-rod by its hexagon centre-piece, ease off the rubber buffer and unscrew the nut to dismantle the diaphragm assembly.
9. Bend back the locking tabs, remove the four securing bolts, and detach the vacuum shell from the slave cylinder. Extract the guide piece, push-rod cup, cup

spreader and spring from the cylinder. Depress the piston with a suitable brass rod and extract the circlip. Gradually release the spring pressure on the piston, and remove the remaining components from the slave cylinder bore.

10. Unscrew the non-return valve from the side of the slave cylinder.

#### Cleaning

11. Wash all parts in industrial methylated spirit (not the air valve cover). Blow compressed air at a low pressure past the air valve and into the filter chamber. Dry all components thoroughly.

#### Reassembling

Reassembly is a reversal of the dismantling procedure, noting the following points.

12. Renew all metal parts showing signs of damage or wear.
13. New rubber seals, cups, and diaphragm should be used throughout.
14. Make an assembly sleeve to the following dimensions: length: 1.61 to 1.62 in. (40.89 to 41.15 mm.); outer diameter: .746 to .748 in. (18.95 to 19.00 mm.); inner diameter: .625 to .627 in. (15.87 to 15.92 mm.). Insert this sleeve in the end of the slave cylinder bore to refit the cap and piston.

15. Take extreme care not to damage the surface finish of the push-rod when reassembling the diaphragm. Lock the securing nut by punching the threads in two opposed places.
16. Do not tighten the end cover clamp bolt fully until the air valve cover has been fitted and the pipe in the end cover is lined up with the pipe and rubber elbow on the air valve cover.
17. Check that the diaphragm spring has its smaller end engaged under the locking plate tabs.

Section M.10

TWO-LEADING-SHOE FRONT BRAKES

Each front brake has two squared adjusters projecting from the rear face of the backplate, one adjuster for each brake-shoe.

Adjusting

1. Jack up the car and deal with one adjuster at a time.
2. Turn the adjuster in the same direction as the forward rotation of the front wheel until the drum is locked, then back off the adjuster the minimum amount necessary to allow the drum to rotate freely.
3. Spin the wheel and apply the foot brake firmly to centralize the shoe.
4. Re-check the adjustment, and repeat the complete operation with the other adjuster.
5. Carry out the same sequence on the other front wheel.




Fig. M.11

The hand brake cable sector mounted on the rear radius arms. Only the corners indicated must be 'nipped' to position the cable

Dismantling

6. Jack up the car and remove the front road wheel.
7. Back off both adjusters completely, extract the two retaining screws, and remove the brake-drum.
8. The tips of the brake shoes are retained on the wheel cylinder pistons by spring-loaded hooks, one to each shoe. Withdraw the hooks from their registers in the pistons and turn them to one side.




Fig. M.10  
The calliper components

- |                          |                                     |
|--------------------------|-------------------------------------|
| 1. Friction pads.        | 6. Piston, showing cut-away at top. |
| 2. Pad retaining spring. | 7. Bleeder screw.                   |
| 3. Retaining split pins. | 8. Mounting half calliper.          |
| 4. Piston dust seal.     | 9. Rim half calliper.               |
| 5. Piston fluid seal.    | 10. Anti-squeak shim.               |




Fig. M.12

A rear wheel cylinder bleeder screw. One bleeder screw is provided on each of the four brake back-plates

9. Mark the position of the shoe return springs in the shoes, and note which end of the shoe is fitted to the wheel cylinder.
10. Lift out one shoe from the recesses in the wheel cylinder, and pivot against the pressure of the return spring. Manoeuvre the assembly of the shoes and springs over the front hub.
11. Wire the pistons to the wheel cylinder castings to prevent them from being accidentally pushed out.

#### Reassembling

12. Reassembly is a reversal of the dismantling procedure.
13. Ensure that the shoes are replaced the correct way round and the return springs are fitted in their correct positions.
14. The shoes must register correctly in the grooves in the pistons and pivot points.

#### Wheel cylinder removal

15. Remove the brake-shoes as described under 'Dismantling'.
16. Disconnect the flexible brake hose from the front wheel cylinder. Unscrew the two union nuts and detach the pipe bridging the two wheel cylinders.
17. Remove the two hexagon screws retaining each wheel cylinder to the backplate and detach the wheel cylinders.
18. Note, on replacement, that the position of the wheel cylinder faces in the same direction as the forward rotation of the brake-drum and that the bleed screw is fitted to the rearmost wheel cylinder.




Fig. M.13

The adjusters for the two-leading-shoe front brakes




Fig. M.14

The left-hand front brake assembly, showing the fitted position of the shoes and pull-off springs

#### Section M.11

#### PREVENTIVE MAINTENANCE


To safeguard against the possible effects of wear, or deterioration, it is recommended that:

1. Disc brake pads, drum brake linings, hoses, and pipes should be examined at intervals no greater than those laid down in the Passport to Service.
2. Brake fluid should be changed completely every 18 months or 24,000 miles (40,000 km.) whichever is the sooner.
3. All fluid seals in the hydraulic system and all flexible hoses should be examined and renewed if necessary every 3 years or 40,000 miles (65,000 km.) whichever is the sooner. At the same time the working surface of the pistons and of the bores of the master cylinder, wheel cylinders, and other slave cylinders should be examined and new parts fitted where necessary.

Care must be taken always to observe the following points:

- a. At all times use the recommended brake fluid.
- b. Never leave fluid in unsealed containers. It absorbs moisture quickly and this can be dangerous.
- c. Fluid drained from the system or used for bleeding is best discarded.
- d. The necessity for absolute cleanliness throughout cannot be over-emphasized.

THE VACUUM SERVO COMPONENTS



E0346

No.	Description	No.	Description
1.	Screw for air valve cover.	21.	Nut for diaphragm assembly.
2.	Air valve cover.	22.	Rubber buffer.
3.	Rubber elbow.	23.	End cover.
4.	Control valve diaphragm.	24.	Clamping bolt.
5.	Screw for valve housing.	25.	Nut for clamping bolt.
6.	Valve housing.	26.	Washer for nut.
7.	Housing gasket.	27.	Screw—vacuum shell to slave cylinder.
8.	Valve piston.	28.	Guide piece.
9.	Rubber cup for piston.	29.	Push-rod cup.
10.	Slave cylinder body.	30.	Cup spreader.
11.	Gasket—slave cylinder to vacuum shell.	31.	Spring.
12.	Vacuum shell.	32.	Circlip.
13.	Abutment plate.	33.	Washer.
14.	Locking plates.	34.	Distance piece.
15.	Push-rod.	35.	Piston.
16.	Return spring.	36.	Cup.
17.	Plate (large) for diaphragm.	37.	Spring guide.
18.	Diaphragm.	38.	Spring.
19.	Plate (small) for diaphragm.	39.	Spring retainer.
20.	Clamping ring.		



## **SECTION Mb**

### **THE BRAKING SYSTEM**

**The information contained in this Section refers specifically to new or modified components fitted to the Mini range coincident with the introduction of NEGATIVE earth electrical systems and must be used in conjunction with Section M.**

	<b>SECTION</b>
Bleeding the system (split braking system) .. .. .	Mb.5
Inertia valve (split braking system) .. .. .	Mb.2
Pressure failure switch (split braking system) .. .. .	Mb.4
Servo unit (Lockheed type 6) .. .. .	Mb.1
Tandem master cylinder (split braking system) .. .. .	Mb.3




Fig. Mb.1

A schematic diagram showing the principle of operation and the main components of the vacuum servo unit. The shaded area represents brake fluid

### Section Mb.1

#### SERVO UNIT (Lockheed Type 6)

##### Operation

Refer to Fig. Mb.1. The vacuum-operated servo unit consists of three main components, namely the vacuum cylinder (1), the air valve assembly (2), and the slave cylinder (3) which is connected in the hydraulic circuit between the main master cylinder and the wheel cylinders. Under light braking, fluid is allowed to pass directly to the wheel cylinders via the hollow centre of the slave piston (4) and no braking assistance is obtained; fluid pressure acting on the air valve piston (5) closes the diaphragm (6), thus separating the chamber behind the main servo diaphragm (7) from the one in front. Under heavier braking, further movement of the air valve pistons opens the air valve and allows air to enter the chamber behind the main diaphragm, destroying the vacuum. The central rod (9) is thus pushed to the left, sealing the hollow centre of the slave piston and pushing it down its bore, so increasing the fluid pressure at the wheel cylinders. When the brake pedal is released, the pressure beneath the air valve piston is destroyed, the diaphragm (6) re-opens and the air valve closes. Via the non-return valve (10), a suspended vacuum is recreated around the main diaphragm. Under the action of the spring (11), the diaphragm and push-rod, and thus the slave piston, are returned to their original positions, and the pressure in the wheel cylinders is lost.

Mb.2

##### Removing

1. From beneath the right-hand front wing, pull the heater hose off the intake unit, and then withdraw the intake unit from inside the engine compartment.
2. Disconnect the vacuum pipe from the servo unit.
3. Remove the securing bracket from the end of the servo unit, disconnect the brake pipes and plug the holes.
4. Remove the nuts securing the servo to the bracket and withdraw the unit.

##### Dismantling

##### AIR VALVE ASSEMBLY (FIG. Mb.2)

5. Grip the slave cylinder in a soft-jawed vice with the air valve uppermost and disconnect the rubber pipe from the connection on the end cover.
6. Remove the screws securing the plastic air valve cover to the valve housing, lift off the cover complete with the air valve sub-assembly. Suspect functioning of the air valve must be remedied by fitting a replacement air valve cover assembly comprising cover, filter, and air valve as an assembled part of the relevant repair kit.
7. Remove the rubber diaphragm and its plastic support to obtain access to valve housing securing screws. Remove the three screws and take off the housing and joint washer.
8. Seal one of the slave cylinder fluid ports with a finger, apply a low-pressure air-line to the remaining port and blow the air control valve piston from its bore. Remove the rubber cup from the valve piston.




Fig. Mb.2

The air valve assembly components and piston

- |                                     |                                   |
|-------------------------------------|-----------------------------------|
| 1. Domed cover for filter.          | 7. Valve housing securing screws. |
| 2. Air filter.                      | 8. Valve housing.                 |
| 3. Air valve cover securing screws. | 9. Joint washer.                  |
| 4. Air valve cover.                 | 10. Piston.                       |
| 5. Diaphragm.                       | 11. Piston cup.                   |
| 6. Diaphragm support.               | 12. Slave cylinder.               |

**SERVO CYLINDER ASSEMBLY**

9. Use thumb pressure to prise the non-return valve from the servo shell and extract the rubber valve mounting.
10. Remove the clamping ring securing the end cover to the servo shell and lift off the cover.

**EARLY UNITS.** To remove the end cover from the servo shell fit Service tool C2030\* as shown in Fig. Mb.3. Turn the tool anti-clockwise with a ½ in. (13 mm.) square drive socket 'T' bar as far as the stops on the cover will allow and lift off the end cover.

11. Turn the diaphragm support so that the push-rod retaining key faces downwards. Apply light fluctuating hand pressure on the support into the shell; this will allow the retaining key to drop out, releasing the support from the push-rod under pressure of the main return spring. Extract the spring from the servo shell.
12. Bend back the locking tabs of the servo shell to slave cylinder securing bolts; remove the bolts, together with the locking and abutment plates. Lift off the servo shell and retrieve the joint washer from the mounting face of the slave cylinder.

**SLAVE CYLINDER ASSEMBLY**

13. Pull the servo push-rod and the piston assembly attached to it from the slave cylinder bore. Slide off the plastic bearing, rubber cup and plastic spacer, noting their relative positions for refitting.
14. Prise off the rubber seal from the head of the slave piston. Open the retaining clip with a small screwdriver to expose the connecting pin, which may then be driven out to separate the piston from the rod (see Fig. Mb.4).

**Inspecting**

Examine all parts for faults and wear and be prepared to fit new rubber parts throughout. If the air valve is faulty, a replacement kit must be fitted. Dust deposits on the air




Fig. Mb.3

Using Service tool C2030\* to remove and refit the end cover

\* Obtainable from V. L. Churchill & Co. Ltd.




Fig. Mb.4

The slave piston, with the retaining clip withdrawn to expose the connecting pin

- |                    |                    |
|--------------------|--------------------|
| 1. Piston body.    | 3. Connecting pin. |
| 2. Retaining clip. | 4. Piston seal.    |

filter, which is otherwise in good condition, can be removed by blowing through with a low-pressure air-line. Do not use a cleaning fluid or lubricant of any description on the filter.

Wash all original components of the slave cylinder assembly and remove light deposits from the cylinder bore with clean brake fluid. If the slave cylinder bore is scored, a replacement unit will be required.

**Reassembling**

Scrupulous cleanliness of all parts of the servo unit is essential. Lay out all parts to be assembled on a clean sheet of paper. Use clean brake fluid as a lubricant when reassembling the hydraulic components of the servo unit.


**SLAVE CYLINDER ASSEMBLY**

15. If the piston and push-rod were separated in item 14, a new retaining clip and connecting pin will be required. Insert the chamfered end of the push-rod into the rear of the piston and depress the spring inside it to uncover the hole in the end of the rod. Fit the pin, followed by its retaining clip; see that this is a snug fit, and does not protrude beyond its groove, otherwise the bore will become scored.  
  
Using only the fingers, bed the rubber seal evenly into the groove on the head of the piston, with the lips of the seal pointing away from the push-rod.
16. Insert the piston into the lubricated bore of the slave cylinder, then, one by one, slide the spacer, the rubber cup, and the bearing over the push-rod into the mouth of the bore. Take care not to bend back the lips of either the seal or the cup, and bed in each part individually.



## THE VACUUM SERVO COMPONENTS

(Lockheed Type 6)



INC638

No.	Description	No.	Description	No.	Description
1.	Slave cylinder.	11.	End cover.	21.	Abutment plate.
2.	Slave piston.	12.	Non-return valve.	22.	Joint washer.
3.	Piston seal.	13.	Rubber mounting.	23.	Air valve cover.
4.	Retaining clip.	14.	Main servo diaphragm.	24.	Air filter.
5.	Spacer.	15.	Diaphragm support.	25.	Air valve.
6.	Cup.	16.	Retaining key.	26.	Air valve diaphragm.
7.	Bearing.	17.	Push-rod.	27.	Diaphragm support.
8.	Connecting pin.	18.	Main return spring.	28.	Air valve piston.
9.	Servo shell.	19.	Servo shell retaining bolts.	29.	Rubber pipe.
10.	Retaining clip.	20.	Locking plate.		

Shown inset.

SERVO CYLINDER ASSEMBLY

17. Grip the slave cylinder in a soft-jawed vice, position the mounting face joint washer and refit the servo shell. After correctly positioning the abutment plate and locking plate, which must be renewed if it has been used more than once previously, tighten the three bolts evenly to the torque figure given in 'GENERAL DATA' and tap up the locking plate tabs.
18. Pull out the push-rod to its limit, fit the main return spring followed by the diaphragm support, with its key slot facing upwards. Make sure that the two end coils are located round the abutment plate and support boss respectively. Press the support into the shell until the groove in the end of the push-rod aligns with the key slot, and insert the key.

Ensure that both the rubber diaphragm and its support are perfectly dry and then fit the diaphragm to the support. Gently stretch the diaphragm to seat its inner edge in the groove of the support.

19. Smear the outer edge of the rubber diaphragm with Lockheed Disc Brake Lubricant where it will contact the rim of the end cover and of the shell, and position the diaphragm evenly around the rim of the shell.
20. Position the end cover with the shell so that the elbow is in alignment with the air valve and secure the two parts with the clamping ring.

EARLY UNITS. Using Service tool C 2030\* secured to the end cover, turn it clockwise as far as the stops will allow whilst maintaining downward pressure on the end cover. Take care not to trap the edge of the rubber diaphragm; remove the Service tool.

21. Push in the non-return valve with its rubber mounting.

AIR VALVE ASSEMBLY (FIG. Mb.2)

22. Using only the fingers, fit the rubber cup to the spigot of the air valve piston, with the lips pointing away from the drilled head, and insert the piston into its bore, spigot end first. Do not bend over the lips of the cup.
23. Fit the valve housing, with its joint washer, to the mounting face of the slave cylinder and tighten the three securing screws to the torque figure given in 'GENERAL DATA'.
24. Insert the spigot of the diaphragm support into the drilled head of the air valve piston, and then fit the inner edge of the air valve diaphragm into the groove of its support and align the screw hole slots. Do not use any lubricant.
25. Refit or replace the filter and snap-fit the dome cover if these have been removed in item 6. Place the valve cover over the diaphragm making sure that the projections on the under surface of the cover engage in the slots of the diaphragm. Tighten the five securing screws firmly, progressively and diametrically; do not overtighten, since the smallest air leakage into the air valve assembly will impair the action of the servo.
26. Refit the rubber pipe to join the end cover elbow to the valve cover port.

Refitting

27. Reverse the removing procedure, items 1 to 4.

\* Obtainable from V. L. Churchill & Co. Ltd.

28. Bleed the braking system (Section Mb.5), using a recommended brake fluid, see 'GENERAL DATA'.

Fluid drained from the system or that used for bleeding should be discarded.

Section Mb.2

INERTIA VALVE  
(Split braking system)

An inertia valve is fitted in the fluid line to the rear brakes; it replaces the pressure regulating valve described in Section M.5 and is similarly located on the rear sub-frame cross-member.

The angle at which the assembly is mounted allows the steel ball inside the body to hold the valve in the open position, so that fluid may pass to the rear brakes. When braking heavily, the weight transfer to the front of the vehicle causes the ball to move away from the valve, which is then closed by a light spring. Thus further pressure is prevented from reaching the rear brakes, and all additional pressure is transferred to the front brakes.

Removing

1. Remove, and then plug the ends of, the hydraulic brake pipes.




Fig. Mb.5  
The inertia valve assembly components

- |                        |                |
|------------------------|----------------|
| 1. Valve sub-assembly. | 3. Steel ball. |
| 2. Copper washer.      | 4. Valve body. |

- Remove the two fixing bolts and lift the inertia valve assembly from its location on the rear sub-frame cross-member.

#### Dismantling and examining

- Remove the end plug and washer from the inertia valve body, and extract the steel ball.
- Clean the body and steel ball with clean brake fluid or industrial methylated spirit and dry thoroughly.
- Carefully examine all the components, which must be in perfect condition if they are to be re-used.

#### Reassembling

- Insert the steel ball into the body.
- Screw in a new valve and end-plug sub-assembly, fitting a new copper washer. See that the seating faces of both the body assembly and end plug are clean and undamaged, and tighten to the torque figure given in 'GENERAL DATA'.

#### Refitting

- Reverse the removing procedure noting the marking 'FRONT' on the inertia valve body.
- Refill the master cylinder reservoir with the recommended brake fluid, see 'GENERAL DATA'.
- Bleed the braking system as in Section Mb.5. Then inspect the inertia valve for fluid leaks with the foot brake pedal fully depressed and also with the system at rest.

**NOTE.**—Brake fluid can have a detrimental effect on paintwork; ensure that fluid is not allowed to contact paint-finished surfaces.

### Section Mb.3

#### TANDEM MASTER CYLINDER (Split braking system)

#### Removing

- Disconnect the hydraulic pipes from the master cylinder, and plug the pipe ends to prevent loss of fluid and the entry of dirt.
- Unscrew the two nuts securing the master cylinder to the bulkhead, and lift it off, leaving the push-rod attached to the brake pedal.

#### Dismantling

- Drain the fluid from the reservoir and refit the cap.
- Plug the pipe connections, thoroughly clean the exterior of the assembly and remove the rubber boot.
- Grip the cylinder body in a soft-jawed vice with the mouth of the bore uppermost.

Refer to Fig. Mb.6.

- Compress the return spring and remove the Spirolox ring from its groove in the primary piston, taking care not to distort the coils of the ring or score the bore of the cylinder.
- Using Service tool 18G 1112, remove the piston retaining circlip. A slight radiusing of the sides of the tool may be necessary for ease of use on this master cylinder.
- Move the piston up and down in the bore to free the nylon guide bearing and cap seal; remove the guide bearing and seal.
- Using Service tool 18G 1112, remove the inner circlip.
- Withdraw the primary and secondary piston assembly complete with stop washer.
- Remove the stop washer.
- Compress the spring separating the two pistons and drive out the roll-pin retaining the piston link.
- Note the positions of the rubber cups by their moulded indentations and remove the cups and washers from the pistons.
- Unscrew the four bolts securing the plastic reservoir to the body and remove the reservoir.
- Remove the two reservoir sealing rings.
- Unscrew the connection adaptors, discard the copper gaskets, and remove the spring and trap valves.

#### Inspecting

- Clean all parts thoroughly in brake fluid and dry them with lint-free cloth.
- Examine all metal components for wear and damage and renew all worn, damaged, or suspect parts.

#### Reassembling

- Reverse the dismantling procedure, with special attention to the following points.
- Use a complete set of new rubber seals when reassembling.
- Immerse all internal components in a recommended brake fluid as in item 26, and assemble them while wet.
- Locate the piston washer 5 over the head of the secondary piston, convex surface first; carefully ease the secondary cup over the piston and seat it with its flat surface against the washer, see Fig. Mb.6.
- The remainder is a reversal of the dismantling procedure 5 to 17. Fit new copper gaskets to the connection adaptors and tighten the connections to the torque figure given in 'GENERAL DATA'.

#### Refitting

- Refit the unit, taking care to guide the push-rod into the opening in the rubber boot; re-connect and tighten pipe connections.




Fig. Mb.6  
An exploded view of the tandem master cylinder components

- 1. Push-rod.
- 2. Rubber boot.
- 3. Spirolox ring.
- 4. Spring retainer.
- 5. Spring.
- 6. Circlip.
- 7. Nylon guide bearing.
- 8. Secondary cup.
- 9. Washer.
- 10. Circlip.
- 11. Stop washer.
- 12. Primary piston.
- 13. Roll pin.
- 14. Piston washer.
- 15. Main cup.
- 16. Pin retainer.
- 17. Spring.
- 18. Secondary piston.
- 19. Reservoir seals.
- 20. Fluid reservoir.

INC637

- 26. Refill the cylinder reservoir with the recommended brake fluid, see 'GENERAL DATA'.
- 27. Bleed the braking system, see Section Mb.5.

**NOTE.**—Brake fluid can have a detrimental effect on paintwork; ensure that fluid is not allowed to contact paint-finished surfaces.

**Section Mb.4.**

**PRESSURE FAILURE SWITCH ASSEMBLY**  
(Split braking system)

This switch replaces the three-way brake pipe connector located on the right-hand side of the engine bulkhead cross-member.

**Removing**

- 1. Pull the electrical connector off the nylon switch.
- 2. Clean the switch assembly and its surroundings, particularly the pipe connections.
- 3. Disconnect and plug the hydraulic pipes.
- 4. Unscrew the retaining bolt and remove the assembly.


**Dismantling**

- 5. Refer to Fig. Mb.7. Remove the end plug and discard the copper washer.
- 6. Unscrew the nylon switch.
- 7. Withdraw the shuttle valve piston assembly from the bore; use a low-pressure air line to free the piston if necessary.
- 8. Remove and discard the two piston seals.

Fig. Mb.7

The pressure failure switch components; inset shows an exploded view of the shuttle valve piston

- |                  |                          |
|------------------|--------------------------|
| 1. Switch body.  | 4. Copper washer.        |
| 2. Nylon switch. | 5. Shuttle valve piston. |
| 3. End plug.     | 6. Piston seals.         |



### Inspection

9. Thoroughly clean all the components using methylated spirit (denatured alcohol) or the recommended brake fluid, and dry with a lint-free cloth.
10. Inspect the bore of the casing for scoring and damage. The complete assembly must be renewed if the bore is not in perfect condition.
11. Reconnect the wiring to the switch and actuate the switch plunger to test the switch operation and warning light circuit.

### Reassembling

12. Refer to Fig. Mb.7. Fit two new seals to the piston.
13. Lubricate the piston assembly with Lockheed Disc Brake Lubricant and fit the piston into the bore.
14. Fit a new copper washer to the end plug, screw in and tighten the plug to the torque figure given in 'GENERAL DATA'.
15. Screw in the switch and carefully tighten it to the torque figure given in 'GENERAL DATA'.

### Refitting

16. Reverse the removing procedure in 1 to 4.
17. Refill the cylinder reservoir with the recommended brake fluid, see 'GENERAL DATA'.
18. Bleed the braking system, see Section Mb.5.

### Section Mb.5.

#### BLEEDING THE SYSTEM (Split braking system)

1. Top up the hydraulic fluid reservoir to the correct level with the recommended brake fluid, see 'GENERAL DATA'. Do not allow the fluid level to drop more than ½ in. (1.25 cm.) throughout the following operations.
2. Attach bleed tubes to the front and rear bleed screws on the driver's side of the car.
3. Submerge the open end of each tube in a small quantity of clean brake fluid in a transparent container.
4. Open both bleed screws half a turn.
5. Fully depress the brake pedal and hold it down.
6. Close both bleed screws and then allow the pedal to return.
7. Repeat operations 4, 5 and 6 until clean fluid, free from air, issues from both tubes. Having achieved this condition, repeat operations 4, 5 and 6 four more times.
8. Keep the brake pedal depressed and tighten both bleed screws to the correct torque.
9. Attach bleed tubes to the front and rear bleed screws on the opposite side of the car.
10. Carry out operations 3 to 8.

**NOTE.** Fluid from the system must be discarded.

# SECTION N


## THE ELECTRICAL SYSTEM

	SECTION
Alternator (11AC)	
Control unit (4TR) .. .. .	N.13
Dismantling and overhauling .. .. .	N.12
Relay .. .. .	N.14
Service precautions .. .. .	N.10
Testing the charging circuit in position .. .. .	N.11
Warning light control .. .. .	N.15
Battery .. .. .	N.1
Bi-metal resistance instrumentation .. .. .	N.7
Cut-out .. .. .	N.5
Dynamo .. .. .	N.2
Lamps .. .. .	N.6
Starter .. .. .	N.3
Voltage regulator .. .. .	N.4
Windscreen wiper motor (Moke) .. .. .	N.8
Windscreen wiper wheelboxes .. .. .	N.9
Wiring diagrams .. .. .	Beginning of Section

N

### WIRING DIAGRAM

Super, Super De-luxe, Countryman, Traveller and Cooper (up to 1964)



A8181BW

## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	L.H. flasher lamp.	23.	Wiper motor.
2.	L.H. headlamp and pilot lamp.	24.	Heater motor.
3.	R.H. headlamp and pilot lamp.	25.	Heater switch.
4.	R.H. flasher lamp.	26.	Wiper switch.
5.	Distributor.	27.	Ignition and starter switch.
6.	Ignition coil.	28.	Lighting switch.
7.	Voltage regulator and cut-out.	29.	Starter motor.
8.	Horn.	30.	Interior lamp.
9.	Thermo element.	31.	Horn-push.
10.	Dynamo.	32.	Starter solenoid.
11.	Thermo gauge illumination light.	33.	Tank unit.
12.	Panel illumination lights.	34.	Direction indicator switch.
13.	Stop lamp switch.	35.	Direction indicator warning light.
14.	Thermo gauge.	36.	Dipper switch.
15.	Main-beam warning light.	37.	12-volt battery.
16.	Fuel gauge.	38.	Fuel pump.
17.	Ignition warning light.	39.	L.H. stop, tail, and flasher lamp.
18.	Oil gauge illumination light.	40.	Number-plate illumination lamp.
19.	Oil gauge.	41.	R.H. stop, tail, and flasher lamp.
20.	Flasher unit.	42.	Earth connection.
21.	35-amp. fuses.	43.	Connect to terminal 6 for North America.
22.	Panel lights switch.		

**NOTE.—On Export models the pilot lamps  
are combined with the flasher lamps.**

### CABLE COLOUR CODE


B. Black.	P. Purple.	Y. Yellow.
U. Blue.	R. Red.	L. Light.
N. Brown.	S. Slate.	M. Medium.
G. Green.	W. White.	D. Dark.

When a cable has two colour code letters the first denotes  
the main colour and the second denotes the tracer colour.



# WIRING DIAGRAM

Standard and De-luxe (up to 1964)



A8307W

## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	L.H. flasher lamp.	22.	Wiper motor.
2.	L.H. headlamp and pilot lamp.	23.	Heater motor.
3.	R.H. headlamp and pilot lamp.	24.	Heater switch.
4.	R.H. flasher lamp.	25.	Wiper switch.
5.	Distributor.	26.	Ignition switch.
6.	Ignition coil.	27.	Lighting switch.
7.	Horn.	28.	Starter motor.
8.	Dynamo.	29.	Tank unit.
9.	Voltage regulator and cut-out.	30.	Horn-push.
10.	Oil pressure switch.	31.	Starter switch.
11.	Main-beam warning light.	32.	Fuel pump.
12.	Panel illumination light.	33.	Companion box switch and lamp.
13.	Stop light switch.	34.	Direction indicator switch and warning light.
14.	Parcel shelf illumination lamp.	35.	Dipper switch.
15.	Oil pressure warning light.	36.	12-volt battery.
16.	Ignition warning light.	37.	L.H. stop, tail, and flasher lamp.
17.	Flasher unit.	38.	Number-plate illumination lamp.
18.	Panel illumination switch.	39.	R.H. stop, tail, and flasher lamp.
19.	Fuel gauge.	40.	Connect to No. 6 terminal for U.S.A.
20.	Parcel shelf illumination switch.	41.	Earth connection.
21.	35-amp. fuse.		


### CABLE COLOUR CODE

B. Black.	P. Purple.	L. Light.
U. Blue.	R. Red.	D. Dark.
N. Brown.	W. White.	M. Medium.
G. Green.	Y. Yellow.	

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour

# WIRING DIAGRAM

Saloon, Van, and Pick-up (1964 to 1967)



B.5473A

## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	Dynamo.	29.	L.H. front flasher lamp.
2.	Control box.	30.	R.H. rear flasher lamp.
3.	12-volt battery.	31.	L.H. rear flasher lamp.
4.	Starter solenoid.	32.	Heater switch
5.	Starter motor.	33.	Heater motor
6.	Lighting switch.		} when fitted.
7.	Headlamp dip switch.	34.	Fuel gauge.
8.	R.H. headlamp.	35.	Fuel gauge tank unit.
9.	L.H. headlamp.	36.	Windscreen wiper switch.
10.	Main-beam warning lamp.	37.	Windscreen wiper motor.
11.	R.H. sidelamp (in headlamp or flasher) lamp.	38.	Ignition/starter switch.
12.	L.H. sidelamp (in headlamp or flasher) lamp.	39.	Ignition coil.
13.	Panel lamps switch	40.	Distributor.
14.	Panel lamps.	41.	Fuel pump.
15.	Number-plate lamp (two for Van).	42.	Oil pressure switch.
16.	R.H. stop and tail lamp.	43.	Oil pressure warning lamp.
17.	L.H. stop and tail lamp.	44.	Ignition warning lamp.
18.	Stop lamp switch.	45.	Speedometer.
19.	Fuse unit: 1-2, 35 amp.; 3-4, 35 amp.	64.	Bi-metal instrument voltage stabilizer.
20.	Interior light.	83.	Induction heater and thermostat (when fitted).
21.	R.H. door switch.	84.	Suction chamber heater (when fitted).
22.	L.H. door switch.	94.	Oil filter switch.
23.	Horn.	105.	Oil filter warning lamp.
24.	Horn-push.	115.	Rear window demister switch (when fitted).
25.	Flasher unit.	116.	Rear window demister unit (when fitted).
26.	Direction indicator switch.	131.	Combined reverse switch/automatic gearbox switch (when fitted).
27.	Direction indicator warning lamp.	139.	Connect to No. 6 for U.S.A. (alternative connection).
28.	R.H. front flasher lamp.	150.	Rear window demister warning light (when fitted).


### CABLE COLOUR CODE

B. Black.    G. Green.    W. White.  
 U. Blue.    P. Purple.    Y. Yellow.  
 N. Brown.    R. Red.    L.G Light Green.

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.

# WIRING DIAGRAM

Cooper, Cooper 'S', Countryman, Traveller, and Super De-luxe (1964 to 1967)



## KEY TO WIRING DIAGRAM


No.	Description	No.	Description
1.	Dynamo.	30.	R.H. rear flasher lamp.
2.	Control box.	31.	L.H. rear flasher lamp.
3.	12-volt battery.	32.	Heater switch
4.	Starter solenoid.	33.	Heater motor
5.	Starter motor.		} when fitted.
6.	Lighting switch.	34.	Fuel gauge.
7.	Headlamp dip switch.	35.	Fuel gauge tank unit.
8.	R.H. headlamp.	36.	Windscreen wiper switch.
9.	L.H. headlamp.	37.	Windscreen wiper motor.
10.	Main-beam warning lamp.	38.	Ignition/starter switch.
11.	R.H. sidelamp (in headlamp or flasher) lamp.	39.	Ignition coil.
12.	L.H. sidelamp (in headlamp or flasher) lamp.	40.	Distributor.
13.	Panel lamps switch.	41.	Fuel pump.
14.	Panel lamps.	42.	Oil pressure switch.
15.	Number-plate lamp (two for Countryman and Traveller).	43.	Oil pressure warning lamp.
16.	R.H. stop and tail lamp.	44.	Ignition warning lamp.
17.	L.H. stop and tail lamp.	45.	Speedometer.
18.	Stop lamp switch.	46.	Temperature gauge.
19.	Fuse unit: 1-2, 35 amp.; 3-4, 35 amp.	47.	Temperature gauge transmitter.
20.	Interior light.	64.	Bi-metal instrument voltage stabilizer.
21.	R.H. door switch.	83.	Induction heater and thermostat (when fitted).
22.	L.H. door switch.	84.	Suction chamber heater (when fitted).
23.	Horn.	94.	Oil filter switch.
24.	Horn-push.	105.	Oil filter warning lamp.
25.	Flasher unit.	115.	Rear window demister switch (when fitted).
26.	Direction indicator switch.	116.	Rear window demister unit (when fitted).
27.	Direction indicator warning lamp.	131.	Combined reverse switch/automatic gearbox switch (when fitted).
28.	R.H. front flasher lamp.	139.	Connect to No. 6 for U.S.A. (alternative connection).
29.	L.H. front flasher lamp.	150.	Rear window demister warning light (when fitted).

### CABLE COLOUR CODE

B. Black.	G. Green.	W. White.
U. Blue.	P. Purple.	Y. Yellow.
N. Brown.	R. Red.	L.G. Light Green.

# WIRING DIAGRAM

## Mini-Moke (up to 1967)



## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	Dynamo.	27.	Direction indicator warning lamp.
2.	Control box.	28.	R.H. front flasher lamp.
3.	12-volt battery.	29.	L.H. front flasher lamp.
4.	Starter solenoid.	30.	R.H. rear flasher lamp.
5.	Starter motor.	31.	L.H. rear flasher lamp.
6.	Lighting switch.	34.	Fuel gauge.
7.	Headlamp dip switch.	35.	Fuel gauge tank unit.
8.	R.H. headlamp.	36.	Windscreen wiper switch.
9.	L.H. headlamp.	37.	Windscreen wiper motor.
10.	Main-beam warning lamp.	38.	Ignition starter switch.
11.	R.H. sidelamp.	39.	Ignition coil.
12.	L.H. sidelamp.	40.	Distributor.
14.	Panel lamps.	41.	Fuel pump.
15.	Number-plate illumination lamp.	42.	Oil pressure switch.
16.	R.H. stop and tail lamp.	43.	Oil pressure warning lamp.
17.	L.H. stop and tail lamp.	44.	Ignition warning lamp.
18.	Stop lamp switch.	45.	Speedometer.
19.	Two-way fuse unit: 1-2, 35 amp.; 3-4, 35 amp.	64.	Bi-metal instrument voltage stabilizer.
23.	Horn.	83.	Induction heater and thermostat.
24.	Horn-push.	84.	Suction chamber heater.
25.	Flasher unit.	94.	Oil filter switch.
26.	Direction indicator switch.	105.	Oil filter warning lamp.

### CABLE COLOUR CODE

B. Black.	G. Green.	W. White.
U. Blue.	P. Purple.	Y. Yellow.
N. Brown.	R. Red.	L.G. Light Green.

When a cable has two colour code letters the first denotes  
the main colour and the second denotes the tracer colour.





## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	Dynamo.	30.	R.H. rear flasher lamp.
2.	Control box.	31.	L.H. rear flasher lamp.
3.	12-volt battery.	32.	Heater switch
4.	Starter solenoid.	33.	Heater motor
5.	Starter motor.		} when fitted.
6.	Lighting switch.	34.	Fuel gauge.
7.	Headlamp dip switch.	35.	Fuel gauge tank unit.
8.	R.H. headlamp.	36.	Windscreen wiper switch.
9.	L.H. headlamp.	37.	Windscreen wiper motor.
10.	Main-beam warning lamp.	38.	Ignition/starter switch.
11.	R.H. sidelamp (in headlamp or flasher) lamp.	39.	Ignition coil.
12.	L.H. sidelamp (in headlamp or flasher) lamp.	40.	Distributor.
14.	Panel lamps.	41.	Fuel pump.
15.	Number-plate lamp (two for Countryman and Traveller).	42.	Oil pressure switch.
16.	R.H. stop and tail lamp.	43.	Oil pressure warning lamp.
17.	L.H. stop and tail lamp.	44.	Ignition warning lamp.
18.	Stop lamp switch.	45.	Speedometer.
19.	Fuse unit; 1-2, 35 amp.; 3-4, 35 amp.	46.	Temperature gauge.
20.	Interior light.	47.	Temperature gauge transmitter.
21.	R.H. door switch.	64.	Bi-metal instrument voltage stabilizer.
22.	L.H. door switch.	67.	Line fuse, 35 amp.
23.	Horn.	75.	Automatic gearbox safety switch (when fitted).
24.	Horn-push.	83.	Induction heater and thermostat (when fitted).
25.	Flasher unit.	84.	Suction chamber heater (when fitted).
26.	Direction indicator and headlamp flasher switch.	94.	Oil filter switch.
27.	Direction indicator warning lamp.	105.	Oil filter warning lamp.
28.	R.H. front flasher lamp.		} Not fitted on Automatic.
29.	L.H. front flasher lamp.	115.	Rear window demister switch (when fitted).
		116.	Rear window demister unit (when fitted).
		150.	Rear window demister warning light (when fitted).


### CABLE COLOUR CODE

B. Black.	G. Green.	W. White.
U. Blue.	P. Purple.	Y. Yellow.
N. Brown.	R. Red.	L.G. Light Green.

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.

# WIRING DIAGRAM

## Standard Saloon, Van, and Pick-up Mark II



### KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	Dynamo.	29.	L.H. front flasher lamp.
2.	Control box.	30.	R.H. rear flasher lamp.
3.	12-volt battery.	31.	L.H. rear flasher lamp.
4.	Starter solenoid.	32.	Heater switch. } when
5.	Starter motor.	33.	Heater motor. } fitted.
6.	Lighting switch.	34.	Fuel gauge.
7.	Headlamp dip switch.	35.	Fuel gauge tank unit.
8.	R.H. headlamp.	36.	Windscreen wiper switch.
9.	L.H. headlamp.	37.	Windscreen wiper motor.
10.	Main-beam warning lamp.	38.	Ignition/starter switch.
11.	R.H. sidelamp (in headlamp or flasher) lamp.	39.	Ignition coil.
12.	L.H. sidelamp (in headlamp or flasher) lamp.	40.	Distributor.
14.	Panel lamps.	41.	Fuel pump.
15.	Number-plate lamp (two for Van).	42.	Oil pressure switch.
16.	R.H. stop and tail lamp.	43.	Oil pressure warning lamp.
17.	L.H. stop and tail lamp.	44.	Ignition warning lamp.
18.	Stop lamp switch.	45.	Speedometer.
19.	Fuse unit: 1-2, 35 amp.; 3-4, 35 amp.	64.	Bi-metal instrument voltage stabilizer.
20.	Interior light.	76.	Line fuse, 35-amp.
21.	R.H. door switch.	75.	Automatic gearbox safety switch (when fitted).
22.	L.H. door switch.	83.	Induction heater and thermostat (when fitted).
23.	Horn.	84.	Suction chamber heater (when fitted).
24.	Horn-push.	94.	Oil filter switch. } Not fitted on
25.	Flasher unit.	105.	Oil filter warning lamp. } Automatic.
26.	Direction indicator and headlamp flasher switch.	115.	Rear window demister switch (when fitted).
27.	Direction indicator warning lamp.	116.	Rear window demister unit (when fitted).
28.	R.H. front flasher lamp.	150.	Rear window demister warning light (when fitted).


#### CABLE COLOUR CODE

B. Black.	G. Green.	W. White.
U. Blue.	P. Purple.	Y. Yellow.
N. Brown.	R. Red.	L.G. Light Green

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.

# WIRING DIAGRAM

## Mini-Moke Mark II



## KEY TO WIRING DIAGRAM

No.	Description	No.	Description
1.	Dynamo.	27.	Direction indicator warning lamp.
2.	Control box.	28.	R.H. front flasher lamp.
3.	12-volt battery.	29.	L.H. front flasher lamp.
4.	Starter solenoid.	30.	R.H. rear flasher lamp.
5.	Starter motor.	31.	L.H. rear flasher lamp.
6.	Lighting switch.	34.	Fuel gauge.
7.	Headlamp dip switch.	35.	Fuel gauge tank unit.
8.	R.H. headlamp.	36.	Windscreen wiper switch.
9.	L.H. headlamp.	37.	Windscreen wiper motor.
10.	Main-beam warning lamp.	38.	Ignition starter switch.
11.	R.H. sidelamp.	39.	Ignition coil.
12.	L.H. sidelamp.	40.	Distributor.
14.	Panel lamps.	41.	Fuel pump.
15.	Number-plate illumination lamp.	42.	Oil pressure switch.
16.	R.H. stop and tail lamp.	43.	Oil pressure warning lamp.
17.	L.H. stop and tail lamp.	44.	Ignition warning lamp.
18.	Stop lamp switch.	45.	Speedometer.
19.	Two-way fuse unit; 1-2, 35 amp.; 3-4, 35 amp.	64.	Bi-metal instrument voltage stabilizer.
23.	Horn.	83.	Induction heater and thermostat.
24.	Horn-push.	84.	Suction chamber heater.
25.	Flasher unit.	94.	Oil filter switch.
26.	Direction indicator switch.	105.	Oil filter warning lamp.

### CABLE COLOUR CODE

B. Black.	G. Green.	W. White.
U. Blue.	P. Purple.	Y. Yellow.
N. Brown.	R. Red.	L.G. Light Green.

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.

### Section N.1

#### BATTERY

##### Maintenance

1. Keep the battery clean and the vent holes in the caps free.
2. Clean corroded terminals with diluted ammonia and smear them with petroleum jelly.
3. Maintain the level of the electrolyte just above the tops of the separators.

**NOTE.—Disconnect the battery earth cable before boost-charging the battery or using arc welding equipment on the body. Considerable damage to the electrical components will result if the ignition is switched on while the battery remains connected to the car electrical system.**

##### Checking

4. The state of charge of the battery is indicated by hydrometer reading as follows:

**FOR CLIMATES BELOW 27 °C. (80 °F.)**

Cell fully charged .. .. .	1.270 to 1.290
Cell about half-charged .. .. .	1.190 to 1.210
Cell completely discharged .. .. .	1.110 to 1.130

**FOR CLIMATES ABOVE 27 °C. (80 °F.)**

Cell fully charged .. .. .	1.210 to 1.230
Cell about half-charged .. .. .	1.130 to 1.150
Cell completely discharged .. .. .	1.050 to 1.070

These figures are given assuming an electrolyte temperature of 16 °C. (60 °F.). If the temperature of the electrolyte exceeds this .002 must be added to hydrometer readings for each 3 °C. (5 °F.) rise to give the true specific gravity. Similarly, .002 must be subtracted from hydrometer readings for every 3 °C. (5 °F.) below 16 °C. (60 °F.).

##### Charging (used battery)

5. Charge at 3.0 amps. until all cells are gassing freely and hydrometer readings of each cell have not risen in four hours. Do not allow the temperature of the electrolyte to exceed the following maximum:  
 For climates below 27 °C. (80 °F.) 30 °C. (100 °F.)  
 For climates above 27 °C. (80 °F.) 49 °C. (120 °F.)

##### Dry-charged batteries

Dry-charged batteries are supplied without electrolyte but with the plates in a charged condition. No initial charging is required.

6. Fill with electrolyte obtained as follows:

For climates	To obtain specific gravity (corrected to 16 °C. (60 °F.)) of	Add 1 vol. of acid of 1.840 S.G (corrected to 16 °C. (60 °F.)) to
Below 27 °C. (80 °F.)	1.260	3.2 volumes of water
Above 27 °C. (80 °F.)	1.210	4.3 volumes of water

Batteries filled in this way are capable of giving a starting discharge one hour after filling. When time permits, however, a short freshening charge at the normal recharge rate (3.0 amps.) will ensure that the battery is fully charged.

During the charge the electrolyte must be kept level with the top edge of the separators by addition of distilled water. Check the specific gravity of the acid at the end of the charge; if 1.260 acid was used to fill the battery, the specific gravity should now be between 1.270 and 1.290. If 1.210 acid was used the specific gravity should now be between 1.210 and 1.230. After filling, a dry-charged battery needs only the attention normally given to a lead-acid battery.

##### New, unfilled, uncharged battery

7. Half fill each cell with electrolyte prepared as in item 6 above and allow it to stand for six hours, fill each cell to the correct level and allow a further standing period of two hours.
8. Charge at 2 amps. until five successive hourly hydrometer checks show no increase in the reading; this will take from 48 to 80 hours, depending on the length of time the battery has been stored before charging. **This charge should not be broken by long rest periods.**
9. If the temperature of any cell rises above the maximum given in 5, the charge must be interrupted until the temperature has fallen at least 5.5 °C. (10 °F.) below that figure.
10. Maintain the level of the electrolyte during the charge.
11. At the end of the charge carefully check the specific gravity in each cell to ensure that, when corrected to 16 °C. (60 °F.) it lies between the specified limits. If any cell requires adjustment some of the electrolyte must be siphoned off and replaced either by distilled water or by acid of strength originally used for filling in, depending on whether the specific gravity is too high or too low. Continue the charge for an hour or so to ensure adequate mixing of the electrolyte and again check the specific gravity readings. If necessary, repeat the adjustment process until the desired reading is obtained in each cell.
12. Finally, allow the battery to cool, and siphon off any surplus electrolyte.

### Section N.2

#### DYNAMO

##### Removing

1. Disconnect the leads, slacken the four mounting bolts, remove the fan belt from the pulley, take out the two upper and one lower mounting bolts and lift off the dynamo.




Fig. N.1  
The C40/1 type dynamo

- |                            |                                |                                |
|----------------------------|--------------------------------|--------------------------------|
| 1. Commutator end bracket. | 9. Shaft collar retaining cup. | 17. Through-bolts.             |
| 2. Felt ring.              | 10. Felt ring.                 | 18. Pole-shoe securing screws. |
| 3. Felt ring retainer.     | 11. Shaft key.                 | 19. Armature.                  |
| 4. Bronze bush.            | 12. Shaft nut.                 | 20. Bearing retaining plate.   |
| 5. Thrust washer.          | 13. Output terminal 'D'.       | 21. Ball bearing.              |
| 6. Field coils.            | 14. Brushes.                   | 22. Corrugated washer.         |
| 7. Yoke.                   | 15. Field Terminal 'F'.        | 23. Driving end bracket.       |
| 8. Shaft collar.           | 16. Commutator.                | 24. Pulley spacer.             |

**Dismantling**

2. Unscrew the nut and take off the pulley.
3. Extract the key from the shaft.
4. Withdraw the two through-bolts and remove the commutator end bracket.
5. Lift the driving end bracket with the armature and bearing out of the yoke.
6. To remove the bearing, press off the end bracket.

12. Withdraw the pole-shoe securing screws (Fig. N.1), draw the shoes and coils from the yoke and remove the coils from the shoes.
13. Fit new coils to the shoes and refit them to the yoke with the shoes in their original positions. Refit the insulating piece at the junction of the coil windings, insert the screws, press the shoes in place with an expander, and tighten the screws (Fig. N.1).

**Servicing**

**BRUSHES**

7. Clean the brushes with petrol (fuel) and, if sticking, polish them lightly with a smooth file.
8. Test the spring tension ('GENERAL DATA').
9. Fit new brushes if the existing ones are worn to a length of less than ¼ in. (6.5 mm.).

**ARMATURE**

14. If special equipment is not available, test the armature by substitution.

**BEARINGS**

15. Screw a ⅝ in. (15.8 mm.) tap into the bush at the commutator end, pull out the bush and fit a new one, using a shouldered mandrel.

**NOTE.**—Soak the new bush in thin engine oil for 24 hours before fitting.

16. Renew the bearing at the driving end as follows:
17. Knock out the rivets and remove the bearing retaining plate.
18. Press the bearing out of the bracket and remove the corrugated and felt washers.
19. Pack the new bearing with grease before pressing it in.

**COMMUTATOR**

10. Clean with petrol (fuel) and cloth or polish with fine glass-paper. If it is in very poor condition it may be skimmed to a minimum diameter of 1.450 in. (.37 mm.). The undercut must have the following dimensions:  
 Width .. .. .040 in. (1.02 mm.).  
 Depth .. .. .020 to .035 in. (.51 to .89 mm.).

Clean the insulating material from the sides of the undercut to a minimum depth of .015 in. (.38 mm.).

**Reassembling and refitting**

20. Reverse the removing and dismantling instructions.
21. The two upper fixing bolts must be fitted with a flat washer under the head of each bolt to register against the dynamo attachment points.

**FIELD COIL REPLACEMENT**

11. Mark the position of the pole-shoes relative to the yoke.






Fig. N.2  
An exploded view of the starter motor and drive

- |                               |                          |                         |
|-------------------------------|--------------------------|-------------------------|
| 1. Terminal nuts and washers. | 7. Bearing.              | 13. Restraining spring. |
| 2. Brush spring.              | 8. Brushes.              | 14. Sleeve.             |
| 3. Through-bolt.              | 9. Yoke.                 | 15. Impact washer.      |
| 4. Band cover.                | 10. Armature shaft.      | 16. Main spring.        |
| 5. Terminal post.             | 11. Driving-end bracket. | 17. Locating washer.    |
| 6. Bearing bush.              | 12. Pinion assembly.     | 18. Circlip.            |

### Section N.3

#### STARTER

##### Removing

1. Disconnect the cable, unscrew the three bolts and lift away.

##### Dismantling

2. Remove the cover band, withdraw the brushes, unscrew the through-bolts and take out the armature complete with drive.

##### Servicing

##### BRUSHES

See Section N.2, items 7 to 9.

##### DRIVE

3. If the pinion is tight on the sleeve, wash it in kerosene.
4. To dismantle, remove the shaft nut and withdraw the main spring and collar. On later types, compress the spring and remove the circlip.
5. Rotate the barrel, push out the sleeve and remove the barrel and pinion.
6. The barrel and pinion are supplied as an assembly.

##### COMMUTATOR

7. If cleaning is not effective, skim lightly removing the absolute minimum amount of metal. Do not undercut the mica.

##### FIELD COILS

See Section N.2, items 11, 12, and 13.

##### BEARINGS

See Section N.2, item 15.

##### ARMATURE

See Section N.2, item 14.

##### Reassembling and refitting

Reverse the removal and dismantling instructions.

### Section N.4

#### VOLTAGE REGULATOR

##### Adjusting (cold unit)

##### ELECTRICAL

1. Disconnect the cables from the control box terminals 'A' and 'A1' and join them together.
2. Connect the negative lead from a voltmeter (0–20 volts) to control box terminal 'D' and the positive lead to terminal 'E'.
3. Slowly increase engine speed until the voltmeter needle flicks and then steadies. This should occur between 15.8 and 16.7 volts, depending on the ambient temperature.
4. If adjustment is required, switch off the engine and remove the control box cover.

- Turn the voltage adjustment screw (1) (Fig. N.3), in a clockwise direction to raise the voltage and anti-clockwise to lower it. Turn only a fraction of a turn at a time. This adjustment should be completed within 30 seconds or the settings will be affected by heat. Do not run the dynamo at a higher speed than is necessary for the adjustment to be made.

**MECHANICAL**

- Slacken the fixed contact and voltage adjusting screws until they are clear of the moving contact and the tension spring respectively. Slacken the two armature assembly securing screws.
- Insert .021 in. (.53 mm.) feeler gauge between the armature and the core shim. Press the armature squarely down against the gauge and tighten the armature assembly securing screws.
- With the gauge still in position, screw the adjustable contact down until it just touches the armature contact. Tighten the locking nut.
- Reset the voltage adjusting screw as in item 5.




Fig. N.4  
Mechanical setting of the regulator

- |                              |                                    |
|------------------------------|------------------------------------|
| 1. Locknut.                  | 5. Fixed contact adjustment screw. |
| 2. Voltage adjusting screw.  | 6. Armature.                       |
| 3. Armature tension spring.  | 7. Core face and shim.             |
| 4. Armature securing screws. | 8. .021 in. (.533 mm.).            |

**Section N.5**

**CUT-OUT**

**Adjustment  
ELECTRICAL**

- To check, connect the voltmeter between terminals 'D' and 'E'. Start the engine and slowly increase the speed until the contacts close; this should occur at 12.7 to 13.3 volts.
- To adjust, turn the adjusting screw clockwise to raise the voltage and anti-clockwise to reduce it. Turn only a fraction at a time. Make the adjustments as quickly as possible to avoid temperature effects.

**MECHANICAL**

- Unscrew the cut-out adjusting screw until it is clear of the armature tension spring. Slacken the armature securing screws.
- Press the armature down against the copper-sprayed core and tighten the securing screws.
- Bend the armature stop arm until the gap between it and the tongue is .030 in. (.76 mm.) when the armature is pressed squarely against the core face 8 (Fig. N.6).
- Bend the fixed contact blade so that there is a gap of .010 to .020 in. (.25 to .30 mm.) between the contact points when the armature is free.
- Reset the cut-out adjusting screw.





Fig. N.3  
The control box

- |                               |  |
|-------------------------------|--|
| 1. Regulator adjusting screw. | 5. Armature tongue and moving contact. |
| 2. Cut-out adjusting screw.   | 6. Regulator fixed contact screw.      |
| 3. Fixed contact blade.       | 7. Regulator moving contact.           |
| 4. Stop arm.                  | 8. Regulator series windings.          |



4876A

Fig. N.5


The control box (regulator and cut-out) internal connections

- |                                 |                        |
|---------------------------------|------------------------|
| 1. Regulator and cut-out frame. | 4. Tapped series coil. |
| 2. Field resistance.            | 5. Series coil.        |
| 3. Shunt coil.                  | 6. Shunt coil.         |

### Section N.6

#### LAMPS

Full details of the lamps, bulbs, warning lights, etc., are given in the Driver's Handbook.



4877C

Fig. N.6

Mechanical setting of the cut-out


- |  |  |
|--|--|
| 1. Cut-out adjusting screw.                            | 5. Armature tongue and moving contact. |
| 2. Armature tension spring.                            | 6. Armature securing screws.           |
| 3. 'Follow through'—.010 to .020 in. (.25 to .51 mm.). | 7. Fixed contact blade.                |
| 4. Stop arm.   | 8. .030 in. (.76 mm.).                 |
| 9. .010 to .020 in. (.25 to .51 mm.).                  |  |

### Section N.7

#### BI-METAL RESISTANCE INSTRUMENTATION

##### General description

The bi-metal resistance equipment for fuel and temperature gauges consists of an indicator head and transmitter unit connected to a common voltage stabilizer. In both applications the indicator head operates on a thermal principle, using a bi-metal strip surrounded by a heated winding, and the transmitter unit is of a resistance type. The system by which the equipment functions is voltage-sensitive and the voltage stabilizer, which serves one or more gauges, is necessary to ensure a constant supply of a pre-determined voltage to the equipment.



A 9500

Fig. N.7

The bi-metal resistance instrumentation circuit

- |                                   |                            |
|-----------------------------------|----------------------------|
| 1. Temperature gauge.             | 4. Ignition switch.        |
| 2. Temperature gauge transmitter. | 5. Voltage stabilizer.     |
| 3. Battery.                       | 6. Fuel gauge.             |
|                                   | 7. Fuel gauge transmitter. |

##### Fault analysis

##### VOLTAGE STABILIZER

Check the mean voltage between the output terminal 'T' and earth, which should be 10 volts.

Substitute voltage stabilizer if faulty.

##### GAUGES

Check for continuity between the terminals with the wiring disconnected. The gauges must not be checked by short circuiting to earth.

Substitute the gauge if faulty.

##### TRANSMITTER

Check for continuity between terminal and case with lead disconnected.

Substitute transmitter if faulty.

**WIRING**

Check for continuity between each unit. Check for leak to earth. Check for short circuits to earth on wiring to each transmitter. Check terminal wiring for security, earth connections, and wiring continuity. Check that the voltage stabilizer and relating transmitters are earthed.

**NOTE.**—If the voltage stabilizer is removed it is essential to ensure that, when replacing, B and E are uppermost and not exceeding 20 degrees from the vertical.

**Section N.8**

**WINDSCREEN WIPER MOTOR  
(Moke)**

The wiper motor fitted to early models of this vehicle operated a single wiping blade on the driver's side only.

Later vehicles are equipped with a motor which operates twin wiper blades, and this motor will be referred to below as the (later type).

**Removing (early type)**

1. Slacken the hexagon screw and pull the blade and arm from the drive spindle.
2. Remove the nuts, locknuts, washers, and seals securing the motor to the scuttle.
3. Disconnect the leads from inside the vehicle and withdraw the motor.

**NOTE.**—A rubber flange with steel inserts is fitted between the wiper motor and the scuttle to prevent the insulating flange being over-compressed.

**Refitting**

4. Reverse the removal sequence.

**Removing (later type)**

5. Remove the four nuts securing the rack to the wheelboxes.
6. Disconnect the electrical connections from the motor.
7. Remove the three screws securing the motor to the bracket and remove the assembly.
8. Remove the gearbox cover and withdraw the retaining circlip from the cross-head connecting link pin and lift off the connecting link and rack cable assembly.

**Dismantling the motor (later type)**

9. Remove the through-bolts and the commutator housing.
10. Lift the brush unit clear of the commutator and withdraw it. Note the position occupied by each brush so that it may be refitted in its original setting on the commutator.
11. Access to the armature and field coils is obtained by withdrawing the yoke.
12. Clean the commutator and brushes, replacing any that are worn. Ensure that the commutator segments are clean; short-circuiting of adjacent segments will cause excessive current consumption. The resistance between segments should be .29 to .35 ohms.




Fig. N.8  
The windscreen wiper (Moke)

1. Arm-locating screw.
2. Motor mountings.

**Dismantling the gearbox**

13. Carry out instruction 8.
14. Remove the circlip and washer from the final drive gear shaft located underneath the gearbox casing, and lift out the final drive gear.
15. The armature can now be withdrawn for cleaning or replacement.
16. Examine the worm drive of the armature and the teeth of the final drive gear and fit replacements if either are damaged or excessively worn.

**Reassembling**

17. Reverse the dismantling procedures, using the following lubricants:  
Use Ragosine Listate grease liberally on the cross-head, guide channel, connecting rod assembly, worm drive, and on the rack cable and wheelbox assemblies.  
Use S.A.E. 20 oil sparingly on the armature and final drive gear bearings.
18. Ensure that the plain steel washer is placed beneath the connecting rod when assembling the final drive gear crankpin.
19. The armature end-float adjusting screw should be set to allow an end-float of .008 to .012 in. (.2 to .3 mm.); this is approximately a quarter of a turn clear of the armature thrust pad.

**Refitting**

20. Reverse the removing procedure, but before switching on the motor remove the wiper arms from the spindles. Switch on the motor and stop it at the end of the stroke; refit the arms so that they are in the correct parking position.

## Section N.9

## WINDSCREEN WIPER WHEELBOXES

## Removing

1. Withdraw the wiper arms from the wheelbox spindles, and remove the external securing nuts.
2. ALL MODELS EXCEPT MOKE. From under the bonnet, slacken the nut securing the rack to the motor. Swivel the wheelboxes through into the engine compartment sufficiently to enable the securing nuts to be removed and release the wheelbox from the rack and cable. Note the location of the flared ends of the Bundy tubing with each wheelbox.
3. MOKE. Removing is similar to item 2 except that the wheelboxes are located inside the vehicle.

## Refitting

4. Reverse the removing procedure and fit new external sealing grommets if required. Tighten the rack securing nut on the motor.
5. Switch on the motor and stop it at the end of the stroke. Ensure that the arms are correctly positioned to give maximum wipe area and park at the end of the stroke.

## Section N.10

## ALTERNATOR SERVICE PRECAUTIONS

The following precautions must be observed when dealing with vehicles fitted with an alternator.

1. When fitting a replacement alternator ensure that it is of the same polarity as the original. Terminal polarity is clearly marked.
2. Do not reverse the battery connections. This will damage the alternator rectifiers. Connect up the earth terminal of the battery first.
3. If a high-rate battery charger is used to charge the battery in position in the vehicle, damage will occur to the regulator if the ignition/starter switch is switched on to the auxiliary position. Detach the connectors from the regulator as a safety measure before boost-charging. Re-connect after charging.
4. When starting an engine with the aid of a high-rate charger, detach the connectors from the regulator prior to using the charger. Do not re-connect the regulator until the charger is disconnected, and the engine is running at idling speed.
5. The battery must never be disconnected while the engine is running, nor must the alternator be run with the main output cable disconnected either at the alternator end or the battery end.
6. The cable connecting the battery and alternator is 'live' even when the engine is not running. Take care not to earth the alternator terminal or the cable end if removed from the terminal.

Do not make or break any connections in the alternator circuit while the engine is running.

7. Disconnect the alternator and regulator as a safety precaution when arc-welding on the vehicle.

## Section N.11

## TESTING THE ALTERNATOR CHARGING CIRCUIT IN POSITION

Before commencing the charging circuit tests given below carry out the 'Maintenance' instructions.

## Maintenance

The driving belt must be tensioned so that a deflection of ½ in. (13 mm.) can be obtained under finger pressure at the mid-point of the longest run of the belt.

**DO NOT** apply leverage to any point of the alternator other than the drive end bracket, or run the engine with the battery or alternator disconnected.

Keep the ventilating holes in the slip-ring end cover clean.

## Alternator charging circuit

The following procedure should be adopted to locate a fault in the charging circuit using the test equipment recommended below.

## TEST EQUIPMENT REQUIRED

- a. Moving-coil D.C. ammeter, accurate up to at least 60 amps.
- b. Moving-coil D.C. voltmeter, scale 0–30 volts (plus one of low range if possible).
- c. Ohmmeter—battery powered. Hand-driven generator type must never be used for testing diodes.

## Testing

1. Check the driving belt for wear and tension (see 'Maintenance').
2. Check that the battery voltage is reaching the brush gear by disconnecting the two cables from the alternator field terminals, connect a voltmeter between the two cables and run the engine. The voltmeter should register battery voltage. If no reading is obtained, check the field circuit wiring.
3. Check the alternator output.

Stop the engine and disconnect the battery earth cable (+). If an ammeter is not fitted, disconnect both connectors from the alternator main output terminal 'B' and connect up a moving-coil ammeter between the terminal and the connectors.

Withdraw the cables from the alternator field terminals and connect a pair of auxiliary cables direct between these terminals and the battery (Fig. N.9).

Re-connect the battery earth lead (+). Start the engine and gradually increase speed until the alternator is rotating at 4,000 r.p.m. At this speed the ammeter reading should be approximately 40 amps.




Fig. N.9  
Alternator output test connections

- a. Zero reading: Stop the engine. Remove and inspect the brush gear (see 'Inspection'). Fit new brush gear if necessary and retest. If zero reading persists, remove and dismantle the alternator for detailed inspection.
- b. Low reading: Indicates either a faulty alternator or poor wiring circuit connections.

Stop the engine and check the wiring connections. Connect a voltmeter (low range) between the alternator output terminal 'B' and the battery negative (-) terminal, restart the engine and note the reading. Transfer the voltmeter connections to the alternator frame and the battery earth (+) terminal and note the reading.

If either reading exceeds .5 volt there is high resistance in the charging circuit which must be traced and remedied. Should the test show no undue resistance (although output is low) proceed to dismantle and inspect the alternator.

Section N.12

DISMANTLING AND OVERHAULING  
THE 11AC ALTERNATOR

Removing

1. Disconnect the battery and detach the electrical leads from the alternator.
2. Slacken the alternator securing bolts, push the alternator towards the engine and detach the driving belt from the alternator pulley. Remove the securing bolts and detach the alternator from the engine.

Dismantling

3. Remove the securing nut and detach the drive pulley, fan, and key from the armature shaft.
4. Mark the relative positions of the drive end bracket, the stator lamination pack, and the slip-ring end bracket for correct reassembly.

5. Remove the through-bolts and detach the drive end bracket and rotor.  
The drive end bracket and rotor need not be separated unless the drive end bearing requires examination or the rotor is to be replaced. Remove the rotor from the drive end bracket by means of a hand press having first removed the shaft key and bearing collar.
6. Remove the terminal nuts, brush box retaining screws, and the heat sink bolt. Withdraw the stator and heat sink from the slip-ring end bracket.
7. Close the retaining tongues on the brush terminal blades and withdraw the terminals from the brush box.

Inspection

BRUSH GEAR

Brushes worn below  $\frac{5}{16}$  in. (8 mm.) should be replaced.

- a. The new brush complete with spring and 'Lucar' terminal blade is pushed into the holder until the tongue registers. To retain the terminal, carefully lever up the retaining tongue with a thin blade.
- b. Check that the brushes move freely in their holders. If sluggish, clean brush sides with a petrol-moistened cloth or, if ineffective, lightly polish brush sides with a smooth file. Clean off and re-house.

SLIP-RINGS

Surfaces should be smooth and free of oil or other foreign matter. Clean the surfaces if necessary, using a petrol-moistened cloth or, if there is evidence of burning, very fine glass-paper.

**NOTE.**—Do not attempt to machine the slip-rings.

Testing

TEST EQUIPMENT REQUIRED:

- a. Moving-coil D.C. ammeter, accurate up to 60 amps.
- b. Moving-coil D.C. voltmeter, scale 0–30 volts.
- c. Ohmmeter—battery-powered. Do not use a hand-driven generator type for testing diodes.
- d. Mains test lamp, 110-volt A.C., 15-watt.




Fig. N.10  
Using an ohmmeter (1) or a battery and ammeter (2) to test the resistance or current flow of the field winding




Fig. N.11  
Alternator components

- |                           |                                      |                                |
|---------------------------|--------------------------------------|--------------------------------|
| 1. Shaft nut.             | 9. Slip rings.                       | 17. Brush.                     |
| 2. Spring washer.         | 10. Stator laminations.              | 18. Rotor.                     |
| 3. Key.                   | 11. Stator windings.                 | 19. Bearing circlip.           |
| 4. Through-bolt.          | 12. Warning light terminal.          | 20. Bearing retaining plate.   |
| 5. Distance collar.       | 13. Output terminal.                 | 21. Ball bearing.              |
| 6. Drive end bracket.     | 14. Field terminal blade.            | 22. 'O' ring oil seal.         |
| 7. Jump ring shroud.      | 15. Output terminal plastic strip.   | 23. 'O' ring retaining washer. |
| 8. Rotor (field) winding. | 16. Terminal blade retaining tongue. | 24. Fan.                       |

### Rotor

- Test the rotor windings by connecting an ohmmeter, or a 12-volt battery supply and ammeter in series, between the slip-rings (Fig. N.10). The resistance or current of the field coils should be as given in 'GENERAL DATA'.
- Defective insulation between the slip-rings and one of the rotor poles. Use a mains test lamp (110-volt A.C., 15-watt), connect it between one of the slip-rings and rotor poles; if the lamp lights, the coil is earthing. Replace the rotor assembly.

**NOTE.**—Do not attempt to machine the rotor poles or true a distorted shaft.

### Stator

- Check for continuity of the stator windings. Unsolder the three stator cables from the heat sink assembly (see 'Replacing diode heat sink'). Connect any two of

the three stator cables in series with a 1.5-watt test lamp and a 12-volt battery. Repeat the test, replacing one of the two cables by a third. Failure of the test lamp to light in either test indicates that the stator windings are open circuit. Replace the stator.

- Test insulation between stator coils and lamination pack with the mains test lamp. Connect the test probes between any of the three cable ends and the lamination pack. If the lamp lights, the stator coils are earthing. Replace the stator.

Carry out the following test before resoldering the stator cables.

### Diodes

Test each diode by connecting a 12-volt D.C. supply and a 1.5-watt test lamp in series with each diode in turn as shown in Fig. N.12, and then reversing the connections. Current should flow in one direction only.




Fig. N.12  
Testing the diodes

D0389




Fig. N.13  
The heat sink diode internal connections

A9625

Should the bulb light up, or not light at all, in both tests the diode is defective. Replace the appropriate heat sink assembly.

The above procedure is adequate for testing. If, however, a battery-ohmmeter is used, it should be understood that no realistic readings can be obtained. A good diode will yield 'Infinity' in one direction, and a much lower, indefinite reading in the other.

#### Replacing diode heat sink

The heat sink assembly comprises two mutually insulated portions, one of positive polarity carries cathode-based diodes (marked red), and the other, negative, carries anode-based diodes (marked black).

- Make the interconnection with 'M' grade 45-55 tin-lead solder.
- Take great care to avoid overheating the diodes. Lightly grip the diode pins with a pair of long-nosed pliers, which will act as a thermal shunt, and carry out the soldering as quickly as possible.
- Arrange the connections neatly around the heat sinks to ensure adequate clearance for the rotor, and secure with a suitable heat-resistant adhesive (Fig. N.13). The three stator connections must pass through the appropriate notches at the edge of the heat sink.

#### Bearings

Renew bearings which allow excessive side play of the rotor shaft.

#### BEARING-SLIP-RING END-COVER

The needle-roller bearing and slip-ring end cover should be renewed as an assembly; if however a new bearing is to be fitted, follow the procedure below.

MINI. Issue 1. 14091

- Check the depth to which the original bearing is pressed into its housing so that the new bearing may be positioned likewise.
- Support the bearing boss, and press the bearing to the required depth. Pack with high-melting-point grease.

#### BEARING-DRIVE-END BRACKET

- Withdraw the rotor shaft from the drive-end bracket.
- The bearing retaining plate is secured by either screws, rivets or a circlip.  
File away the rivet heads and punch out the rivets; withdraw the screws or extract the circlip.
- Press the bearing from the bracket.
- Ensure that the new bearing is clean and pack it with high-melting-point grease. Locate the bearing and press fully into the housing.
- Refit the bearing retaining plate. When circlip retained, press in enough to allow the circlip to be located.

#### Re-assembling

- Reverse the dismantling procedure, bending the retaining tongues of the field terminal blades out at an angle of 30 degrees before fitting.
- Align the marks on the drive-end bracket, stator lamination pack and the slip-ring end-bracket.
- Support the inner journal of the drive-end bearing on a suitable tube and press the rotor home. Do not use the drive-end bracket as a support for the bearing while fitting the rotor. Tighten the through-bolts, brushbox fixing screws, and diode heat sink fixings to the correct torque figures (see 'GENERAL DATA').






Fig. N.14  
The alternator charging circuit

1. Alternator.
2. 4TR control unit.
3. 12-volt battery.
4. Starter solenoid.
5. Starter motor.
6. Lighting switch.
19. Fuse unit; 1-2, 35-amp.; 3-4, 35-amp.
38. Ignition/starter switch.
44. Ignition warning lamp.
85. Alternator field isolating relay.
107. Alternator charge indicator unit 3AW.

### Section N.13

#### CONTROL UNIT (4TR)

##### Testing

1. Check the resistance of the wiring circuits of the alternator, control unit and battery to control unit, including the relay unit. The resistance should not exceed .1 ohm.  
**NOTE.—Do not use an ohmmeter of the type which incorporates a hand-driven generator when checking the rectifiers or transistors.**
2. Check that the battery is fully charged.
3. Check the voltage output as follows:
  - a. Connect an accurate voltmeter across the battery terminals and note the reading.
  - b. Connect an ammeter between the alternator main cable and its terminal 'B' on the alternator.
  - c. Switch on enough lights to give a load of 2 amps.

- d. Start the engine and run for at least eight minutes at an alternator speed of 3,000 r.p.m. until the ammeter reads 10 amps.
- e. The voltmeter reading should then be between 13.9 and 14.3 volts. If the reading is unstable or has not risen above the battery voltage, renew the control unit. If the reading is stable but outside the correct limits, adjust the control unit.
4. If adjustment is needed, proceed as follows:
  - a. Stop the engine and detach the control unit from its mountings.
  - b. Scrape out the compound sealing the potentiometer adjustment at the back of the unit.
  - c. Ensure the connections on the unit are secure and re-start the engine.
  - d. Run the engine to give an alternator speed of 3,000 r.p.m., with the conditions of test as in 3.




Fig. N.15

The 4TR control unit potentiometer adjuster. Turn clockwise to increase the voltage reading




Fig. N.16  
Warning light control terminals

1. Alternator 'AL'.
2. Positive '+'.  
3. Warning light 'WL'.

- e. Turn the adjuster slot gradually until the voltmeter registers a stable reading within the correct voltage limits (see Fig. N.15). Only a small adjuster movement is needed to effect an appreciable difference in the voltmeter reading.
- f. Re-check by stopping the engine, re-starting it and running the alternator at 3,000 r.p.m. Check the voltmeter reading, and when it is correct, refit the control unit and remove the voltmeter and ammeter. Do not attempt to re-seal the adjuster hole. Application of undue heat will damage the control unit.

#### Section N.14

### RELAY

#### Description

The relay de-energizes the alternator rotor field winding when the engine is stationary by disconnecting the supply from the rotor field immediately the ignition is switched 'off'. This allows contact 'C1' and 'C2' to part and open-circuit the rotor field winding. The alternator will not generate if the contacts fail to close when the ignition is switched 'on'.

#### Testing

1. Connect an ammeter as detailed in Section N.11, item 3.
2. Remove the lead from terminal 'C2' and temporarily join to the 'C1' terminal, ensuring good electrical contact.
3. If the alternator generates its specified output with the leads connected (as above), the relay is faulty and must be replaced.

Check the continuity of relay operating winding, relay circuit wiring, and earth. If the relay and circuit are satisfactory (with cables 'C1' and 'C2' still joined), but no output from the alternator, check the alternator and control unit.

#### Section N.15

### WARNING LIGHT CONTROL

The control is electrically connected to the centre point of one pair of diodes in the alternator and enables a warning light to be used to indicate that the alternator is charging when the engine is running at normal speed.

If proved faulty, replace the unit.



## SECTION Nb

### THE ELECTRICAL SYSTEM

The information contained in this section refers specifically to new or modified components fitted to the Mini range coincident with the introduction of NEGATIVE earth electrical systems and must be used in conjunction with Section N.

	SECTION
Alternator (type 16ACR) .. .. .	Nb.9
Direction indicator flasher unit .. .. .	Nb.6
Instrument panel (Clubman and 1275 GT) .. .. .	Nb.1
Instrument panel printed circuit (Clubman and 1275 GT) .. .. .	Nb.3
Instruments (Clubman and 1275 GT) .. .. .	Nb.2
Lamps, bulb replacement, etc.—Refer to Handbook	
Speedometer drive cable .. .. .	Nb.5
Starter (type M35J—inertia drive) .. .. .	Nb.7
Voltage stabilizer .. .. .	Nb.4
Windscreen wiper motor (type 14W) .. .. .	Nb.8
Wiring diagrams with master key .. .. .	Appendix




Fig. Nb.1  
Removing the instrument panel (Mini Clubman and 1275 GT)

- |                                     |                          |            |
|-------------------------------------|--------------------------|------------|
| 1. Panel securing screws.           | 4. Tachometer connection | } 1275 GT. |
| 2. Speedometer cable release lever. | 5. Tachometer connection |            |
| 3. Multi-plug wiring connector.     |                          |            |

### Section Nb.1

#### INSTRUMENT PANEL (Clubman and 1275 GT)

##### Removing

1. Disconnect the battery earth cable (NEGATIVE).
  2. Remove the air ventilation louvre adjacent to the instrument panel (see Section Rb.4).
  3. Release the portion of the door seal securing the fascia trim liner, withdraw the liner from behind the side of the panel and remove it.
  4. Release the trim liner on the other side of the instrument panel in a similar manner but do not remove it; the instrument panel securing screws are now accessible (see Fig. Nb.1).
  5. Remove the four securing screws (1) and partially withdraw the panel; press in the release lever (2) on the speedometer cable and pull the cable out of the instrument. Pull out the multi-plug wiring connector (3) from the rear of the panel and remove the assembly (see Fig. Nb.1).
- 1275 GT. In addition to the above instructions also disconnect the tachometer connections (4) and (5) (see Fig. Nb.1).

##### Refitting

6. Reverse the removing instructions but note that the connector plug will fit one way only and make sure the speedometer cable is fully engaged in the instrument. Carefully refit the trim liners and use adhesive when refitting the door seal.

### Section Nb.2

#### INSTRUMENTS (Clubman and 1275 GT)

##### Removing

1. Remove the instrument panel (see Section Nb.1).

Nb.2

Removal of the instruments for replacement is as follows:

##### SPEEDOMETER (CLUBMAN)

2. Remove the screws securing the complete instrument unit to the panel, and lift off the unit.
3. Remove the three clips (1) and withdraw the lens assembly (2) (see Fig. Nb.2).
4. Unscrew the retaining screws (3) and withdraw the speedometer unit (4) (see Fig. Nb.2).

##### SPEEDOMETER (1275 GT)

5. Before removing the complete instrument unit as detailed in item 2, disconnect the printed circuit earth connection (arrowed) and remove the illuminating light bulb holder (5) from the tachometer (see Fig. Nb.2).
6. Carry out instructions 3 and 4.

##### FUEL AND TEMPERATURE GAUGES

7. Remove the clips (1), withdraw the lens assembly (6) from the instrument unit and lift out the instrument sub-dial (7). Unscrew the appropriate securing screws (8) and remove the instrument(s) (9), (10) for replacement (see Fig. Nb.2).

##### TACHOMETER (1275 GT)


8. Disconnect the printed circuit earth connection (arrowed) and withdraw the illuminating bulb holder (5). Remove the screws securing the tachometer unit to the panel and lift out the complete assembly.

The tachometer is replaceable as a complete unit (12) (see Fig. Nb.2). Do not remove the unit from its casing.

##### Refitting

##### INSTRUMENTS AND GAUGES

9. Reverse the removing procedure for all units.



M3040A

Fig. Nb.2  
An exploded view of the instrument assembly (Mini Clubman and 1275 GT)

- |  |   |                          |
|--|---|--------------------------|
| 1. Instrument lens securing clips.     | 6. Fuel/temperature gauge dial and lens assembly. | 10. Temperature gauge.   |
| 2. Speedometer dial and lens assembly. | 7. Fuel/temperature gauge sub-dial.               | 11. Voltage stabilizer.  |
| 3. Speedometer securing screws.        | 8. Fuel/temperature gauge securing screws.        | 12. Tachometer assembly. |
| 4. Speedometer unit.                   | 9. Fuel gauge.                                    |                          |
| 5. Panel lamp bulb and holder.         |   |                          |




Fig. Nb.3  
Removing the printed circuit

1. Printed circuit.
2. Printed circuit securing stud.
3. Fuel and temperature gauge securing screws.
4. Panel and warning lamp bulb holders.
5. Voltage stabilizer.

### Section Nb.3

#### INSTRUMENT PANEL PRINTED CIRCUIT (Clubman and 1275 GT)

##### Removing

1. Remove the instrument panel (Section Nb.1).
2. Withdraw all the panel and warning light bulb holders (4) and pull off the voltage stabilizer (5) (see Fig. Nb.3).
3. Remove the three voltage stabilizer terminals.
4. To avoid damaging the fuel and temperature gauge indicators, remove these instruments from their holder as detailed in Section Nb.2.
5. 1275 GT. In addition to the above instructions disconnect the connections to the tachometer and withdraw the additional bulb holder(s).
6. Ease out the pins (2) securing the printed circuit and remove the circuit (1).

##### Replacing

7. Fit the replacement circuit, bending the bulb contacts into each respective holder recess. The remainder is a reversal of the removing procedure.

### Section Nb.4

#### VOLTAGE STABILIZER

The voltage stabilizer is a push-fit into the rear of the instrument panel. For testing or replacement of the unit the panel must be withdrawn.

##### Testing

To carry out a rapid diagnosis of the voltage stabilizer, fuel and temperature gauges and their electrical circuits use a Smiths Automotive Instrument Tester (which incorporates a thermal-sensitive voltmeter).

1. Withdraw the instrument panel for access to the voltage stabilizer and gauges (see Section Nb.1), but leave the battery connected and do not disturb the wiring connector plug on the rear of the panel.

Nb.4

#### BATTERY VOLTAGE

1. Connect a voltmeter to the '2' terminal of the fuse block and earth. With the ignition switched off, check the voltage, it should be approximately 12 volts.
2. Start the engine and run it at approximately 1,000 r.p.m., and ensure that the ignition warning light is out. Check the voltage, which should be 12 to 13 volts.

#### WIRING

3. Check for continuity between each unit and for short-circuits in the wiring to the temperature gauge transmitter.
4. Ensure that the voltage stabilizer, gauges and transmitter are earthed.

#### VOLTAGE STABILIZER

5. Switch the ignition on. After a pause of two minutes, check the main voltage between the output terminal 'I' and earth; it should be 10 volts.
6. Substitute the voltage stabilizer if faulty.

#### GAUGES

7. Check for continuity between the terminals with the wiring disconnected. **DO NOT short-circuit a gauge to earth.**
8. Substitute a gauge if faulty.

#### TRANSMITTER

9. Check for continuity between the terminal and outer casing with the lead disconnected.
10. Substitute the transmitter if faulty.

#### Refitting

11. Refit the instrument panel as detailed in Section Nb.1.

Section Nb.5

**SPEEDOMETER DRIVE CABLE**

**Removing**

1. Remove the instrument panel (see Section Nb.1).
2. Press in the release lever (2) on the cable and pull the cable out of the instrument (see Fig. Nb.1). Withdraw the cable into the engine compartment.
3. From beneath the car, disconnect the cable through the aperture above the left-hand drive shaft. If the cable securing nut is too tight to turn by hand, use a suitable tool, or, remove the set screw securing the speedometer drive and withdraw the cable complete with the drive assembly and then remove the cable.

**Refitting**

4. Reverse the removing procedure, fitting a new joint washer if the speedometer drive has been removed. Tighten the lower securing nut by hand.

**Lubrication**

5. Withdraw the inner cable and lightly grease it except for 8 in. (200 mm.) at the speedometer end, re-insert it in the outer casing and wipe away surplus grease. Check that there is approximately in. (10 mm.) projection of the inner cable beyond the outer casing at the speedometer end.

Section Nb.6.

**DIRECTION INDICATOR FLASHER UNIT**

**Removing**

1. Access to the unit is through an aperture in the fascia parcel shelf. Pull the flasher unit from its spring clip holder and through the access hole; pull off the wiring connections.

**Replacing**

2. Connect the wiring to the new unit and refit it into the holder.

Section Nb.7

**STARTER**  
(Type M35J—Inertia Drive)

**Removing**

1. Disconnect the battery earth cable.
2. Disconnect the cable at the starter motor, remove the two bolts securing the starter motor to the flywheel housing and manoeuvre the starter away from the engine.

**Dismantling**

3. Remove the screws securing the drive-end bracket.
4. Withdraw the drive-end bracket complete with the armature and drive.

5. Remove the thrust washer from the commutator end of the armature.
6. Remove the screws securing the commutator end bracket.
7. Detach the bracket from the yoke, disengage the field brushes from the brush gear and remove the bracket.
8. If necessary the drive assembly can be removed by compressing the spring, removing the jump ring and withdrawing the drive from the shaft.

**Inspecting and testing**

**BRUSH GEAR**

9. Check the brush spring tension; fit a new brush into each holder in turn, and press on top of the brush with a push-type spring gauge until the brush protrudes approximately in. (1.5 mm.) from the holder. At this point check the gauge, which should read approximately 28 oz. (794 gm.); renew the commutator-end bracket if the tension is incorrect.
10. Check the brushes for wear, and renew any brush worn to or approaching the minimum length of in. (9.5 mm.).
11. To renew the end-bracket brushes, cut the brush leads from the terminal post, slot the head of the post sufficiently deep to accommodate the new brush leads and solder the new leads to the post.
12. To renew the field winding brushes, cut the brush lead approximately ½ in. (6.4 mm.) from the field winding junction, solder the new brush leads to the stumps of the old ones ensuring that the insulation sleeves provide adequate coverage.




Fig. Nb.4  
Commutator end bracket assembly

- |  |   |
|--|---|
| 1. Short brush-flexible, commutator end bracket. | 4. Short brush-flexible, field winding. |
| 2. Long brush-flexible commutator end bracket.   | 5. Yoke insulation piece.               |
| 3. Long brush-flexible, field winding.           | 6. Field winding junction.              |
|  | 7. Terminal post.                       |






Fig. Nb.5

The M35J-type starter motor components

- |                            |                          |                             |
|----------------------------|--------------------------|-----------------------------|
| 1. Commutator end bracket. | 7. Pole shoe.            | 13. Screwed sleeve.         |
| 2. Bush housing.           | 8. Field coils.          | 14. Buffer washer.          |
| 3. Brush springs.          | 9. Drive end bracket.    | 15. Main spring.            |
| 4. Brushes.                | 10. Brush box mouldings. | 16. Spring cup.             |
| 5. Yoke.                   | 11. Armature.            | 17. Circlip.                |
| 6. Pole screw.             | 12. Pinion and barrel.   | 18. Drive end bracket bolt. |

### COMMUTATOR

13. Clean the commutator with a cloth moistened with fuel and examine it for burrs, pitting and excessive wear; provided that the amount of metal removed does not reduce the thickness of the commutator beyond the minimum thickness, the commutator may be reconditioned as follows:
  - a. Skim the commutator at high speed using a very sharp tool and removing the minimum amount of metal necessary to restore the surface.
  - b. Polish the commutator with very fine sandpaper.
  - c. Using an air-blast, clean any copper residue from the armature.

**IMPORTANT.**—The commutator segment insulators must not be undercut.

### ARMATURE

14. Test the insulation of the armature windings with a 110-volt A.C., 15-watt test lamp connected between the armature shaft and the commutator; if the lamp lights the armature must be renewed.
15. Check the windings at their connections with the commutator for signs of melted solder or lifted conductors.
16. Check the shaft for distortion, and if it is bent or distorted the armature must be renewed; do not attempt to straighten the shaft or machine the armature core laminations.

### FIELD WINDINGS

17. Connect a 12-volt battery-operated test lamp between each of the field brushes and a clean part of the yoke;

the lamp will light if continuity is satisfactory between the brushes, windings and yoke connection.

18. Disconnect the field windings from their riveted connection with the yoke, and using a 110-volt A.C., 15-watt test lamp connected between the yoke and each of the brushes in turn, check the insulation of the field windings; if the lamp lights the windings must be renewed.
19. The field windings may be renewed as follows:
  - a. Disconnect the windings from their connection with the yoke.
  - b. Slacken the four pole-shoe retaining screws using a wheel-operated screwdriver.
  - c. Remove the retaining screws from one pair of diametrically opposite pole-shoes and remove them from the yoke.
  - d. Slide the windings from beneath the remaining pair of pole-shoes and withdraw them from the yoke.
  - e. Clean the inside of the yoke, the pole-shoes, and the insulation piece.
  - f. Loosely fit the new windings and the pole-shoes and position the insulation piece between the yoke and the brush connections to the windings.
  - g. Tighten the pole-shoe screws evenly using a wheel-operated screwdriver.
  - h. Re-connect the winding junction connector to the yoke.

**COMMUTATOR END BRACKET**

20. Check the insulation of the springs and terminal post by connecting a 110-volt A.C., 15-watt test lamp between a clean part of the end bracket and, in turn, each spring and the terminal; the lamp will light if the insulation is unsatisfactory.

**BEARINGS**

21. If a bearing is worn sufficiently to allow excessive side play of the armature shaft, the bearing bush must be renewed as follows:

**Commutator-end bracket**

- a. Drill out the rivets securing the brush box moulding and remove the moulding, bearing seal retaining plate and felt washer seal.
- b. Screw a 1/2-in. tap a few turns into the bush and withdraw the bush with the tap.

**Drive-end bracket**

- c. Support the bracket and press out the bush.  
**NOTE.**—New bushes must be immersed in S.A.E. 30/40 engine oil for 24 hours or in oil heated to 100° C. (212°F.) for two hours prior to fitting. The bushes must not be reamed after fitting.

**Commutator- and drive-end brackets**

- d. Using a polished, shouldered mandrel, the same diameter as the shaft bearing journal, press the new bushes in to the brackets.

**DRIVE**

22. Wash the drive with paraffin (kerosene) and dry using an air blast.
23. Check the components for damage and excessive wear; renew worn or damaged parts.

**Reassembling and refitting**

24. Carry out items 3 to 8 in reverse order, and refit the starter by reversing the removal sequence items 1 and 2.




Fig. Nb.6  
Armature insulation test




Fig. Nb.7  
Field winding continuity test

**Bench testing**

**LIGHT RUNNING CURRENT**

25. Clamp the starter firmly in a vice.
26. Connect a starter switch, a 0–600 amp. ammeter and a 12-volt battery in series, to the starter, using the lug as the earth connection.
27. Operate the switch and check the speed of the motor with a tachometer while noting the ammeter readings.
28. Check the readings obtained in item 27 against the figures given for light running speed and current in 'GENERAL DATA'.

**LOCK TORQUE AND CURRENT**


29. With the starter connected and clamped as for the light running check, secure an arm to the driving pinion.
30. Connect a spring balance to the free end of the arm.
31. Operate the switch and note the ammeter and spring balance readings. Calculate the lock torque by multiplying the reading of the spring balance in pounds by the length of the arm in feet.
32. Check the readings obtained in item 31 against the figures given for lock torque and current in 'GENERAL DATA'.

**Section Nb.8**

**WINDSCREEN WIPER**  
(Lucas Type 14W—Permanent Magnet)

**Operation**

This windscreen wiper, which is produced in either single- or two-speed form, has two permanent field magnets incorporated in a cylindrical yoke. The two-speed type is fitted with a third brush, to which the positive feed is transferred when a faster wiper speed is required.



DO692B

Fig. Nb.8

The two-speed wiper motor components

- |                         |                             |                            |
|-------------------------|-----------------------------|----------------------------|
| 1. Gearbox cover.       | 7. Shaft and gear.          | 13. Screw for brush gear.  |
| 2. Screw for cover.     | 8. Dished washer.           | 14. Armature.              |
| 3. Connecting rod.      | 9. Gearbox.                 | 15. Yoke assembly.         |
| 4. Circlip.             | 10. Screw for limit switch. | 16. Yoke bolts.            |
| 5. Plain washers.       | 11. Limit switch assembly.  | 17. Armature thrust screw. |
| 6. Cross-head and rack. | 12. Brush gear.             |                            |

A self-switching limit switch is incorporated in the terminal assembly. A cam on the underside of the gear wheel operates the two-stage switch via a plunger. When switched off, the motor continues under control of the limit switch until the wipers reach park position, the first stage contacts open and the motor is switched off. A period of no contact by the switch follows, then the second-stage contacts close to brake the armature and park the blades in the same position each time.

### Testing

If the wiper fails to operate, or the wiper speed is slow or irregular, first locate the fault. Start by checking that the battery is fully charged, and that the wiper blades are in good condition and are not sticking.

1. Check the voltage at the motor connector plug; if the fuse (35/17 amp.) connecting '3' and '4' has blown, replace it, but before continuing make certain that this has not been caused by a fault in another circuit or by poor insulation.

2. Remove the motor, disconnect the cable rack at the gearbox (see 'Dismantling' items 13 to 15), connect a 0-15 moving-coil ammeter to the supply cable, and switch on the wiper. If the current consumption of the motor and the operating speeds of the drive gear are not as given in 'GENERAL DATA', carry out the electrical tests; if the operation is now satisfactory, the fault is mechanical.

### ELECTRICAL

3. If the wiper takes no current and the fuse is intact, check the electrical circuit for continuity, including the fascia switch. If the fuse had blown, (item 1) check the wiring insulation, and if in order carry out the electrical test, 5.
4. If the wiper takes an abnormally low current, the motor must be dismantled and an examination made of the brush gear and commutator (see 'Inspecting').

- If the wiper takes an abnormally high current, adjust the armature end-float if necessary (see item 25). If the current consumption is still abnormal with the correct end-float, remove and test the armature (see 'Inspecting', item 22).

**NOTE.**—If the motor is run other than from the vehicle's own connector, connect up as follows: negative—terminal 1, positive—terminal 5 for normal speed or terminal 3 for fast speed (two-speed type).

#### MECHANICAL

- See that the wiper arm spindles rotate freely; replace seized or damaged wheelboxes.
- Use a spring balance to measure the force required to pull the cable rack out of the casing from the fully-in position. This force must not exceed 6 lb. (2.7 kg.). Reform any bends of less than 9 in. (230 mm.) radius and replace any kinked or damaged tubes. Inspect the drive cable rack for damage.
- Check the wheelboxes and connector tubes for alignment.

#### Removing

##### MOTOR AND GEARBOX ASSEMBLY

- Disconnect the battery, withdraw the terminal connector from the motor, and release the earth wire from the valance.
- Remove the wiper arms.
- Unscrew the union on the Bundy tube at the gearbox and release the strap from the mounting bracket. Withdraw the assembly, pulling the cable rack from the Bundy tube.

#### WHEELBOXES

- Remove the wheelboxes, as described in Section N.9.

#### Dismantling

##### MOTOR AND GEARBOX ASSEMBLY (WHEN REMOVED)

- Unscrew the four gearbox cover retaining screws and remove the cover.
- Remove the circlip and flat washer securing the connecting rod to the crankpin.
- Withdraw the connecting rod, noting the flat washer fitted under it.
- Remove the circlip and washer securing the shaft and gear.
- Clean any burrs from the gear shaft and withdraw the gear, noting the dished washer fitted under it.
- After marking the motor yoke and gearbox to ensure that they are reassembled the original way round, unscrew the two fixing bolts and remove the yoke and armature assembly. Keep the yoke clear of metallic particles which will be attracted to the pole pieces.
- Remove the screws securing the brush gear and the terminal and switch assembly, which are connected by cables, and remove both of them.

#### Inspecting

##### MOTOR AND GEARBOX ASSEMBLY

- Examine the brush gear assembly, which must be replaced before either of the main brushes is worn to the minimum length of  $\frac{3}{16}$  in. (5 mm.), or the narrow section of the third brush (two-speed models) is worn down to the full width of the brush (see Fig. Nb.9).
- Check that the brushes move freely in the boxes and test the brush spring pressure with a push-type gauge. The gauge reading should be 5 to 7 oz. (140 to 200 gm.) when the bottom of the brush is level with the end of the slot in the brush box (see Fig. Nb.9). Renew the brush gear assembly if the springs are unsatisfactory.
- Test the armature for open- or short-circuits. Use a mains test lamp of 110 volts and 15 watts and renew the armature if faulty.
- Examine the gear wheel for damage or excessive wear. Renew if necessary.

#### Reassembling

##### MOTOR AND GEARBOX ASSEMBLY

- Reverse the dismantling procedure in 13 to 19, noting the following points.
  - If either the brush gear or switch assembly requires replacing, unsolder the motor supply leads at the brush boxes. If a new switch is to be fitted to a single-speed motor remove the third wire, yellow and green, at the switch terminal. Use high-melting-point solder to reconnect the leads to the brush boxes, in the order shown in Fig. Nb.9, when refitting the new assembly(ies); ensure that the leads are inside the recess in the switch unit moulding when refitting it to the gearbox.




Fig. Nb.9  
The brush gear assembly components

- |                                    |   |
|------------------------------------|---|
| 1. Soldered brush box connections. | 3. Fast speed brush (where fitted).     |
| 2. Main brushes.                   | 4. Brush gear assembly securing screws. |
| RG—Red with green.                 | YG—Yellow with green.                   |
|                                    | UG—Blue with green.                     |

- b. Use Ragosine Listate Grease to lubricate the gear wheel teeth and cam, armature shaft worm gear, connecting rod and connecting pin, crosshead slide, cable rack and wheelbox gear wheels.
- c. Use Shell Turbo 41 oil to lubricate the bearing bushes, armature shaft bearing journals (sparingly), gear wheel shaft and crankpin, felt washer in the yoke bearing (thoroughly soak), and the wheelbox spindles.
- d. If a replacement armature is being fitted, slacken the thrust screw to provide end float for fitting the yoke.
- e. Tighten the yoke fixing bolts to a torque figure of 14 lb. in. (0.16 kg. m.).
- f. Fit the dished washer beneath the gear wheel with its concave side towards the gear wheel.

**IMPORTANT.**— If a new gear wheel is being fitted, ensure that the type obtained has the correct relationship between the crankpin and ramp to give the parking position required for either right- or left-hand-drive vehicles (see Fig. Nb.10).

- g. When fitting the connecting rod to the crankpin ensure that the larger of the two flat washers is fitted under the connecting rod with the smaller one on top beneath the circlip.

### ARMATURE END-FLOAT ADJUSTING

- 25. Tighten the thrust screw until the end-float is just eliminated, and then turn back one-quarter turn to give an end-float within the limits of .002 to .008 in. (.05 to .2 mm.). Measure the gap under the head of the thrust screw with a feeler gauge, fit a suitable shim beneath it and fully tighten it.




Fig. Nb.10

The gear wheel showing the alternative positions of the crankpin

- (A) R.H.D. cars: cable rack retracted with the crankpin (1) opposite the ramp (2).
- (B) L.H.D. cars: cable rack extended with the crankpin (3) adjacent to the ramp (2).

Nb.10




Fig. Nb.11

The armature end-float adjusting screw

### Refitting

- 26. Reverse the procedure 9 to 12, leaving the wheelbox covers slack until after the cable rack has been inserted and the motor secured. Do not re-fit the wiper blades until after the action of the wheelboxes has been checked.

### Section Nb.9

### ALTERNATOR (Lucas type 16ACR)

The model 16ACR alternator is similar in basic construction to that of the type 11AC as described in Section N.12, except that the slip-rings are mounted behind the rear rotor shaft bearing outside the slip-ring end bracket, and no separate control unit is fitted. Instead, a voltage regulator, of micro-circuit construction is incorporated on the slip-ring end bracket, inside the alternator cover.

### Precautions

The alternator service precautions given in Section N.10 must be observed. Note that the battery polarity is **NEGATIVE EARTH**, which must be maintained at all times. The field connector block, which has three blades and is marked 'B+' and 'IND', has an offset moulded stop and must be removed before the main output connector block, which has two blades and is marked '+' and '-'. Since the B+ connector blade, although shrouded, is always live, disconnect the battery earth before removing the field connector block.

### Testing in position

#### OUTPUT TEST

1. Check that the fan belt is correctly tensioned and that all charging circuit electrical connections are secure.
2. Run the engine at fast idle speed until its normal operating temperature is reached, and see that the battery is fully-charged.
3. Disconnect both connector blocks from the alternator.




Fig. Nb.12

The in-built regulator connections, showing 'A' the 11TR and 'B' the 8TR type of regulator unit

- |   |                        |
|---|------------------------|
| 1. B+.                                  | 4. Earth (-)-8TR.      |
| 2. Positive (+).                        | 5. Earth (-)-11TR.     |
| 3. Field (F).                           | 6. Mounting screw-8TR. |
| 7. Long mounting screw and spacer-11TR. |                        |

4. Switch on the ignition and connect up a voltmeter with its negative lead to earth and with its positive lead to each cable connector blade of the two connector blocks in turn. If battery voltage is not available at any cable, locate and remedy the fault.
5. Remove the alternator end cover.
6. The leads from the in-built regulator to the alternator are unmarked. Refer to Fig. Nb.12 and then bridge the regulator field connector to a suitable earth, such as the earth-lead tag.
7. Refit the three-way connector block to the alternator. Do not refit the two-way connector block, instead, connect an ammeter in series with its positive blade and the main positive output terminal of the alternator. Do not make any connection to the inner (negative) main terminal.
8. Start the engine and run it at 2,800 r.p.m. The ammeter should read 34 amps. nominal. If the correct alternator output cannot be obtained, repair or replace the alternator.

**CHARGING CIRCUIT RESISTANCE TEST**

12. Connect a voltmeter between the positive terminal of the alternator and the positive terminal of the battery. Start the engine, switch on the headlamps, and run the engine at 2,800 r.p.m. The voltmeter reading should not exceed .5 volt.
13. Transfer the voltmeter connections to the negative terminals of the alternator and battery. With the engine running at 2,800 r.p.m. the voltmeter reading should not exceed .25 volt.
14. If either of the readings in 12 and 13 exceed the voltage stated, the charging circuit has developed a high-resistance fault, which must be traced and remedied.

If this test is satisfactory, then the incorrect voltage reading obtained in 11 would have been caused by a faulty regulator pack, so the alternator must either be replaced or removed for overhaul.

**REGULATOR TEST**

9. Disconnect the lead which was connected up in item 6 to bridge the regulator field connector to earth.
10. Connect a voltmeter across the battery terminals. Start the engine and run it at 2,800 r.p.m. If the ammeter which was connected for item 7 of the output test reads zero, the regulator pack must be replaced.
11. Adjust the engine speed until the ammeter reading falls below 10 amps. The voltmeter should read between 14.0 and 14.4 volts. If it does not, either the regulator is faulty or there is a high resistance in the charging circuit cables; restore the original connections to the alternator and then check the charging circuit resistance.




Fig. Nb.13  
Alternator output test

1. Positive terminal of alternator.
2. Positive blade of two-way connector block.




Fig. Nb.14  
The 16ACR alternator components

- |                           |                        |                        |
|---------------------------|------------------------|------------------------|
| 1. Regulator pack.        | 5. Fan.                | 9. Rectifier pack.     |
| 2. Slip-ring end bracket. | 6. Pulley.             | 10. Slip-rings.        |
| 3. Stator.                | 7. End cover.          | 11. Rotor bearings.    |
| 4. Rotor.                 | 8. Brush box moulding. | 12. Drive end bracket. |

#### Removing the regulator pack

15. Remove the alternator as described in items 17 to 20.
16. Remove the moulded end cover, and identify the type of regulator pack fitted; the 8TR type has two short mounting screws at each end, while the 11TR type has a single longer one, with a spacer, screwed into the top lug of the brush box moulding only. Both types have two legs which locate in the brush box moulding.

Disconnect the coloured tag lead connectors from the brush box, and detach the black (earth) lead after removing the lower mounting screw (8TR) or one of the brush box retaining screws (11TR). Remove the remaining screw securing the regulator pack.

#### Removing the alternator

17. Withdraw the terminal block from the alternator.
18. Remove the adjusting link bolt from the alternator.
19. Slacken the alternator mounting bolts, lower the alternator and slip the fan belt from the alternator pulley.
20. Unscrew the alternator mounting bolts and remove the alternator.

#### Testing—alternator removed

21. Unscrew the cover retaining screws and remove the cover if this has not already been done in item 16.
22. Unsolder the three stator connections from the rectifier pack, noting the connection positions.

**IMPORTANT.**—When soldering or unsoldering connections to the diodes great care must be taken not to overheat the diodes or bend the pins. During the soldering operations the diode pins should be gripped lightly with a pair of long-nosed pliers which will then act as a thermal shunt, see Fig. Nb.15.

23. Unscrew the two brush moulding securing screws, and, if necessary, the lower regulator pack securing screw.




Fig. Nb.15  
Using pliers as a thermal shunt when soldering the alternator diodes




Fig. Nb.16

To renew a brush and spring assembly, remove the appropriate pair of screws and extract the brush assembly from its housing

- 1. Brush box moulding.
- 2. Brush and spring assembly.
- 3. Retaining screws (4).

- 24. Slacken the rectifier pack retaining nuts and withdraw both the brush moulding, with or without the regulator pack, and the rectifier pack.

**BRUSHES**

- 25. Check the brushes for wear by measuring the length of brush protruding beyond the brushbox moulding. If the length protruding is .2 in. (5 mm.) or less, the brush must be renewed.
- 26. Check that the brushes move freely in their holders. If a brush shows a tendency to stick, clean it with a petrol- (gasoline-) moistened cloth or, if necessary polish the sides of the brush with a fine file.
- 27. Check the brush spring pressure using a push-type spring gauge. The gauge should register 7 to 10 oz. (198 to 283 gm.) when the brush is pushed back until its face is flush with the housing. If the gauge reading is outside the limits given, renew the brush assembly, as shown in Fig. Nb.16.




Fig. Nb.17

The stator winding continuity test

**SLIP-RINGS**

- 28. Clean the surfaces of the slip-rings using a petrol- (gasoline-)moistened cloth.
- 29. Inspect the slip-ring surfaces for signs of burning; remove burn marks using very fine sand paper. On no account must emery-cloth or similar abrasives be used or any attempt made to machine the slip-rings.

**ROTOR**

- 30. Connect an ohmmeter, or a 12-volt battery and an ammeter, to the slip-rings. An ohmmeter reading of 4.3 ohms or an ammeter reading of 3 amps. should be recorded.
- 31. Using a 110-volt A.C. supply and a 15-watt test lamp, test for insulation between one of the slip-rings and one of the rotor poles. If the test lamp lights, the rotor must be renewed.




Fig. Nb.18  
Testing the diodes

**STATOR**

- 32. Connect a 12-volt battery and a 36-watt test lamp to two of the stator connections. Repeat the test, replacing one of the two stator connections with the third. If the test lamp fails to light in either of the tests, the stator must be renewed (see Fig. Nb.17).
- 33. Using a 110-volt A.C. supply and a 15-watt test lamp, test for insulation between any one of the three stator connections and the stator laminations. If the test lamp lights, the stator must be renewed.

**DIODES**

- 34. Connect a 12-volt battery and a 1.5-watt test lamp in turn to each of the nine diode pins and its corresponding heatsink on the rectifier pack, then reverse the connections. The lamp should light with the current flowing in one direction only. If the lamp lights in both directions or fails to light in either, the rectifier pack must be renewed (see Fig. Nb.18).

**IMPORTANT.**— See notes on soldering the diodes given in item 22.






Fig. Nb.19  
Dimensions of the rotor removing tool

- A. 3 in. (76 mm.).                      C. 1.32 in. (33.5 mm.).  
B. 1.5 in. (38 mm.).                    D. 1.24 in. (31.5 mm.).

### Dismantling

35. Carry out the operations detailed in 21 to 24.
36. Remove the three through-bolts.
37. Fit a tube of the dimensions given in Fig. Nb.19 over the slip-ring moulding so that it registers against the outer track of the slip-ring end bearing and carefully drive the bearing from its housing.
38. Remove the shaft nut, washer, pulley, fan, and shaft key.
39. Press the rotor from the drive end bracket.
40. Remove the circlip retaining the drive end bearing and remove the bearing.
41. Unsolder the field connections from the slip-ring assembly and withdraw the assembly from the rotor shaft.
42. Remove the slip-ring end bearing.

### Reassembling

43. Reverse the dismantling procedure in 35 to 42 and 21 to 24, noting the following points.
  - a. Use Shell Alvania 'RA' to lubricate the bearings where necessary.
  - b. When refitting the slip-ring end bearing, ensure that it is fitted with its open side facing towards the rotor and is pressed onto the rotor shaft as far as it will go.
  - c. Re-solder the field connections to the slip-rings using Fry's H.T.3 solder.
  - d. When refitting the rotor to the drive end bracket, support the inner track of the bearing with a suitable piece of tube. Do not use the drive end bracket as the only support for the bearing when fitting the rotor.
  - e. Tighten the through-bolts evenly.
  - f. Check that the brushes are entered in their housings before fitting the brush moulding.
  - g. Tighten the shaft nut to the torque figure given in 'GENERAL DATA'.
  - h. Refit the regulator pack to the brush moulding if it had been removed separately. See that the correct number and size of securing screws are used for the type being refitted, which need not be the same as the original, using the spacer if required. Refer to item 16.

### Refitting the alternator

Reverse the removal procedure in 17 to 21, and ensure that the drive belt is correctly tensioned.

### FAULT DIAGNOSIS

Alternator			Probable fault and associated damage
Temperature	Noise	Output	
High	Normal	Higher than normal—40 amps. approximately at 2,800 r.p.m.	Live side output diode open-circuit. (May damage rotor windings and regulator output stage, overheat brush boxes, and blow warning light).
High	Excessive	Very low—10 amps. approximately at 2,800 r.p.m.	Live side output diode short-circuit. (May cause failure of associated field diode.)
Normal	Excessive	Poor at low speed, slightly below normal at 2,800 r.p.m.—32 amps. approximately.	Earth side output diode open-circuit.
Normal	Excessive	Very low at all speeds above 850 r.p.m.—7 amps. approximately.	Earth side output diode short-circuit. or one phase winding shorted to earth.
Normal	Normal	Lower than normal—29 amps. approximately at 2,800 r.p.m.	Field diode open-circuit.
Normal	Excessive	Very low—7 amps. approximately at 2,800 r.p.m.	Field diode short-circuit.

**THE ELECTRICAL SYSTEM****WIRING DIAGRAMS**

	<b>PAGE</b>
Master key to wiring diagrams .. .. .	.. Nb.II
<b>Wiring diagrams:</b>	
Mini Cooper 'S' Mk. III .. .. .	.. Nb.III
Mini 850 De-luxe Saloon, Van and Pick-up (with dynamo and toggle type switches) ..	.. Nb.IV
Mini 850 De-luxe Saloon, Van and Pick-up (with alternator and rocker type switches)	.. Nb.V
Mini 1000 Special De-luxe Saloon (with dynamo and toggle type switches) .. ..	.. Nb.VI
Mini 1000 Special De-luxe Saloon (with alternator and rocker type switches) .. ..	.. Nb.VII
Mini Clubman Saloon and Estate (with dynamo and toggle type switches) .. ..	.. Nb.VIII
Mini Clubman Saloon and Estate (with alternator and rocker type switches) .. ..	.. Nb.IX
Mini 1275 GT (with dynamo and toggle type switches) .. .. .	.. Nb.X
Mini 1275 GT (with alternator and rocker type switches) .. .. .	.. Nb.XI
Mini 1000 Saloon (CANADA) .. .. .	.. Nb.XII

## MASTER KEY TO WIRING DIAGRAMS

Several of the components listed in this key may not be fitted to individual models. Some are a special fitment to vehicles exported to certain countries or territories to conform to the mandatory requirements or legislation of those countries.


No.	Description	No.	Description
1.	Alternator or dynamo.	41.	Fuel pump.
2.	Control box.	42.	Oil pressure switch.
3.	Battery (12 volt).	43.	Oil pressure gauge or warning lamp.
4.	Starter solenoid.	44.	Ignition warning lamp.
5.	Starter motor.	45.	Headlamp flasher switch (Mini 1000 Canada).
6.	Lighting switch.	46.	Coolant temperature gauge.
7.	Headlamp dip switch.	47.	Coolant temperature transmitter.
8.	R.H. headlamp.	49.	Reverse lamp switch.
9.	L.H. headlamp.	50.	Reverse lamp.
10.	Main-beam warning lamp.	64.	Bi-metal instrument voltage stabilizer.
11.	R.H. sidelamp/parking lamp.	67.	Line fuse.
12.	L.H. sidelamp/parking lamp.	75.	Automatic transmission safety switch (when fitted).
14.	Panel lamps.	83.	Induction heater and thermostat.
15.	Number-plate lamp(s).	84.	Suction chamber heater.
16.	R.H. stop and tail lamps.	95.	Tachometer.
17.	L.H. stop and tail lamps.	110.	R.H. direction indicator repeater lamp. } when
18.	Stop lamp switch.	111.	L.H. direction indicator repeater lamp. } fitted.
19.	Fuse block.	115.	Rear window demister switch.
20.	Interior light.	116.	Rear window demister unit.
21.	R.H. door switch (and buzzer) } when fitted.	139.	Alternative connection for two-speed wiper motor and switch.
22.	L.H. door switch (and buzzer) }	150.	Rear window demist warning lamp.
23.	Horn(s).	153.	Hazard warning switch.
24.	Horn-push.	154.	Hazard warning flasher unit.
25.	Flasher unit.	158.	Printed circuit instrument panel.
26.	Direction indicator, headlamp flasher and dip switch.	159.	Brake pressure warning lamp and lamp test switch.
27.	Direction indicator warning lamp(s).	160.	Brake pressure differential switch.
28.	R.H. front direction indicator lamp.	164.	Ballast resistor.
29.	L.H. front direction indicator lamp.	168.	Ignition key audible warning buzzer.
30.	R.H. rear direction indicator lamp.	170.	R.H. front side-marker lamp.
31.	L.H. rear direction indicator lamp.	171.	L.H. front side-marker lamp.
32.	Heater or fresh air blower switch.	172.	R.H. rear side-marker lamp.
33.	Heater or fresh air blower.	173.	L.H. rear side-marker lamp.
34.	Fuel gauge.	198.	Driver's seat belt switch.
35.	Fuel gauge tank unit.	199.	Passenger's seat belt switch.
36.	Windscreen wiper switch.	200.	Passenger's seat switch.
37.	Windscreen wiper motor.	201.	Seat belt warning gearbox switch.
38.	Ignition/starter switch.	202.	Seat belt warning lamp.
39.	Ignition coil.	203.	Seat belt warning diode.
40.	Distributor.		

### CABLE COLOUR CODE


B.	Black.	N.	Brown.	U.	Blue.
G.	Green.	O.	Orange.	W.	White.
K.	Pink.	P.	Purple.	Y.	Yellow.
L.G.	Light Green.	R.	Red.		

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.


### Mini Cooper 'S' Mk. III



## Mini 850 De-luxe Saloon, Van and Pick-up (with dynamo and toggle type switches)




Mini 850 De-luxe Saloon, Van and Pick-up (with alternator and rocker type switches)






Mini 1000 Special De-luxe Saloon (with alternator and rocker type switches)



2NB033




## Mini Clubman Saloon and Estate (with dynamo and toggle type switches)






## Mini 1275 GT (with dynamo and toggle type switches)



Mini 1275 GT (with alternator and rocker type switches)





# SECTION R

## THE BODY

	SECTION
Alignment .. .. .	R.13–R14
Door frame—rear (Countryman and Traveller) .. .. .	R.8
Door locks .. .. .	R.7
Glasses	
Back-light .. .. .	R.2
Door .. .. .	R.3
Quarter-light .. .. .	R.4
Sliding (Countryman and Traveller) .. .. .	R.9
Windscreen .. .. .	R.1
Heater assembly (recirculatory type) .. .. .	R.5
Heater assembly (fresh-air type) .. .. .	R.16
Instrument panel (Mk. I models) .. .. .	R.11
Instrument nacelle (Mk. II models) .. .. .	R.18
Instruments (Mk. II models) .. .. .	R.17
Roof liner .. .. .	R.6
Speedometer (Super De-luxe and Cooper) .. .. .	R.12
Tilt frame and cover (Pick-up) .. .. .	R.10
Windscreen (Moke) .. .. .	R.15

## Section R.1

## WINDSCREEN GLASS

## Removing

1. Lift the wiper blades from the glass.
2. Prise up the end of the locking filler and pull it from the rubber channel.
3. Push the glass from inside the car and ease the rubber surround from the body.

## Refitting

4. Fit the rubber surround to the body and lubricate with soap and water.
5. Fit the glass into the lower channel of the rubber and lift the lip of the surround with the short peg of Service tool 18G 468, starting at one corner and working round.
6. Thread the locking filler through the handle and eye of the tool, insert the tool into the filler strip channel and draw the tool along the channel, feeding the filler through the tool. When cutting the filler, allow a small overlap and then force the ends into position.

## Section R.2

## BACK-LIGHT GLASS

As items 2 to 6 in 'Windscreen Glass'.

## Section R.3

## DOOR GLASSES

## Removing and refitting

Take out the screws from the lower channel and remove the glass and channel. Reverse to refit.

## Section R.4

## QUARTER-LIGHT GLASSES

## Removing (Fixed type)

1. Support the outside of the glass and hit it with the palm of the hand inside at the top, then remove the glass and rubber.

## Refitting

2. Fit the surround rubber to the glass.
3. Pass a length of thin cord round the outer channel of the surround, leaving the ends hanging down on the inside of the glass.

R.2




Fig. R.1

Use Service tool 18G 468 to ease the channel lip over the windscreen glass

4. Lubricate the body edge with soap and water, hold the glass in position, press lightly and pull the cord from inside the car to draw the lip of the rubber over the edge of the body.

## Removing (Hinged type)

5. Remove the catch from the body.
6. Open the quarter-light, ease up the seal on the body, unscrew the exposed screws securing the hinge and detach the window assembly.
7. Remove the frame from the glass after unscrewing the hinge screws at top and bottom.

## Refitting

Reverse the removal instructions.

## Section R.5

HEATER ASSEMBLY  
(Recirculatory Type)

## Initial fitting


Full instructions for fitting are contained in the heater kit.

## Removing

1. Disconnect the battery.
2. Drain the cooling system.
3. Disconnect the motor leads.
4. Slacken the demister and water hose clips.
5. Withdraw the screws securing the unit to the parcel shelf and remove.

**Refitting**

6. Reverse the removal instructions.
7. Open the heater tap on the rear of the engine and refill the cooling system.
8. Test the heater; if the water return hose does not warm up in a few minutes, there may be an airlock.
9. To clear, disconnect the return hose from the lower radiator hose and plug the hole.
10. Extend the return hose to reach the radiator filler.
11. Start up and note the flow of water from the return hose; when it is free from bubbles, switch off and reconnect.



4928

Fig. R.2

The use of the glazing tool and eye to thread the locking filler strip into the rubber channel

**Section R.6****ROOF LINER****Removal**

1. Disconnect the battery and remove the roof light.
2. Mark the position of the rear edge of the front liner on the cant rail.
3. Grip the outer edges of the liner and pull it backwards and inwards.
4. Mark the position of the front edge of the rear liner and pull it forwards and inwards.

**Refitting**

Reverse the removal instructions.

4. Extract the self-tapping screws from the edge of the door and remove the frame assembly from the panel.

**Refitting**

5. Clean off sealing compound and remake the joints.
6. Refit the frame; locate all the screws before tightening any.

**Section R.7****DOOR LOCKS****Removing**

1. Withdraw the screw securing the lock to the inner panel and the screw from the end of the locking handle spindle.
2. Slacken the screw clamping the inner lever and remove the handle and escutcheon.

**Refitting**

Reverse the removal instructions. Ensure that the inner control cable lever is fitted upright.

**Section R.9****SLIDING GLASSES  
(Countryman and Traveller)****Removing**

1. Remove the trim panel from above the sliding windows.
2. Remove the upper channels, support the inside and push the glass from the outside.

**Refitting**

3. Reverse the removal instructions.

**Section R.8****DOOR FRAME—REAR  
(Countryman and Traveller)****Removing**

The wood frame is a complete assembly.

1. Remove the rear door and take off the lock.
2. Remove the two screws from the centre of the inner door panel.
3. Remove the door sealing rubber and retaining clips.

MINI. Issue 1. 4908

**Section R.10****TILT FRAME AND COVER  
(Pick-up)**

The tilt frame and cover are supplied as a separate kit; the centre and rear hoop sockets, and the front attachment bracket for the struts, are fitted to the vehicle as original equipment.

R.3






Fig. R.3  
The tilt frame and cover assembly

- |                           |                             |                                     |
|---------------------------|-----------------------------|-------------------------------------|
| 1. Front fixing brackets. | 7. Turn-button.             | 13. Cover retaining channel.        |
| 2. Strut.                 | 8. Cover assembly.          | 14. Screw—turn-button to body side. |
| 3. Front hoop.            | 9. Adjuster plate—cable.    | 15. Eyelet—tilt cover.              |
| 4. Rear hoop.             | 10. Cover fixing cable.     | 16. Screw—lever bracket to body.    |
| 5. L.H. lever bracket.    | 11. Wing nut—strut to hoop. | 17. Spring washer.                  |
| 6. R.H. lever bracket     | 12. Hoop housing assembly.  | 18. Nut for screw.                  |

### Fitting

1. Fit the rear hoop ends into the sockets at either side of the rear end of the body. Ensure that the three brackets attached to the top of the hoop face forwards.
2. Fit the centre hoop ends into the sockets at the centre position.
3. Engage the studs of one of the struts of the hole in the centre bracket at the top of the rear hoop, the centre hole pierced in the top of the centre hoop, and the hole in the centre bracket attached to the rear of the cab at the top (see Fig. R.3). Fit a spring washer and wing nut to each stud and tighten fully (inset (A) of Fig. R.3).
4. Repeat this operation with the other two struts, using the fixing holes in the brackets and centre hoop either side of the central fixing points.
5. Place the R.H. lever bracket assembly on the rear face of the channel fixed around the rear of the cab with the drilled face of the bracket against the channel, its lower edge approximately in line with the top edge of the seam (body cross-member to cab). The lever attached to the bracket must face outwards and the lever pin must face forwards.

Mark off the position of the two holes in the drilled

face of the bracket onto the body and drill two holes  $\frac{13}{64}$  in. (5.16 mm.) diameter. Fix the bracket to the channel with two of the No. 10 panhead screws, nuts, and spring washers, the heads of the screws facing outwards (see inset (B) of Fig. R.3). Repeat this operation with the L.H. bracket on the L.H. side of the channel.

6. Lay the tilt cover, smooth face upwards, over the tilt frame with the fixing cable at the front.

Arrange the centre longitudinal seam to run centrally along the central strut and the centre transverse seam to be central about the centre hoop.

Lift the levers on the bracket to their fullest extent and hook the fixed loop in one end of the fixing cable over the pin of the corresponding lever.

Ensure that the cable running through the tilt cover is forwards of the rear edge of the channel round the outer edge of the cab for its full length. Adjust the loop at the other end of the cable until it will engage over the pin on its lever without undue slackness in the cable. The adjuster consists of a rectangular plate pierced with four holes. The cable is fed up through one hole from the rear of the plate, and then passed down through the hole below and in line along the length of the plate. The loop is formed below the plate, and the free end of the cable is then threaded through the lower vacant hole from the bottom face

of the plate, and returns down through the corresponding hole at the top. By adjusting the position of the cable in the plate the length of the cable can be varied as necessary (see inset [C] of Fig. R.3).

With both loops engaged over their respective lever pins, press down each lever in turn until it toggles over into its locked position. The cable should now be holding the front of the tilt cover firmly, and must fit snugly down in the retaining channel throughout its length.

When the adjustment of the cable is satisfactory and the cable and tilt cover are seating correctly in the channel, tuck the free end of the cable back into the tilt cover alongside the cable.

7. Arrange the tilt cover so that it lies evenly and smoothly over the tilt frame. The fixing position of the turn-buttons can be marked off, using the eyelets in the lower edges of the cover as templates.

Beginning with the extreme front eyelets, adjust the cover so that it takes its natural position and mark around the inside of the eyelet on the vertical face of the body. Hold the base of the turn-button against the body in the position so marked and mark and drill the two fixing holes, using a  $\frac{7}{8}$  in. (2.78 mm.) diameter drill. Attach the turn-button to the body with two of the No. 6 countersunk self-tapping screws provided.

Repeat this operation on the remaining turn-button positions, working from front to rear, attaching the cover to the body as the work proceeds. Repeat on the opposite side of the body, then lower the rear flap and mark off, fit the turn-button in the centre of the tailboard in the same manner.

8. Loop the short centre strap attached to the under side of the top of the cover around the central strut, and fasten the ends together with the turn-button and eyelet provided. Attach the corners of the rear flap to the side of the cover by means of the turn-buttons and eyelets provided. The two long straps at the top of the cover are for securing the rear flap when it is rolled and out of use.

3. Disconnect the oil gauge pipe and the temperature gauge wires.
4. Remove four screws and withdraw the panel with oil and temperature gauges.
5. Unscrew the knurled nuts and remove the gauges.

#### Refitting

Reverse the removal instructions.

#### Section R.12

### SPEEDOMETER (Super De-luxe and Cooper)

#### Removing

1. Remove the panel.
2. Unscrew two screws and remove the speedometer instrument panel brackets and distance pieces.
3. Disconnect the cable from the speedometer.
4. Disconnect the fuel gauge cable.
5. Pull out the bulb holders from the speedometer.
6. Withdraw the speedometer into the engine compartment.

#### Section R.13

### CHECKING BODY ALIGNMENT (Without Checking Jig)

1. Raise the vehicle and support it parallel to a level floor using the comparative measurements given on page R.11 (vertical alignment check).
2. Check the relative heights of all the intermediate points for distortion of the vehicle in the vertical plane.
3. Chalk the floor below the points shown on page R.12 (horizontal alignment check).
4. With a plumb-line, project the checking points from the vehicle onto the floor and mark the position with a pencil.
5. Mark the central points between each pair of checking points on the floor.
6. Mark the diagonals between any two pairs of points and intersections.
7. Stretch a length of chalk-covered cord so that it passes through as many of the marked central points and intersections as possible.
8. While the cord is held taut by two operators, a third should raise the cord and allow it to spring back and leave a white line on the floor. Any points through which the resulting white line does not pass will indicate the point where the underframe is out of alignment.

#### Section R.11

### INSTRUMENT PANEL (Super De-luxe, Traveller, and Countryman)

#### COOPER

#### Removing

1. Remove four screws from the front face of the shroud.
2. Withdraw the shroud and disconnect the panel light switch wires.




Fig. R.4  
The assembly of the jig components

9. Considerable deviations in the measurements given on pages R.11 and R.12 confirm body misalignment. Allowance must be made for normal manufacturing tolerances and a reasonable departure from nominal dimensions can be permitted without detriment to performance.

#### Section R.14

##### CHECKING BODY ALIGNMENT (With Checking Jig)

The equipment required for checking the body alignment consists of the basic body checking jig Service tool 18G 560, and adaptor set 18G 560 E used in conjunction with basic adaptor set 18G 560 A.

This equipment is intended to be used solely as a checking fixture, and under no circumstances must any welding or repair work be carried out on the body while it is still in position on the jig.

##### Assembling the jig

Where item numbers are quoted in this sub-section refer to Fig. R.4.

Remove the two inner socket screws from each corner plate on the front cross-member of the basic jig. Attach the two tall support pedestals (1) from adaptor set 18G 560 E to the cross-member at these points. Each pedestal is clearly R.6

labelled to show its correct location directionally. Fit the plate marked 'Forward 1' (2) from the basic adaptor set 18G 560 A and the plate marked 'Forward 2' (3) from the adaptor set 18G 560 E to the basic jig at the points indicated on the inside of the left hand side-member.

Attach the shorter pair of support pedestals (4) from adaptor set 18G 560 E to the rear of the front checking frame (13). Mount the frame with the rear pedestals on plate 1 (2) and attach the frame to the front pedestals and the rear pedestals to the plate.

Fit the two checking adaptors (5) and the two jacking screws (6) from 18G 560 E to plate 2 (3). Place the short jacking bar (7) from adaptor set 18G 560 in position on the jacking screws.

Attach the two jacking screw brackets (8) from 18G 560E to the side-member of the basic jig at the position marked 'OX' on the top of the left-hand side-member and at the corresponding position on the right-hand side-member.

Screw in the two longer jacking screws (9) from adaptor set 18G 560 A. Assemble the long jacking bar (10) from 18G 560 A and place in position on the screws.

Fit the two support pedestals (11) from 18G 560 E to the rear of the jig corner plates.

Attach the other pair of pedestals (12) from 18G 560 E to the front of the rear checking frame (14) and mount the checking frame on the rear pedestals and the side-member




Fig. R.5  
The jig checking points

of the basic jig. Do not tighten completely the pedestal to jig fixing bolts.

**NOTE.**—The rear checking frame has two alternative pairs of holes each side for attachment to the pedestals. The forward pair are for use when checking the body of a Van, Countryman or Traveller, the pair are for use when checking a Saloon body (see inset [A]).

When the assembly of the jig and adaptor sets is complete, adjust the basic jig by means of its six adjustable feet (15) (one at each corner, one on each side) until the weight is taken from the castors and the jig is level. Levelling indicators are provided, one on each side-member and one on the front cross-member.

If a fixed-position hoist is to be used to lift the body onto the jig, the jig must be levelled up in a central position under the hoist with the body already raised.

#### Checking alignment

All item numbers quoted in the following description refer to Fig. R.5.

Remove the four pins with knurled heads (12) from the top checking faces (2) of the front checking frame.

Move the rear checking frame to its most rearward position by means of the slotted holes in the base of the pedestal supports.

Lower the body squarely over the checking frames until it rests on the jacking bars.

**At no time must the weight of the body be taken by the checking frames.**

Lower the jacking bars equally, keeping the body square with the jig, until the body is lightly in contact with the top faces (2) of the front checking frame.

Insert the four pins (12) through the holes in the body and into the holes in the top faces of the front checking frame. Check the relation of the holes in the body to the plain shank of the checking pins. The ideal position is when each of the holes in the body is concentric with the shank of its checking pin (see Fig. R.6). Adjust the body on the jig until this position, or the nearest possible approach to it, has been attained.

Line up the top holes in the front checking brackets (8) of the rear checking frame with the corresponding holes in the body. Insert one of the threaded checking pins (13) in each side to check the alignment.

Move the rear checking frame forward until a parallel clearance of  $\frac{1}{8}$  in. (3.18 mm.) is obtained between the forward faces of the front checking brackets (8) and the body (a drill shank is a convenient gauge to use when checking these clearances).

Tighten down the pedestal fixing bolts, and check the relative positions of the lines scribed on the outer edge of each rear pedestal and the lines scribed on either outer edge of the jig rear corner plates (10). The ideal position is when the lines on the pedestals coincide with the central lines on the corner plates (see inset [B], Fig. R.4). The lines scribed either side of each central line show the maximum permissible limits of adjustment, and the correct clearance between the checking bracket and the body must be obtained with the adjustment set within these limits.




Fig. R.6

Showing an equal clearance around the checking pins with the body correctly aligned

Should the body be damaged in such a way that it is impossible to lower the body on the checking jig with all of the checking brackets on the rear checking frame in position, it is possible to detach either bracket by removing the hexagon-headed dowel bolt passing through the bracket, which can then be pulled off its mounting point.

After the correct location of the body on the jig has been established at the top checking faces on the front frame (2), and at the top holes of the front checking brackets (8) on the rear frame, the remaining alignment points and clearances can be checked.

The two checking holes (1) on the front member of the front checking frame, the four holes on the checking adaptors (3 and 4), and the eight holes in the front and rear checking brackets (8 and 9) on the rear checking frame should all line up by sight with their corresponding holes in the body.

A parallel clearance of  $\frac{1}{4}$  in. (6.35 mm.) must exist between the checking faces (16) on the front member of the checking frame and the body and between both faces of each checking adaptor (15) and the under side of the body floor.

Examine the clearance between the body and the front checking frame at all points, including around the sides of the frame towers. If there is a foul at any point, the body must be dressed back until a clearance is obtained.

The face of the cross-member at the rear of the front frame must have a clearance to the body on its top vertical face (6) of  $\frac{1}{8}$  in. (3.18 mm.), and  $\frac{1}{16}$  in. (1.6 mm.) clearance at the inclined face (7). Should these clearances not be present, the body must be dressed back until the requisite clearance is obtained.

A parallel clearance of  $\frac{1}{8}$  in. (3.18 mm.) must exist between the body and the checking faces of the four checking brackets (8 and 9) on the rear checking frame.

R.8

## Section R.15

### WINDSCREEN (Moke)

## Removal

1. Remove the windscreen wiper arm and blade.
2. Remove four nuts and screws.
3. Slacken the bottom retaining screws.
4. Lift the frame and glass from the vehicle.
5. Remove two screws, detach the bottom channel, and remove the glass from the frame.

## Section R.16

### HEATER ASSEMBLY (Fresh-air Type)

## Removing

1. Disconnect the battery and drain the cooling system.
2. Remove the front floor covering to avoid damage by coolant when removing the heater pipes.
3. Disconnect the two electrical snap connectors below the parcel shelf and the blower switch connection from the ignition switch.
4. Remove the demister tube covers, pull off the demister tubes and release the fresh-air intake hose.
5. Release the heater water hose clips and pull the hoses from the heater unit.
6. Slacken the nut securing the rear of the unit to the bracket, and remove the two screws beneath the parcel shelf securing the front of the heater (Fig. R.7). Lift the unit from the slotted rear brackets, hold the fingers over the matrix pipes and lift the unit out of the car. Drain the coolant from the unit.

On early models the heater unit is secured by four nuts. Lift the parcel shelf trimming and remove the nuts to withdraw the unit; distance pieces are fitted on the mounting studs.

## Heater matrix replacement

7. Slacken the screws securing the control panel, remove the end cover screws and lift off the cover complete with the blower motor.
8. Lift out the heater matrix and fit the replacement unit.
9. Reverse the procedure given in item (7).

## Heater motor replacement

10. Carry out operations 1 to 7.
11. Drill out the three Pop rivets securing the motor unit to the end cover and remove the motor.
12. Locate the replacement motor in the end cover with the wiring positioned to the top of the heater box when reassembled, and Pop rivet in position.

- Refitting the end cover is a reversal of the removal procedure. Ensure that the flap valve is located on the end cover pivot and operated correctly before refitting the heater to the car.

#### Blower switch replacement

- Remove the heater control panel and the switch securing nut. Pull the flap valve outwards, withdraw the switch and pull off the wiring connections.
- Fitting a replacement switch is a reversal of item 14.

#### Refitting

- Reverse the removal procedure and refill the radiator with coolant. Start and warm up the engine, check for leaks and correct operation of the heater assembly. Top up the coolant in the radiator to the correct level.

#### Section R.17

### INSTRUMENTS (Mk. II Models)

It is not necessary to withdraw the instrument nacelle to remove the instruments, access to these being from under the bonnet behind the carburetter.

#### Removing

##### SPEEDOMETER

- Remove the carburetter air cleaner and pull back the sound blanket from the speedometer aperture.
- Disconnect the speedometer cable and pull off the electrical connections from the rear of the instrument. Remove the two securing screws and withdraw the instrument through the aperture into the engine compartment.

##### FUEL GAUGE

- Carry out instructions 1 and 2; remove the two securing screws and lift out the fuel gauge.

##### OIL AND TEMPERATURE GAUGES

- Carry out instruction 1.
- Disconnect the electrical connections and the oil pressure gauge pipe, unscrew the knurled securing nuts and withdraw the gauges through the nacelle into the car interior.




Fig. R.7

The fresh-air heater assembly securing points (arrowed)

#### Refitting

- Refitting or replacing all units is a reversal of the removing procedure.

#### Section R.18

### INSTRUMENT NACELLE (Mk. II Models)


#### Removing

- Remove the fascia ashtray and bend up the retaining tab.
- Release the portion of the door seal covering the fascia trim liner and carefully lift the liner which is fixed by adhesive solution to the body. Ease the liner from the fascia sufficiently to gain access to the instrument nacelle securing screws.
- Remove the nacelle securing screws and lift off the nacelle complete with instruments after disconnecting the speedometer cable, oil gauge pipe and the electrical connections (see Section R.17).

#### Refitting

- Reverse the removing procedure.

**THE HEATER ASSEMBLY COMPONENTS**  
(Fresh-air Heater)




F 0042

- | No. | Description            |
|-----|------------------------|
| 1.  | Heater unit.           |
| 2.  | Cover—air intake side. |
| 3.  | Cover—motor side.      |
| 4.  | Control panel.         |
| 5.  | Matrix.                |
| 6.  | Motor.                 |
| 7.  | Seal.                  |
| 8.  | Rotor (fan).           |
| 9.  | Rotor securing ring.   |

- | No. | Description                      |
|-----|----------------------------------|
| 10. | Blower switch.                   |
| 11. | Flap valve.                      |
| 12. | Control knob.                    |
| 13. | Securing screws—side cover.      |
| 14. | Securing screws—control panel.   |
| 15. | Securing screws—heater assembly. |
| 16. | Securing nut—heater assembly.    |
| 17. | Plain washer.                    |
| 18. | Spring washer.                   |

- | No. | Description           |
|-----|-----------------------|
| 19. | Demister tubes.       |
| 20. | Demister duct—R.H.    |
| 21. | Demister duct—L.H.    |
| 22. | Water hoses.          |
| 23. | Covers—demister tube. |
| 24. | Air intake hose.      |
| 25. | 'Heat' control cable. |
| 26. | Valve—water control.  |

VERTICAL ALIGNMENT CHECK




A9006

Code Letter	Dimension	Location
A	10 $\frac{11}{16}$ in. (274.64 mm.)	Front sub-frame mounting (front)
B	16 $\frac{11}{16}$ in. (423.86 mm.)	Front sub-frame mounting (front) to wheel centre
C	1 $\frac{3}{8}$ in. (45.24 mm.)	Wheel centre to tower mounting
D	10 $\frac{3}{32}$ in. (259.56 mm.)	Front sub-frame mounting (tower) to front sub-frame mounting (extreme rear)
E	{ 80 $\frac{1}{2}$ in. (2036.37 mm.) 84 $\frac{3}{32}$ in. (2137.97 mm.)	Saloon Van, Countryman, Traveller and Pick-up } wheel-base
F	5 $\frac{3}{8}$ in. (148.43 mm.)	Body sill to datum line
G	20 $\frac{3}{4}$ in. (523.08 mm.)	Tower mounting (sub-frame) to datum line

Code Letter	Dimension	Location
H	8 $\frac{3}{4}$ in. (212.72 mm.)	Lower rear sub-frame mounting (front) to datum line
K	2 $\frac{1}{4}$ in. (57.15 mm.)	Mounting hole centres—rear sub-frame mounting (front)
L	14 $\frac{3}{8}$ in. (367.11 mm.)	Rear sub-frame mounting (front)—body face to wheel centre
M	23 $\frac{3}{4}$ in. (599.28 mm.)	Rear sub-frame mounting (front)—body face to rear sub-frame mounting (rear) forward fixing hole
N	2 $\frac{1}{4}$ in. (57.15 mm.)	Rear sub-frame mounting (rear) fixing hole hole centres
O	12 $\frac{1}{4}$ in. (310.75 mm.)	Rear sub-frame mounting (rear)—body face to datum line



## HORIZONTAL ALIGNMENT CHECK



### TRANSVERSE DIMENSIONS

**AA**  
Width between centres of the front  
sub-frame front mounting set screws  
26 in. (660.4 mm.)

**BB**  
Width between centres of the front  
sub-frame rear mounting set screws  
16¼ in. (412.75 mm.)




**CC**  
Width between centres of the rear  
sub-frame front mounting block  
lower set screws  
50½ in. (1282.7 mm.)

**DD**  
Width between centres of the rear  
sub-frame rear mounting block set  
screws  
38½ in. (977.9 mm.)

A preliminary check of the alignment can best be carried out by the system of diagonals and measurement checks from points projected onto a level floor by means of a plumb-bob.

A centre-line can then be established by means of a large pair of compasses and any deviation from correct alignment will be evident by failure of the diagonals to intersect on the centre-line or by considerable deviations in the measurements.

SUB-FRAME ALIGNMENT DIAGRAM



A2349

KEY TO DIMENSIONS

- A.  $10 \frac{1}{8}$  in.  $\pm \frac{1}{16}$  in. (276.62 mm.  $\pm \frac{1.6}{0}$  mm.).
- B.  $14 \frac{1}{8}$  in.  $\pm \frac{1}{16}$  in. (374.45 mm.  $\pm \frac{1.6}{0}$  mm.).
- C.  $2 \frac{1}{4}$  in.  $\pm .010$  in. crs. (57.15 mm  $\pm .254$  mm.).
- D. 3 in.  $\pm .010$  in. crs. (76.20 mm.  $\pm .254$  mm.).
- E.  $10 \frac{1}{32}$  in.  $\pm \frac{1}{32}$  in. (259.56 mm.  $\pm .800$  mm.).

- F.  $5 \frac{1}{2}$  in.  $\pm .010$  in. (139.7 mm.  $\pm .254$  mm.).
- G.  $1 \frac{1}{2}$  in. (38.10 mm.).
- H.  $13 \frac{1}{8}$  in.  $\pm \frac{1}{32}$  in. (346.08 mm.  $\pm .800$  mm.).
- J.  $27 \frac{1}{4}$  in.  $\pm .010$  in. (692.55 mm.  $\pm .254$  mm.).
- K.  $23 \frac{1}{8}$  in.  $\pm \frac{1}{32}$  in. (598.88 mm  $\pm .800$  mm.).

- L. 6 in.  $\pm .010$  in. (152.4 mm.  $\pm .254$  mm.).
- M.  $2 \frac{1}{4}$  in.  $\pm .010$  in. crs. (57.17 mm.  $\pm .254$  mm.).
- N.  $19 \frac{1}{4}$  in.  $\pm \frac{1}{32}$  in. (488.75 mm.  $\pm .800$  mm.).
- P.  $38 \frac{1}{2}$  in.  $\pm .010$  in. (977.5 mm.  $\pm .254$  mm.).



## SECTION Rb

### THE BODY

The information contained in this Section refers specifically to new or modified components fitted to the Mini range coincident with the introduction of NEGATIVE earth electrical systems and must be used in conjunction with Section R.

	SECTION
Bumpers .. .. .	Rb.1
Door glass .. .. .	Rb.8
Door glass channel .. .. .	Rb.10
Door glass regulator .. .. .	Rb.9
Door locks (Operation, Adjustments, Lubrication) .. .. .	Rb.5
Door locks (Removing and Refitting) .. .. .	Rb.6
Exterior door handles .. .. .	Rb.7
Fresh-air ventilation (Fascia louvres) .. .. .	Rb.4
Front grille .. .. .	Rb.2
Heater unit .. .. .	Rb.3
Roof lining (Mini Saloon Range) .. .. .	Rb.11
Roof liners (Mini Clubman Estate) .. .. .	Rb.12
Seat belts: Automatic (central console type) .. .. .	Rb.13
Static (central console type) .. .. .	Rb.14
Rear (when fitted) .. .. .	Rb.15

## Section Rb.1

**BUMPERS****Removing  
FRONT**

1. From beneath the wings, remove the two bolts securing each end of the bumper.
2. Remove the under-riders (secured by four bolts inside the front valance). Unscrew the remaining two bumper securing bolts and remove the bumper.

**REAR**

3. Remove the four securing screws from the under side of the bumper and remove it.

**Refitting****FRONT AND REAR**

4. Reverse the removing instructions.

## Section Rb.2

**FRONT GRILLE****Removing**

1. Remove the headlamp/grille extension panels (four screws securing each panel).
2. Remove the grille panel securing screws and lift the panel out of the locating holes in the lower grille panel assembly.

**Refitting**

3. Engage the lower attachment strips on the panel into the locating holes in the lower grille panel; the remainder is a reversal of the removing procedure.




Fig. Rb.1  
The heater unit securing points (arrowed)

## Section Rb.3

**HEATER ASSEMBLY****Removing**

1. Drain the cooling system (Section C.1).
2. Remove the front floor covering to avoid damage by coolant when disconnecting the heater pipes.
3. Pull the demister and air intake tubes out of the heater unit.
4. Remove the two screws (1) securing the front of the heater and slacken the nut (2) securing the rear of the unit (Fig. Rb.1).
5. Disconnect the electrical connections from the blower motor and switch.
6. Disconnect the heater water hoses, hold the fingers over the matrix pipes and lift the heater from the slotted rear bracket and out of the car. Drain the coolant from the heater.

**Dismantling****HEATER MATRIX REPLACEMENT**

7. Remove the blower switch/air distribution panel (two screws), lever off the clips securing the twin casings and separate the unit (see page Rb.3).
8. Withdraw the matrix, clean the casings and fit the replacement unit.

**BLOWER MOTOR REPLACEMENT**

9. Carry out operations 1 to 7.
10. Remove the motor assembly, withdraw each rotor from the unit and fit them to the replacement motor. Remove and connect the electrical wiring to the new unit.
11. Refit the unit into the heater casing.


**BLOWER SWITCH REPLACEMENT**

12. The blower switch can be removed without removing the heater unit as follows:  
From behind the blower switch/air distribution panel, pull off the electrical connections, and using a pair of pliers, press in the retainers on each side of the switch and manoeuvre the switch through the face of the panel.
13. Press in the replacement switch and refit the electrical connections.

**Refitting the heater**

14. Reverse the removing procedure and refill the cooling system. Start and warm up the engine, check for leaks and correct operation of the heater. Top up the coolant in the radiator to the correct level.

THE HEATER UNIT COMPONENTS



E3015

No.	Description
1.	Heater casing.
2.	Heater casing.
3.	Matrix.
4.	Blower motor.
5.	Rotor (recirculatory).
6.	Rotor securing clips.
7.	Rotor (air intake).
8.	Air distribution flap.
9.	Heater control panel.

No.	Description
10.	Blower switch.
11.	Securing screws—control panel to casing.
12.	Washers for item (11).
13.	Trunnion and screw—control lever to flap.
14.	One-way valve.
15.	Valve securing plate.
16.	Valve securing screws.
17.	Heater casing joining clips.




Fig. Rb.2  
Removing a fresh-air ventilating louver

1. Retaining ring. 2. Moulding. 3. Louvre.

### Section Rb.4

#### FRESH-AIR VENTILATION (Fascia Louvres)

##### Removing LOUVRES

1. Unscrew the louver moulding retaining ring and remove the moulding (Fig. Rb.2). Turn the ventilation louver anti-clockwise and withdraw it.

##### INTAKE HOSES

2. From beneath the wing, pull off both ends of the hose(s) from their respective units and remove the hose(s).

##### Refitting

3. Reverse the removing procedures.

### Section Rb.5

#### DOOR LOCKS (Operation, Adjustments, Lubrication)

Before attempting to remove any part of the mechanism because of faulty operation first check that the condition is not caused by bad installation.

##### Operation

1. Wind the window down and close the door.
2. Move the interior locking latch rearwards to the locked position. Check that the exterior handle push-button is inoperative and that the door is locked.
3. To unlock the door, insert the key and turn it one-quarter of a turn towards the rear of the car; open the door by depressing the exterior handle push-button.

Rb.4

4. Close the door and re-open it using the interior release lever.

**NOTE.**—The interior locking latch cannot be set in the locked position while the door is open.

##### Adjustments

##### PUSH-BUTTON PLUNGER

This is preset during manufacture to provide free button movement before the latch contactor 1 begins to operate and release from the striker before full depression (see Fig. Rb.3). However, if further adjustment of the plunger screw is required proceed as detailed below:

5. Remove the exterior door handle (see Section Rb.6).
6. Adjust the plunger screw and ensure that when the handle is refitted there is a clearance of approximately  $\frac{1}{32}$  to  $\frac{1}{16}$  in. (1 to 1.5 mm.) between the head of the screw and the contactor mechanism.

**IMPORTANT.**—The plastic bush immediately under the head of the screw must not be screwed in fully against the plastic push-button stem or the lock link cannot be operated.

##### STRIKER UNIT

Before attempting to close the door ensure that the latch disc is in the open position; if not, 'fire' the latch (using the push-button) and pull the latch disc back to the open position using a screwdriver. Do not slam the door while making adjustments as the mechanism may be strained. The striker screws (1) (see Fig. Rb.4) should be tightened sufficiently to allow the door to be closed to the fully





Fig. Rb.3  
Door handle push-button plunger adjustment

1. Latch contactor. 2. Push-button plunger screw.  
'A' =  $\frac{1}{32}$  to  $\frac{1}{16}$  in. (1 to 1.5 mm.)



MO687

Fig. Rb.4  
The door striker unit

- 1. Securing screws.
- 2. Over-travel stop.
- 3. Striker loop.

Positioning is carried out by a process of trial and error, until the door can be closed easily without rattling and no lifting or dropping of the door is apparent. When the door is closed it should be possible to press it in fractionally against its seals beyond the latched position thus ensuring that the striker is not set too far in.

**Lubrication**

The latching elements are enclosed and apart from initial lubrication during manufacture will need no further attention.

- 11. Smear with grease any moving parts of the door latch locking and release mechanism connecting points.
- 12. After assembly, introduce a few drops of 'Loclube' or a thin machine oil into the key slots.

latched position, but will allow the striker to move with the door as the door is aligned with the body.

- 7. Pull the door outwards or press it inwards (without using the press-button) until the door is in alignment with the body.
- 8. Use the push-button to open the door and pencil a line around the striker cover-plate to establish its new horizontal position.
- 9. Remove the striker plate over-travel rubber stop (2) as this tends to twist the striker during adjustment (see Fig. Rb.4).
- 10. Set the striker loop (3) at right angles to the door hinge plane before finally tightening the screws (1) (see Fig. Rb.4). The door can then be checked for 'drop' or 'lift' and if necessary the striker screws slackened again while the striker is moved vertically as required.

**Section Rb.6**

**DOOR LOCKS**

**Removing**

- 1. Remove the interior release handle, window regulator handle, and the door trim panel. Pull back the adhesive strip adjacent to the lock.
- 2. Remove the screws securing the latch unit and the lock remote control (Fig. Rb.5).
- 3. Remove the interior locking control securing screws (Fig. Rb.5).
- 4. Pull or carefully prise the bottom of the key-operated lock link (3) off the latch locking rod (4) (see Fig. Rb.6).
- 5. Ease the latch outwards, remove the circlips securing the remote control (1) and the interior locking lever (2) to the latch (see Fig. Rb.6) and withdraw both units and the latch from the door frame.




Fig. Rb.5  
Removing the latch (1),  
interior locking control (2),  
and remote control (3)

MO694






Fig. Rb.6  
Showing the locking latch connections

- |                              |                               |
|------------------------------|-------------------------------|
| 1. Remote control.           | 3. Exterior handle lock link. |
| 2. Interior locking control. | 4. Latch locking rod.         |

### Refitting

- Reverse the removing procedure, with particular attention to the following instructions.
- Refer to Fig. Rb.6. Ensure that the circlip securing the remote control lever (1) and the interior lock control lever (2) are correctly located, and that the latch locking rod (4) is engaged in the spring clip of the exterior handle lock link (3).
- Check the adjustment of the push-button plunger; see 'Adjustments' in Section Rb.5.
- Refit or fit new adhesive sealing strips to the door panel. Check the door lock operation before refitting the trim panel.
- The door striker-plate can be repositioned if required, see 'Adjustments' in Section Rb.5.

### Section Rb.7

#### EXTERIOR DOOR HANDLES

### Removing

- Remove the interior handles, door trim, and latch assembly—Section Rb.6, operations 1 to 5.
- Wind up the window, remove the exterior handle securing screws (Fig. Rb.7), and withdraw the handle from the door.

### Refitting

- Reverse the removing procedure, with particular attention to instructions 7 and 8 as detailed in Section Rb.6.

Rb.6

### Section Rb.8

#### DOOR GLASS

### Removing

- Remove the interior release handle, the window regulator handle, and the door trim panel. Pull off the adhesive sealing strips where necessary.
- Remove the outer and inner waist rail finishers (Fig. Rb.8).
- Remove the regulator assembly securing screws and use the regulator handle to raise the door glass approximately one-half of its travel (Fig. Rb.8), and use a wooden wedge or block to maintain this position whilst removing the regulator.
- Lever the regulator assembly slightly away from the door panel and turn the regulator handle until the arms are in the vertical position (see Fig. Rb.8). The regulator arms can now be disengaged from the glazing channel by moving the regulator towards the front of the door until the rear arm is free and then moving it rearwards to release the other arm.
- Release the wedge on the door glass, turn the glass as shown in Fig. Rb.8 and remove it from the door.

### Refitting

- Reverse the removing procedure, with particular attention to the following instructions.
- When refitting the door glass, ensure that it is located in the glazing channels and wedge it in the position shown in Fig. Rb.8 to facilitate engagement of the regulator arms. Apply sealer around the edge of the regulator plate.
- Ensure that the waist rail securing clips are equally spaced before refitting the finishers.
- When refitting the inner waist rail finisher, butt the forward end against the glazing channel rubber seal before attempting to refit the remainder in position.
- Refit or fit new adhesive sealing strips.




Fig. Rb.7  
The exterior handle securing screws (arrowed)




Fig. Rb.8  
Removing the door glass regulator, with insets showing the regulator arms and position of the door glass for removal

- |                               |                                 |                                  |
|-------------------------------|---------------------------------|----------------------------------|
| 1. Regulator unit.            | 3. Wedge (to secure glass).     | 5. Waist rail finisher (outer).  |
| 2. Regulator securing screws. | 4. Waist rail finisher (inner). | 6. Securing clips for finishers. |

### Section Rb.9

#### DOOR GLASS REGULATOR

##### Removing

1. Remove the interior handles, door trim, and regulator assembly—see Section Rb.8, operations 1, 3, and 4.

##### Refitting

2. Apply sealer around the edge of the regulator plate. Ensure that the lip on the front edge of the regulator is engaged inside the door frame. The remainder is a reversal of the removing procedure.

### Section Rb.10

#### DOOR GLASS CHANNEL

##### Removing

1. Follow the instructions given in Section Rb.8 for door glass removal.
2. Remove the glazing channel rubber strip and pull the channel from the door frame.

##### Refitting

3. Fit a new glazing channel into the door frame and refit the rubber securing strip.
4. The remainder is a reversal of the removal procedure as detailed in Section Rb.8, items 6 to 10.

### Section Rb.11

#### ROOF LINING (Mini Saloon range)

##### Removing

1. Disconnect the battery earth cable.
2. Disconnect and remove the roof lamp.
3. Remove both front seats and the rear seat squab (to give increased access).
4. Remove the sun visors and driving mirror.
5. Remove the front and rear screens as detailed in Sections R.1 and R.2.
6. Remove the rear quarter-light glass assemblies (hinged or fixed type).
7. Release the door seals from around the top of the door apertures.
8. The roof lining is secured with adhesive to the roof cant-rail and on the outside flanges of the front and rear screens, door and quarter-light apertures. Release the stuck down areas of the lining, pull the lining towards the front and disengage the lining support rails from the roof cant-rails.
9. Before refitting or replacing the liner remove surplus adhesive from the body using white spirit.

##### Refitting

10. If fitting a new roof liner, remove the support rails from the old liner and insert them into the new liner;

Rb.7




Fig. Rb.9

Fitting the liner support rails into the plastic locators (arrowed) of the roof cant rails




Fig. Rb.10

Cutting and sticking the liner around the screen, door and quarter light exterior flanges

the rails are colour coded and should be fitted in the following order commencing at the front: Nos. 1 (Red), 2, 3 (White), 4 (Black), 5 (Blue), and 6 (Yellow).

On earlier cars the support rails are also colour coded and are fitted from front to rear as follows: Nos. 1 (Red), 2 and 3 (Green), 4 (Blue), and 5 (Yellow).

11. Lay out the lining and apply a 4 in. (100 mm.) wide strip of Dunlop adhesive (S914 or S1022) around the edge of the lining.
12. Apply the above adhesive to the roof cant rails and to all exterior aperture flanges to which the lining is to be secured.
13. Start at the front and engage the liner support rails into the plastic locators in the roof cant rails (see Fig. Rb.9).
14. Stretch out the lining front to rear and keeping the lining taut, commence sticking the lining to the front and rear screen aperture flanges and then simultaneously to both roof cant rails.
15. Continue cutting and sticking the lining to the door and quarter light exterior flanges and trim off excess material as required.
16. Use adhesive when refitting the door seals. The remainder is a reversal of the removing procedure.
17. Water test the front screen, back-light, and the rear quarter-light ventilators.

### Section Rb.12

#### ROOF LINERS (Mini Clubman Estate)

##### Removing

1. Disconnect the battery and remove the roof light.
2. Mark the position of the rear edge of the front liner on the roof cant rail.

Rb.8

3. Grip the outer edges of the liner and pull it backwards and inwards to withdraw it.
4. Remove the trim liner from over the rear doors.
5. Mark the position of the front edge of the rear liner and pull it forward and inwards to withdraw it.

##### Refitting

6. Reverse the removing procedure items 1 to 5.

### Section Rb.13

#### AUTOMATIC SEAT BELTS (Central Console Type)

##### Removing

##### REEL ASSEMBLY—BRITAX BELTS

1. Before removing any belt fixings, attach a clip (1) to the belt just above the reel assembly to prevent the belt retracting during removal and storage. The clip (1) must not be removed until the belt assembly has been refitted, see Fig. Rb.11.
2. Withdraw most of the belt webbing from the reel and remove the locking unit retaining screw (3). Lift up the locking unit (4) to expose the reel retaining screw (2). Remove the screw (2) and detach the reel and locating bracket (5), see Fig. Rb.11.
3. Remove the screws retaining the belt brackets to the door pillar and sill. Note the assembly sequence of the distance pieces and anti-rattle washers, also the individual lengths of the fixing screws, see Figs. Rb.11 and Rb.12.




Fig. Rb.11

The Britax 'automatic type' seat belt

- |  |   |  |
|--|---|--|
| 1. Belt restraining clip.              | 7. Upper belt bracket.                  | 13. Shallow shouldered distance piece. |
| 2. Reel retaining screw.               | 8. Anti-rattle washers.                 | 14. Self-locking nut.                  |
| 3. Locking unit retaining screw.       | 9. Deep shouldered distance piece.      | 15. Centre console retaining bolt.     |
| 4. Locking unit.                       | 10. Plain distance piece.               | 16. Centre console mounting straps.    |
| 5. Reel locating bracket.              | 11. Lower belt bracket retaining screw. | 17. Fibre washers.                     |
| 6. Upper belt bracket retaining screw. | 12. Lower belt bracket.                 | 18. Centre console.                    |

## REEL ASSEMBLY—KANGOL BELTS

4. Remove the reel retaining screw (1) with the plain washer (2) and detach the reel assembly, see Fig. Rb.12.
5. Carry out operation 3.

## CENTRAL CONSOLE

6. Remove the nut and bolt retaining the central console to its mounting straps and detach the console unit.

Britax: Note that a fibre washer (17) is fitted on either side of the console and is located between the central console and the mounting strap, see Fig. Rb.11.

## MOUNTING BRACKETS—CENTRAL CONSOLE

7. Remove the carpet to obtain access to the bracket securing screws. Unscrew and remove the two securing screws (1) (with their spring washers) and detach the mounting straps (3), see Fig. Rb.15.

## Refitting

8. Reverse the order of the removing procedure, noting the following:
  - a. On the Britax belt use the short retaining screw (11) with the shallow shouldered distance piece (13) when attaching the belt bracket to the sill mounting point.

- b. Ensure that the reel locking plate is not distorted and that the threaded hole in the anchor plate is in perfect condition.
- c. The reel must be mounted at an angle of  $6\frac{1}{2}^{\circ}$  from the vertical. This is attained by the reel being mounted onto the locating bracket which has two legs and these engage the holes in the companion box.

KANGOL. Check that the 'arrow' on the side of the reel is pointing vertically. To adjust, slacken the screw (15) adjacent to the arrow, turn the arrow (16) to the vertical position and retighten the screw, see Fig. Rb.12.

- d. The reel assembly, belt brackets and central console must be refitted with the relevant component parts assembled in the order shown in Figs. Rb.11, Rb.12, Rb.13, and Rb.14.
- e. All distance pieces must make metal-to-metal contact with the body fixing points.
- f. Tighten the bolt and nut securing the central console until the unit is **lightly gripped** between the mounting straps, but can be pivoted with resistance.
- g. Tighten all belt bracket securing screws to a torque figure of 25 lb. ft. (3.5 kg. m.).
- h. Tighten the reel locking unit retaining screw (3) Fig. Rb.11 to a torque figure of 5 lb. in. (.06 kg. m.).

**NOTE.**—If the seat belts were being used whilst the car was involved in a severe impact, the complete belt assemblies must be renewed including the central console, its mounting straps and the reel-to-companion box locating bracket.

### Testing

9. With the belts being worn, drive the car at 5 m.p.h. (8 km.p.h.) and brake sharply; the automatic locking device should operate and lock the reel.

### Section Rb.14

#### STATIC SEAT BELTS (Central Console Type)

##### Removing

##### BELT FIXING BRACKETS

1. Remove the hexagon screw (1) retaining the belt bracket (2) to the sill mounting point; note the anti-rattle washer (3) and the shouldered distance piece (4), see Figs. Rb.13 and Rb.14.
2. Prise out the protective cap (5) covering the hexagon screw (6) at the pillar fixing point. Remove the screw and detach the belt bracket noting the plain washer, parking device, anti-rattle washer and shouldered distance piece on the 'Kangol' belt, and the parking device and shouldered distance piece on the 'Britax' belt, see Figs. Rb.13 and Rb.14.

##### CENTRAL CONSOLE

3. Remove the nut (10) and bolt (11) retaining the central console to its mounting straps (14) and detach the console unit.

**BRITAX.** Note that a fibre washer (12) is fitted on either side of the console and is located between the central console and the mounting strap, see Fig. Rb.13.

##### MOUNTING STRAPS—CENTRAL CONSOLE

4. Remove the carpet to obtain access to the strap securing screws. Unscrew and remove the two securing screws (1) (with their spring washers) and detach the mounting straps (3), see Fig. Rb.15.

##### Refitting

5. Reverse the order of the removing procedure, noting the following:
  - a. All distance pieces must make metal-to-metal contact with the body fixing points.
  - b. The belt brackets must be refitted with their relevant component parts assembled in the order shown in Fig. Rb.13.

Tighten the bracket securing screws to a torque figure of 25 lb. ft. (3.5 kg. m.).

  - c. Tighten the central console until the unit is **lightly gripped** between the mounting straps, but can be pivoted with resistance.

**NOTE.**—If the seat belts were being used whilst the car was involved in a severe impact, the complete belt assemblies must be renewed including the central console and its mounting straps.





Fig. Rb.12  
The Kangol 'automatic type' seat belt


- |                                    |   |   |
|------------------------------------|---|---|
| 1. Reel retaining screw.           | 6. Belt bracket retaining screws.         | 12. Centre console retaining bolt.        |
| 2. Plain washer.                   | 7. Upper belt bracket.                    | 13. Centre console mounting straps.       |
| 3. Reel assembly.                  | 8. Anti-rattle washer.                    | 14. Centre console.                       |
| 4. Reel locating bracket.          | 9. Distance piece—upper and lower fixing. | 15. Screw—(slacken for arrow adjustment). |
| 5. Plastic cover for upper fixing. | 10. Lower belt bracket.                   | 16. Vertical adjustment arrow.            |
|                                    | 11. Self-locking nut.                     |   |



D1389B

Fig. Rb.13  
The Britax 'static type' seat belt

- |  |  |                                     |
|--|--|-------------------------------------|
| 1. Lower belt bracket retaining screw. | 6. Upper belt bracket retaining screw. | 11. Centre console retaining bolt.  |
| 2. Lower belt bracket.                 | 7. Parking device.                     | 12. Fibre washers.                  |
| 3. Anti-rattle washer.                 | 8. Upper belt bracket.                 | 13. Centre console.                 |
| 4. Distance piece.                     | 9. Distance piece—upper fixing.        | 14. Centre console mounting straps. |
| 5. Protective cap.                     | 10. Self-locking nut.                  |                                     |



D1390B

Fig. Rb.14  
The Kangol 'static type' seat belt

- |                                   |                                 |                                     |
|-----------------------------------|---------------------------------|-------------------------------------|
| 1. Belt bracket retaining screws. | 5. Protective cap.              | 10. Self-locking nut.               |
| 2. Lower belt bracket.            | 6. Plain washer.                | 11. Centre console retaining bolt.  |
| 3. Anti-rattle washers.           | 7. Parking device.              | 12. Centre console.                 |
| 4. Distance piece.                | 8. Upper belt bracket.          | 13. Centre console mounting straps. |
|                                   | 9. Distance piece—upper fixing. |                                     |




Fig. Rb.15  
The centre console mounting straps

1. Securing screw.
2. Lock washer.
3. Mounting straps.

### Section Rb.15

#### REAR SEAT BELTS

(When fitted)

##### Removing

1. Remove the rear seat cushion and squab.
2. Remove the belt bracket retaining screws (1) with their spring washers (2), see Fig. Rb.16.

##### Refitting

3. Reverse the order of the removing procedure, noting that the longer section of the belt is fitted to the fixing point nearest to the centre line of the car, see Fig. Rb.16.
4. Ensure that a spring washer is fitted under the head of each bracket retaining screw; align the brackets as shown in Fig. Rb.16 and tighten the retaining screws to a torque figure of 25 lb. ft. (3.5 kg. m.).




Fig. Rb.16  
The rear seat belt mounting points and the belt components

1. Securing screws.
2. Spring washers.
3. Belt with buckle fixing (adjustable).
4. Short belt.

## SECTION S

## SERVICE TOOLS

All Service tools mentioned in this Manual are only obtainable from the tool manufacturer:

Messrs. V. L. Churchill & Co. Ltd.  
P.O. Box No. 3,  
London Road, Daventry  
Northants, England

This Section includes all Service tools for the Mini range of vehicles including the Mini-Cooper, Mini-Cooper 'S' and the 1275 GT. The tools which are only applicable to these models are shown in brackets after the 'Operation' description.

ENGINE	OPERATION	TOOL No.	PAGE No.
Camshaft liner reaming	.. .. .	18G 123 A	S.7
		18G 123 AH	S.8
		18G 123 AJ	S.8
		18G 123 AN	S.8
Camshaft liner reaming (Cooper and Cooper 'S')	.. .. .	18G 123 A	S.7
		18G 123 B	S.8
		18G 123 AN	S.8
		18G 123 AP	S.8
		18G 123 AT	S.8
		18G 123 AQ	S.8
		18G 123 BA	S.8
		18G 123 BB	S.8
Camshaft liner removing and replacing	.. .. .	18G 124 A	S.8
		18G 124 K	S.9
Camshaft liner removing and replacing (Cooper, Cooper 'S' and 1275 GT)	.. .. .	18G 124 A	S.8
		18G 124 B	S.9
		18G 124 K	S.9
		18G 124 M	S.9
Circlip removing and refitting	.. .. .	18G 257	S.10
		18G 1004	S.17
Crankshaft and camshaft gear removing	.. .. .	18G 2	S.7
		18G 98	S.7
Crankshaft primary gear oil seal removing and replacing	.. .. .	18G 134	S.9
		18G 134 BC	S.9
		18G 1043	S.18
		18G 1068	S.18
Flywheel and clutch removal (coil spring clutch)	.. .. .	18G 304	S.11
		18G 304 M	S.11
		18G 587	S.15
Flywheel and clutch removal (diaphragm spring clutch)	.. .. .	18G 304	S.11
		18G 304 N	S.11
		18G 587	S.15
Flywheel housing bearing removing and replacing	.. .. .	18G 617 A	S.16




OPERATION	TOOL No.	PAGE No.
Flywheel oil seal replacing .. .. .	{ 18G 134 18G 134 BH	S.9 S.9
Oil pump relief valve seat grinding .. .. .	18G 69	S.7
Piston refitting .. .. .	18G 55 A	S.7
Piston refitting (Cooper, Cooper 'S' and 1275 GT) .. .. .	{ 18G 55 A 18G 1150 18G 1150 A or 18G 1002	S.7 S.21 S.17
Timing cover oil seal replacing .. .. .	{ 18G 134 18G 134 BD	S.9 S.9
Timing cover refitting .. .. .	{ 18G 138 18G 1044	S.9 S.18
Torque setting nuts and bolts .. .. .	{ 18G 372 18G 536 18G 537 18G 592	S.11 S.12 S.12 S.15
Valve removing and refitting .. .. .	18G 45	S.7
Valve grinding-in .. .. .	18G 29	S.7
Valve seat cutting .. .. .	{ 18G 27 18G 167 18G 167 A 18G 167 B 18G 167 C 18G 167 D	S.7 S.9 S.9 S.10 S.10 S.10
<b>FUEL SYSTEM</b>		
Fuel tank gauge unit removing and refitting .. .. .	18G 1001	S.17
Mechanical fuel pump testing .. .. .	18G 1116	S.20
Mechanical fuel pump oil seal removing and replacing .. .. .	18G 1119	S.21
<b>CLUTCH</b>		
Clutch dismantling and reassembling (coil spring clutch) .. .. .	{ 18G 304 M 18G 571	S.11 S.12
Clutch dismantling and reassembling (coil spring clutch—Cooper) .. .. .	{ 18G 304 M 18G 684	S.11 S.16
Clutch dismantling and reassembling (diaphragm spring clutch) .. .. .	{ 18G 304 N 18G 571	S.11 S.12
Clutch dismantling and reassembling (diaphragm spring clutch—Cooper, Cooper 'S' and 1275 GT) .. .. .	{ 18G 304 N 18G 684	S.11 S.16
Clutch housing cover — alignment .. .. .	18G 1247	S.22

OPERATION	TOOL No.	PAGE No.
<b>TRANSMISSION UNIT</b>		
Change speed shaft oil seal replacement .. .. .	18G 573	S.13
Circlip removing and refitting .. .. .	{ 18G 257 18G 1004	S.10 S.18
Final drive gear removing and refitting .. .. .	{ 18G 586 18G 587	S.15 S.15
First and third motion shaft bearing replacement .. .. .	18G 579	S.14
First motion shaft and bearing removing .. .. .	{ 18G 284 18G 284 B	S.11 S.11
First motion shaft bearing circlip—checking for correct thickness circlip .. .. .	18G 569	S.12
First motion shaft needle-roller bearing removing and replacing .. .. .	{ 18G 581 18G 581 B 18G 589	S.14 S.14 S.15
Idler gear bearing removing and replacing (3-speed synchromesh) .. .. .	{ 18G 581 18G 582	S.14 S.14
Idler gear bearing removing and replacing (4-speed synchromesh) .. .. .	18G 1126	S.21
Laygear needle-roller bearing replacement .. .. .	18G 194	S.10
Layshaft reassembly .. .. .	18G 471	S.12
Synchromesh unit assembling .. .. .	18G 572	S.13
Third motion shaft bearing removing (3-speed synchromesh) .. .. .	18G 613	S.15
Third motion shaft bearing removing (4-speed synchromesh) .. .. .	18G 1127	S.20
Torque setting nuts and bolts .. .. .	{ 18G 372 18G 536 18G 537	S.11 S.12 S.12
<b>DIFFERENTIAL UNIT</b>		
Differential bearing removing and replacement .. .. .	{ 18G 2 18G 2 G 18G 578	S.7 S.7 S.14
Differential assembly removing and refitting (Rod change type transmission) .. .. .	18G 1236	S.21
Differential end cover oil seal replacement (Rod change type transmission) .. .. .	18G 1238	S.22
Drive shaft coupling flange removing and refitting .. .. .	18G 669	S.16
Torque setting nuts and bolts .. .. .	{ 18G 372 18G 537	S.11 S.12
<b>AUTOMATIC TRANSMISSION</b>		
Auxiliary pump and governor assembly removing and refitting .. .. .	{ 18G 1094 18G 1097 18G 1106	S.19 S.20 S.20
Converter housing oil seal replacing .. .. .	{ 18G 1068 18G 1068 A 18G 1087	S.18 S.18 S.19

OPERATION	TOOL No.	PAGE No.
Converter housing removing and refitting .. .. .	{ 18G 1088 18G 1098	S.19
		S.20
Converter removing and refitting .. .. .	{ 18G 587 18G 1086	S.15
		S.19
Differential drive shaft coupling removing .. .. .	18G 1100	S.20
Forward clutch dismantling and reassembling .. .. .	18G 1102	S.20
Forward clutch hub nut removing and refitting .. .. .	{ 18G 1095 18G 1096	S.19
		S.19
Gear carrier assembly dismantling and reassembling (early-type units) ..	18G 1093	S.19
Gear carrier assembly dismantling and reassembling (later-type units)	{ 18G 284 AJ 18G 1093 A	S.11
		S.19
Idler and input gears—checking adjustment .. .. .	{ 18G 1089 18G 1089.A	S.19
		S.19
Pressure and stall checks .. .. .	{ 18G 677 C 18G 677 Z	S.16
		S.16
Converter output gear oil seal removing and replacing .. .. .	{ 18G 134 18G 134 CN	S.9
		S.9
Top and reverse clutch dismantling and reassembling .. .. .	18G 1103	S.20
Top and reverse clutch hub removing and refitting .. .. .	{ 18G 1095 18G 1096	S.19
		S.19
Torque setting .. .. .	{ 18G 372 18G 537 18G 592	S.11
		S.12
		S.15
<b>DRIVE SHAFTS</b>		
Constant velocity joint—checking ball cage and inner race .. .. .	{ 18G 1012 18G 1099	S.18
		S.20
Drive shaft removing and refitting .. .. .	{ 18G 1063 18G 304 or 18G 304 Z 18G 304 F	S.18
		S.11
		S.11
		S.11
● Drive shaft or offset sphere inboard joint removing and refitting ..	{ 18G 1240 18G 1241 18G 1243	S.22
		S.22
		S.22
Offset sphere inboard joint rubber boot replacement (fitting the small endless clip) .. .. .	18G 1251	S.22 ●
Torque setting .. .. .	18G 372	S.11
<b>REAR SUSPENSION</b>		
Displacer unit or strut removing and refitting .. .. .	18G 703	S.17
Hub bearing outer race removing .. .. .	{ 18G 260 18G 260 C	S.10
		S.10
Hub removing .. .. .	{ 18G 304 or 18G 304 Z 18G 304 F	S.11
		S.11
		S.11


OPERATION	TOOL No.	PAGE No.
Hydrolastic suspension—checking pressure .. .. .	{ 18G 685 18G 703	S.17 S.17
Hydrolastic suspension—depressurizing, evacuating, and pressurizing ..	.. 18G 703	S.17
Radius arm bush reaming .. .. .	{ 18G 588 18G 588 A	S.15 S.15
Radius arm bushes removing and replacing .. .. .	{ 18G 583 18G 584	S.14 S.15
Radius arm needle bearing removing and replacing .. .. .	{ 18G 583 18G 583 B 18G 620	S.14 S.15 S.16
Radius arm (Hydrolastic suspension) removing and refitting .. ..	.. 18G 703	S.17
Sub-frame (Hydrolastic models) removing and refitting .. .. .	.. 18G 703	S.17
 <b>STEERING GEAR</b>		
Steering-column bush (upper) removing and replacing .. .. .	.. 18G 1191	S.21
Steering rack dismantling and reassembling .. .. .	{ 18G 207 18G 207 A 18G 707	S.10 S.10 S.17
Steering rack tie-rod ball joint removal .. .. .	.. 18G 1063	S.18
Torque setting .. .. .	{ 18G 372 18G 537	S.11 S.12
 <b>FRONT SUSPENSION</b>		
Displacer unit or strut removing and refitting .. .. .	.. 18G 703	S.17
Hydrolastic suspension—checking pressure .. .. .	{ 18G 685 18G 703	S.17 S.17
Hydrolastic suspension—depressurizing, evacuating, and pressurizing ..	.. 18G 703	S.17
Lower arm removal .. .. .	.. 18G 1063	S.18
Spring unit or strut (Rubber suspension models) removing and refitting	{ 18G 574 B 18G 1063	S.13 S.18
Swivel hub joint removing and replacing .. .. .	{ 18G 587 18G 1063	S.15 S.18
Swivel hub dismantling, fitting bearings, and reassembling .. ..	{ 18G 304 or 18G 304 Z 18G 304 F 18G 575 18G 260 18G 260 H	S.11 S.11 S.11 S.14 S.10 S.10

OPERATION	TOOL No.	PAGE No.
Swivel hub driving flange removing (without dismantling the swivel hub)	18G 284	S.11
	18G 304 or	S.11
	18G 304 Z	S.11
	18G 304 F	S.11
	18G 304 P	S.11
Swivel hub oil seal (inner), replacing .. .. .	18G 134 DO	S.9
Swivel hub outer oil seal replacing .. .. .	18G 284	S.11
	18G 304 or	S.11
	18G 304 Z	S.11
	18G 304 F	S.11
	18G 304 P	S.11
	18G 705	S.17
18G 705 B	S.17	
Swivel hub removing and refitting .. .. .	18G 1063	S.18
Torque setting nuts and bolts .. .. .	18G 372	S.11
	18G 537	S.12
Upper arm (Hydrostatic suspension models) removing, dismantling and reassembling .. .. .	18G 581	S.14
	18G 582	S.14
	18G 582 A	S.14
	18G 703	S.17
	18G 1063	S.18
Upper arm (rubber suspension models) removing, dismantling, and re-assembling .. .. .	18G 574 B	S.13
	18G 581	S.14
	18G 582	S.14
	18G 582 A	S.14
	18G 1063	S.18
<b>BRAKING SYSTEM</b>		
Brake adjusting .. .. .	18G 619 A	S.16
Disc brake piston seal replacing (Cooper, Cooper 'S' and 1275 GT) ..	18G 672	S.16
<b>BODY</b>		
Body alignment checking .. .. . Existing alternative to 7-700 range.	18G 560	S.13
	18G 560 A	S.13
	18G 560 E	S.13
Body alignment checking (not illustrated) .. .. .	Churchill 7-700	
This jig is available with various adaptors for model ranges. The operating notes supplied with the jig adaptors must be used instead of the instructions given in Section R.14, which refer to the existing jig 18G 560 only.		
Door hinge screws removing and refitting (doors with wind-up windows) ..	18G 1188	S.21
Windscreen and back-light glass refitting .. .. .	18G 468	S.12
	18G 468 A	S.12




MO827

18G 2. Crankshaft Gear and Pulley Remover




I NA 038

18G 45. Valve Spring Compressor




3NAO25

18G 2 G. Differential Shaft Bearings Remover – Adaptor




MO836

18G 27. Valve Seat Cutter Handle




MO804

18G 55 A. Piston Ring Compressor




MO842

18G 29. Valve Suction Grinder




I NA 042

18G 98 A. Crankshaft Nut Spanner



I NA 024

18G 69. Oil Pump Release Valve Grinding-in Tool




I NC 102

18G 123 A. Camshaft Liner Reamer (basic tool)



I NA 014

18G 123 AH. Camshaft Liner Reamer Pilot—Centre




I NA 019

18G 123 B. Camshaft Liner Reamer Cutter




I NA 014

18G 123 AJ. Camshaft Liner Reamer Pilot—Rear



I NA 017

18G 123 BA. Camshaft Liner Reamer Pilot—Rear




I NA 019

18G 123 AN. Camshaft Liner Reamer Cutter—Front



I NA 016

18G 123 BB. Camshaft Liner Reamer Pilot—Rear




I NA 027

18G 123 AP. Camshaft Liner Reamer Cutter—Rear




I NA 014

18G 123 BC. Camshaft Liner Reamer Pilot—Front




I NA 015

18G 123 AQ. Camshaft Liner Reamer Pilot—Front



I NA 017

18G 123 AT. Camshaft Liner Reamer Pilot—Centre




I NC 104

18G 124 A. Camshaft Liner Remover and Replacer (basic tool)




A4933

18G 124 B. Camshaft Liner Remover Adaptor




A1429A

18G 134 BH. Flywheel and Front Hub Oil Seal Replacer Adaptor



A4933

18G 124 K. Camshaft Liner Remover Adaptor




A6720

18G 134 CN. Replacer Oil Seal Stator Carrier



A4933

18G 124 M. Camshaft Liner Remover Adaptor




INC537

18G 134 DO. Swivel Hub Oil Seal Replacer (Inner oil seal with water shield.)




829XX

18G 134. Bearing and Oil Seal Replacer (basic tool)




8138

18G 138. Crankshaft Gear and Pulley Replacer




A1430

18G 134 BC. Crankshaft Primary Gear Oil Seal Replacer Adaptor




18G 167. Valve Seat Finishing Cutter



A1424


18G 134 BD. Timing Case Oil Seal Replacer Adaptor



9145A


18G 167 A. Valve Seat Glaze Breaker






9021B

18G 167 B. Valve Seat Narrowing Cutter—Top




DO624

18G 207 A. Steering Rack Pinion Preload Adaptor



9 021A


18G 167 C. Valve Seat Narrowing Cutter—Bottom



18G 257. Circlip Pliers—Large




18G 167 D. Valve Seat Cutter Pilot




4350E

18G 260. Hub Bearing Outer Race Remover (basic tool)




9172

18G 194. Laygear Needle-roller Bearing Replacer




4349E

18G 260 C. Hub Bearing Outer Race Remover Adaptor




18G 207. Bearing Preload Gauge




A1423


18G 260 H. Front Hub Drive Flange Bearing Outer Race Remover Adaptor




18G 284. Impulse Extractor (basic tool)




18G 284 AJ. Planetary Gear Spindles Remover Adaptor




18G 284 B. First Motion Shaft Remover Adaptor




18G 304. Front and Rear Hub Remover (basic tool)




18G 304 F. Front and Rear Hub Remover Bolt Adaptor  
MINI. Issue 2. 16495




18G 304 M. Flywheel and Clutch Remover Adaptor




18G 304 N. Flywheel and Clutch Remover Adaptors




18G 304 P. Drive Flange Remover Adaptor



18G 304 Z. Hub Remover-Hydraulic (basic tool)



18G 372. Torque Wrench-30 to 140 lb. ft. (4 to 20 kg.m.)




AD994

### 18G 468. Rubber Moulding Glazing Tool


The tool comprises:

- |            |          |          |
|------------|----------|----------|
| 1. Handle. | 3. Post. | 5. Hook. |
| 2. Key.    | 4. Eye.  |          |




44414

### 18G 468 A. Rubber Moulding Glazing Tool Adaptor




04579

### 18G 471. Dummy Layshaft



A7042


### 18G 502 K. Pressure Hose (8 ft.) with Adaptor



44445


### 18G 536. Torque Wrench—20 to 100 lb. in. (2 to 8 lb. ft.) (300 to 1200 gm.m.)

### 18G 537. Torque Wrench—10 to 50 lb. ft. (2 to 7 kg. m.)



A1437


### 18G 569. First Motion Shaft Bearing Circlip Gauge



44604


### 18G 502 A. Hydraulic Pressure Gauge

S.12




A1443

### 18G 571. Clutch Centralizer




18G 560 E. Body Checking Jig Adaptor Set



18G 572. Synchromesh Unit Assembly Ring


18G 574 B. Suspension Rubber Spring Compressor

18G 573. Change Speed Shaft Oil Seal Replacer




A1427

18G 575. Front Hub Drive Flange Remover




A4464

18G 581 B. First Motion Shaft Spigot Bearing Remover Adaptor




A1425

18G 578. Differential Bearing Replacer




A1441

18G 582. Front Suspension and Idler Gear Bearing Replacer




A1422

18G 579. First and Third Motion Shaft Bearing Replacer




A1439

18G 582 A. Front Suspension and Idler Gear Needle Bearing Replacer Adaptor




A1433

18G 581. Front Suspension and Idler Gear Needle-bearing Remover




A1438

18G 583. Rear Radius Arm Bush Remover.




A4464A

18G 583 B. Rear Radius Arm Needle Bearing Remover Adaptor




18G 588. Rear Radius Arm Bush Reamer




A1428

18G 584. Rear Radius Arm Bush Replacer




A4745

18G 588 A. Reamer Guide Bush




A1822

18G 589. First Motion Shaft Spigot Bearing Replacer




A1442

18G 586. Final Drive Gear Nut Spanner



9800

18G 592. Torque Wrench—50 to 225 lb. ft. (5 to 30 kg. m.)




A1426

18G 587. Swivel Hub Ball Pin Nut Spanner




A4725


18G 613. Third Motion Shaft Bearing Remover




**18G 617 A. Flywheel Housing Bearing (First Motion Shaft) Outer Race Remover/Placer**




**18G 672. Disc Brake Piston Seal Replacer**




**18G 619 A. Brake Adjusting Spanner**




**18G 677 C. Pressure Test Equipment Adaptor**




**18G 620. Rear Radius Arm Needle Bearing Replacer**




**18G 677 Z. Pressure Test and Tachometer Equipment**



**18G 669. Drive Shaft Coupling Flange Wrench**  
S.16




**18G 684. Clutch Centralizer**




A4988

18G 685. The Hydrolastic Hand Pump




A5787

18G 705 B. Bearing Centre Race Remover Adaptor




A725A

18G 703. The Hydrolastic Suspension Service Unit




18G 707. Steering Rack Ball Joint Spanners



DO740


18G 1001. Gauge Locking Ring



A9512

18G 705. Bearing Centre Race Remover (basic tool)


MINI. Issue 2. 81601




A.6917

18G 1002. Gudgeon Pin Removing and Replacing Tool  
Existing alternative to 18G 1150.







18G 1004. Circlip Pliers




18G 1063. Steering Arm and Swivel Hub Ball Pin Remover




18G 1012. Selection Gauge—Constant Velocity Joint




18G 1068 B. Remover and Replacer (basic tool)




18G 1043. Crankshaft Primary Gear Oil Seal Protector Sleeve



18G 1068 A. Adaptor Set—Replacer Converter Housing Oil Seal. Use with 18G 1068




18G 1044. Engine Front Cover Centralizer  
S.18




18G 1086. Converter Remover

A6788.




18G 1093. Dummy Shaft-Forward Gear Carrier Assembly

A6789




18G 1087. Converter Housing Oil Seal Remover

A6725




18G 1093 A. Dummy Shaft-Forward Gear Carrier

D0856




18G 1088. Converter Output Gear Holding Tool

A6727A




18G 1094. Positioning Fixture-Oil Pump Pipes

A6787




18G 1089. Idler and Input Gear Gauge Kit

A6784




18G 1095. Holder-Top and Reverse Clutch Hub

A6788




18G 1089 A. Input Gear Gauge Kit Adaptor

D 0309




18G 1096. Socket Spanner-Forward Clutch Hub Nut


A6789




18G 1097. Retainer—Forward Clutch




18G 1102. Replacer—Forward Clutch Piston Seal




18G 1098. Protector Sleeve—Converter Output Gear Oil Seal




18G 1103. Replacer—Reverse Clutch Piston Seal




18G 1099. Pliers—Retaining Clip—Drive Shaft Boots




18G 1106. Centralizer—Governor Housing




18G 1100. Wrench—Drive Shaft Coupling Flange  
S.20




18G 1116. Test Gauge—Mechanical Fuel Pump.




18G 1119. Mechanical Fuel Pump Oil Seal Retainer-Remover/Replacer




18G 1150 A. Gudgeon Pin Remover/Replacer Adaptor




18G 1126. Idler Gear Bearing Remover/Replacer (Four-speed synchromesh transmission only.)




18G 1188. Door Hinge Screws Remover/Replacer




18G 1127. Third Motion Shaft Bearing Remover (Use on four-speed synchromesh transmission.)




18G 1191. Steering-column Bush (Upper) Remover/Replacer




18G 1150. Gudgeon Pin Remover/Replacer (basic tool) (18G 1002 existing alternative.)




18G 1236. Selector Shaft Seal Protector and Replacer




18G 1238. Differential End-cover Seal Replacer




18G 1243. Separator Drive Shaft from Inboard Joint




18G 1240. Drive Shaft Assembly Remover



18G 1247. Clutch Housing Cover Alignment Gauge



18G 1241. Drive Shaft Circlip Compressor



18G 1251. Inboard Joint Boot Retaining Clip Fitting Tool

# SECTION T

## EMISSION CONTROL

This section contains information and servicing instructions for the exhaust emission, crankcase emission, and evaporative loss control systems fitted to 1975 vehicles onwards, to conform with the Canadian Federal Motor Vehicle Safety Act.

The sequence numbers in each Section identifies the components numbered in the appropriate illustration.

	SECTION
Adsorption canister – remove and refit .. .. .	T.16
Air manifold – remove and refit .. .. .	T.10
Air pump – remove and refit .. .. .	T.5
Air temperature control valve – check, remove and refit .. .. .	T.11
Carburetter – tuning .. .. .	T.17
Check valve – remove, check, refit .. .. .	T.9
Cylinder head assembly – remove and refit .. .. .	T.18
Diverter valve – checking, remove and refit .. .. .	T.8
Drive belts – remove and refit .. .. .	T.4
Engine tuning data .. .. .	T.2
Emission control systems – general description .. .. .	T.3
Fuel line filter – remove and refit .. .. .	T.15
Gulp valve	
– testing .. .. .	T.6
– remove and refit .. .. .	T.7
Hot air duct – remove and refit .. .. .	T.14
Service operations summary .. .. .	T.1
Throttle damper	
– check and adjust .. .. .	T.12
– remove and refit .. .. .	T.13
Wiring diagram – 1975 model year on .. .. .	End of section

### Section T.1

### SERVICE OPERATIONS SUMMARY

The maintenance summary on this and the following pages is the minimum service required to maintain your vehicle under normal driving conditions. For other than normal driving conditions, and those caused by seasonal changes, we recommend that you consult your Dealer.

**NOTE:** The service intervals are based on an annual mileage of approximately 12,500 miles. Should the vehicle complete substantially less miles than this per annum, it is recommended that a 'C' service is completed at six-month intervals, and a 'D' service at twelve-month intervals.

Service	Mileage x 1000	Monthly intervals
A	1	After Sales Service
B	3, 9, 16, 22, 28, 34, 41, 47	3
C	6, 19, 31, 44	6
D	12.5, 37.5	12
E	25, 50	24

† These items are emission related



#### LUBRICATION

- Lubricate all grease points including hand brake mechanical linkage and cable guides.....
- Renew engine oil filter.....
- Renew engine oil.....
- Check/top up engine oil.....
- Lubricate all locks and hinges except steering lock.....
- † Lubricate accelerator control linkage and pedal pivot; check operation.....

#### ENGINE

- Check/top up cooling system.....
- Check cooling and heater systems for leaks, hoses and pipes for security and condition.....
- † Check all driving belts; adjust or renew.....
- † Check exhaust system for leaks and security.....
- Check security of engine bolts and mountings.....
- † Check/adjust torque of cylinder head nuts.....
- † Check/adjust valve clearances.....
- † Check/adjust air injection system hoses for security.....
- † Check air injection hoses/pipes for condition and security; rectify if necessary.....
- † Check gulp valve, check valve and air diverter valve operations; rectify/renew if necessary.....
- † Check crankcase breathing and evaporative loss systems, check hoses/pipes and restrictor for security, condition and blockage; rectify if necessary.....
- Check/adjust clutch return stop clearance.....

#### IGNITION SYSTEM

- † Check ignition wiring for fraying, chafing and deterioration; rectify if necessary.....
- † Check/adjust ignition timing and dwell angle using electronic equipment.....
- † Check distributor cap, check for cracks and tracking.....

	A	B	C	D	E
Lubricate all grease points including hand brake mechanical linkage and cable guides.....	X	X	X	X	X
Renew engine oil filter.....			X	X	X
Renew engine oil.....	X		X	X	X
Check/top up engine oil.....	X	X	X	X	X
Lubricate all locks and hinges except steering lock.....	X		X	X	X
† Lubricate accelerator control linkage and pedal pivot; check operation.....	X		X	X	X
Check/top up cooling system.....	X	X	X	X	X
Check cooling and heater systems for leaks, hoses and pipes for security and condition.....	X		X	X	X
† Check all driving belts; adjust or renew.....	X	X	X	X	X
† Check exhaust system for leaks and security.....	X	X	X	X	X
Check security of engine bolts and mountings.....	X				
† Check/adjust torque of cylinder head nuts.....	X				
† Check/adjust valve clearances.....	X			X	X
† Check/adjust air injection system hoses for security.....	X				
† Check air injection hoses/pipes for condition and security; rectify if necessary.....				X	X
† Check gulp valve, check valve and air diverter valve operations; rectify/renew if necessary.....				X	X
† Check crankcase breathing and evaporative loss systems, check hoses/pipes and restrictor for security, condition and blockage; rectify if necessary.....				X	X
Check/adjust clutch return stop clearance.....		X	X	X	X
† Check ignition wiring for fraying, chafing and deterioration; rectify if necessary.....	X			X	X
† Check/adjust ignition timing and dwell angle using electronic equipment.....	X		X	X	X
† Check distributor cap, check for cracks and tracking.....				X	X

	A	B	C	D	E
<b>IGNITION SYSTEM</b> – continued					
†Lubricate distributor .....	X		X	X	X
†Renew contact breaker points .....				X	X
†Clean and adjust spark plugs .....			X		
†Renew spark plugs .....				X	X
†Check coil performance on oscilloscope .....				X	X
<b>FUEL SYSTEM</b>					
†Check fuel system for leaks .....	X	X	X	X	X
†Top up carburettor piston damper .....	X			X	X
†Check condition of fuel filler cap seal .....				X	X
†Renew fuel line filter .....				X	X
†Renew carburettor air filter element .....				X	X
†Check air intake temperature control system .....				X	X
†Renew adsorption canister .....					X
†Check/adjust crankcase breathing and evaporative loss system hoses for security .....	X				
†Check/adjust carburettor idle settings .....	X			X	X
<b>SAFETY</b>					
Check all fluid reservoirs; brake, clutch, battery and windscreen washer .....	X	X	X	X	X
Check visually hydraulic pipes and unions for chafing, leaks and corrosion .....	X	X	X	X	X
Check brake linings for wear and drums for condition; rectify/renew if necessary .....				X	X
Check/adjust foot and hand brakes .....	X	X	X	X	X
Check condition and security of steering unit, joints and gaiters .....	X	X	X	X	X
Check suspension dampers and steering rack for oil leaks .....	X	X	X	X	X
Check/adjust tightness of steering-column clamp bolt .....			X	X	X
Check/adjust security of suspension fixings .....	X		X	X	X
Check/adjust tyre pressures, including spare .....	X	X	X	X	X
Check/adjust front wheel alignment .....	X		X	X	X
Check tightness of road wheel fastenings .....	X	X	X	X	X
Check tyres comply with manufacturer's specification .....		X	X	X	X
Check tyres for tread depth, visually for cuts in tyre fabric, exposure of ply or cord structure, lumps or bulges .....	X	X	X	X	X
Check output of charging system .....	X		X	X	X
Check function of original equipment, i.e. interior and exterior lamps, horns, warning indicators, wipers and washers .....	X	X	X	X	X
Check instrumentation .....	X		X	X	X
Check, if necessary renew, wiper blades .....		X	X	X	X
Check/adjust headlamp alignment .....	X	X	X	X	X
Check operation of all door locks and window controls .....	X			X	X
Check condition and security of seats, seat belts, and seat belt warning system .....			X	X	X
<b>TEST</b>					
Road/roller test and check operation of all instrumentation; report additional work required .....	X		X	X	X

**SUPPLEMENT****Brakes**

Every 19,000 miles or 1½ years, whichever is the sooner, renew the brake fluid.

Every 37,500 miles or 3 years, whichever is the sooner, renew all fluid seals and flexible hoses in the brake and clutch systems. Examine working surfaces of pistons and bores in master, slave and wheel cylinders and renew parts where necessary.



## Section T.2

## ENGINE TUNING DATA

Model: **MINI 1000 (CANADA)**Year: **1975 on****ENGINE**

Type	.. .. .	99H 834 V.
Capacity	.. .. .	998 c.c. (60.96 cu.in.).
Compression ratio	.. .. .	8.3 : 1.
Firing order	.. .. .	1, 3, 4, 2.
Compression pressure (cranking)	.. .. .	120 lb/sq. in. (8.44 kg./cm <sup>2</sup> ).
Idling speed	.. .. .	850 ± 100 r.p.m.
Fast idle speed	.. .. .	1,250 ± 100 r.p.m.
Ignition tuning:		
Stroboscopic at 1,500 r.p.m. *	.. .. .	8° B.T.D.C.
Timing marks	.. .. .	Dimples on timing wheels, marks on flywheel.
Valve rocker clearance (warm)	.. .. .	.012 in. (.30 mm.).

**DISTRIBUTOR**

Make/type	.. .. .	Lucas 43D4.
Rotation of rotor	.. .. .	Anti-clockwise.
Dwell angle	.. .. .	51° ± 5°
Contact breaker gap	.. .. .	.014 to .016 in. (.35 to .40 mm.).
Condenser capacity	.. .. .	.18 to .24 mF.
Serial No.	.. .. .	41404.

**Centrifugal advance**

Decelerating check*	.. .. .	18° to 22° at 4,000 r.p.m. 11° to 15° at 2,800 r.p.m. 4° to 8° at 1,600 r.p.m. 0° to 3° at 800 r.p.m.
No advance below	.. .. .	300 r.p.m.

\* Crankshaft degrees and r.p.m.

**SPARK PLUGS**

Make/type	.. .. .	Champion N-9 Y.
Gap	.. .. .	.025 in. (.65 mm.).

**IGNITION COIL**


Make/type	.. .. .	A.C. Delco or Lucas 11C 12.
Primary resistance at 20°C (68°F)	.. .. .	1.43 to 1.58 ohms.
Consumption—ignition on	.. .. .	4.5 to 5 amps.
Ballast resistance	.. .. .	1.3 to 1.4 ohms.

**CARBURETTER**

Make/type	.. .. .	S.U. HS4.
Type specification	.. .. .	FZX 1016.
Choke diameter	.. .. .	1½ in. (38 mm.).
Jet size	.. .. .	.090 in. (3 mm.).
Needle	.. .. .	ADD.
Piston spring	.. .. .	Red.
Initial jet adjustment	.. .. .	11 flats from bridge.
Throttle to damper	.. .. .	.080 in. (2.0 mm.).
Fuel minimum octane setting	.. .. .	91.

**EXHAUST EMISSION**

Exhaust gas content (carbon monoxide) at engine idle speed	.. .. .	5% ± ½%.
--	---------	----------



SNC 268

THE EMISSION CONTROL COMPONENTS

- |                                 |  |  |
|---------------------------------|--|--|
| 1. Air pump                     | 8. Air diverter valve signal pipe (from carburettor) | 13. Carburettor air cleaner                            |
| 2. Air pump filter              | 9. Gulp valve  | 14. Air temperature control device                     |
| 3. Air pump relief valve        | 10. Gulp valve signal pipe                           | 15. Hot air duct                                       |
| 4. Restrictor (gulp valve line) | 11. Air diverter control valve                       | 16. Shroud (hot air duct)                              |
| 5. Air diverter valve           | 12. Carburettor                                      | 17. Manifold vacuum pipe to air diverter control valve |
| 6. Check valve                  |  |  |
| 7. Air manifold                 |  |  |

## Section T.3

## EMISSION CONTROL SYSTEMS

## EXHAUST EMISSION

Air is pressure-fed from an air pump via an injection manifold to the cylinder head exhaust port of each cylinder. A check valve in the air delivery pipe prevents blow-back from high pressure exhaust gases. The pump also supplies air through a gulp valve to the inlet manifold to provide air during conditions of deceleration and engine over-run.

**IMPORTANT:** The efficient operation of the system is dependent on the engine being correctly tuned. The ignition and spark plug settings, valve clearances, and carburettor adjustments given for a particular engine (see 'ENGINE TUNING DATA') must be strictly adhered to at all times.

## Air pump

The rotary vane type air pump is mounted on the front of the cylinder head and is belt driven from the water pump pulley. Provision is made for tensioning the belt.

Air is drawn into the pump through an extraction filter. A relief valve in the pump discharge port allows excessive air pressure at high engine speeds to discharge to the atmosphere.

## Diverter valve

The vacuum operated diverter valve, fitted between the pump and the check valve, is actuated by a vacuum switch operated by the mixture control (choke) mechanism. During choke operation the air injection is cut off and air pressure is diverted to atmosphere.

## Check valve

The check valve, fitted in the pump discharge line to the injection manifold, protects the pump from the back-flow of exhaust gases.

The valve shuts if the air pressure ceases while the engine is running; for example, if the pump drive belt should break.

### Gulp valve

The gulp valve, fitted in the pump discharge line to the inlet manifold, controls the flow of air for leaning-off the rich air/fuel mixture present in the inlet manifold immediately following throttle closure after running at full throttle opening (i.e. engine over-run)

A sensing pipe connected between the inlet manifold and the gulp valve maintains manifold depression directly to the underside of the diaphragm and through a bleed hole to the upper side. Sudden increases in manifold depression which occur immediately following throttle closure act on the underside of the diaphragm which opens the valve and admits air to the inlet manifold. The bleed hole allows the differences in depression acting on the diaphragm to equalize and the valve closes.


A restrictor is fitted in the air pump discharge connection to the gulp valve, to prevent surging when the gulp valve is operating.

### Carburetter

The carburetter is manufactured to a special exhaust emission control specification and is tuned to give optimum engine performance with maximum emission control.

The metering needle is arranged in such a manner that it is always lightly spring-loaded against the side of the jet to ensure consistency of fuel metering.

The throttle by-pass valve limits the inlet manifold depression and ensures that during conditions of engine over-run the air/fuel mixture enters the engine cylinders in a burnable condition consistent with low emission levels.



SNC 269

THE LAYOUT OF THE FUEL EVAPORATIVE LOSS CONTROL SYSTEM

- |                                 |  |                            |
|---------------------------------|--|----------------------------|
| 1. Charcoal adsorption canister | 6. Oil separator/flame trap (arrester) | 11. Air vent hose          |
| 2. Vapour lines                 | 7. Crankcase purge pipe                | 12. Fuel pipe              |
| 3. Purge line                   | 8. Carburetter                         | 13. Fuel tank              |
| 4. Restricted connection        | 9. Fuel pump                           | 14. Sealed fuel filler cap |
| 5. Sealed oil filler cap        | 10. Fuel filter                        |                            |

### CRANKCASE EMISSION CONTROL

The engine crankcase breather outlet incorporates an oil separator flame-trap (arrester) attached to the cylinder block side cover which is connected by a hose to the controlled depression chamber between the piston and the throttle disc of the carburetter. Piston blow-by fumes are


drawn into the depression chamber of the carburetter from the side cover and are joined by purged air from the charcoal canister of the fuel evaporative loss system. These fumes combine with the inlet charge for combustion in the normal way.

**FUEL EVAPORATIVE LOSS CONTROL**


To prevent air pollution by vapours from the fuel tank, the control equipment stores the vapour in a charcoal-filled canister while the engine is stopped and disposes of it via the engine crankcase emission control system when the engine is running.

The fuel tank venting is designed to ensure that no liquid fuel is carried to the storage canister with the vapours and that vapours are vented through the control system.

The capacity of the fuel tank is limited by the position of the filler tube which ensures sufficient volume is available after filling to accommodate fuel which would otherwise be displaced as a result of a high temperature rise.

**Section T.4****DRIVE BELTS****Removing**

1. Remove the two screws securing the radiator to the top mounting bracket.
2. Slacken the top hose to radiator clip and pull the radiator against the valance.
3. Slacken the pump pivot and adjusting link bolts.
4. Slacken the alternator pivot and adjusting link bolts. Press the alternator against the engine.
5. PUMP: Remove the drive belt from the pulleys and feed the belt between the fan blades and the radiator cowling at the top as the blades are rotated. Pull the belt out from between the fan and radiator.
6. ALTERNATOR: Release the drive belt from the pulleys and remove the belt in the same way as for the pump belt.

**Refitting**


7. Fit the belts onto the pulleys.
8. Adjust the tension of the alternator drive belt and then the pump drive belt. Total deflection: ½ in under thumb pressure at mid-point between pulleys.
9. Reconnect radiator and top hose. Top up the cooling system.

**Section T.5****AIR PUMP****Removing**

1. Disconnect the outlet hoses from the pump adaptor.
2. Remove the No. 1 cylinder spark plug.
3. Slacken the pump adjusting bracket and the alternator pivot bolt securing the pump.
4. Remove the screw securing the adjusting bracket to the pump.
5. Remove the pump pivot bolt.
6. Release the drive belt and remove the pump assembly.
7. Remove the pump pulley.

**Refitting**

8. Reverse the procedure in 1 to 7.
9. Adjust the drive belt tension; total deflection of ½ in under thumb pressure at mid-point between pulleys.




## Section T.6

## GULP VALVE

## Testing

1. Slacken the clip and disconnect the gulp valve air supply hose at the air pump.
2. Connect a vacuum gauge, with a 'T' (tee) adaptor to the gulp valve hose.
3. Start the engine and run it at idle speed.
4. The engine must remain at idle during this test. Seal the end of the 'T' (tee) adaptor and check that the gauge reads zero for approximately 15 seconds. If a vacuum is registered, renew the gulp valve.
5. Seal the end of the 'T' (tee) adaptor and open the throttle rapidly; the gauge should register a vacuum. Unseal the adaptor. Repeat the test several times. If a vacuum is not registered, renew the gulp valve.
6. Reconnect the supply hose and tighten the hose clips securely.



SNC 274

## Section T.7


## GULP VALVE

## Removing

1. Slacken all the hose to valve clips.
2. Pull the vacuum hose from the valve adaptor.
3. Pull the pump hose from the valve.
4. Remove the two bolts securing the valve to the bracket.
5. Pull the gulp valve from the manifold hose.

## Refitting

6. Reverse the procedure in 1 to 5.



SNC 285

## Section T.8

## DIVERTER VALVE

## Checking


1. Slacken the clip securing the hose to the check valve.
2. Remove the two bolts securing the valve to the bracket.
3. Pull the diverter valve and hose from the check valve.
4. Start the engine and allow it to idle. Air pressure should be felt at the hose end.
5. Operate the mixture control (choke); the air supply should be cut off completely. If air pressure is felt at the hose, renew the diverter valve.

## Removing

6. Slacken all the hose to valve clips.
7. Pull the vacuum hose from the valve adaptor.
8. Pull the pump hose from the valve.
9. Remove the two bolts securing the valve to the bracket.
10. Pull the valve from the check valve hose.
11. Remove the air vent hose from the diverter valve.

## Refitting

12. Reverse the procedure in 6 to 11.



SNC 271

## Section T.9

## CHECK VALVE

## Removing

1. Release the clip securing the hose to the check valve. Move the clip along the hose and free the hose on the valve adaptor.
2. Hold the air manifold union to prevent it twisting and unscrew the check valve.
3. Pull the check valve from the hose.


## Testing

4. Using the mouth; blow into the valve from each end in turn. Air should only pass through the valve from the air supply end. If air passes through from the air manifold end, renew the check valve.

**CAUTION: DO NOT APPLY AIR LINE PRESSURE TO THE VALVE.**

## Refitting

5. Reverse the procedure in 1 to 3.




SNC 273

## Section T.10

## AIR MANIFOLD

## Removing

1. Release the clip securing the hose to the check valve and move the clip along the hose.
2. Disconnect the lead from No. 1 spark plug.
3. Unscrew the four unions from the cylinder head, pull the check valve from the hose and remove the air manifold assembly.
4. Hold the air manifold union and unscrew the check valve.



SNC 270

## Refitting

5. Reverse the procedure in 1 to 4.

## Section T.11

## AIR TEMPERATURE CONTROL VALVE

## Checking


1. Note the position of the valve plate (when the engine is cold or warm), depress the plate and release it. The plate should return to its original position.
2. Inspect the valve seal for signs of deterioration.

## Removing

3. Slacken the clip securing the control valve adaptor to the air cleaner.
4. Pull the control valve assembly from the air cleaner and hot air box tube.
5. Remove the adaptor from the control valve.

## Refitting

6. Reverse the procedure in 1 to 5; ensure the valve is aligned correctly.



SNC 275

## Section T.12

## THROTTLE DAMPER


**NOTE:** The engine idle speed must be set before checking and adjusting.

**Checking**

1. Remove the air cleaner and air temperature control valve assembly.
2. Insert a 0.080 in (2.03 mm) feeler gauge between the lever pad and the damper plunger.
3. Depress the lever, the idle adjusting screw should contact and the damper plunger should be fully depressed.

**Adjusting**

4. Slacken the damper lever clamp.
5. Insert a 0.080 in (2.03 mm) feeler gauge between the lever pad and the damper plunger.
6. Depress the lever and hold the plunger at the bottom of its stroke. Ensure the throttle is closed and that a clearance exists between the lever clamp and the carburettor body.
7. Tighten the lever clamp nut. Check the action of the throttle linkage.
8. Refit the air cleaner and air temperature control valve assembly.



5NC288

## Section T.13


## THROTTLE DAMPER

**Removing**

1. Remove the air cleaner and air temperature control valve assembly.
2. Remove the hot air duct, see Section T.14.
3. Release the nut, hold the throttle open and unscrew the throttle damper.

**Refitting**

4. Fit the damper and adjust the lever, see Section T.12.
5. Refit the hot air duct, see Section T.14.
6. Refit the air cleaner and air temperature control valve.



SNC 289

## Section T.14


## HOT AIR DUCT

**Removing**

1. Remove the air temperature control valve assembly.
2. Remove the flexible tube from the hot air duct.
3. Remove the two nuts securing the duct to the manifold.
4. Extract the hot air duct.

**Refitting**

5. Ensure the two plain washers are on the outside stud.
6. Ensure the large washer bridging the manifold flanges is in place.
7. Reverse the procedure in 1 to 4.



SNC 279

## Section T.15


## FUEL LINE FILTER

## Removing

1. Slacken the clip and disconnect the inlet hose.
2. Slacken the clip and pull the fuel filter from the outlet hose.

## Refitting

3. Ensure the filter is fitted with the flow arrow towards the carburettor.  
Alternative filter: Inlet hose to connector marked 'IN'.



## Section T.16


## ADSORPTION CANISTER

## Removing

1. Disconnect the air vent hose from the bottom of the canister.
2. Disconnect the vapour and purge hoses from the top of the canister.
3. Remove the retaining screw, open the the bracket sufficiently to withdraw the canister.

## Refitting

4. Reverse the procedure in 1 to 3.
5. Disconnect the purge hose from the rocker cover elbow.
6. Examine the restrictor orifice, clear any dirt or deposits using a length of soft wire.
7. Reconnect the purge hose.



## Section T.17

## CARBURETTER

## Tuning

Adjustments should only be undertaken if an accurate tachometer, and exhaust gas analyser (CO meter) are available for use.


The tuning of the carburettor is confined to topping-up the damper, setting idle and fast idle speeds, mixture strength (CO percentage), and adjusting the throttle damper.

The efficient operation of the engine and exhaust emission equipment depends not only on correct carburettor settings but is also affected by:

- Ignition timing
- Spark plug condition
- Contact breaker condition (dwell angle)
- Valve rocker clearances
- Presence of air leaks in the induction system

Also; check for good seals at oil filler cap, rocker cover to cylinder head, engine oil dipstick to block.

Refer to 'ENGINE TUNING DATA' or to the 'Vehicle Emission Control Information' label attached to the vehicle.





1. Remove the air cleaner assembly.
2. Check that the throttle functions correctly.
3. Ensure the mixture control (choke) is fully returned, that the cable has  $\frac{1}{16}$  in free movement before it starts to pull on the lever.
4. The fast idle screw must be well clear of the cam, unscrew if necessary.
5. Top up the carburetter piston damper.
6. Start the engine and run it at fast idle speed until it attains normal running temperature, and then drive the vehicle for five minutes on the road.
7. Connect a tachometer.
8. Disconnect the diverter valve hose at the pump and plug the hose.  
**DO NOT restrict the pump outlet.**
9. Increase the engine speed to 2,500 r.p.m. for 30 seconds.

**NOTE:** Tuning must commence immediately the car reaches normal running temperature. If delay prevents the adjustment being complete within three minutes, increase the engine speed to 2,500 r.p.m. for 30 seconds and then continue tuning. Repeat this clearing procedure at three minute intervals until tuning is completed.

10. Set the engine idle speed by turning the throttle adjusting screw, see 'ENGINE TUNING DATA'.
11. Connect an exhaust gas analyser. In accordance with the manufacturer's instructions check the percentage CO at idle. If the reading falls outside the limits (see 'ENGINE TUNING DATA') turn the jet adjusting nut by the **minimum** amount to bring the reading within the limits.  
**NOTE:** If adjustment cannot be obtained within the limits of the restrictor see item 15.
12. Unplug and reconnect the diverter valve hose to the pump.
13. Run the engine at 2,500 r.p.m. for 30 seconds and then reset the idle speed.
14. Adjust the throttle damper, see Section T.12.
15. If a smooth idle at the correct speed and CO reading is not obtainable and all other engine adjustments are correct, check the needle and piston as follows and then readjust:
  - a. Remove the suction chamber and piston assembly. Check that the correct needle is fitted. Refit, ensure the needle guide mark is towards the piston transfer ports and the shoulder of the needle **must be flush** with the face of the piston. Refit the suction chamber assembly. Top up the damper with oil.
  - b. Raise the piston slowly up and down through its full travel using a finger, remove the intake elbow if necessary.  
The piston movement must be free and smooth.
  - c. Repeat operations 9 to 11. If the CO reading is still outside the limits, bend the restrictor tab clear of the jet adjusting nut and turn the nut by the minimum amount necessary to bring the CO reading within the limits.  
Centralize the restrictor and bend the tab down against the nut.
  - e. Carry out operations 13 to 15.

#### FAST IDLE


16. Pull out the mixture control knob until the jet linkage is just about to move the carburetter jet, and lock the control.
17. Turn the fast idle adjusting screw to give the correct fast idle speed, see 'ENGINE TUNING DATA'.
18. Unlock and return the mixture control fully. Stop the engine.
19. Refit the air cleaner assembly.

#### Section T.18


##### CYLINDER HEAD ASSEMBLY

#### Removing

1. Drain the cooling system and refit the cylinder block drain plug.
2. Remove the air cleaner and air temperature control valve assembly.
3. Remove the bolts securing the diverter valve to the bracket.
4. Disconnect the hose at the check valve, the vacuum hose from the diverter valve and the pump hose from the gulp valve.
5. Disconnect the leads from the spark plugs.
6. Remove the No. 1 spark plug.
7. Slacken the bolt, alternator pivot and air pump adjusting link.
8. Remove the screw securing the adjusting bracket to the air pump.
9. Remove the air pump pivot bolt, release the drive belt and remove the air pump and diverter valve assembly.
10. Slacken the top hose clips, remove the two screws securing the radiator to the top mounting bracket and remove the top hose.
11. Remove the rocker cover nuts. Position the heater hoses clear.
12. Pull the purge pipe from the rocker cover pipe and remove the rocker cover and gasket.
13. Release the heater water control valve from the cylinder head and position it clear.
14. Disconnect the lead from the manifold heater.
15. Remove the two nuts securing the carburetter to the manifold. Withdraw the carburetter assembly, induction heater and mounting bracket from the studs and position them clear.
16. Remove the hot air duct.
17. Remove the exhaust manifold pipe clamp.
18. Progressively slacken the cylinder head and rocker shaft nuts in the reverse order of the tightening sequence.
19. Remove the rocker assembly.
20. Remove the push-rods, **keeping them in their installed order.**
21. Remove the coil and position it clear.
22. Slacken the clip securing the by-pass hose to the cylinder head.
23. Remove the four remaining nuts and lift the cylinder head assembly squarely off the studs. Lift the gasket from the studs.  
**NOTE:** If the head will not release from the gasket, tap each side of the head with a soft faced mallet.




WIRING DIAGRAM—1975 model year on



**Refitting**

24. Reverse the procedure in 1 to 23, noting:
- Thoroughly clean the joint faces of the cylinder block and head.
  - Fit a new gasket dry, with the end marked 'FRONT' to the water pump and the face marked 'TOP' upwards.
  - Progressively tighten the cylinder head and rocker bracket nuts in sequence illustrated.
- |                     |           |          |
|---------------------|-----------|----------|
| Cylinder head nuts  | 40 lbf ft | 5.5 kg m |
| Rocker bracket nuts | 25 lbf ft | 3.5 kg m |
- Check the carburettor throttle damper, see Section T.12.
  - Check and adjust the valve rocker clearances, see 'MAINTENANCE'.
  - Refill the cooling system.
  - Check and adjust the carburettor setting, see Section T.17.
  - Adjust the tension of the drive belts, see Section T.4.



5NC 335

**KEY TO THE WIRING DIAGRAM**

1. Alternator	44. Ignition warning lamp
3. Battery	45. Headlamp flasher switch
4. Starter solenoid	46. Coolant temperature gauge
5. Starter motor	47. Coolant temperature transmitter
6. Lighting switch	49. Reverse lamp switch
7. Headlamp dip switch	50. Reverse lamp
8. R.H. headlamp	59. Interior light switch
9. L.H. headlamp	60. Radio (when fitted)
10. High-beam warning lamp	64. Bi-metal instrument voltage stabilizer
11. R.H. parking lamp	67. Line fuse
12. L.H. parking lamp	77. Windscreen washer motor
14. Panel lamps	78. Windscreen washer switch
15. Number-plate illumination lamp	82. Switch illumination lamp
16. R.H. stop and tail lamp	83. Induction heater and thermostat
17. L.H. stop and tail lamp	84. Suction chamber heater
18. Stop lamp switch	115. Heated rear window demist switch
19. Fuse unit	116. Heated rear window demist unit
20. Interior lamp	150. Heated rear window warning light
21. R.H. door switch light and buzzer	153. Hazard warning switch
22. L.H. door switch light and buzzer	154. Hazard warning flasher unit
23. Horn	159. Brake failure warning lamp and test switch
24. Horn-push	160. Brake pressure differential switch
25. Flasher unit	164. Ballast resistor
26. Direction indicator switch	169. Buzzer-door switch
27. Direction indicator warning lamp	170. R.H. front side-marker lamp
28. R.H. front direction indicator lamp	171. L.H. front side-marker lamp
29. L.H. front direction indicator lamp	172. R.H. rear side-marker lamp
30. R.H. rear direction indicator lamp	173. L.H. rear side-marker lamp
31. L.H. rear direction indicator lamp	198. Driver's seat belt switch
32. Heater motor switch	199. Passenger seat belt switch
33. Heater motor	200. Passenger's seat switch
34. Fuel gauge	201. Seat belt warning gearbox switch
35. Fuel gauge tank unit	202. Seat belt warning lamp
36. Windscreen wiper switch	203. Seat belt warning diode
37. Windscreen wiper motor	210. Panel light rheostat
38. Ignition/starter switch	211. Heater control illumination
39. Ignition coil	
40. Distributor	

**CABLE COLOUR CODE**

B. Black	N. Brown	S. Slate
G. Green	O. Orange	U. Blue
K. Pink	P. Purple	W. White
L.G. Light Green	R. Red	Y. Yellow

When a cable has two colour code letters the first denotes the main colour and the second denotes the tracer colour.

