

## Mini Boot Lining Kit

The following parts are needed (as per drawings supplied):

- 1 x Boot Base
- 2 x Sides
- 1 x Rear Bulkhead Cover
- 1 x Fuel Tank Cover

It is suggested on the drawings that MDF (Medium Density Fibreboard) is used to make the Kit. This is due to its sound insulation qualities, and its general suitability for this application.

Manufacture Notes:

- It is suggested that the sides are cut according to the interior of your mini. The shape is only shown as a guide. This is to ensure a good fit, and there are no squeaks or rattles once fitted.
- When in position the fuel tank cover will be bent. If not using MDF, make sure the material used will be able to do this.
- Once the parts have been cut, they can be covered using a suitable material, such as acoustic carpet. This can be fixed using contact adhesive, or a staple gun.
- The lining kit is designed to be a press fit, so no extra fixings or tools are required.
- Once fitted, it may be necessary to insert a piece of material underneath the boot base, in order to make it level. This is dependant on your spare wheel.
- This kit is designed to fit minis with the 7.5 gallon petrol tank. Adaptation will be required in order for it to fit other models of mini.