



38-01-001 , Radio/Cassette , Without amplifier

- ◆ → '95
- ◆◆ 95 → '95 ½
- ◆◆◆ '95 ½ →






38-01-002 , Radio/Cassette , Without amplifier






38-01-003 , Radio/Cassette , With amplifier

- ◆ → 95
- ◆◆ 95 → 95 ½
- ◆◆◆ 95 ½ →





38-01-004 , Radio/Cassette , With amplifier

- ◆ → 95
- ◆◆ 95 → 95 1/2
- ◆◆◆ 95 1/2 →

