




33-01-4 before 95

33-01-5 as of 95

33-01-002 , Entry Illumination , Subhead

- ◆ → '95
- ◆◆ '95 → '95 ½
- ◆◆◆ '95 ½ →








G1046

33-01-003 , Entry Illumination , Subhead

- ◆ → '95
- ◆◆ '95 → '95 ½
- ◆◆◆ '95 ½ →





33-01-6



N187
Door entry switch,
passenger side
[1] Door closed
[2] Door open

33-01-004 , Entry Illumination , Before 95, RS Cosworth





N188
Door entry switch,
driver side
[1] Door closed
[2] Door open

33-01-6





A36
Auxiliary warning
module





Fuse Details

33-01-005 , Entry Illumination , As of 95 without RS Cosworth





D
33-01-6



33-01-006 , Entry Illumination , Subhead

- ◆ → '95
- ◆◆ 95 → '95 1/2
- ◆◆◆ '95 1/2 →

