



- ◆ → '95
- ◆◆ 95 → '95 ½
- ◆◆◆ '95 ½ →






29-06-002 , Engine Control 2,0 | EFI , Power



29-06-003 , Engine Control 2,0 I EFI , Fuel injectors, diagnostic connection


- ◆ → 95
- ◆◆ 95 → 95 1/2
- ◆◆◆ 95 1/2 →





29-06-004 , Engine Control 2,0 | EFI , Sensors


- ◆ → 95
- ◆◆ 95 → 95 ½
- ◆◆◆ 95 ½ →






29-06-005 , Engine Control 2,0 I EFI , Sensors


- ◆ → 95
- ◆◆ 95 → 95 ½
- ◆◆◆ 95 ½ →





G1004

29-06-006 , Engine Control 2,0 | EFI






G1004



G1004

29-06-007 , Engine Control 2,0 I EFI , Fuel pump, except 4x4

- ◆ → 95
- ◆◆ 95 → 95 ½
- ◆◆◆ 95 ½ →





G1046




G1046









LED TV module

29-06-008 , Engine Control 2,0 I EFI , Fuel pump, 4x4




29-06-009 , Engine Control 2,0 | EFI , As of 95






29-06-010 , Engine Control 2,0 I EFI , Engine cooling fan (with air conditioning)


- ◆ → '95
- ◆◆ 95 → '95 ½
- ◆◆◆ '95 ½ →





29-06-011 , Engine Control 2,0 I EFI , Engine cooling fan (without air conditioning)

- ◆ → 95
- ◆◆ 95 → 95 ½
- ◆◆◆ 95 ½ →





↻ Circuit Description
